

British Cycle Supply Company's Inventory and Supersession List

The British Cycle Supply inventory and supersession list is designed to be used with the factory parts book for the particular motorcycle being worked on, or with the appropriate BCS CD. To have a current priced version of this list e-mailed to you please e-mail us anytime you wish with the following information which will allow us to make sure we have your current details in our database and facilitate any future contacts. We will give you a customer number for future reference. Although we may send occasional newsletters and product bulletins pertaining to British Motorcycles, we do not share your information with anyone, and promise not to send you any junk or spam.

Full Name:
BCS Customer # (if you have one):
Full mailing Address:
Home, Cell and Work Telephone Number(s) as applicable:
Fax Number if possible:
e-mail:
Engine Serial #(s):

For your information: Any future e-mails we send will be in compliance with with the new CAN-SPAM Bill 2003. The following is information all messages must contain so as NOT to be considered Spam:

1. There must be a valid Remove Link.
2. Sender must give a valid name.
3. Sender must give a valid email address.
4. Sender must give a valid postal address.
5. Sender must give clear and conspicuous notice that this email is a commercial advertisement such as:

"This is a commercial advertisement, which you are receiving because you have requested information from me in the past."

British Cycle Supply Company
604 Davison Street, RR 3 Wolfville, Nova Scotia, Canada, B4P 2R3
& 146 Porter Street, Hackensack, New Jersey, USA, 07601

tel: (902)542-7478
fax: (902)542-7479
info@britcycle.com
www.britcycle.com

```
--
-----
-100215E      USE 82-4717      ea
-10411-58     USE 67-1205 *    ea
-10553-54     USE 67-0338 *    ea
-110204/00/1  USE 14-1201      ea
-11104/04/2   USE 14-0101      ea
-11104/06/2   USE 14-0103      ea
-11105/04/2   USE 21-1822      ea
-11105/06/2   USE 14-0114      ea
-11105/08/2   USE 14-0116      ea
-12105/09/2   USE 14-0216      ea
-13104/00/2   USE 14-0301      ea
-13206/00/1   USE 14-0403      ea
-13206/00/2   USE 14-0403      ea
-13208/00/2   USE 14-0405      ea
-15104/00/2   USE 14-0701      ea
-15105/00/2   USE 14-0702      ea
-15106/00/2   USE 14-0703      ea
-3417         gasket,rubber,pri.cov,Nor rigid EA
-52091/5      USE 571-32/D     ea
-904          ROYAL ENFIELD PARTS *
-9556         USE 532-A2/507  ea
-A            OLD NORT, TRI&BSA NUMBERS *
-A-----
-A11/113      USE 552-110037/46 * ea
-A11/447      USE 552-110046/76 * ea
```

-A125/4AS	velo pt.	EA
-A125/7AS	velo pt.	EA
-A131	velo pt.	EA
-A132	velo pt.	EA
-A132/2	velo pt.	EA
-A133	velo pt.	EA
-A134/4	velo pt.	EA
-A15/2	velo pt.	EA
-A1521S	velo pt.	EA
-A179/5	velo pt.	EA
-A179/6	velo pt.	EA
-A2/159	USE NME4102	ea
-A2/256	USE 526-187	ea
-A2/30	USE 89-3022	ea
-A2/316	USE 70-9494	ea
-A2/32	bearing,roller,Nort.crank	EA
-A2/321	USE 04-0099	ea
-A2/356	USE 06-2015	ea
-A2/367	USE 04-0043	ea
-A2/383	USE 422-1414	ea
-A2/385	clutch centre,Norton gbx.	EA
-A2/393	USE 04-0391	ea
-A2/454	USE 06-0292 *	ea
-A2/479	USE 552-11004626	ea
-A2/480	USE 552-11004630	ea
-A2/486	USE 06-7627	ea
-A2/507	USE 532-A2/507	ea
-A2/586	battery carrier,16H,etc.	EA
-A2/868	USE 60-0003	ea
-A20/4	velo pt.	EA
-A229	velo pt.	EA
-A234/10AS	velo pt.	EA
-A253	velo pt.	EA
-A254/3	velo pt.	EA
-A273/3	velo pt.	EA
-A287	velo pt.	EA
-A288	element,oilfilter,VELO single	EA
-A293/2	velo pt.	EA
-A3	USE 60-0003	ea
-A3/140	USE 452-269	ea
-A3/142	USE 453-37	ea
-A353	velo pt.	EA
-A37/2	USE 02-2894	ea
-A37/4	velo pt.	EA
-A37/5	velo pt.	EA
-A37/6	velo pt.	EA
-A37/7	velo pt.	EA
-A40	USE 60-1816	ea
-A44	USE 60-1816	ea
-A52	USE 60-0052	ea
-A56	USE 60-0056	ea
-A57	USE 99-3507	ea
-A57/004	USE 99-3507	ea
-A57/005	USE 99-3508	ea
-A57A	USE 99-3508	ea
-A61	USE 60-0061	ea
-A61/2AS	velo pt.	EA
-A61A	USE 60-0061/A	ea
-B100	velo pt.	EA
-B101	velo pt.	EA
-B11/654	USE 37-4151	ea
-B2/605	USE NM18467	EA
-B2/606	USE 06-7519	ea
-B2/614	USE 06-7521	ea
-B2/616	USE 06-5483	ea
-B2/617	USE 06-7520	ea
-B22	velo pt.	EA
-B31/2	velo pt.	EA
-B34	velo pt.	EA
-B35/3	velo pt.	EA
-B38S	velo pt.	EA

-B39/26	velo pt.	EA
-B43/2	velo pt.	EA
-B60/4	velo pt.	EA
-B60/5	velo pt.	EA
-B97	velo pt.	EA
-B98	velo pt.	EA
-BK100/3	velo pt.	EA
-BK101/2	velo pt.	EA
-BK102	velo pt.	EA
-BK103	velo pt.	EA
-BK106/3	velo pt.	EA
-BK11/2	velo pt.	EA
-BK12/3	velo pt.	EA
-BK12/5	velo pt.	EA
-BK14	velo pt.	EA
-BK18	velo pt.	EA
-BK18/3	velo pt.	EA
-BK19	velo pt.	EA
-BK19/2	velo pt.	EA
-BK32	velo pt.	EA
-BK33	velo pt.	EA
-BK36/2	velo pt.	EA
-BK4	velo pt.	EA
-BK40	velo pt.	EA
-BK5/6	velo pt.	EA
-BK52	velo pt.	EA
-BK64/3	velo pt.	EA
-BK66	velo pt.	EA
-BK68	velo pt.	EA
-BK7/2	velo pt.	EA
-BK70	velo pt.	EA
-BK73/2S	velo pt.	EA
-BK75/5	velo pt.	EA
-BK77	velo pt.	EA
-BK78	velo pt.	EA
-BK8/2AS	velo pt.	EA
-BK8/3AS	sleeve gear,17T std,Velo	EA
-BK8/4AS	velo pt.	EA
-BK80/3	velo pt.	EA
-BK80/5	velo pt.	EA
-BK82	velo pt.	EA
-BK83/2	velo pt.	EA
-BK85/2	velo pt.	EA
-BK86	velo pt.	EA
-BK86/2	velo pt.	EA
-BK86/3	velo pt.	EA
-BK87	velo pt.	EA
-BK87/4	velo pt.	EA
-BK88AS	velo pt.	EA
-BK89AS	velo pt.	EA
-BK90	velo pt.	EA
-BK90/2	velo pt.	EA
-BK91	velo pt.	EA
-BK95	velo pt.	EA
-BK96	velo pt.	EA
-BK97	velo pt.	EA
-BK98	velo pt.	EA
-BK98/2	velo pt.	EA
-BK99/2	velo pt.	EA
-C12/4	velo pt.	EA
-C2/113	USE 552-110037/44	ea
-C23AS	velo pt.	EA
-C24/2	velo pt.	EA
-C25	velo pt.	EA
-C25/2	velo pt.	EA
-C26AS	velo pt.	EA
-C28	velo pt.	EA
-C29/26	velo pt.	EA
-C30/2	velo pt.	EA
-C31/3	velo pt.	EA
-C32/2	velo pt.	EA

-C5/2	velo pt.	EA
-C6/3	velo pt.	EA
-C7/26	velo pt.	EA
-C8	velo pt.	EA
-CD115	USE 215-990842/A	ea
-CD451	USE 431-03	ea
-CD465	USE 442-13570	ea
-CD533	USE 431-01	ea
-CD535	USE 431-02	ea
-CK14/2	velo pt.	EA
-CK21/2S	velo pt.	EA
-CK34/4	velo pt.	EA
-CORE	CORE CHARGE, MISC	EA
-CP102	USE 451-510	ea
-CP105	USE 441-19119	ea
-CP128	USE 551-997	ea
-CP129	USE 99-3721	ea
-CP141	USE 441-12581	ea
-CP156	USE 99-3733	ea
-CP157	USE 441-15897	ea
-CP163	USE 441-13529 (pr)	ea
-CP165	USE 442-10280	ea
-CP167	USE 99-3741	ea
-CP171	USE 451-514	ea
-CP172	USE 441-12581	ea
-CP174	USE 441-15123	ea
-CP175	USE 442-13570	ea
-CP177	USE 451-615	ea
-CP180	USE 442-13570	ea
-CP184	USE 551-10581	ea
-CP185	USE 451-466	ea
-CP188	USE 451-574	ea
-CP200	USE 441-15219 (pr)	ea
-CP205	USE 551-1095	ea
-CP208	USE 442-11050	ea
-CP211	USE 442-23010	ea
-CP212	USE 442-23020	ea
-CP27	USE 99-3701	ea
-CP38	USE 551-2031 (set)	ea
-CP40	USE 442-3850	ea
-CP40/010	USE 442-3850/010	ea
-CP40/020	USE 442-3850/020	ea
-CP40/040	USE 442-3850/040	ea
-CP5	USE 451-279	ea
-CP50	USE separate components	ea
-CP57	USE 99-3708	ea
-CP66	USE 551-951	ea
-CP99	USE 442-11050	ea
-D	OLD TRIUMPH #S,USE 60-XXXX	*
-D-----	-----	---
-D12/140	USE 452-544	ea
-D12/142	USE 453-26	ea
-D12/143	USE 453-27	ea
-D12/159	USE NMT2160	ea
-D12/27	USE 421-57 (set)	ea
-D12/282	kneepad set,Nort,2 screw type	PR
-D12/961	USE 552-110038/38	ea
-D12/972	USE 06-7557	ea
-D208-5	USE 60-4255	ea
-D3437	USE 60-4258	ea
-D3T/140	USE 452-269 *	ea
-D402/3	USE 60-0402	ea
-DA50/1	USE 222-127	ea
-DA70	USE 222-180	ea
-DS40	USE 99-3514	ea
-DS47	USE 97-0193	ea
-DS48	USE 99-3557	ea
-DS55	USE 99-3516	ea
-DS57	USE 99-3517	ea
-DS58	USE 99-3518	ea
-E	OLD TRIUMPH #, USE 70-XXXX	*

-E-----	-----	----
-E1	OLD TRIUMPH #S,USE 71-XXXX	*
-E1-----	-----	----
-E12/4	velo pt.	EA
-E12/5	velo pt.	EA
-E16/3	velo pt.	EA
-E16/4	velo pt.	EA
-E19/8	velo pt.	EA
-E19/9	velo pt.	EA
-E2/463	sprocket/br.drum,Nor.43T	EA
-E51	velo pt.	EA
-E51/2	velo pt.	EA
-E53	velo pt.	EA
-E6/2	velo pt.	EA
-E8/8	velo pt.	EA
-E9/5S	velo pt.	EA
-E9/6S	velo pt.	EA
-ET2003	USE 222-158	ea
-F	OLD TRIUMPH #S,USE 82-XXXX	*
-F-----	-----	----
-F1	OLD TRIUMPH #S,USE 83-XXXX	*
-F1-----	-----	----
-F12/957	USE 391-463109	ea
-F126/6	velo pt.	EA
-F126/9	velo pt.	EA
-F130/14	velo pt.	EA
-F130/16	velo pt.	EA
-F165	velo pt.	EA
-F196/7	velo pt.	EA
-F201/2	velo pt.	EA
-F233/5S	velo pt.	EA
-F245	velo pt.	EA
-F245/2	velo pt.	EA
-F246	velo pt.	EA
-F246/2	velo pt.	EA
-F251	velo pt.	EA
-F251/3	velo pt.	EA
-F252	velo pt.	EA
-F253/2S	velo pt.	EA
-F253S	velo pt.	EA
-F256/2	velo pt.	EA
-F257S	velo pt.	EA
-F259	velo pt.	EA
-F260	velo pt.	EA
-F262	velo pt.	EA
-F263	velo pt.	EA
-F265	velo pt.	EA
-F266/2	velo pt.	EA
-F267	velo pt.	EA
-F268	velo pt.	EA
-F269	velo handlebar bolt	EA
-F269S	velo pt.	EA
-F270/3	velo pt.	EA
-F271S	velo pt.	EA
-F272	velo pt.	EA
-F278	velo pt.	EA
-F278S	velo pt.	EA
-F282	velo pt.	EA
-F284	velo pt.	EA
-F285	velo pt.	EA
-F285/2	velo pt.	EA
-F291	velo pt.	EA
-F292	velo pt.	EA
-F292/4	velo pt.	EA
-F293	velo pt.	EA
-F297	velo pt.	EA
-F298	velo pt.	EA
-F300S	velo pt.	EA
-F301	velo pt.	EA
-F302	velo pt.	EA
-F303	velo pt.	EA

-F309	velo pt.	EA
-F309/2	velo pt.	EA
-F310	velo pt.	EA
-F311	velo pt.	EA
-F32/3	velo pt.	EA
-F39/11	velo pt.	EA
-F39/14	velo pt.	EA
-F39/2	velo pt.	EA
-F4/10	velo pt.	EA
-F69/5	velo pt.	EA
-FA1/3	velo pt.	EA
-FA1/3C	velo pt.	EA
-FA104/7S	velo pt.	EA
-FA3/5	velo pt.	EA
-FA47S	velo pt.	EA
-FK151/4	velo pt.	EA
-FK152/2	velo pt.	EA
-FK152/2S	velo pt.	EA
-FK157/15	velo pt.	EA
-FK167/9S	velo pt.	EA
-FK19/2	velo pt.	EA
-FK205	velo pt.	EA
-FK207/2	velo pt.	EA
-FK220/8	velo pt.	EA
-FK220/9	velo pt.	EA
-FK221/3	velo pt.	EA
-FK228S	velo pt.	EA
-FK23/14	velo pt.	EA
-FK239	velo pt.	EA
-FK242	velo pt.	EA
-FK243	velo pt.	EA
-FK244	velo pt.	EA
-FK246	velo pt.	EA
-FK247	velo pt.	EA
-FK248	velo pt.	EA
-FK249	velo pt.	EA
-FK257	velo pt.	EA
-FK26/11	velo pt.	EA
-FK264	velo pt.	EA
-FK266/2	velo pt.	EA
-FK27/10	velo pt.	EA
-FK27/9	velo pt.	EA
-FK274	velo pt.	EA
-FK29/11	velo pt.	EA
-FK43	velo pt.	EA
-FK43/2	velo pt.	EA
-FK50/2	velo pt.	EA
-FK61/8	velo pt.	EA
-FK75/14	velo pt.	EA
-FK81	velo pt.	EA
-FK81/2	velo pt.	EA
-FS879	key	EA
-FS881	key	EA
-FS882	key	EA
-FS885	key	EA
-FS887	key	EA
-FS890	key	EA
-FS896	key	EA
-FS898	key	EA
-FS899	key	EA
-FS903	key	EA
-FS904	key	EA
-FS905	key	EA
-FS907	key	EA
-FS909	key	EA
-FS914	key	EA
-FS917	key	EA
-FS920	key	EA
-FS921	key	EA
-FS922	key	EA
-FS923	key	EA

-FS924	key	EA
-FS925	key	EA
-FS931	key	EA
-FS933	key	EA
-FS942	key	EA
-FS947	key	EA
-FS948	key	EA
-FS950	key	EA
-FS953	key*	EA
-GC23/2	velo pt.	EA
-GC24/2	velo pt.	EA
-GC4/21	velo pt.	EA
-GC4/26	velo pt.	EA
-GC41/8	velo pt.	EA
-GC42/3	velo pt.	EA
-GC45/4	velo pt.	EA
-GC53	velo pt.	EA
-GC54	velo pt.	EA
-GC55	velo pt.	EA
-GC58/2	velo pt.	EA
-GC59/2	velo pt.	EA
-GC9/5	velo pt.	EA
-GS127	USE 57-3673	ea
-GS153	USE 99-3527	ea
-GS203	USE 71-0245	ea
-GS251	USE 70-8752	ea
-GS254	USE 70-8754	ea
-GS272	oilpipe,rockerbox drain,intake	EA
-GS273	oilpipe,rockerbox drain,ex.	EA
-GS299	USE 60-4256	ea
-GS308	USE 70-8770	ea
-GS36	tappet block,inlet & exh,alloy	EA
-GS36/005	tappet block,inlet & exh,alloy,oversize	EA
-GS439	USE 71-2505	ea
-GS662	USE 60-4264	ea
-GS87	USE 70-2254	ea
-GSB6365	USE 433-04	ea
-GSB6366	USE 433-04	ea
-GSB6667	USE 433-04	ea
-GST110/56	USE 432-812	ea
-H	OLD TRIUMPH #S,USE 97-XXXX	*
-H-----	-----	--
-H12-2/1070	USE NM16256	EA
-H12-2/1071	USE NM16238	ea
-H12-2/497	chainguard,wideFeatherbed,early	EA
-H12-6/605	USE 06-7714	ea
-H12/497	USE NM16810	ea
-INFO	Book/Accessory info	EA
-K119	velo pt.	EA
-K12-2/432	USE 06-7712	ea
-K12-2/654	USE 06-7712	ea
-K127	velo pt.	EA
-K149/2	velo pt.	EA
-K191	velo pt.	EA
-K220	velo pt.	EA
-K235	velo pt.	EA
-K235/2	velo pt.	EA
-K235/6	velo pt.	EA
-K246/5	velo pt.	EA
-K36/2	velo pt.	EA
-K4/4	velo pt.	EA
-K4/6	velo pt.	EA
-K5/6	velo pt.	EA
-K5/7	velo pt.	EA
-K53	velo pt.	EA
-K55	velo pt.	EA
-K76	velo pt.	EA
-K95	velo pt.	EA
-KA100/20	velo pt.	EA
-KA100/21	velo pt.	EA
-KA115/2	velo pt.	EA

-KA115/3	velo pt.	EA
-KA142/2	baffle,muffler,Velo	EA
-KA16/13	velo pt.	EA
-KA16/13S	velo pt.	EA
-KA16/15	velo pt.	EA
-KA16/15S	velo pt.	EA
-KA244	velo pt.	EA
-KA280/3	velo pt.	EA
-KA280/4	velo pt.	EA
-KA312	velo pt.	EA
-KA314	velo pt.	EA
-KA314/3	velo pt.	EA
-KA315	velo pt.	EA
-KA315/4	velo pt.	EA
-KA46	velo pt.	EA
-KA46/3	velo pt.	EA
-KA52	velo pt.	EA
-KA70/7	velo pt.	EA
-KA76/2	velo pt.	EA
-KA93/11	velo pt.	EA
-KC1/2	velo pt.	EA
-KC12/4	velo pt.	EA
-KC17/9AS	velo pt.	EA
-KC2/25	velo pt.	EA
-KC40/2AS	velo pt.	EA
-KC43/2	velo pt.	EA
-KS12/4	velo pt.	EA
-KS44S	velo pt.	EA
-KS60/2	velo pt.	EA
-KS60S	velo pt.	EA
-KS61/2	velo pt.	EA
-KS61/3	velo pt.	EA
-KS61/4	velo pt.	EA
-KS8/10	velo pt.	EA
-L12-2/622	USE 06-7743	ea
-L4292	USE 06-0592	ea
-LABOUR	misc.shop time	HR
-LABOUR A	rebore cyl.& fit piston	EA
-LABOUR B	cyl.sleeve installation	EA
-LABOUR C	glassbead pts,per minute	EA
-LABOUR D	repair threaded exh.ports	EA
-LABOUR E	deglaze cylinder bore	EA
-LABOUR F	grind crank,3 cylinder	EA
-LABOUR G	grind crank,twin cylinder	EA
-LABOUR H	reprofile cam followers	EA
-LABOUR I	conversion,crankbrg,A50/65,hidden	EA
-LABOUR J	conversion,crankbrg,A50/65,outside	EA
-LABOUR K	conversion,crankbrg,A7/10,hidden	EA
-LABOUR L	guide install&cut seat	EA
-LE191	velo pt.	EA
-LE215	velo pt.	EA
-LE216	velo pt.	EA
-LE242	velo pt.	EA
-LE319/2	velo pt.	EA
-LE333	velo pt.	EA
-LE335/2	velo pt.	EA
-LE431	velo pt.	EA
-LE543	velo pt.	EA
-LE572	velo pt.	EA
-LE573	velo pt.	EA
-LE598	velo pt.	EA
-LE689S	velo pt.	EA
-M10	velo pt.	EA
-M100215E	USE 82-4717	ea
-M11	velo pt.	EA
-M12/2	velo pt.	EA
-M120	velo pt.	EA
-M120/2	velo pt.	EA
-M131	USE 15-2419	ea
-M15/2	velo pt.	EA
-M155/2	velo pt.	EA

-M17/7	velo pt.	EA
-M17/8	velo pt.	EA
-M180/2	velo pt.	EA
-M190/2	velo pt.	EA
-M192/6	velo pt.	EA
-M193/2	velo pt.	EA
-M194/3	velo pt.	EA
-M198/3	velo pt.	EA
-M199/2	velo pt.	EA
-M2/12	velo pt.	EA
-M2/16	velo pt.	EA
-M2/17	velo pt.	EA
-M2/18	velo pt.	EA
-M2/6	velo pt.	EA
-M2/7	velo pt.	EA
-M200/4	velo pt.	EA
-M202/4	velo pt.	EA
-M203/5	velo pt.	EA
-M203/6	velo pt.	EA
-M206/2	velo pt.	EA
-M207	velo pt.	EA
-M209/3	velo pt.	EA
-M212	velo pt.	EA
-M214	velo banjo jet	EA
-M214S	velo pt.	EA
-M216	velo pt.	EA
-M217/2	velo pt.	EA
-M22/17	velo pt.	EA
-M22/18	velo pt.	EA
-M220/3	velo pt.	EA
-M226	velo pt.	EA
-M234	velo pt.	EA
-M244	velo pt.	EA
-M245	velo pt.	EA
-M249/4	velo pt.	EA
-M253	velo pt.	EA
-M255	velo pt.	EA
-M256/2	velo pt.	EA
-M257/2	velo pt.	EA
-M259	velo pt.	EA
-M260	velo pt.	EA
-M261	velo pt.	EA
-M261/2	velo pt.	EA
-M263	velo pt.	EA
-M267	velo pt.	EA
-M272	velo pt.	EA
-M274	velo pt.	EA
-M275	velo pt.	EA
-M29/3	velo pt.	EA
-M3/5	USE 452-477/PB	EA
-M3/6	velo pt.	EA
-M31/3	velo pt.	EA
-M32/4	velo pt.	EA
-M38/4	velo pt.	EA
-M39/2	velo pt.	EA
-M4/1062	USE 432-258	ea
-M4/1063	USE 432-258	ea
-M45/7	velo pt.	EA
-M45/8	velo pt.	EA
-M52	velo pt.	EA
-M56/6	velo pt.	EA
-M56/7S	velo pt.	EA
-M6/4	velo pt.	EA
-M6/5	velo pt.	EA
-M68	velo pt.	EA
-M70	velo pt.	EA
-M70/3	velo pt.	EA
-M72/7	velo pt.	EA
-M72/8	velo pt.	EA
-M72/9	velo pt.	EA
-M87/3	velo pt.	EA

-M89/8	velo pt.	EA
-M9/8	velo pt.	EA
-M9/9	velo pt.	EA
-M90	velo pt.	EA
-M90/2	velo pt.	EA
-M91/4	velo pt.	EA
-M93/2	velo pt.	EA
-MAS1/2	velo pt.	EA
-MAS102/2	velo pt.	EA
-MAS105	velo pt.	EA
-MAS106	velo pt.	EA
-MAS120	velo pt.	EA
-MAS122	velo pt.	EA
-MAS122/2	velo pt.	EA
-MAS123/2	velo pt.	EA
-MAS125/3S	velo pt.	EA
-MAS125/6S	velo pt.	EA
-MAS125/7	velo pt.	EA
-MAS14	velo pt.	EA
-MAS148/2	velo pt.	EA
-MAS18/2	velo pt.	EA
-MAS19/6	velo pt.	EA
-MAS24	velo pt.	EA
-MAS28	velo pt.	EA
-MAS29/6	velo pt.	EA
-MAS30/4	USE 711-VEL/01	ea
-MAS32/6	velo pt.	EA
-MAS35	velo pt.	EA
-MAS36	velo pt.	EA
-MAS38	velo pt.	EA
-MAS47/2	velo pt.	EA
-MAS50/4	velo pt.	EA
-MAS53/2	velo pt.	EA
-MAS55	velo pt.	EA
-MAS6	velo pt.	EA
-MAS60	velo pt.	EA
-MAS7/2	velo pt.	EA
-MAS77	velo pt.	EA
-MAS77/2	velo pt.	EA
-MAS8	velo pt.	EA
-MAS8/2	velo pt.	EA
-MAS84/5	velo pt.	EA
-MAS84/5S	velo pt.	EA
-MAS89/10	velo pt.	EA
-MAS89/8	velo pt.	EA
-MAS89/9	velo pt.	EA
-MAS9	velo pt.	EA
-MAS9/2	velo pt.	EA
-MAS9/3	velo pt.	EA
-MAS95	velo pt.	EA
-MAS97/28	velo pt.	EA
-MAS97/29	velo pt.	EA
-MAS97/30	velo pt.	EA
-MAS98	velo pt.	EA
-MAS99	velo pt.	EA
-MISC	NON-STOCKED/SPECIAL ORDER ITEM	ea
-NA14A	USE 221-15	ea
-NA43A	USE 71-3573	ea
-NE507	USE 40-0239	ea
-NF704	USE 532-23/B	ea
-NF708	USE 532-23/A	ea
-NM	NORTON-MATCHLESS OLD NUMBERS	*
-NM-----	-----	--
-NM11790	USE 06-7621	ea
-NM11796	USE 06-7622	ea
-NM11907	USE 60-4258	ea
-NM12093	USE 222-234	ea
-NM13185	USE 06-7627	ea
-NM13270	USE 06-7629	ea
-NM13765	USE 70-2615	ea
-NM13786	USE 06-6007	ea

-NM13870	USE 06-7632	ea
-NM14118	USE 06-7633	ea
-NM14119	USE 06-7634	ea
-NM14275	USE 06-7635	ea
-NM14298	USE 06-7636	ea
-NM14366	USE 06-7637	ea
-NM14367	USE 06-2653	ea
-NM14481	USE 57-2703	ea
-NM14506	USE 06-7640	ea
-NM14605	USE 06-7641	ea
-NM14698	USE 06-7642	ea
-NM14837	USE 06-7643	ea
-NM15339	badge,crankcase LH,preCommando	EA
-NM15398	USE 06-7908/A	ea
-NM15404	USE 06-7646	ea
-NM15511	USE 06-7827	ea
-NM15512	USE 06-7648	ea
-NM15515	USE 06-7649	ea
-NM15628	USE 06-7651	ea
-NM15630	USE 06-7652	ea
-NM15689	USE 06-7655	ea
-NM15801	USE 06-7657	ea
-NM16176	USE 82-2610	ea
-NM16187	USE 06-7664	ea
-NM16213	USE 06-4147	ea
-NM16237	USE 06-3204	ea
-NM16238	rubber,tankstrap,Featherbed	EA
-NM16249	rubber,passenger,Nort.flat	EA
-NM16250	USE 24-6035	ea
-NM16255	USE 742-134/A *	ea
-NM16256	strap,tank holdown,wideline	EA
-NM16256/SS	strap,tank holdown,wideline,stainless	EA
-NM16411	spring,centerstand,49-61	EA
-NM16547	USE 551-996 (set)	ea
-NM16782	USE 551-999 (set)	ea
-NM16783	USE 06-7674	ea
-NM16810	chainguard,7,77,Nomad	EA
-NM16945	USE 06-7676	ea
-NM16946	USE 06-7677	ea
-NM16947	USE 06-7678	ea
-NM16948	USE 06-7679	ea
-NM16949	USE 06-7680	ea
-NM16997	USE 06-2654 w/2)14-0402	ea
-NM16998	USE 06-7682	ea
-NM17221	USE 453-195	ea
-NM17429	USE 06-7685	ea
-NM17697	USE 06-7686	ea
-NM17713	USE 06-5483	ea
-NM17719	USE 04-0100	ea
-NM17721	USE 06-7688	ea
-NM17773	USE 60-0003	ea
-NM17806	USE 552-110038/38	ea
-NM17822	USE 60-4167 (or 06-4118) *	ea
-NM17823	USE 06-7690	ea
-NM17824	USE 70-9493 (or 06-4118)	ea
-NM17828	USE 421-57 (set)	ea
-NM17835	USE 552-110046/80	ea
-NM17842	USE 60-4255	ea
-NM18033	USE 06-7693	ea
-NM18092	USE 06-2464	ea
-NM18093	USE 06-7694	ea
-NM18094	USE 06-7695	ea
-NM18101	USE 06-7696	ea
-NM18102	USE 06-7697	ea
-NM18103	USE 06-7698	ea
-NM18149	USE 06-7699	ea
-NM18202	USE 01-4117	ea
-NM18232	USE 06-7702	ea
-NM18233	USE 06-7703	ea
-NM18234	USE 06-7704	ea
-NM18257	USE 552-110037/42	ea

-NM18263	USE 37-7041	ea
-NM18268	USE 06-7708	ea
-NM18285	USE 06-7709	ea
-NM18315	USE 60-2320	ea
-NM18320	USE 60-2417	ea
-NM18339	stud,9/16x20x7/16x26,brkdrum	EA
-NM18348	USE 06-7711	ea
-NM18350	USE 06-7712	ea
-NM18403	USE 523-18053	ea
-NM18467	forktube,Roadholder,long,23.312"	EA
-NM18482	USE 06-7714	ea
-NM18502	USE 06-7715 (PAIR)	PR
-NM18551	USE 06-3918	ea
-NM18678	USE NM25217	ea
-NM18731	USE 06-7718	ea
-NM18755	USE 06-7720	ea
-NM18772	USE 06-7722	ea
-NM18810	rivet	EA
-NM18813	USE 06-7723	ea
-NM18890	USE 526-187	ea
-NM18943	USE 06-7726	ea
-NM19021	USE 06-7727	ea
-NM19086	mounting plt,bat.box,Atlas	EA
-NM19100	USE 06-7730	ea
-NM19189	USE 06-7733	ea
-NM19195	USE 06-7734	ea
-NM19228	badge,timing cover,preCommando	EA
-NM19264	USE 03-0500	ea
-NM19266	USE 06-7738	ea
-NM19267	USE 06-7739	ea
-NM19307	USE 06-7743	ea
-NM19379	USE 06-0592	ea
-NM19429	USE 06-7744	ea
-NM19437	USE 06-7745	ea
-NM19490	USE 06-7746	ea
-NM19584	USE 06-3417	ea
-NM19629	hose,breather,pre72	EA
-NM19646	USE 06-7748	ea
-NM19664	USE 06-0364*	ea
-NM19680	USE 06-7750	ea
-NM19714	USE 06-7751	ea
-NM19828	USE 526-769 *	ea
-NM19846	chainguard,wideFeatherbed,late	EA
-NM19929	USE 06-7757	ea
-NM19983	USE 532-81	ea
-NM20061	USE 06-2525	ea
-NM20063	USE 06-2526	ea
-NM20083	USE 06-7767	ea
-NM20126	USE NM25302 ?	ea
-NM20230	USE 21-0649	ea
-NM20253	USE 06-7769	ea
-NM20276	USE 526-44/38 *	ea
-NM2032	USE 06-7534	ea
-NM20618	USE 526-44/38 *	ea
-NM20621	USE 00-0203	EA
-NM20692	USE 06-7772	ea
-NM20732	USE 06-7774	ea
-NM20744	USE 453-184	ea
-NM20829	USE 06-7775	ea
-NM20842	USE 06-2580	ea
-NM20885	USE 06-7777	ea
-NM20936	USE 06-7778	ea
-NM20939	USE 06-7779	ea
-NM20942	USE 00-0340	ea
-NM20948	USE 06-5718 key or 14-0304 nut	ea
-NM20999	USE 06-7782	ea
-NM21146	USE 06-7784	ea
-NM21248	USE 06-7785	ea
-NM21259	USE 04-3442*	ea
-NM21287	USE 06-7786	ea
-NM21383	USE 06-8070	ea

-NM21433	USE 06-7788	ea
-NM21457	USE 453-183	EA
-NM21467	decal,RECOMMENDED OIL LEVEL	ea
-NM21480	USE 04-3191*	ea
-NM21832	USE 06-7789	ea
-NM21851	USE 06-7790	ea
-NM21852	USE 06-7791	ea
-NM21998	USE 14-0303	ea
-NM21999	USE 57-0323	ea
-NM22017	USE 623-13	ea
-NM22024	USE 70-3695	ea
-NM22061	USE 06-7797	ea
-NM22082	USE 06-7799	ea
-NM22401	USE 60-2420	ea
-NM22403	USE 14-0114	ea
-NM22460	USE 06-0729	ea
-NM22473	USE 06-7804	ea
-NM22528	USE 60-2418	ea
-NM22546	USE 526-769/5 *	ea
-NM22636	USE 06-7808	ea
-NM22688/2	USE 14-0221	ea
-NM22688/3	USE 14-0113	ea
-NM22713/22714	tankbadge set,slimline	PR
-NM22721	USE 06-7815/7816 (set)	ea
-NM22722	USE 06-7815/7816 (set)	ea
-NM22729	USE 06-7817	ea
-NM22755	USE 06-7818	ea
-NM22764	USE 06-7819	ea
-NM22771	USE 06-7820 (pair)	ea
-NM22771/2	USE 06-7820	ea
-NM22772	USE 06-7820 (pair)	ea
-NM22838	USE 451-720 (set)	ea
-NM22839	USE 451-720 (set)	ea
-NM22840/4	USE 14-6217	ea
-NM22850	USE 06-4188	ea
-NM23153	USE 60-0985	ea
-NM23252	USE 06-7835	ea
-NM23253	USE 06-7827	ea
-NM23254	USE 06-6486	ea
-NM23255	USE 421-53 (set)	ea
-NM23264	USE 82-3227	ea
-NM23265	USE 06-7830	ea
-NM23276	USE 06-7834	ea
-NM23280	USE 06-7835	ea
-NM23298	USE 06-3544	ea
-NM23305	USE 621-54	ea
-NM23308	USE 04-3442*	ea
-NM23319	USE 06-7838	ea
-NM23331	USE 06-7839	ea
-NM23332	USE 06-7840	ea
-NM23352	USE 06-7501	ea
-NM23354	USE 06-7502	ea
-NM23358	USE 06-3458	ea
-NM23384	USE 68-0237	ea
-NM23392	USE 06-7845	ea
-NM23412	USE 06-2536	ea
-NM23441	USE 222-186	ea
-NM23459	USE 02-7137	ea
-NM23555	USE 633-04	ea
-NM23559	USE 06-7854	ea
-NM23563	USE 06-7855	ea
-NM23580	USE 06-2084	ea
-NM23595	USE 526-44/38 *	ea
-NM23868	USE 06-7858	ea
-NM23876	bracket,chrono mtg.	EA
-NM23926	USE 511-100	ea
-NM24074	USE 06-7866	ea
-NM24081	USE 70-1545	ea
-NM24237	USE 06-1705 *	ea
-NM24249	USE 06-7869	ea
-NM24250	USE 06-7870	ea

-NM24251	USE 06-7871	ea
-NM24252	USE 06-4147	ea
-NM24253	USE 06-7873	ea
-NM24255	gasket,cyl.hd,pre65 Atlas	EA
-NM24260	USE 06-3192	ea
-NM24298	USE 06-7877	ea
-NM24300	USE 06-7878	ea
-NM24301	USE 06-7879	ea
-NM24320	USE 06-7882	ea
-NM24322	USE 06-7883	ea
-NM24330	USE 453-240	ea
-NM24389	USE 06-7885	ea
-NM24562	stud,1/4x26x20	EA
-NM24563	USE 572-BG150805	ea
-NM24571	USE 633-03	ea
-NM24595	USE 06-7744	ea
-NM24689	USE 06-7888	ea
-NM24732	USE 06-7889	ea
-NM24733	USE 06-7890	ea
-NM24820	USE 391-53973	ea
-NM24840	USE 391-53973	ea
-NM24872	rim,WM2x18,Norton drum*	EA
-NM24948	USE 06-7894	ea
-NM24984	bracket,bridge,fr.mudguard,650/Atlas	EA
-NM24984/SS	bracket,bridge,fr.mudguard,650/Atlas	EA
-NM24987	USE 526-579	ea
-NM25003	USE 06-7896	ea
-NM25008	USE 526-91	ea
-NM25033	USE 526-92	ea
-NM25035	USE 526-769	ea
-NM25036	USE 526-769/5	ea
-NM25038	USE 526-579/6 *	ea
-NM25060	USE 06-7903	ea
-NM25087	USE 571-69/A	ea
-NM25100	USE 06-7905	ea
-NM25101	decal,crossed flags,Norton	EA
-NM25105	USE 06-7906	ea
-NM25116	USE 06-7907	ea
-NM25117	USE 06-7908	ea
-NM25165	USE 421-53/010 (set)	ea
-NM25166	USE 421-53/020 (set)	ea
-NM25167	USE 421-53/030 (set)	ea
-NM25168	USE 421-53/040 (set)	ea
-NM25190	bracket,muffler,Atlas,etc .	EA
-NM25217	badge,gastank,Nort,2 hole	PR
-NM25220	USE 526-579/6 *	ea
-NM25272	USE 432-260	ea
-NM25273	USE 432-260/D	ea
-NM25287	USE 432-261	ea
-NM25302	cover,gusset plate,featherbed	EA
-NM25302/SS	cover,gusset plt,featherbed,stainless	EA
-NM25313	USE 06-7918	ea
-NM25318	USE 06-7919	ea
-NM25323	USE 06-1705 *	ea
-NM25324	USE 06-7920	ea
-NM25328	USE 06-5561	ea
-NM25330	USE 06-2473	ea
-NM25332	USE 06-2471	ea
-NM25334	USE 06-2474	ea
-NM25336	USE 06-2472	ea
-NM25341	USE 06-7922	ea
-NM25348	USE 06-0592	EA
-NM25350	USE 06-7924	ea
-NM25360	USE 432-261	ea
-NM25369	USE 06-4896	ea
-NM25382	USE 06-1180	ea
-NM25384	USE 421-53 (set)	ea
-NM25396	USE 06-6193	ea
-NM25403	airfilter assy,Atlas style,389/689	EA
-NM25409	USE 421-53/010 (set)	ea
-NM25410	USE 421-53/020 (set)	ea

-NM25411	USE 421-53/030 (set)	ea
-NM25412	USE 421-53/040 (set)	ea
-NM25453	USE 06-0332	ea
-NM25499	USE 06-7942	ea
-NM25500	USE 453-264	ea
-NM25501	USE 453-263	ea
-NM25515	USE 06-7940	ea
-NM25516	USE 06-7941	ea
-NM25592	USE 60-2427	ea
-NM25599	USE 14-0203	ea
-NM25607	USE 06-7950	ea
-NM25614	USE 06-7951	ea
-NM26076	USE 60-2322	ea
-NM26078	USE 14-0403	ea
-NM26313	USE 60-2350/CHR	ea
-NM26484	USE 14-0101	ea
-NM26494	USE 60-2430	ea
-NM26634	USE 60-2429	ea
-NM26944	USE 14-0204	ea
-NM26947	USE 14-0301	ea
-NM26948	USE 06-1344	ea
-NM27027	USE 14-0101	ea
-NM27436	USE 14-0206	ea
-NM27815	USE 14-0302	ea
-NM28681	USE 21-0151	ea
-NM30755	USE 60-2322	ea
-NM30802	USE 06-7963	ea
-NM30858	USE 60-2347	ea
-NM30859	USE 60-2348	ea
-NM31236	USE 06-7963	ea
-NM3579	kneepad set,Nort,1 screw type	PR
-NM50245	sprocket,rear,1/4"chain	EA
-NME	NORTON-MATCHLESS OLD NUMBERS	*
-NME-----	-----	--
-NME3135	USE 06-7584	ea
-NME3154	USE 06-7585	ea
-NME3214	USE 06-7585	ea
-NME3221	USE 06-7588	ea
-NME3223	USE 06-7589	ea
-NME3224	USE 00-0003	ea
-NME3227	USE 04-1265	ea
-NME3229	USE 82-0879	ea
-NME3231	USE 70-1310	ea
-NME3682	USE 06-7595	ea
-NME4102	bush,small end,Norton singles	EA
-NME4591	USE 06-7600	ea
-NME5061	USE 00-0113	ea
-NME5264	USE 623-02/A	ea
-NME5276	USE 06-7603	ea
-NME5278	USE 01-2873	ea
-NME5377	USE 60-2323	ea
-NME5456	USE 06-7606	ea
-NME5832	USE 06-7607	ea
-NME6055	USE 06-7609	ea
-NME6056	USE 06-7610	ea
-NME6066	USE 06-7609	ea
-NME6283	USE 04-5057	ea
-NME6472	USE 453-37	ea
-NME6640	USE 06-7611	ea
-NME6706	USE 97-0211	ea
-NME6742	USE 06-7612	ea
-NME6743	USE 06-7613	ea
-NME6885	USE 06-7614	ea
-NME6889	USE 06-7616	ea
-NME6980	USE 06-7617	ea
-NME8223	USE 00-0004	ea
-NME9731	USE 422-1414	ea
-NME9732	USE 06-8088	ea
-NMLTU07	USE 221-15	ea
-NMS650/82EX	USE 06-7502	ea
-NMS650/82IN	USE 06-7501	ea

-NMT	NORTON-MATCHLESS OLD NUMBRS	*
-NMT	-----	--
-NMT1009	USE 06-7517	ea
-NMT1048	USE 06-7519	ea
-NMT1049	USE 06-7520	ea
-NMT1055	USE 06-7521	ea
-NMT1084	USE 06-7522	ea
-NMT1085	USE 70-3858	ea
-NMT186	USE 06-7506	ea
-NMT187	USE 06-7507	ea
-NMT2007	USE 06-7525	ea
-NMT2008	USE 06-7526	ea
-NMT2010	USE 453-26	ea
-NMT2011	USE 452-544	ea
-NMT2013	USE 06-2661	ea
-NMT2016	USE 06-7528	ea
-NMT2017	USE 06-7529	ea
-NMT2018	USE 06-7530	ea
-NMT2031	USE 06-7533	ea
-NMT2032	USE 06-7534	ea
-NMT2033	USE 06-7535	ea
-NMT2035	USE 06-7537	ea
-NMT2036	USE 06-7538	ea
-NMT2037	USE 06-7539	ea
-NMT2054	USE 06-7540	ea
-NMT2057	USE 06-7541	ea
-NMT2058	USE 06-7542	ea
-NMT2059	USE 06-6195	ea
-NMT2060	USE 06-7543	ea
-NMT2061	USE 06-7544	ea
-NMT2063	USE 06-6978	ea
-NMT2073	USE 06-7545	ea
-NMT2074	USE 06-7546	ea
-NMT2078	USE 06-7547	ea
-NMT2080	USE 06-7548	ea
-NMT2082	USE 06-7549	ea
-NMT2083	USE 06-7550	ea
-NMT2084	USE 06-7551	ea
-NMT2085	USE 06-7552	ea
-NMT2086	USE 06-7553	ea
-NMT2088	USE 06-7554	ea
-NMT2093	USE 06-7556	ea
-NMT2096	USE 06-7557	ea
-NMT2097	USE 82-1760	ea
-NMT2105	USE 06-7558	ea
-NMT2108	USE 06-7559	ea
-NMT2124	USE 04-8023	ea
-NMT2141	gask, cyl.hd, 49on500-650cc	EA
-NMT2142	USE 06-3092	ea
-NMT2143	USE 06-7560	ea
-NMT2160	bush, small end, NortonTwin	EA
-NMT2161	USE 06-7561	ea
-NMT2162	USE 06-7562	ea
-NMT2166	USE 06-3995	ea
-NMT2180	sprocket, engine, 16T	EA
-NMT2180A	sprocket, engine, 17T	EA
-NMT2180B	sprocket, engine, 18T	EA
-NMT2180C	USE 06-7563	ea
-NMT2180D	USE 06-7564	ea
-NMT2180E	USE 06-7565	ea
-NMT2180F	sprocket, engine, 22T	EA
-NMT2180G	USE 06-7566	ea
-NMT2187	USE 06-7567	ea
-NMT2191	USE 06-7568	ea
-NMT2196	USE 06-7569	ea
-NMT2204	USE 453-27	ea
-NMT2209	USE 06-7571	ea
-NMT2210	USE 06-7572	ea
-NMT2217	USE 06-7574	ea
-NMT2218	USE 06-7575	ea
-NMT2218A	USE 06-7576	ea

-NMT2221	USE 06-7577	ea
-NMT2236	USE 06-1092 & 06-2447	ea
-NMT2238	USE 06-7578	ea
-NMT2239	USE 06-7579	ea
-NMT2240	USE 06-7580	ea
-NMT2245	USE 06-7581	ea
-NMT2252	USE 06-7582	ea
-NMT232	USE 06-7508	ea
-NMT247	USE 06-7509	ea
-NMT272	USE 06-7510	ea
-NMT320	USE 06-7511	ea
-NMT387	USE 00-0485	ea
-NMT597	USE 06-7512	ea
-NMT814	USE 06-7514	ea
-NMT831	USE 06-0762	ea
-NS191	USE 524-CX53	ea
-NS362	USE 99-3541	ea
-NS372	nut,brakerod,CEI, knurled	EA
-NT261	USE 57-2595	ea
-NT297	USE 57-2009	ea
-NT367	USE 99-3544	ea
-NT376	USE 99-3545	ea
-NW100	USE 60-1841	ea
-NW243	USE 551-2031 (set)	ea
-OF522	USE 60-1006	ea
-OF618	USE 60-0984	ea
-P17/1062	USE 432-260	ea
-P17/1063	USE 432-260/D	ea
-P52305	USE 392-951	ea
-P53279/1	USE 572-05	EA
-PCE102F	USE 99-0045	ea
-PCW73A	USE 60-4251	ea
-PO172A	USE 99-0047	ea
-PR4	element,oilfilter,Vincent twin	EA
-PT104B	USE 60-4262	ea
-PT108B	USE 57-3988	ea
-PU5E	USE 335-09	ea
-PU7E	USE 335-07	ea
-PUZ5A	USE 335-02 *	ea
-PUZ5E	USE 335-09	ea
-R25010	USE 442-18020 (set)	ea
-R25830	USE 442-26260 (set)	ea
-R26640	USE 442-26730 (set)	ea
-RLS7	USE 37-1041	ea
-S	OLD TRIUMPH #S,USE 21-XXXX	*
-S-----	-----	---
-S130	USE 14-0305	ea
-S151	USE 00-0004	ea
-S152	USE 60-4261	ea
-S251	USE 60-4245	ea
-S2513	USE 60-4248	ea
-S252	USE 60-2331	ea
-S253	USE 60-4247	ea
-S2543	USE 70-8163	ea
-S256	USE 37-2027	ea
-S261	USE 60-4259	ea
-S2616	USE 60-3541	ea
-S262	USE 60-4250	ea
-S263	USE 60-4260	ea
-S32/2	velo pt.	EA
-S357	USE 60-3552	ea
-S413	USE 99-3557	ea
-S521	USE 57-4356	ea
-S522	USE 57-4356	ea
-S55/3	velo pt.	EA
-S66/3	velo pt.	EA
-S661	USE 60-4253	ea
-S68	velo pt.	EA
-S703	USE 422-14	ea
-S704	USE 422-316	ea
-S707	USE 422-732	ea

-S792	USE 37-4200	ea
-SCZ45	USE 82-8245	ea
-SL102/13	velo pt.	EA
-SL3/70	velo pt.	EA
-SL3/71	velo pt.	EA
-SL31/17	velo pt.	EA
-SL56/27	velo nut	EA
-SL56/33	velo pt.	EA
-SL80/22	velo screw,pri.cover	EA
-SL94	velo pt.	EA
-SPECIAL	SPECIAL CHARGE	EA
-SURCHARGE	surcharge	EA
-T	OLD TRIUMPH #S,USE 57-XXXX	*
-T-----	-----	--
-TE164E	USE 99-0055	ea
-TT1/19KS	velo pt.	EA
-TW5	USE 06-2307	ea
-USED PART	NON STOCK ITEM	EA
-W	OLD TRIUMPH #S,USE 37-XXXX	*
-W-----	-----	--
-W12/2	velo pt.	EA
-W21/6	velo pt.	EA
-W33/6AS	velo pt.	EA
-W62/2	velo pt.	EA
-W65/2	velo pt.	EA
-WE170	USE 60-4263	ea
-WE203E	USE 70-6861	ea
-WE259A	USE 71-3748	ea
-WE479	USE 70-6869	ea
-WF32	USE 60-4252	ea
-XA69	USE 60-4254	ea
-Z103	USE 222-616025	ea
-Z111	USE 222-617019	ea
-Z121	USE 222-158	ea
-Z13	USE 222-613768	ea
-Z130	USE 221-82/6065	ea
-Z132	USE 221-82/6570	ea
-Z139	USE 222-158	ea
-Z143	USE 222-061359	ea
-Z144	USE 222-155	ea
-Z145	USE 222-155	ea
-Z151	USE 222-616046	ea
-Z162	USE 222-617017	ea
-Z164	USE 222-616050	ea
-Z169	USE 222-191	ea
-Z182	USE 222-616024	ea
-Z22	USE 221-82/7075	ea
-Z23	USE 222-616008	ea
-Z55	USE 222-296 or 222-296/A	ea
-Z56	USE 222-296 or 222-296/A	ea
-Z60	USE 222-158	ea
-Z76	USE 222-617024	ea
-Z89	USE 222-155	ea
00-	NORTON, TRIUMPH, &BSA PARTS	*
00-----	-----	--
00-0002	USE 97-0193	ea
00-0003	nut, 3/8x26, plain	EA
00-0004	USE 21-0151	ea
00-0005	USE 82-0879	ea
00-0005*	oilseal, forks, Harris Bonnie	EA
00-0008	washer, 1/2", flat	EA
00-0009	USE 60-2323	ea
00-0010	USE 60-2322	ea
00-0011	USE 60-2321	ea
00-0012	USE 60-2320	ea
00-0021	USE 422-14	ea
00-0039	washer, 3/16, flat	EA
00-0051	USE 06-3411	ea
00-0072	USE 422-316	ea
00-0073	USE 37-0076 *	ea
00-0074	nut, 5/16x26, thin	EA

00-0075	USE 422-1414	ea
00-0080	nut,2BA,plain	EA
00-0113	rivet,brake lining	EA
00-0174	washer,5/16,flat	EA
00-0183	USE 623-02	ea
00-0190	USE 60-2416	ea
00-0191	USE 60-2417	ea
00-0192	USE 60-2428	ea
00-0200	washer,fibre,3/8 inch	EA
00-0203	washer,fibre,1/4inch	EA
00-0230	USE 02-6536	ea
00-0271	stud,5/16x22x26TPI	EA
00-0292	USE 06-7772	ea
00-0340	bolt,1/4x20	EA
00-0350	USE 70-5451	ea
00-0402	USE 97-0426	ea
00-0450	screw,2BA,gbx. insp.&sprocket	EA
00-0451	screw,2BA	EA
00-0455	USE 06-1105	ea
00-0457	screw,2BA,clutch release arm	EA
00-0482	screw,1/4x26CEI	EA
00-0484	USE 00-0482	ea
00-0485	screw,1/4x26,fork drain	EA
00-0513	USE 82-3337	ea
00-0572	key,cam and crank pinion	EA
00-0577	pin,dowel	EA
00-0873	USE 40-8016	ea
00-3151	USE 432-306/D	ea
00-3152	USE 432-327/D	ea
00-3156	USE 432-325/D	ea
00-3163	USE 432-332/D	ea
00-3171	USE 432-332/D	ea
00-3251	USE 432-300	ea
00-3252	USE 432-324	ea
00-3253	USE 432-301	ea
00-3254	USE 432-302	ea
00-3255	USE 432-326	ea
00-3258	USE 432-327	ea
00-3307	USE 432-333	ea
00-3310	USE 432-335 or 432-835	ea
00-3316	USE 432-339	ea
00-3318	USE 432-338	ea
00-3415	USE 442-23010	ea
00-3416	USE 442-23010/020	ea
00-3417	USE 442-23010/040	ea
00-3422	USE 442-15490/020	ea
00-3448	USE 442-3650	ea
00-3449	USE 442-3650/020	ea
00-3450	USE 442-3650/040	ea
00-3451	USE 442-17360	ea
00-3452	USE 442-17360/020	ea
00-3453	USE 442-17360/040	ea
00-3454	USE 442-17350	ea
00-3455	USE 442-17350/020	ea
00-3456	USE 442-17350/040	ea
00-3463	USE 442-15490	ea
00-3466	USE 442-23020	ea
00-3468	USE 442-23020/010	ea
00-3469	USE 442-23020/020	ea
00-3470	USE 442-23020/040	ea
00-3472	USE 442-23010/020	ea
00-5158	kickstarter crank,Bantam	EA
00-5178	USE 70-8737	ea
00-5196	USE 40-0437/0438	ea
00-5220	USE 572-51	ea
00-9195	decal,reserve	EA
01-	NORTON,TRIUMPH &BSA PARTS	*
01-----	-----	---
01-0692	bush,fortube,bot,steel,1-1/8"Teledrauli	EA
01-0719	USE 97-2667	ea
01-1094	USE 06-4152	ea

01-1111	circlip, valve guide, 850	EA
01-1404	USE 557-WM2	ea
01-1697	rivet, mudguard bridge	EA
01-1796	USE 00-0003	ea
01-1835	USE 324-92	ea
01-1835/SS	number plate, fr, UKtype, stainless	EA
01-1836	mount, front numberplate	EA
01-1843	USE 70-8089	ea
01-1846	nut, 2BA, lock	EA
01-1907	USE 60-4258	ea
01-2443	washer, felt, inner pri.	EA
01-2542	USE 37-1041	ea
01-2873	screw, 2BA	EA
01-3325	USE 622-04	ea
01-4117	washer, 5/16 shakeproof	EA
01-4119	washer, 3/8, lock	EA
01-4577	USE 04-0137	ea
01-4606	screw, 2BA	EA
01-4675	USE 422-14	ea
01-4676	USE 422-316	ea
01-4714	USE 68-4084	ea
01-4734	USE 00-0004	ea
01-4999	washer, 5/16, flat	EA
01-5286	bush, fork tube, top, 1-1/8" Teledraulics	EA
01-5306	washer, 1/4" lock	EA
01-6032	nut, 1/4X26, small hex*	EA
01-6033	USE 82-8981	ea
01-6072	USE 97-2661	ea
01-6213	USE 06-4147	ea
01-6304	USE 97-2666	ea
01-6339	USE 97-2662	ea
01-7060	USE 557-WM2	ea
01-7191	USE 89-3022	ea
01-7252	USE 221-09	ea
01-7357	rod, fork damper, Matchless	EA
01-7376	USE 552-110056/110	ea
01-9490	grommet, wiring harness, 1"OD*	EA
01-9512	circlip, external	EA
01-9824	USE 524-244104	ea
02-	NORTON, TRIUMPH &BSA PARTS	*
02-----	-----	--
02-0046	USE 00-0003	ea
02-0047	USE 21-5161	ea
02-0049	USE 70-8133	ea
02-0051	USE 82-0879	ea
02-0079	USE 24-7178	ea
02-0100	USE 623-02 or 623-02/A	ea
02-0124	USE 37-2325	ea
02-0204	USE 82-9019	ea
02-0220	USE 82-9060	ea
02-0292	USE 97-3893	ea
02-0319	USE 06-0720	ea
02-0370	USE 82-9196	ea
02-0433	key, clutch, preunit BSA	EA
02-0440	USE 37-2332	ea
02-0443	USE 60-4264	ea
02-0449	USE 60-4261	ea
02-0452	USE 37-2316	ea
02-0463	USE 531-15 (set)	ea
02-0522	USE 60-2429	ea
02-0525	USE 70-8072	ea
02-0923	USE 60-2321	ea
02-0927	USE 60-2428	ea
02-0930	washer, fibre	EA
02-1027	USE 82-9042	ea
02-1299	USE 97-1876	ea
02-1309	USE 70-7354	ea
02-1462	USE 60-2427	ea
02-1495	bush, fork tube, bot, steel, 1-1/4" Teledraulic	EA
02-1584	screw, tank badge	EA
02-1588	nut, tank badge	EA

02-1590	washer,5/8,flat	EA
02-1693	USE 37-2294	ea
02-1694	USE 06-2595	ea
02-1700	spring,brake return	EA
02-1733	USE 82-8998	ea
02-1872	USE 70-1592	ea
02-1925	USE 82-9033	ea
02-1945	USE 60-2323	ea
02-1967	USE 82-9034	ea
02-2138	washer,3/8",flat,thick	EA
02-2395	USE 82-0879*	ea
02-2484	bars,AMC low	EA
02-2527	USE 37-1798	ea
02-2548	USE 391-31563	ea
02-2578	USE 57-4356 (assy)	ea
02-2579	USE 57-4356 (assy)	ea
02-2580	USE 57-4356 (assy)	ea
02-2699	oilseal,forks,Teledraulic	EA
02-2700	bush,forttube,top,1-1/4"Teledraulics	EA
02-2757	USE 532-74	ea
02-2823	forttube,Teledraulic,P11,etc.	EA
02-2870	USE 552-110046/68	ea
02-2894	washer,fibre	EA
02-2903	USE 60-2429	ea
02-3753	USE 526-769/5	ea
02-4020	gask,pri,AJS/MATCH 1cyl,58on*	EA
02-4021	gask,pri,AJS/MATCH dyno2cyl,58-61	EA
02-4145	dowel,primary cover	EA
02-4248	rim,WM2x19,AMC front	EA
02-4249	rim,WM2x19,AMC rear	EA
02-4365	USE 221-400935	ea
02-4544	USE 70-2441	ea
02-4553	USE 71-2505	ea
02-5037	gasket,primary,G&N15& P11*	EA
02-5352	USE 622-06	ea
02-5615	USE 06-7709	ea
02-6359	pad,gastank,etc.	EA
02-6476	USE 523-16011	ea
02-6536	nut,5/8x20,thin	EA
02-6559	USE 02-6359	ea
02-6656	bracket,heatsink,zener diode	EA
02-6762	USE 89-3022	ea
02-7026	badges,tank,Mat,plastic,round	PR
02-7137	oring,gastank mount	EA
02-8238	USE 526-97	ea
02-8239	USE 526-96	ea
02-8535	cover,gearbox,outer,Atlas,etc.	EA
02-9431	numberplate,rear,Featherbed,G15/N15	EA
02-9469	chainguard,N15/G15,Model33	EA
02-9593	sidepanel,RH,G15/N15	EA
02-9594	USE 02-9593	ea
02-9604	USE 391-49072	ea
02-9758/9760	numberplate,r,w/bracket,P11	EA
02-9983	USE 06-1105	ea
02-9984	USE 70-6559	ea
03-	NORTON,TRIUMPH &BSA PARTS	*
03-----	-----	---
03-0023	washer,5/8,flat	EA
03-0026	USE 06-0344	ea
03-0036	forttube,G15/N15 type	EA
03-0045	USE 391-70276	ea
03-0051	USE 391-49345	ea
03-0052	sprocket,rear,Atlas,etc,3/8,CEI,43T	EA
03-0052/42	sprocket,rear,Atlas,etc,3/8,CEI,42T	EA
03-0052/ER	sprocket&drum,econo repl.	EA
03-0055	USE 06-0362 & 06-0361	ea
03-0080	pin,pointshaft,rear mt.type	EA
03-0082	cover,points,rear mt.type*	EA
03-0084	clip,pointscover,rear mt.	EA
03-0097	USE 37-7041	ea
03-0098	USE 37-7041	ea

03-0101	USE 82-9065	ea
03-0175	USE 82-6738	ea
03-0238	cover plt,gbx.mt,G15/N15	EA
03-0248	USE 543-33007	ea
03-0258	USE 572-SSM300100	ea
03-0289	USE 02-9593	ea
03-0337	airfilt.assy,Atlas,etc,376&389	EA
03-0343	bolt,5/16x18,allen	EA
03-0344	USE 571-69/A	ea
03-0358	bracket,instr,Atlas,G15,N15	EA
03-0391	USE 572-RSM300300	ea
03-0392	USE 571-30/C	ea
03-0398	bars,braced,P11,N15CS,G15CS*	EA
03-0408	USE 521-8 *	ea
03-0435	USE 391-54959626	ea
03-0448	bolt,5/16x18	EA
03-0453	slider extension,Roadholder,long	EA
03-0454	USE 06-0350	ea
03-0461	decal,OIL RECOMMENDATIONS	EA
03-0500	bolt,1/4x26,r.chain adj.	EA
03-0517	decal,MADE IN ENGLAND,small	EA
03-0531	cover tube,forks,lower	EA
03-0584	dampner valve seat,forks	EA
03-0720	USE 37-0076 *	ea
03-1075	USE 391-54170009	ea
03-1156	bolt,5/16x26*	EA
03-1346	USE 60-3541	ea
03-1399	bolt,3/8X26	EA
03-1399/CHR	bolt,3/8X26,chrome	EA
03-1544	bracket,hdlt,Atlas typeLH	EA
03-1544/1545	brackets,hdlt,Atlas type,blk.	PR
03-1545	bracket,hdlt,Atlas typeRH	EA
03-1553	USE 40-8016	ea
03-1555	spacer,5/16,headlight	EA
03-1612	USE 526-96	ea
03-1613	USE 526-92	ea
03-1614	USE 526-91	ea
03-1621	USE 391-34815	ea
03-1651	bars,braced,P11A. Ranger	EA
03-1746	USE 621-131	ea
03-1943	USE 391-31827	ea
03-2010	USE 391-69219	ea
03-2018	plates,heatsink,zener diode	EA
03-2018/A	heatsink assy,zener diode,featherbed	EA
03-2044	gasket,oiline junction	EA
03-2097	bolt,5/16x26,axle adjust.	EA
03-2220	USE 345-10/D	ea
03-3001	USE 68-8083	ea
03-3015	USE 391-45276/A	ea
03-3016	USE 391-30608	ea
03-3027	adaptor,airfilter,900Amal	EA
03-3030	airfilter assy,Atlas style,900	EA
03-3030/ELEMENT	element,airfilter	EA
03-3030/SS	airfilter assy,stainless*	EA
03-3044	USE 391-54335169	ea
03-3051	rim,WM3x18,P11 rear	EA
03-3056	oring,points,Atlas type	EA
03-3057	USE 14-0301	ea
03-3063	bracket,instr,P11/P11A	EA
03-3068	bearing,needle	EA
03-3144	USE 526-92	ea
03-3145	USE 526-99	ea
03-3155	USE 621-132	ea
03-3186	USE 03-3188/ASSY	ea
03-3187	USE 03-3188/ASSY	ea
03-3188	element,airfilter,P11,K&N	EA
03-3188/ASSY	airfilter body assy,P11 *	EA
03-3195	spacer	EA
03-3217	clamp, fork gaiter,bot,P11	EA
03-3218	USE 532-18	ea
03-3258	USE 03-3188/ASSY	ea

03-3278	pin,pre71 Comm. sidestand	EA
03-3279	circlip	EA
03-3281	USE 691-622101	ea
03-4033	chainguard,P11A,Ranger,1968	EA
03-4052	bearing,needle	EA
03-4053	USE 06-3609	ea
03-4072	grommet	EA
03-5039	decal,NORTON,tail section	EA
03-5073	decal,MADE IN ENGLAND	EA
04-	NORTON,TRIUMPH &BSA PARTS	*
04-----	-----	---
04-0001	mainshaft,preCommando	EA
04-0002	pawl carrier,bare	EA
04-0003	ring,locking,cl.rel.body	EA
04-0005	oring,kickstart shaft	EA
04-0005/A	oilseal,kickstart shaft	EA
04-0006	oring,shift	EA
04-0010	sprocket,gbox,19T,5/8x1/4	EA
04-0010/13	sprocket,gbox,13T,5/8x1/4	EA
04-0010/15	sprocket,gbox,15T,5/8x1/4	EA
04-0010/16	sprocket,gbox,16T,5/8x1/4	EA
04-0010/17	sprocket,gbox,17T,5/8x1/4	EA
04-0010/18	sprocket,gbox,18T,5/8x1/4	EA
04-0010/19	USE 04-0010	EA
04-0010/20	sprocket,gbox,20T,5/8x1/4	EA
04-0010/21	sprocket,gbox,21T,5/8x1/4	EA
04-0010/22	sprocket,gbox,22T,5/8x1/4	EA
04-0010/23	sprocket,gbox,23T,5/8x1/4	EA
04-0010/24	sprocket,gbox,24T,5/8x1/4	EA
04-0015	USE 04-0108	ea
04-0017	USE 06-2015	ea
04-0018	camplate,bare*	EA
04-0019	gear,2nd lay,24T,old type *	EA
04-0019/ER	gear,2nd lay,24T,old type,econo	EA
04-0020	USE 06-1058 & 06-5954	ea
04-0021	USE 06-4640 & 06-4639	ea
04-0022	shifter fork,genuine	EA
04-0022/ER	shifter fork,econo repl.	EA
04-0023	nut,9/16x20	EA
04-0024	pawl,gearshift	EA
04-0025	USE 06-6666	ea
04-0026	gear,1st main,14T	EA
04-0026/ER	gear,1st main,econo repl.	EA
04-0029	lever,cl.rel,preCommando	EA
04-0030	gasket,gearbox,inner cov.	EA
04-0031	USE 422-12	ea
04-0032	USE 04-0146	ea
04-0033	pin,kickstarter pawl	EA
04-0034	plunger,shift detent	EA
04-0035	shaft,shift fork	EA
04-0036	housing,detent plunger	EA
04-0038	spring,gearshift pawl	EA
04-0041	rivet,inner gbx.cover,kickcam	EA
04-0042	stop plate,kick shaft	EA
04-0043	spring,kick return,early	EA
04-0044	spring,kickstart pawl	EA
04-0046	USE 06-6664	ea
04-0047	USE 06-6665	ea
04-0048	bush,2nd main	EA
04-0049	circlip	EA
04-0051	pointer,gearshift indic.	EA
04-0052	USE 06-4049	ea
04-0055	gasket,gearbox cov,outer	EA
04-0056	bush,gearbox housing	EA
04-0057	gasket,gearbox insp.cover	EA
04-0059	body,clutch release	EA
04-0060	roller,clutch release	EA
04-0061	bush,shift,inner gbx cov.	EA
04-0062	bush,gearbox,4th main	EA
04-0063	bush,shift,outer gbx.cov.	EA
04-0064	stud,5/16x22x26TPI	EA

04-0065	sleeve,cl. release	EA
04-0067	pin,pawl carrier,gbx.	EA
04-0069	plunger,kickstart pawl	EA
04-0070	nut,1-1/4x20gbx.sprocket,LH	EA
04-0071	camplate,kickshaft,inner gbx.cov.	EA
04-0076	washer,retaining,gbx.nut	EA
04-0078	roller,shift	EA
04-0079	oring,shift ratchet shaft	EA
04-0084	pushrod,clutch release	EA
04-0086	USE 532-54	ea
04-0098	USE 60-3556	ea
04-0099	bearing,ball	EA
04-0100	bearing,ball	EA
04-0100/A	USE 06-7710 (roller brg.)	ea
04-0101	kickstart crank,nonfolding	EA
04-0102	bolt,3/8x20,kickstart	EA
04-0105	bolt,1/4x26CEI	EA
04-0108	camplate assy,RH shift	EA
04-0109	quadrant,operating,shift	EA
04-0110	pawl carrier assy,shift	EA
04-0111	ratchet plate assy,shift	EA
04-0115	gear,1st lay,28T,w/bush	EA
04-0115/ER	gear,1st lay,w/bush,econo	EA
04-0129	oring,gearbox housing	EA
04-0131	sleeve,gbx.sprocket seal	EA
04-0132	oilseal,Nor.gbx&BSA crank	EA
04-0135	washer,11/16,flat	EA
04-0136	USE 06-7635	ea
04-0137	bolt,1/4x26	EA
04-0137/SS	bolt,1/4x26,stainless	EA
04-0138	bolt,3/8x20	EA
04-0146	bush,RH lay	EA
04-0269	USE 04-0434	ea
04-0284	USE 06-1058 & 06-5954	ea
04-0355	clutch plate,plain,mid56-59*	EA
04-0358	spring,clutch,preCommando	EA
04-0360	screw,1/2x20,cl.adj,preCommando	EA
04-0362	plate,clutch centre,outer,early	EA
04-0366	clutch centre,AMC gbx.	EA
04-0373	nut,5/8x20	EA
04-0373/A	nut,clutch,w/cl.pushrod seal	EA
04-0374	USE 06-3459	ea
04-0376	USE 06-0005	ea
04-0385	USE 04-0358	ea
04-0386	rubber,clutch centre,lg.	EA
04-0387	rubber,clutch centre,sm.	EA
04-0388	cup,clutch spring,preCommando	EA
04-0389	nut,clutch spring	EA
04-0391/A	clutch plate,BARNETT,mid56-58*	EA
04-0407	sprocket,gearbox,16 tooth	EA
04-0418	gear,2nd main,18T,old type *	EA
04-0420	USE 04-0634	ea
04-0422	USE 06-5954 & 06-1058	ea
04-0429	arm,kickstarter crank,Atlas type	EA
04-0431	pedal,kickstart,Atlas type	EA
04-0432	USE 70-1435	ea
04-0433	washer,spring,kick pedal	EA
04-0434	kickstart crankAssy,Atlas folding	EA
04-0434/ER	kickcrankAssy,Atlas folding,econo	EA
04-0442	spring,detent plunger	EA
04-0451	sprocket,gearbox,17 tooth	EA
04-0451/A	USE 04-0458	ea
04-0458	sprocket,gearbox,18 tooth	EA
04-0467	USE 06-5163	ea
04-0472	bush,kick,outer	EA
04-0473	bush,kickstart,inner cov.	EA
04-0474	rivet,inner gbx.cov,kickstop	EA
04-0475	spring,kickstart return	EA
04-0477	USE 06-6169	ea
04-0479	spring,shift quad return	EA
04-0480	sprocket,gearbox,19 tooth	EA

04-0482	USE 04-0451	ea
04-0483	USE 04-0407	ea
04-0606	USE 06-2624*	ea
04-0607	pushrod,clutch,Atlas etc.	EA
04-0632	USE 06-1499	ea
04-0633	USE 04-0019	ea
04-0634	gear,3rd lay,20T*	EA
04-0634/ER	gear,3rd lay,econo repl.	EA
04-0635	gear,3rd main,21T	EA
04-0635/ER	gear,3rd main,econo repl.	EA
04-0636	USE 04-0434	ea
04-1065	grommet	EA
04-1104	cover,gearbox insp,drilled*	EA
04-1123	USE 60-4263	ea
04-1265	nut,1/2x20	EA
04-1311	USE 06-1499	ea
04-1400	bolt,5/16x22	EA
04-2025	USE 06-2581	ea
04-2065	USE 06-7611	ea
04-2276	USE 82-9089	ea
04-2569	USE 532-58	ea
04-2608	USE 82-9004	ea
04-2775	USE 42-5323	ea
04-2889	kneepad,LH,Matchless,stick on	EA
04-2889/2890	kneepads,Matchless,stick on	PR
04-2934	pedal,kickstart	EA
04-3191	cl.plate,steel,pre.Comm,late*	EA
04-3192	USE 04-3442	ea
04-3193	clutch plate,single sided	EA
04-3251	USE 24-7178	ea
04-3279	USE 391-189307	ea
04-3441	stud,clutch spring,preCom	EA
04-3442	cl.plate,friction,preComm	EA
04-3442/A	cl.kit,Barnett,pre Comm.	ST
04-3443	spider,clutch centre,Atlas etc.	EA
04-5057	washer,fibre,1/4 inch	EA
04-5062	USE 70-3302	ea
04-7431	USE 82-9004	ea
04-8023	oilseal,crank,RH,Norton	EA
04-8079	circlip	EA
04-8300	sidepanel,LH,G15/N15	EA
04-8301	USE 04-8300	ea
04-8425	USE 04-8300	ea
04-8499	badges,tank,Mat,plastic"M"	PR
04-8500	backing,tankbadge,Matchless,late	EA
06-	NORTON PARTS	*
06-----	-----	--
06-0005	nut,1/2UNF,clutch adj.	EA
06-0006	brakeshoe set,Nort.fr,DLS	PR
06-0013	brake shoe pad	EA
06-0014	spring,brakeshoe	EA
06-0015	tie rod,DLS front brake	EA
06-0018	clevis,DLS fr.brake,top L(LH thread)	EA
06-0019	clevis,DLS fr.brake,bot.R	EA
06-0020	screen,fr.brake plt,inlet	EA
06-0021	screen,fr.brake plt,outlet	EA
06-0025	lever,brk.oper,long,DLS*	EA
06-0027	lever,brk.oper,short,DLS	EA
06-0029	USE 14-0303	ea
06-0289	axle,rear,pre75 Commando	EA
06-0289/ER	axle,rear,pre75 Commando,econo.repl.	EA
06-0289/SS	axle,R,pre75Com,stainless	EA
06-0291	axle,dummy,pre71	EA
06-0292	nut,9/16x18,axle	EA
06-0292/SS	nut,9/16x18axle,stainless	EA
06-0299	damper tube,forks,early Comm.	EA
06-0302	USE 06-3423	ea
06-0308	USE 06-1179	ea
06-0314	cam,brake oper,rear	EA
06-0317	lockring,rear hub	EA
06-0319	sprocket,rear,pre71 Comm,3/8,UNF,42T	EA

06-0319/43	sprocket, rear, pre71 Comm, 3/8, UNF, 43T	EA
06-0319/ER	sprocket&drum, econo repl, 42T*	EA
06-0323	nut, 7/16x20, brakedrum	EA
06-0324	spacer, 9/16x1-5/16, axle	EA
06-0325	pin, pivot, brakeshoe, R	EA
06-0326	nut, 5/8x18, lipped	EA
06-0327	USE 14-0101	ea
06-0329	nut, 3/4x28, thin	EA
06-0332	brakeplate, rear	EA
06-0333	bolt, 5/16x24UNF, allen head	EA
06-0333/SS	bolts, bar clip, stainless	ST
06-0334	spacer, rear brake plate	EA
06-0335	forkyoke, top, Fastback*	EA
06-0336	stud, 7/16x20, forkcrown pinch	EA
06-0337	USE 14-0304	ea
06-0340	nut, 13/16x28, chrome domed	EA
06-0341	nut, 13/16x28, forkstem adj	EA
06-0344	forkyoke, bottom, pre71 wide	EA
06-0345	nut, forktube top, Commando	EA
06-0345/ER	nut, forktube top, Commando, econo	EA
06-0345/SS	nuts, forktube topStainless	PR
06-0346	rod, fork damper	EA
06-0347	USE 14-0403	ea
06-0348	USE 14-0302	ea
06-0350	slider extension, Roadholder	EA
06-0350/ER	slider ext, Roadholder, replacement	EA
06-0350/SS	slider extensionStainless	EA
06-0351	USE 06-3318	ea
06-0352	forkleg, drum, brake side	EA
06-0354	screw, 1/4x20, fork drain	EA
06-0354/SS	screws, stainlessForkdrain	PR
06-0355	nut, 1/4x20	EA
06-0356	USE 06-3189	ea
06-0357	bolt, 5/16x18UNC	EA
06-0359	USE 14-0113	ea
06-0360	USE 06-1347	ea
06-0361	nut, 9/16x18, axle	EA
06-0362	axle, front, Comm. drum&disc	EA
06-0362/SS	axle, stainless steel	EA
06-0363	lockring, front wheel brg.	EA
06-0364	hub/brakedrum, front, bare*	EA
06-0366	USE 552-116038/92	ea
06-0367	nut, primary cover, chrome	EA
06-0367/SS	nut, pri.cover, stainless	EA
06-0368	washer, flat	EA
06-0368/SS	washer, 1/2 flat, stainless	EA
06-0370	USE 06-2585	ea
06-0374	primary inner cover	EA
06-0375	USE 06-3124	ea
06-0376	stud, 3/8x24, primary centre	EA
06-0377	spacer, stator stud	EA
06-0383	sprocket, engine, triplex, 26T	EA
06-0384	mainshaft, Commando gbx.	EA
06-0384/ER	mainshaft, gbx, econo repl.	EA
06-0386	stud, stator	EA
06-0387	USE 06-4680	ea
06-0388	cap, inspection, primaryCov, lg.	EA
06-0389	USE 06-2582	ea
06-0394	USE 06-5561	ea
06-0395	washer, tab	EA
06-0396	USE 06-1705	ea
06-0397	nut, 3/8x24, lock	EA
06-0398	oring, lg, Commando pri.cov*	EA
06-0399	washer, shim	EA
06-0400	gask, cyl.hd, asbestos, Commando*	EA
06-0401	bolt, 3/8x26, cylinder head*	EA
06-0401/SS	headbolt set, stainless	ST
06-0402	spacer, alternator rotor	EA
06-0403	USE 14-1901	ea
06-0418	USE 06-1410	ea
06-0420	nut, 9/16x20TPI	EA

06-0421	USE 06-1226	ea
06-0422	isolastic mount collar,Fr	EA
06-0423	bolt,1/2x20	EA
06-0424	USE 06-4060	ea
06-0427	isolastic spacer tube,fr.	EA
06-0428	USE 06-1278	ea
06-0430	stud,3/8"	EA
06-0431	USE 06-3212	ea
06-0432	USE 06-1227 *	ea
06-0434	isolastic spacertube,rear	EA
06-0435	USE 06-1280	ea
06-0436	isolastic collar,rear	EA
06-0438	USE 14-1305	ea
06-0441	USE 06-4539	ea
06-0446	dustcover,swingarm,Comm.	EA
06-0447	bush,swingarm,1-1/2" long	EA
06-0448	oring	EA
06-0449	oring,Commando swingarm,L	EA
06-0453	spindle,swingarm pivot,preMK2A	EA
06-0453/005	USE 06-4077	ea
06-0453/010	spindle,swingarm+.010inch,preMk2A	EA
06-0453/ER	spindle,swingarm,econo	EA
06-0456	chainguard,68-70 Fastback &"R"	EA
06-0459	USE 14-0206	ea
06-0463	bolt,3/8x24,shock abs.mt.	EA
06-0465	stud,seat & shock mt,Comm	EA
06-0471	spacer	EA
06-0472	spacer,rear eng. mt. stud	EA
06-0473	USE 06-3117	ea
06-0475	USE 06-3118	ea
06-0481	bolt & lubrication nipple	EA
06-0482	USE 526-252	ea
06-0487	mounting lug,rear footpeg	EA
06-0489	USE 06-5459	ea
06-0490	spacer,top motor mount	EA
06-0493	stud,5/16x24	EA
06-0496	USE 06-2025	ea
06-0498	oring,gastank mt,Commando	EA
06-0499	USE 06-0864	ea
06-0501	USE 511-101	ea
06-0502	USE 06-2039	ea
06-0504	USE 06-4220	ea
06-0506	bracket,rear mudguard mt.	EA
06-0507	mudguard,rear,early Fastback,unpainted	EA
06-0509	manifold,in,28-30mm tapered	EA
06-0510	case,instrument mt, short	EA
06-0511	oiltank,Fastback	EA
06-0544	USE 03-2018	ea
06-0550	nut,acorn,3/8 UNF	EA
06-0552	clevis pin,brake linkage	EA
06-0553	clip,retaining	EA
06-0563	bracket,muffler,Fastback,LH	EA
06-0564	bracket,muffler,Fastback,RH	EA
06-0568	battery strap assy,early	EA
06-0575	USE 623-11	ea
06-0577	stud,5/16UNF	EA
06-0578	USE 06-4748	ea
06-0583	mudguard,fr,chr,w/bridge,pre71 Comm *	EA
06-0583/A	bracket,bridge,fr.mudguard,narrow	EA
06-0583/A/SS	bracket,bridge,fr.mudguard,narrow	EA
06-0583/B	mudguard,fr,chr,pre71Comm,bare*	EA
06-0585	USE 345-1202	ea
06-0588	USE 06-1039	ea
06-0589	USE 06-1116	ea
06-0592	filter screen,oiltank,FB,etc.	EA
06-0592/A	valve,antidrain,w/screen*	EA
06-0595	USE 06-2657	ea
06-0597	stud,1/2X20,gbx.bot.pivot	EA
06-0599	bolt,3/8 UNF*	EA
06-0599/M	bolt,kick crank,metric	EA
06-0616	pedal,rear footpeg*	EA

06-0617	USE 14-0103	ea
06-0618	bolt,3/8x24	EA
06-0619	bracket,front mudguard,narrow	EA
06-0620	USE 721-N62	ea
06-0621	USE 721-N62	ea
06-0622	mount,bonded rubber	EA
06-0622/ER	mount,bonded rubber,econo	EA
06-0624	USE 06-3211	ea
06-0625	USE 14-0305	ea
06-0626	USE 06-3383	ea
06-0627	USE 572-BG5330171	ea
06-0629	spacer,early centrestand	EA
06-0630	USE 21-0588	ea
06-0631	USE 14-0304	ea
06-0634	USE 06-0643	ea
06-0636	mount,bonded rubber	EA
06-0636/ER	mount,bonded rubber,econo	EA
06-0643	spacer,3/16x3/4,tailight	EA
06-0644	plate,backing,Fastback tailite	EA
06-0646	numberplate,rear,Fastback,pre72	EA
06-0647	USE 06-4009	ea
06-0648	washer,rubber,mounting	EA
06-0650	bolt,5/16x24,chain adjust	EA
06-0650/SS	adj.set,r.axle,stainless	ST
06-0651	USE 14-0402	ea
06-0652	USE 14-0105	ea
06-0659	cap,inspection,rotor,sm.	EA
06-0662	USE 06-0763	ea
06-0663	screw,hammerdrive	EA
06-0664	washer,rotor shim,.036	EA
06-0665	washer,rotor shim,.010	EA
06-0668	plug,oiltank drain,3/8x24	EA
06-0670	spigot,balance hose,in.manifold	EA
06-0671	USE 06-2537	ea
06-0673	airfilter element,paper	EA
06-0673/A	airfilt.element,K&N gauze	EA
06-0673/B	airfilter assy,K&N,thick*	EA
06-0673/C	airfilter assy,K&N,thin	EA
06-0673/D	airfilter element,UNIfoam	EA
06-0676	USE 06-1228	ea
06-0677	bolt,10-32	EA
06-0678	USE 82-4717	ea
06-0681	cap,gas,flip up NortonBSA, repl.*	EA
06-0681/A	cap,gas,flip up locking*	EA
06-0681/B	gasket,flipup gascap	EA
06-0684	isolastic end cap,front	EA
06-0685	isolastic end cap,rear	EA
06-0686	isolastic shim,.005 front	EA
06-0687	isolastic shim,.010 front	EA
06-0688	isolastic shim,.020 front	EA
06-0689	isolastic shim,.030 front	EA
06-0693	bracket,tailite sw.wire	EA
06-0695	pin,dowel,split,seat knob	EA
06-0699	bolt,1/4x28UNF	EA
06-0700	nut,5/16UNF smallOD,stator	EA
06-0701	bush & stay,R.brake plate	EA
06-0704	spring,rear brake arm	EA
06-0710	USE 572-BG150806	ea
06-0711	gasket,inner pri,pre75Com	EA
06-0715	arm,clutch release,Comm.	EA
06-0719	USE 06-1092	ea
06-0720	bolt,1/4x26,advance unit*	EA
06-0721	sprocket,gbx,21 tooth	EA
06-0727	USE 14-0219	ea
06-0729	handlebar,US,pre71 Commando	EA
06-0740	cover,gearbox,outer	EA
06-0742	USE 06-2482	ea
06-0743	USE 06-3979	ea
06-0744	USE 06-1166 & 2)06-1167	ea
06-0745/A	pressure plate,4 plate cl,alloy*	EA
06-0746	clutch plate,plain,Comm.	EA

06-0747	washer,cupped,clutch loc.	EA
06-0749	USE 06-1339	ea
06-0750	bearing,ball	EA
06-0750/A	bearing,ball,sealed	EA
06-0751	circlip,clutch diaphragm	EA
06-0752	circlip,clutch location	EA
06-0753	circlip,clutch brg,inner	EA
06-0754	circlip,clutch brg,outer	EA
06-0756	USE 06-1167	ea
06-0759	sprocket,gbx,22 tooth	EA
06-0760	washer,sealing,early fork	EA
06-0762	washer,bot.cov,early fork	EA
06-0763	plate,timing mark	EA
06-0765	lug,sidestand,pre71 Comm.	EA
06-0766	sidestand,pre 71 Commando*	EA
06-0768	USE 82-2610	ea
06-0769	plate,inner primary cover	EA
06-0770	spring,diaphragm,Comm. cl.	EA
06-0771	isolastic spacer	EA
06-0772	isolastic spacer	EA
06-0773	USE 06-3718	ea
06-0774	USE 06-3719	ea
06-0775	isolastic shim,.005 rear	EA
06-0776	isolastic shim,.010 rear	EA
06-0777	isolastic shim,.020 rear	EA
06-0778	isolastic shim,.030 rear	EA
06-0779	stud,5/16x24	EA
06-0780	roller,rearbrake	EA
06-0781	collar,rear brake linkage	EA
06-0784	handlebar,UK,pre71 Commando	EA
06-0785	USE 341-3859	ea
06-0787	screw,selftapping	EA
06-0789	plate,fr.brake blanking,inlet	EA
06-0790	USE 551-996 (set)	ea
06-0796	yoke,rear brake linkage	EA
06-0797	USE 14-1902	ea
06-0806	trunnion,rear brake	EA
06-0806/SS	trunnion,rear brake,stainless	EA
06-0808	USE 06-5207	ea
06-0811	grommet,oiltank bottom mt	EA
06-0812	USE 551-999 (set)	ea
06-0815	USE 06-1694	ea
06-0816	perforated plate,airfilt.	EA
06-0816/SS	perforated plate,airfilt,stainless	EA
06-0828	USE 06-3417	ea
06-0845	plate,fr.brake blanking,outlet	EA
06-0847	rotolock fastener	EA
06-0848	rotolock,sidecover	EA
06-0854	USE 06-1119	ea
06-0856	grommet,sidepanel mount	EA
06-0858	USE 14-0235	ea
06-0863	bolt,3/8x24UNF	EA
06-0864	badge,tank/tailsection,Fastback	EA
06-0865	USE 14-0102	ea
06-0868	endcap,swingarm,RH	EA
06-0869	end cap,swingarm,LH	EA
06-0871	washer,copper	EA
06-0873	rod,threaded	EA
06-0881	oiler outlet,rear chain	EA
06-0882	pin,split,gas cap pivot*	EA
06-0886	clamp,chainoil restrictor	EA
06-0887	felt,chainoiler regulator	EA
06-0890	bracket,reflector	EA
06-0894	washer,clutch shim,.036	EA
06-0895	washer,clutch shim,.048"	EA
06-0900	USE 14-0211	ea
06-0902	plate,airfilter,front	EA
06-0902/A	plate,airfilter,fr,singlecarb	EA
06-0902/A/SS	plate,a/c,fr,singlecarb,stainless	EA
06-0902/CHR	plate,airfilter front,chrome	EA
06-0902/SS	plate,airfilter,fr,stainless	EA

06-0903	grommet,alternator	EA
06-0908	USE 526-96	ea
06-0909	bolt,10-32	EA
06-0910	USE 433-07/B	ea
06-0911	USE 432-269/D	ea
06-0915	USE 83-0033	ea
06-0918	USE 526-602	ea
06-0919	USE 526-812 *	ea
06-0920	clamp,hose,crimp type	EA
06-0921	clamp,hose,crimp type	EA
06-0923	USE 526-91	ea
06-0924	USE 526-601	ea
06-0926	washer,tab,airfilterPlate	EA
06-0927	clip,hose	EA
06-0929	USE 06-1499	ea
06-0930	USE 526-811	ea
06-0931	sprocket,gearbox,20 tooth	EA
06-0934	USE 222-190	ea
06-0941	USE 222-170	ea
06-0943	USE 14-0116	ea
06-0944	bracket,peg mount,alloy,LH	EA
06-0945	USE 06-1228	ea
06-0946	screw,10-32	EA
06-0949	USE 222-060949	ea
06-0955	pin,piston,750	EA
06-0988	USE 06-4048	ea
06-0999	USE 222-168	ea
06-1005	brakeplate,DLS,complete	EA
06-1017	decal,750 COMMANDO,gld&bl	EA
06-1025	USE 06-2585	ea
06-1026	USE 06-2585	ea
06-1028	USE 222-189	ea
06-1039	spring,centrestand,pre 71	EA
06-1040	decal,gastank,NORT,blkW/gold trim	EA
06-1044	decal,750,Fastback tail	EA
06-1046	bars,Commando US	EA
06-1046/ER	bars,Commando US,econo repl.	EA
06-1052	USE 06-3118 & 06-2734	ea
06-1053	USE 06-3117 & 06-2734	ea
06-1054	pedal,rear brake,pre75Com	EA
06-1055	arm,kickstarter crank*	EA
06-1057	USE 06-5954	ea
06-1058	gear,4th lay,18T,late type	EA
06-1058/ER	gear,4th lay,late,econo.	EA
06-1059	USE 06-1464	ea
06-1073	timing cover,engine*	EA
06-1076	USE 526-603	ea
06-1077	gear/sprocket,idler	EA
06-1078	shaft,intermediate gear	EA
06-1079	bush,intermediate gear	EA
06-1080	sprocket,camshaft,18T,late	EA
06-1084	camshaft,70 on Commando *	EA
06-1084/ER	cam,70on Comm,econo repl.	EA
06-1086	washer,thrust,camshaft	EA
06-1087	cover,points	EA
06-1087/A	cover,points,finned &pol.	EA
06-1089	tachdrive gear,Commando,early RH points	EA
06-1090	USE 06-5200	ea
06-1092	gasket,timing cover	EA
06-1093	sleeve,rubber,points wire	EA
06-1094	USE 06-4647	ea
06-1102	USE 06-2685	ea
06-1103	USE 06-2687	ea
06-1104	USE 06-2686	ea
06-1105	screw,2BA,points cover,Norton	EA
06-1106	screw,1/4x20	EA
06-1106/SS	screws,tachdrive,stainless	ST
06-1114	USE 06-3423	ea
06-1115	fork boot,Commando	EA
06-1115/ER	fork boots,Commando	PR
06-1116	centrestand,Commando,pre71	EA

06-1118	USE 571-30/C	ea
06-1119	sidepanel,LH Fastback&"R",pre71	EA
06-1121	clip,rear mudguard	EA
06-1122	housing,tailight,750 type	EA
06-1122/ER	housing,tailight,750 type,repl*	EA
06-1128	bracket,side,top mtr.mt.	EA
06-1131	forkyoke,top,68-70 Commando.	EA
06-1133	USE 06-0344	ea
06-1136	stud,stepped,forkyoke	EA
06-1137	collar,lower fork leg	EA
06-1157	bolt,1/2x20,oiltank banjo	EA
06-1159	filter screen,oiltank	EA
06-1166	plate,backing,cl.drum	EA
06-1167	pin,split dowel,clutch	EA
06-1168	USE 511-102	ea
06-1173	USE 06-3887	ea
06-1175	USE 06-1119	ea
06-1179	screw,1/2x20,clutch adj,Commando	EA
06-1179/A	clutch adj,Commando,needle brg. style	EA
06-1180	ring,oil,std,shallow 750	EA
06-1198	USE 06-1513	ea
06-1202	USE 06-1513	ea
06-1204	bracket,top,side panel	EA
06-1206	grommet,fiberglass covers	EA
06-1207	decal,COMMANDO 750 S	EA
06-1209	USE 06-1514	ea
06-1213	USE 06-1514	ea
06-1226	isolastic bush,front	EA
06-1227	isolastic bush, rear	EA
06-1228	bracket,peg mount,alloy,RH	EA
06-1229	USE 222-183	ea
06-1234	spacer,headlight	EA
06-1238	bracket,hdlt mt,LH,S type*	EA
06-1238/1239/45	bracket set,headlight,halo type	ST
06-1239	ring,hdlt.surround,S type*	EA
06-1245	bracket,hdlt.mt,RH,S type*	EA
06-1246	bolt,5/16x18	EA
06-1247	nut,5/16UNC,lock,thin	EA
06-1272	chainguard,69-70"S"& Roadster	EA
06-1277	USE 06-3960	ea
06-1278	isolastic buffer,front	EA
06-1279	USE 06-3928 & 2) 063927	ea
06-1280	isolastic buffer,rear	EA
06-1281	pillarbolt,pointplate,Nor	EA
06-1282	oring,tach drive,pre 1974	EA
06-1282/A	oilseal,tachdrive leakFix*	EA
06-1284	USE 221-64947081	ea
06-1286	plate,frame ident,750	EA
06-1287	rivet,frame ID plate	EA
06-1295	spring,centrestand locating	EA
06-1304	bracket,muffler,S model	EA
06-1307	bracket,muffler,S model	EA
06-1314	heatshield,Commando S exh,F	EA
06-1314/1315	heatshields,Commando S exhaust	ST
06-1315	heatshield,Commando S exh,R	EA
06-1328	muffler clamp assy,1-1/2"	EA
06-1339	clutch plate,friction,Nor,fibre*	EA
06-1339/A	clutch kit,Barnett,4plate *	ST
06-1339/ER	clutch kit,4plate,econo.repl.	ST
06-1341	circlip,dzus fastener	EA
06-1342	USE 06-2489	ea
06-1344	bolt,1/4x28	EA
06-1347	cap,damper tube,28TPI	EA
06-1352	USE 06-0352	ea
06-1361	spacer,airfilter	EA
06-1389	rubber cover,ign.sw	EA
06-1391	USE 06-4048 *	ea
06-1399	cup,valvespring,lower,850only	EA
06-1402	USE 06-3887	ea
06-1410	isolastic housing,fr,pre75 *	EA
06-1411	USE 06-4060	ea

06-1440	fueline assy,complete,early	EA
06-1441	USE 06-3247	ea
06-1451	USE 526-331	ea
06-1464	kickstart crank assy,Commando*	EA
06-1464/ER	kickstart crank assy,econo*	EA
06-1481	USE 04-0026	ea
06-1482	USE 04-0115	ea
06-1484	USE 06-5459/A	ea
06-1499	lever,gearshift,pre 1975,gen,compl.	EA
06-1499/ER	lever,gearshift,pre 1975,repl.	EA
06-1513	sidepanel,LH,S&70Roadster	EA
06-1514	sidepanel,RH,S&70Roadster	EA
06-1556	USE 06-0673	ea
06-1577	USE 06-0364*	ea
06-1628	USE 391-54483155	ea
06-1649	USE 06-5509	ea
06-1650	spacer,oiltank lower mt.	EA
06-1659	rubber strip,bat.crossbar	EA
06-1661	strap,battery holdown,Interpol	EA
06-1662	strap,battery holdown	EA
06-1667	crossbar,battery,1971-74	EA
06-1669	chainoiler regulator assy	EA
06-1675	sidepanel,RH Fastback,71on	EA
06-1676	spring,Dzus fastener	EA
06-1677	clip,oilhose	EA
06-1686	rubber buffer,R.sidepanel	EA
06-1687	USE 06-3503	ea
06-1693	USE 06-3504	ea
06-1694	plate,airfilter rear	EA
06-1694/SS	plate,airfilter rear,stainless*	EA
06-1699	decals,ROADSTER	EA
06-1702	USE 14-1204	ea
06-1705	cylinder barrel,750 Nort.* /	EA
06-1705/A	cyl.barrel,alloy,750 *	EA
06-1705/B	cyl.barrel,750,heavy duty*	EA
06-1705/U	cylinder barrel,750,used	EA
06-1720	bracket,muffler	EA
06-1720/21/22/SS	bracket set,,muffler,Commando,stainless	ST
06-1721	bracket,muffler,Commando	EA
06-1722	bracket,muffler	EA
06-1766	USE 511-102	ea
06-1785	USE 06-2227	ea
06-1798	USE 14-0104	ea
06-1830	USE 522-01 (set)	ea
06-1856	USE 06-3456	ea
06-1865	chainguard,chrome,Commando,1971-73	EA
06-1865/ER	chainguard,Commando,71-73,econo	EA
06-1865/SS	chainguard,Commando,71-73,stainless	EA
06-1876	hose,crankcase breather	EA
06-1879	USE 522-01 (set)	ea
06-1885	rotor,disc brake	EA
06-1885/A	rotor,discbrake,drilled	EA
06-1885/CHR	rotor,disc brake,hardchromed *	EA
06-1885/ER	rotor,disc brake,econo*	EA
06-1888	dampner tube,forks	EA
06-1894	USE 06-6005	ea
06-1896	piston,caliper	EA
06-1896/SS	piston,caliper,stainless	EA
06-1898	piston,master cylinder	EA
06-1900	USE 691-622101	ea
06-1906	USE 99-2755	ea
06-1911	bolt,3/8x24UNF,allen head	EA
06-1911/SS	bolts,3/8x24aln,stainless	PR
06-1912	washer,7/8,flat,strg.stem	EA
06-1912/SS	washer,7/8 flat,stainless	EA
06-1915	fork yoke,top,750 type,71on	EA
06-1916	fork yoke,bottom,750 type	EA
06-1920	cap,master cyl,aluminium	EA
06-1926	caliper assy,fr.&rear brk	EA
06-1929	nipple,bleed,caliper	EA
06-1930	USE 06-4243 (kit)	ea

06-1934	USE 391-34619	ea
06-1938	USE 06-4871	ea
06-1939	USE 06-3667	EA
06-1941	rubber boot, master cyl.*	EA
06-1942	USE 99-2757	ea
06-1943	USE 99-2758	ea
06-1944	USE 99-2754	ea
06-1945	USE 99-2760	ea
06-1946	USE 60-4366	ea
06-1947	circlip, master cylinder	EA
06-1950	wheel assy, WM2x19, disc, F	EA
06-1951	rim, WM2x19, Nor. disc front	EA
06-1951/A	rim, WM2x19 alloy w/shoulder	EA
06-1951/B	rim, WM3x18 alloy w/shoulder	EA
06-1951/SS	rim, WM2x19, Norton disc, F, stainless	EA
06-1955	spacer, fr. hub, disc	EA
06-1960	stud, 5/16x24	EA
06-1972	USE 99-2756	ea
06-1978	USE 711-Z601/A	ea
06-1982	USE 06-2025	ea
06-1984	USE 06-3763	ea
06-1987	screw, selftapping, phillip	EA
06-1999	spacer, centrestand	EA
06-2001	USE 06-5490	ea
06-2002	USE 06-5632	ea
06-2006	footpeg assembly, rear, w/rubber*	EA
06-2006/ER	footpeg assys, rear, econo. repl*	PR
06-2007	USE 391-575189	ea
06-2008	USE 391-57183	ea
06-2015	pawl, kickstart	EA
06-2019	decal, COMM. 750, gold/black	EA
06-2019/A	decal, COMM. 750, gold vinyl	EA
06-2020	decal, COMMANDO 750, black	EA
06-2020/A	decal, COMM. 750, blk. vinyl	EA
06-2021	USE 06-4880	ea
06-2022	USE 06-4881	ea
06-2025	tank, gas, Fastback type	EA
06-2026	USE 06-2701	ea
06-2027	USE 523-18838/839 (assy)	ea
06-2028	bracket, headlight, R. hand	EA
06-2028/2029/ER	brackets, hdlght, repl	ST
06-2028/2029/SS	brackets, hdlght, stainless	ST
06-2029	bracket, headlight, L. hand	EA
06-2032	USE 523-71	ea
06-2035	USE 06-6547	ea
06-2037	numberplate, rear, Fastback, 1972	EA
06-2037/SS	numberplate, rear, stainless	EA
06-2038	bracket, tailamp, 750 type	EA
06-2039	tail section, fastback	EA
06-2040	USE 21-0588	ea
06-2041	USE 391-56605 turn signal	ea
06-2043	USE 391-39595	ea
06-2044	USE 391-39596	ea
06-2045	USE 391-35048	ea
06-2046	USE 391-54385091	ea
06-2054	USE 391-38706	ea
06-2055	USE 06-3909	ea
06-2058	USE 391-30552	ea
06-2059	USE 391-60600443	ea
06-2060	USE 391-56605	ea
06-2061	USE 06-4891 & 06-4892	ea
06-2063	hub, 71-74 Commando, rear	EA
06-2066	USE 06-2764	ea
06-2067	axle, dummy	EA
06-2069	spacer, R wheel inner, late	EA
06-2070	USE 06-5290	ea
06-2071	washer, flat, felt retainer	EA
06-2072	washer, flat, felt retainer	EA
06-2073	USE 06-2889	ea
06-2074	buffer, cush hub, large	EA
06-2075	buffer, cush hub, small	EA

06-2082	cover, rear hub, blank	EA
06-2082/SS	cover, rear hub, blank, stainless	EA
06-2084	hose, oil	EA
06-2085	hose, oil	EA
06-2086	USE 391-51271406	ea
06-2090	circlip, wheel bearing	EA
06-2092	USE 391-45275	ea
06-2098	USE 391-47225	ea
06-2099	plug & socket	ST
06-2140	USE 06-5632	ea
06-2168	USE 06-5561	ea
06-2169	bracket, rear mudguard	EA
06-2170	spacer, airfilter plate	EA
06-2171	mudguard, rear, lateFastback, chrome*	EA
06-2172	mudguard, rear, chrome *	EA
06-2179	USE 543-6135 (pair)	ea
06-2184	USE 21-2157	ea
06-2185	plug, caliper body	EA
06-2185/SS	plug, caliper, stainless	EA
06-2187	seal, caliper plug	EA
06-2192	USE 06-4031 *	ea
06-2193	USE 523-100/RH	ea
06-2200	hose, oil, 3/8" braided herringbone	EA
06-2201	hose, oil, 3/8" ID braided herringbone	EA
06-2206	junction block, oil line	EA
06-2207	banjo, oil tank	EA
06-2227	sidepanel, LH Fastback, 71on	EA
06-2231	USE 06-2577 ?	ea
06-2235	USE 21-2048*	ea
06-2237	USE 523-18838/839 (assy)	ea
06-2240	USE 14-1201	ea
06-2241	screw, 3/16x24, master cyl.	EA
06-2249	USE 06-2702	ea
06-2250	USE 06-2553	ea
06-2263	USE 345-1202	ea
06-2266	USE 06-0902	ea
06-2277	USE 572-SSM300109	ea
06-2279	USE 572-RSM300315	ea
06-2283	hose, oil	EA
06-2284	hose, balance	EA
06-2290	USE 543-64546048	ea
06-2300	spacer, 5-3/4" headlight	EA
06-2305	rubber plug, fork yoke	EA
06-2306	bars, Interpol	EA
06-2321	bolt, 7/16 UNF, chrome	EA
06-2323	bracket, front mudguard, wide	EA
06-2323/ER	bracket, front mudguard, repl.	EA
06-2323/SS	bracket, F.mdgrd, stainless	EA
06-2328	mudguard, fr, chrome, 71onComm *	EA
06-2332	rubber plug, bot. fork yoke	EA
06-2334	USE 623-24	ea
06-2348	USE 336-N7YC	ea
06-2363	mudguard, fr, chrome, 71Commando SS*	EA
06-2367	USE 06-3239	ea
06-2374	grabrail, Hirider	EA
06-2379	clip, grabrail, Hirider	EA
06-2383	bracket, muffler, SS R.hand	EA
06-2384	bracket, muffler, SS, L.hand	EA
06-2386	heatshield, SS model, LH	EA
06-2389	heatshield, SS model, RH	EA
06-2390	USE 511-106 *	ea
06-2392	spacer, SS model exhaust	EA
06-2405	USE 06-2599	ea
06-2406	USE 526-96/6 *	ea
06-2409	USE 60-2350/CHR	ea
06-2412	washer, tab, finned x nut	EA
06-2442	stud, 1/2x20, isolastic, R.	EA
06-2443	USE 14-1305	ea
06-2447	gasket, oilpump	EA
06-2448	spacer, front wheel, RH	EA
06-2464	nut, finned exhaust, 750 style*	EA

06-2465	USE 14-6217	ea
06-2471	rocker arm,RH intake	EA
06-2472	rocker arm,RH exhaust	EA
06-2473	rocker arm,LH inlet*	EA
06-2474	rocker arm,LH exhaust	EA
06-2482	clutch drum,Commando	EA
06-2485	rivet,clutch drum	EA
06-2488	USE 391-54115246	ea
06-2489	dzus fastener,sidepanel	EA
06-2491	USE 526-603	ea
06-2492	USE 526-812	ea
06-2496	hose,chainoil restrictor	EA
06-2503	USE 526-603/10	ea
06-2514	USE 06-4643	ea
06-2515	spring,sidestand,1971	EA
06-2524	rubber cover,fr.brake sw.	EA
06-2525	spoke,19 inch drum	EA
06-2526	spoke,19 inch drum	EA
06-2527	USE 06-2525	ea
06-2528	USE 06-3318	ea
06-2535	USE 523-100/LH *	ea
06-2536	bolt,5/16x18 allen head	EA
06-2537	hose,airfilter,pre75 Comm	EA
06-2537/ER	hose,airfilter,pre75 Comm,econo	EA
06-2538	spoke,19" front disc	EA
06-2539	spoke,19" front disc	EA
06-2540	spoke,19" front disc	EA
06-2544	USE 06-2524	ea
06-2548	gasket,blanking plate	EA
06-2553	lever,RH console,alloy*	EA
06-2553/2702	levers,alloy,clutch/brake	PR
06-2557	battery tray,71-74 Commando	EA
06-2567	rubber pad,gas tank	EA
06-2571	USE 06-0811	ea
06-2577	bracket,ign.coils,Commando,71on	EA
06-2580	oring,pri.insp.cap,small	EA
06-2581	oring,pri.insp.cap,large	EA
06-2582	screw,3/8x24,level plug	EA
06-2583	oring	EA
06-2585	primary cover,pre75 Comm.	EA
06-2592	spring,sidestand	EA
06-2593	mounting kit,sidestand	ST
06-2594	grommet,Fastback	EA
06-2595	nipple,spoke,8g.x.300	EA
06-2599	bars,Hirider,hirise	EA
06-2600	bush,cam,1972 on 750,L&RH,scrolled	EA
06-2601	washer,thrust,camshaft bush*	EA
06-2602	rubber pad,battery box	EA
06-2608	USE 06-1084	ea
06-2609	key,oilpump drive gear	EA
06-2614	adaptor,breather outlet,72	EA
06-2615	foam,crankcase breather	EA
06-2617	adaptor,oilhose	EA
06-2618	gasket,breather,72 on 750	EA
06-2619	hose,oil	EA
06-2620	breather housing,72	EA
06-2621	pin,dowel	EA
06-2624	washer,sealing	EA
06-2639	stud,3/8x16x24,cyl. base	EA
06-2640	stud,stepped,cyl.base	EA
06-2641	stud,3/8,cylinder base	EA
06-2650	nut,5/16x24	EA
06-2651	nut,3/8x24UNF*	EA
06-2652	nut,3/8x24UNF,deep	EA
06-2653	bolt,9/16x18,gbx.top mt.	EA
06-2654	adjuster eyebolt,gearbox	EA
06-2656	nut,9/16x18,gbx.bolt,top	EA
06-2657	eyebolt,gbx.adjuster	EA
06-2661	stud,3/8x16x24,crankcase	EA
06-2662	stud,1/4x20x28,crankcase	EA
06-2663	bolt,5/16x24	EA

06-2664	stud,5/16x18x24	EA
06-2665	stud,5/16x18x24	EA
06-2666	plug & socket	ST
06-2669	USE 14-6102	ea
06-2670	USE 06-1106	ea
06-2673	USE 06-3536	ea
06-2674	USE 06-1705	ea
06-2676	hose,oil,5/16"	EA
06-2685	screw,1/4x20UNC	EA
06-2686	screw,1/4x20UNC	EA
06-2687	screw,1/4x20UNC	EA
06-2692	nut,5/16x24UNF	EA
06-2700	USE 06-3458	ea
06-2701/092	tank,gas,Roadster	EA
06-2702	lever,LH console,alloy*	EA
06-2706	bracket,fr.brake line	EA
06-2707	brakehose,top,25 inch	EA
06-2707/A	USE 06-3508/A	ea
06-2708	USE 06-3899	ea
06-2711	manifold,in,32mm	EA
06-2722	screw,philips,countersunk,self tapping	EA
06-2723	USE 60-2333	ea
06-2725	USE 452-543	ea
06-2726	oilseal,inlet valve	EA
06-2734	footpeg,fr,Commando pre75	EA
06-2734/A	footpegs,front,folding	PR
06-2760	USE 452-543/002	ea
06-2761	USE 14-0218	ea
06-2763	USE 14-6115	ea
06-2764	sprocket & brakedrum assy,42T	EA
06-2764/ER	sprocket & brakedrum assy,42T,econo	EA
06-2767	USE 452-543/005	ea
06-2768	USE 452-543/010	ea
06-2769	USE 452-543/015	ea
06-2799	USE 06-1694	ea
06-2807	USE 06-3536	ea
06-2813	USE 526-812	ea
06-2814	USE 526-812/10	ea
06-2819	manifold,in,30mm	EA
06-2828	USE 60-4258	ea
06-2839	USE 06-4643	ea
06-2867	hub assy,disc,front,pre75	EA
06-2871	spacer,5/8x7/16x11/16*	EA
06-2872	USE 06-5436	ea
06-2889	washer,felt,wheel bearing	EA
06-2930	decal,tank,NORTON,black mylar*	EA
06-2931	USE 06-4880	ea
06-3012	washer,dished	EA
06-3020	bush,cam,850 RH,1973 & 74	EA
06-3021	USE 06-5425	ea
06-3024	USE 14-1203	ea
06-3031	clip,brake hose mounting	EA
06-3037	USE 06-6193	ea
06-3051	USE 06-4031	ea
06-3052	USE 06-4874	ea
06-3055	USE 06-1694	ea
06-3056	gasket,tachdrive housing	EA
06-3062	USE 523-71	EA
06-3085	bolt,3/8x16,allen,850 cyl	EA
06-3087	USE 06-5490	ea
06-3089	USE 14-1204	ea
06-3090	USE 06-3456	ea
06-3092	plate,tappet retaining*	EA
06-3105	spacer,1/2x5/8x11/16,sidestand*	EA
06-3106	crankshaft assy,750 Commando	EA
06-3114	USE 06-4118	ea
06-3117	footrest assy,RH pre 75*	EA
06-3118	footrest assy,LH pre 1975*	EA
06-3121	strap,gas tank,Roadster	EA
06-3123	USE 14-1902	ea
06-3124	bolt,1/4x20BSW	EA

06-3124/SS	bolts,rkr.plate,stainless	ST
06-3129	washer,copper	EA
06-3131	bracket,muffler,Inter*	EA
06-3132	bracket,muffler,LH Inter.	EA
06-3139	mounting head,oilfilter	EA
06-3141	USE 60-2323	ea
06-3142	USE 06-5006	ea
06-3143	grommet,steel sidepanels&horn	EA
06-3144	hose,oil,3/8" braided herringbone	EA
06-3146	USE 06-4060	ea
06-3173	USE 06-5364	ea
06-3175	USE 06-6204 *	ea
06-3176	USE 06-3505	ea
06-3177	USE 06-4136	EA
06-3179	USE 06-4882	ea
06-3184	decal,COMMANDO 750,silver	EA
06-3184/A	decal,750 COMM,silv.vinyl	EA
06-3188	USE 06-3887	ea
06-3189	stud,1/4x20	EA
06-3192	nut,cyl.head,bottom front	EA
06-3192/SS	nut,cyl.head,stainless	EA
06-3204	rubber pad,gas tank	EA
06-3207	USE 37-7034	ea
06-3211	bolt,5/16x24UNF	EA
06-3212	bolt,3/8x24UNF	EA
06-3213	bolt,3/8x24*	EA
06-3215	stud,5/16x24	EA
06-3227	hose,breather,battery,1/8"	EA
06-3239	bracket,gas tank mt,Inter&Hirider	EA
06-3241	lever,disc brake,pre 1975	EA
06-3244	USE 335-02	ea
06-3245	USE 06-0029	ea
06-3246	USE 06-7892	ea
06-3247	plate,frame identif.	EA
06-3248	clamp,hose	EA
06-3253	USE 06-3995	ea
06-3272	cam,brake performance kit	EA
06-3273	pin,pivot,brake perf.kit,short	EA
06-3274	pin,pivot,brake perf.kit,long	EA
06-3275	plate,brake performance kit	EA
06-3282	USE 453-264	ea
06-3283	USE 453-263	ea
06-3300	USE 335-05	ea
06-3316	fork leg,caliper side	EA
06-3318	fork leg,pinch side,all	EA
06-3324	rubber buffer,sidestand	EA
06-3327	USE 06-4048	ea
06-3338	USE 441-19145 (set)	ea
06-3339	USE 441-19145 (set)	ea
06-3342	USE 441-19145/020 (set)	ea
06-3343	USE 441-19145/020 (set)	ea
06-3344	USE 441-19145/030 (pair)	ea
06-3345	USE 441-19145/030 (pair)	ea
06-3346	USE 441-19145/040 (pair)	ea
06-3347	USE 441-19145/040 (pair)	ea
06-3348	USE 441-19145 (set)	ea
06-3349	USE 441-19145 (set)	ea
06-3352	USE 441-19145/020 (set)	ea
06-3353	USE 441-19145/020 (set)	ea
06-3354	USE 441-19145/030 (pair)	ea
06-3355	USE 441-19145/030 (pair)	ea
06-3356	USE 441-19145/040 (pair)	ea
06-3357	USE 441-19145/040 (pair)	ea
06-3367	spring,protective	EA
06-3368	retainer,oilfilterElement	EA
06-3369	hoseclamp,oilfilter retaining	EA
06-3371	oilfilter element,Norton,CROSSLAND	EA
06-3371/CHR	oilfilter element,chrome,reprl.	EA
06-3371/ER	oilfilter element,econo repl	EA
06-3372	USE 391-54343791	ea
06-3373	USE 391-54343791	ea

06-3374	USE 391-54343791	ea
06-3383	stud,5/16UNF/UNC	EA
06-3389	USE 06-5490	ea
06-3394	USE 06-5364	ea
06-3410	kit,drumbrake performance	ST
06-3411	nipple,lubrication,Zerk,1/4x26	EA
06-3417	brakeshoe set,Norton rear	ST
06-3417/ER	brakeshoe set,Norton rear,econo	ST
06-3418	washer,tab	EA
06-3420	sprocket,gearbox,23 tooth	EA
06-3421	sprocket,gearbox,24 tooth	EA
06-3423	forktube,Commando,std,23-3/8"*	EA
06-3423/2	forktubes,Commando +2inch	PR
06-3423/4	forktubes,Commando +4inch	PR
06-3423/6	forktubes,Commando +6inch	PR
06-3423/8	forktubes,Commando +8inch	PR
06-3423/ER	forktubes,Commando,std,econo*	PR
06-3447	washer,5/8,flat	EA
06-3448	USE 06-7542	ea
06-3456	oiltank,Commando,1971on	EA
06-3458	gasket,heat insul,in.man.	EA
06-3459	washer,tab,clutch centre	EA
06-3503	sidepanel,Roadster,LH,1971-74,steel	EA
06-3503/ER	sidepanel,Roadster,LH,1971-74,econo	EA
06-3504	sidepanel,RH 71on,exeptInter*	EA
06-3505	sidepanel,LH Interstate,fibreglas*	EA
06-3506	USE 06-4136	ea
06-3507	brakehose,front,28 inch	EA
06-3508	brakehose,front,23 inch	EA
06-3508/A	brakehose kit,stainless steel*	EA
06-3527	USE 452-544	ea
06-3529	USE 452-544/010	ea
06-3530	USE 452-544/015	ea
06-3536	camshaft,Combat 2S*	EA
06-3536/ER	cam,Combat 2S,econo repl.	EA
06-3537	USE 06-3536	ea
06-3540	brakehose,34 inch	EA
06-3541	brakehose,31 inch	EA
06-3544	washer,3/8",sealing	EA
06-3555	nut,finned xpipe,850 type,long*	EA
06-3556	USE 06-4748	ea
06-3579	bracket,muffler,RH Inter.	EA
06-3598	USE 14-1305	ea
06-3608	USE 433-07/B	ea
06-3609	oilseal,points	EA
06-3632	grabrail,Interstate only	EA
06-3641	USE 06-3798	ea
06-3667	mastercyl.body,bare,preMk3	EA
06-3668	rubber plug,mirror hole	EA
06-3676	USE 511-107	ea
06-3677	USE 511-108	ea
06-3678	bracket,control lever,cl,black	EA
06-3718	isolastic gaiter,front	EA
06-3719	isolastic gaiter,rear	EA
06-3724	bracket,tailight,850 type	EA
06-3727	bracket,tailamp to mudgrd	EA
06-3731	housing,tailamp,850 type	EA
06-3731/ER	housing,tailamp,850 type,repl.	EA
06-3733	beading,tailamp,850 type	EA
06-3741	clutch plate,sintered*	EA
06-3741/A	clutch kit,Barnett,5plate*	ST
06-3741/ER	clutch plate,econo.repl.	EA
06-3756	decal,BREAK IN RECOMMEND.	EA
06-3763	mute,muffler	EA
06-3768	pressure plate,5 plate cl	EA
06-3768/A	pressure plate,5 plate cl,alloy	EA
06-3786	USE 06-4045 (set)	ea
06-3787	USE 06-4045 (set)	ea
06-3798	clip,grabrail mounting	EA
06-3798/SS	clip,grabrail mounting,stainless	EA
06-3811	gasket,cyl.hd,850,copper	EA

06-3812	gasket,cylinder base,850	EA
06-3813	USE 06-0902	ea
06-3819	USE 06-4978	ea
06-3823	USE 06-5074	ea
06-3824	stud,stepped,cyl.base,850	EA
06-3825	USE 21-2177	ea
06-3830	cylinder head,850,all	EA
06-3838	USE 441-19342 (set)	ea
06-3842	pin,piston,850	EA
06-3844	gasket,cyl.hd,750eyletted,genuine	EA
06-3844/ER	gasket,cyl.hd,750eyletted,econo	EA
06-3857	washer,5/16,flat	EA
06-3859	USE 511-106	ea
06-3887	mudguard,rear,stainless *	EA
06-3899	brakeline,to caliper	EA
06-3899/SS	brakeline to caliper,stainless	EA
06-3905	decal,GAS RECOMMENDATIONS	EA
06-3909	spring,assimilator mount	EA
06-3918	washer,wheel brg.dust cov	EA
06-3919	spacer,wheel,front disc	EA
06-3921	nut,3/16x32,long	EA
06-3922	spoke,19" front disc	EA
06-3923	spoke,19" front disc	EA
06-3924	spoke,19" front disc	EA
06-3925	spoke,19" front disc	EA
06-3926	bolt,internally threaded	EA
06-3927	circlip,isolastic spacers	EA
06-3928	isolastic spacertube,rear	EA
06-3960	isolastic spacer tube,fr.	EA
06-3961	rubber pad,battery tray	EA
06-3962	USE 06-2602	ea
06-3963	sprocket,gbx,25T	EA
06-3964	USE 221-175	ea
06-3968	USE 222-183	ea
06-3977	decal,OIL RECOMMENDATIONS	EA
06-3979	clutch centre,750 and 850	EA
06-3979/ER	clutch centre,economy rep	EA
06-3988	nut,finned xpipe,850 type,short*	EA
06-3988/A	nut,finned xpipe,short,oversize*	EA
06-3990	collet,ex.pipe,pre75 850	EA
06-3991	clamp,balance pipe,850exh*	EA
06-3994	USE 06-6332	ea
06-3995	washer,sealing,xpipe toHd	EA
06-3997	USE 721-N64 (set)	ea
06-3998	USE 721-N64 (set)	ea
06-3999	USE 721-N67 or N70 (set)	ea
06-4000	USE 721-N67 or N70 (set)	ea
06-4009	knob,Commando seat mount	EA
06-4009/ER	knob,seat mount,econo rep*	EA
06-4013	decal,850 COMMANDO,black	EA
06-4014	decal,850 COMM,gold/black	EA
06-4015	decal,850 COMMANDO,silver	EA
06-4016	spacer,tailamp	EA
06-4018	USE 221-64947081	ea
06-4025	USE 552-110056/99	ea
06-4031	centrestand,850 type	EA
06-4031/ER	centrestand,850 type,econo*	EA
06-4034	USE 453-263	ea
06-4038	USE 06-3830	ea
06-4041	USE 441-19342/020 (pair)	ea
06-4045	crankcases,1973/74Nor850	ST
06-4047	USE 06-3887	ea
06-4048	cyl.hd,750 Norton,all	EA
06-4049	plate,shift stop	EA
06-4057	spacer,steppedCentrestand	EA
06-4060	mounting,eng/gbx.rear,pre75*	EA
06-4061	washer,fibre	EA
06-4062	USE 03-5073	ea
06-4064	USE 82-9355	ea
06-4065	pin,bat.strap,850 Mk3 ES	EA
06-4066	receptacle,dzus fastener	EA

06-4067	clip,dzus fastener,Mk3 ES	EA
06-4070	battery strap,850 Mk3 ES	EA
06-4071	gasket,cyl.head,copper750	EA
06-4072	gasket,cyl.head,alloy,750	EA
06-4077	spindle,swingarm+.005inch,preMk2A	EA
06-4077/ER	spindle,swingarm+.005inch,preMk2A,econo	EA
06-4078	forkyoke,lower,Nort850,pre75*	EA
06-4080	fork yoke,upper,850 type	EA
06-4081	sidepanel,LH Inter.Mk2A	EA
06-4082	USE 82-8091	ea
06-4088	USE 06-2374	ea
06-4097	USE 06-4048	ea
06-4102	USE 561-RH28 *	ea
06-4103	stem,mirror,Norton,3/8X24UNF	EA
06-4103/SS	stem,mirror,Norton,stainless	EA
06-4118	bearing,roller,Superblend*	EA
06-4124	USE 452-547	ea
06-4125	USE 452-548	ea
06-4126	USE 06-5207	ea
06-4126/A	gearbox shell,RH shift,reinforced*	EA
06-4126/B	gearbox shell,RH shift,5spd type*	EA
06-4132	bars,Commando UK	EA
06-4134	USE 06-2206	ea
06-4136	sidepanel,RH Interstate	EA
06-4137	USE 526-96 *	ea
06-4140	USE 06-5632 *	ea
06-4144	bracket,inst.housing,late *	EA
06-4144/ER	bracket,inst.housing,late,econo	EA
06-4145	USE 06-4103	ea
06-4147	washer,3/8,flat	EA
06-4147/SS	washer,3/8,flat,stainless	EA
06-4148	bracket,muffler,MK3	EA
06-4149	bracket,pass.peg.MK3	EA
06-4150	bracket,muffler,Mk3	EA
06-4152	grommet,wire	EA
06-4153	washer,sealing,sumpfilter	EA
06-4157	stud,3/8x16x24	EA
06-4160	nut,5/16x24,crankshaft	EA
06-4170	USE 711-Z602	ea
06-4173	tooltray,Commando	EA
06-4179	USE 06-5459	ea
06-4180	airfilter hose,850 Mk3 ES	EA
06-4184	stud,5/16x24	EA
06-4185	stud,5/16x24	EA
06-4188	plug,magnetic,sump drain	EA
06-4189	nut,5/16x24,crankshaft	EA
06-4200	tube,crankcase breather	EA
06-4220	rubber pad,R.mudguard mt.	EA
06-4243	caliper rebuild kit	ST
06-4244	sealkit,mastercyl,fr.	ST
06-4247	steering damper kit,COMMANDO	EA
06-4249	USE 12-1018	ea
06-4254	crankshaft assy,850cc,73/74	EA
06-4283	oilfilter kit,Norton twins	EA
06-4285	USE 421-53 (set)	ea
06-4286	USE 421-53/010	ea
06-4287	USE 421-53/020	ea
06-4288	USE 421-53/030	ea
06-4289	USE 421-53/040 (set)	ea
06-4297	USE 222-170 or 222-064297	ea
06-4298	USE 222-190 & 222-189	ea
06-4536	airfilterElement,foam,Mk3	EA
06-4536/ER	airfilterElement,foam,Mk3, repl.	EA
06-4539	swingarm,pre75 Commando	EA
06-4600	USE 523-364018	ea
06-4601	USE 526-499 *	ea
06-4602	USE 526-496 *	ea
06-4617	USE 37-3969	ea
06-4618	USE 37-1197	ea
06-4619	USE 37-3970	ea
06-4620	USE 37-1198	ea

06-4622	USE 221-188	ea
06-4635	USE 391-54343792	ea
06-4638	USE 526-496/8 *	ea
06-4639	gear,2nd lay,23T,late type	EA
06-4639/ER	gear,2nd lay,late,econo.	EA
06-4640	gear,2nd main,18T,late type*	EA
06-4640/ER	gear,2nd main,late,econo.	EA
06-4643	spring,centrestand	EA
06-4647	slipper,camchain,rub.face,late	EA
06-4647/A	tensioner assy,camchain,automatic	EA
06-4665	isolastic adjuster,Mk3	EA
06-4666	isolastic gaiter,rear Mk3	EA
06-4674	isolastic gaiter,front Mk3	EA
06-4680	nut,rotor	EA
06-4681	sprocket,engine,Mk3	EA
06-4688	stud,5/16x24	EA
06-4689	gasket,inner primary,Mk3	EA
06-4691	primary cover,outer,Mk3	EA
06-4694	timing indicator plateMk3	EA
06-4697	bolt,9/16x18,gbx.mtg,Mk3	EA
06-4699	spindle,swingarm,850 Mk3	EA
06-4699/010	spindle,swingarm+.010inch,short	EA
06-4700	USE 57-4356	ea
06-4704	oring,Mk3 starter to case	EA
06-4711	bearing,needle	EA
06-4716	stud,5/16x18x24	EA
06-4718	body,hydraulic tensioner	EA
06-4723	clip,Mk3 isolastic gaiter	EA
06-4727	plug,sealing	EA
06-4728	washer,tab,Mk3 inner pri.	EA
06-4729	screw,1/4x20UNC,philip head	EA
06-4730	nut,9/16x18	EA
06-4733	starter clutch,sprag type	EA
06-4740	spring,disc,starter drive	EA
06-4741	washer,thrust,starter gear,Mk3	EA
06-4743	USE 422-6MM	ea
06-4745	nut,shouldered,electric start	EA
06-4748	isolastic PTFE washer,bronze loaded	EA
06-4772	rubber plug,Mk3 swingarm	EA
06-4787	USE 21-0686	ea
06-4791	starter motor,850 Mk3 ES	EA
06-4791/A	plate,to replace starter	EA
06-4791/B	starter motor,850 Mk3 ES,hi power	EA
06-4811	rubber,cush drive,lg,Mk3	EA
06-4812	rubber,cush drive,sm,Mk3	EA
06-4822	chainguard extension	EA
06-4822/SS	chainguard extension,stainless	EA
06-4823	washer,button,chngrd ext.	EA
06-4824	spring,chainguard ext.	EA
06-4833	USE 06-3503	ea
06-4837	chainguard,chrome,Commando,74on*	EA
06-4837/ER	chainguard,Commando,econo rep.	EA
06-4837/SS	chainguard,Commando,74on,stainless	EA
06-4839	airfilter venturi,Mk3	EA
06-4858	camshaft,4S racing	EA
06-4871	mastercylinder assy,pre75 *	EA
06-4873	spacer,centrestand,750	EA
06-4874	kit,centrestand,71onCommando	ST
06-4875	clamp,chain oiler adjust.	EA
06-4880	decal,tank,NORTON,gold vinyl	EA
06-4881	decal,tank,NORTON,black vinyl	EA
06-4882	decal,tank,NORTON,silver vinyl	EA
06-4887	USE 06-5748	ea
06-4891	rubber cover,ign.sw,rear	EA
06-4892	rubber cover,ign.sw,front	EA
06-4894	USE 06-1694	ea
06-4896	conrod,Norton twins *	EA
06-4896/A	conrods,CARRILLO Hiperf.	PR
06-4918	USE 06-3458	ea
06-4963	USE 526-812	ea
06-4973	USE 60-4365	ea

06-4978	grabrail,Roadster & Inter	EA
06-4978/SS	grabrail,stainless steel	EA
06-4989	circlip,4th gear main	EA
06-4991	USE 06-5954	ea
06-4997	USE 06-5428	ea
06-5006	washer,tab,oilfilterMount	EA
06-5024	USE 452-548	ea
06-5025	USE 452-548/002	ea
06-5026	USE 452-548/015	ea
06-5027	USE 452-547	ea
06-5028	USE 452-547/002	ea
06-5029	USE 452-547/015	ea
06-5030	USE 433-08/B	ea
06-5046	backing plate,rear mudflap	EA
06-5050	clip,oilhose	EA
06-5051	gasket,cyl.hd,850eyletted	EA
06-5052	USE 06-5561	ea
06-5053	spindle,swingarm,Mk2A	EA
06-5062	USE 06-3830	ea
06-5074	cylinder barrel,850 Nort.	EA
06-5074/A	cyl.barrel,alloy,850 *	EA
06-5095	decal,850 COMM,silv.vinyl	EA
06-5096	decal,850 COMM,blk.vinyl	EA
06-5097	decal,850 COMM,gold vinyl	EA
06-5108	rubber cover,instruments	EA
06-5115	USE 453-264	ea
06-5130	USE 691-376419	ea
06-5140	mounting,eng/gbx.rear,MK3	EA
06-5163	cover,gbx inner,pre75	EA
06-5173	USE 06-1926	ea
06-5181	oilseal,Mk3 gearshift,LH	EA
06-5183	oilseal,Mk3 gbx.crossshaft	EA
06-5184	bush,gearbox cover	EA
06-5185	bush,gearshift,Mk3 priCov	EA
06-5186	footrest mount,Mk3 L.hand	EA
06-5192	fueline assembly,complete	EA
06-5196	manifold,in,30-32mm tapered	EA
06-5199	breather vent,gbx.housing	EA
06-5200	tachdrive housing,Comman.	EA
06-5201	tachdrive gear,Commando,late	EA
06-5203	oring,tachdrive,late type	EA
06-5207	gearbox shell,Commando,MK3style*	EA
06-5209	bush,shift quadrant,Mk3	EA
06-5210	gearbox cover,inner,MK3 type	EA
06-5216	pawl carrier,gearshift,Mk3	EA
06-5222	screw,3/16x32	EA
06-5225	mudflap,front	EA
06-5226	backing plate,fr.mudflap	EA
06-5227	oilseal,swingarm shaftMk3	EA
06-5229	felt oilwick,swingarm,Mk3	EA
06-5230	felt oilwick,swingarm,Mk3	EA
06-5234	USE 511-154	ea
06-5245	circlip	EA
06-5256	USE 721-N65 (set)	ea
06-5257	USE 721-N65 (set)	ea
06-5259	seating,spherical ex.pipe	EA
06-5260	collet,spherical exh.pipe	EA
06-5270	USE 06-4539	ea
06-5271	USE 06-0289	ea
06-5273	USE 06-0324	ea
06-5278	USE 06-0292	ea
06-5290	spacer,wheel brg,LH rear	EA
06-5315	fitting,"T",breather	EA
06-5316	hose,balance	EA
06-5320	bush,swingarm shaft,Mk3	EA
06-5329	USE 70-7351	ea
06-5341	slipper assy,Mk3pri.chain	EA
06-5364	tank,gas,Interstate type	EA
06-5382	USE 511-156	ea
06-5390	USE 391-30702	ea
06-5393	hose,oil	EA

06-5404	frame,preMk3 Commando	EA
06-5407	footrest peg,front,Mk3	EA
06-5420	hose,oil,3/8"braided herringbone	EA
06-5425	bush,cam,LH	EA
06-5428	bush,cam,RH	EA
06-5436	bolt,sidestand,gen.Norton	EA
06-5436/ER	bolt,sidestand,econo repl	EA
06-5441	USE 552-110056/100	ea
06-5445	cover,forklock,Mk3	EA
06-5447	rollpin,Neiman fork lock	EA
06-5448	forklock assy,Neiman type	EA
06-5454	spring,top motor mt,Mk3	EA
06-5456	trunnion,top motor mt,Mk3	EA
06-5458	bracket,headsteady spring	EA
06-5459	mount,top head steady	EA
06-5459/A	isolastic headSteady assy	EA
06-5464	USE 721-N65 (set)	ea
06-5465	USE 721-N65 (set)	ea
06-5483	oilseal,fortube,Roadholder*	EA
06-5483/A	oilseals,fork,LEAKPROOF	PR
06-5483/B	oilseal,forks,LEAKPROOF,moly	PR
06-5483/ER	oilseal,fortube,Nor,econo	EA
06-5490	sidestand,71 on Commando *	EA
06-5490/ER	sidestand,71 on Commando,econo	EA
06-5491	spacer,.687"OD*	EA
06-5492	USE 14-1204	ea
06-5504	camplate assy,Mk3	EA
06-5507	USE 06-3830	ea
06-5508	solenoid,starter,Mk3	EA
06-5509	USE 82-9659	ea
06-5510	isolastic housing,Mk3 fr.	EA
06-5512	USE 06-2764	ea
06-5514	isolastic abutment,Mk3,F	EA
06-5517	cover,gearbox inspection	EA
06-5517/A	cover,gbx.insp,NORTONlogo	EA
06-5518	isolastic abutment,Mk3,R	EA
06-5525	isolastic endcap,Mk3,fr.	EA
06-5526	isolastic endcap,Mk3,rear	EA
06-5531	screw,10-32,setscrew	EA
06-5532	screw,1/4x20 philip head	EA
06-5533	screw,1/4x20UNC,philip head	EA
06-5534	gasket,primary cover,Mk3	EA
06-5540	USE 572-BG5333171	ea
06-5541	USE 37-7042	ea
06-5542	bearing,ball,sealed	EA
06-5544	USE 06-6544	ea
06-5545	spacer,caliper,R	EA
06-5548	lockring,rear wheel,Mk3	EA
06-5549	washer,axle	EA
06-5550	spacer,brg,rear axle,MK3	EA
06-5552	axle,dummy,Mk3 rear	EA
06-5553	axle,rear,Mk3 Commando	EA
06-5554	USE 06-5544	ea
06-5557	oilseal,rear wheel,Mk3	EA
06-5561	oiline assy,rockerfeed	EA
06-5561/A	oiline assy,braided stainless	EA
06-5561/ER	oiline assy,rockers,econo	EA
06-5562	oilseal,rear sprocket,Mk3	EA
06-5574	USE 06-5490	ea
06-5585	retainer,top mtr.mtSpring	EA
06-5604	lever,front discbrake,Mk3	EA
06-5607	sleeve,gearshift,Mk3	EA
06-5612	USE 511-155	ea
06-5613	USE 511-162	ea
06-5616	tooltray,Commando 850 Mk3 *	EA
06-5617	bracket,seatlock,Mk3	EA
06-5621	lock assy,Mk3 seat	EA
06-5623	USE 60-2087	ea
06-5626	collar,seatlock,Mk3	EA
06-5632	frame,Commando,Mk3 type	EA
06-5646	washer,5/8"	EA

06-5660	crankshaft assy,850ccMk3	EA
06-5666	crankcases,1975 Commando	PR
06-5669	bush,timing gear	EA
06-5671	stud,crankshaft dowel,Mk3	EA
06-5672	stud,crankshaft,Mk3	EA
06-5673	nut,3/8x24,crankshaft,Mk3*	EA
06-5674	stud,crankshaft,Mk3	EA
06-5675	key,timing gears	EA
06-5718	key,rotor*	EA
06-5719	console,850Mk3 dashboard	EA
06-5722	decal,Mk3 dash console	EA
06-5723	cover,ign.sw,Mk3,bot	EA
06-5724	screw,self tapping	EA
06-5727	USE 06-2525	ea
06-5728	USE 06-2525	ea
06-5729	USE 06-2526	ea
06-5730	USE 06-7712	ea
06-5740	USE 60-4365	ea
06-5741	mastercyl.body,bare,Mk3	EA
06-5742	mastercylinder assy,Mk3,F	EA
06-5743	USE 531-35 (pr)	ea
06-5748	bars,European"Majorca"	EA
06-5751	USE 221-15	ea
06-5753	rubber sleeve,crosshaft	EA
06-5766	grommet,rear brake plate	EA
06-5770	spacer,RH footpeg,Mk3	EA
06-5773	spring,brake pedal,Mk3	EA
06-5774	nut,7/16x20,sleeve	EA
06-5776	mastercylinder,rear,Mk3 *	EA
06-5777	pedal,brake,Commando Mk3	EA
06-5826	USE 06-0332 *	ea
06-5837	USE 567-09	ea
06-5878	USE 97-7035	ea
06-5888	swingarm,Mk3	EA
06-5916	USE 391-49181	ea
06-5929	USE 391-35317	ea
06-5930	USE 391-35316	ea
06-5944	USE 567-07	ea
06-5945	USE 567-07	ea
06-5954	gear,4th main,23T,sleeve gear,w/bushes	EA
06-5954/ER	gear,4th main,econo repl.	EA
06-5956	oilseal,inner primary,Mk3	EA
06-5961	USE 06-0944 *	ea
06-5984	washer,11/16",plain	EA
06-6005	brake pads,AP Lockheed	PR
06-6005/A	brakepads,hi friction SBS	PR
06-6005/B	brakepads,lo friction SBS	PR
06-6005/ER	brakepads,econo. replace.	PR
06-6006	bolt,timing hole	EA
06-6007	washer,1/2x13/16,sealing	EA
06-6008	USE 523-16008	ea
06-6011	sprocket,rear,850Mk3 ES,UK made	EA
06-6011/ER	sprocket,rear,850Mk3 ES,econo	EA
06-6023	cover,inner primary,Mk3ES	EA
06-6025	wheel assy,WM2x19,Mk3,F	EA
06-6032	USE 60-4366	ea
06-6033	USE 345-1597	ea
06-6039	USE 567-07	ea
06-6041	USE 567-07	ea
06-6042	USE 06-0699	EA
06-6050	circlip,shift seal,Mk3	EA
06-6084	USE 526-99	ea
06-6085	USE 526-92	ea
06-6109	adjuster,rear chain,Mk3	EA
06-6115	spoke,LH outer,Mk3 rear	EA
06-6116	spoke,LH inner,Mk3 rear	EA
06-6117	spoke,RH,Mk3 rear	EA
06-6119	rim,WM2x19,rear,Mk3	EA
06-6119/A	rim,WM2x19 R,alloy w/shoulder	EA
06-6119/B	rim,WM3x18 R,alloy w/shoulder	EA
06-6119/SS	rim,WM2x19,rear,Mk3,stainless	EA

06-6123	spacer, 9/32"	EA
06-6125	isolastic bush assy, Mk3, F	EA
06-6126	isolastic bush assy, Mk3, R	EA
06-6145	oilseal, kickshaft, Mk3	EA
06-6160	bracket, brakeline	EA
06-6161	timing cover, Mk3*	EA
06-6165	cap, insp, Mk3 timing cover	EA
06-6166	oring, timing cov. insp. cap	EA
06-6169	shaft, kickstart, w/bush	EA
06-6169/ER	shaft, kickstart, w/bush, econo rep*	EA
06-6179	decal, SHIFT PATTERN, Mk3	EA
06-6180	spindle w/gear, Mk3 shifter	EA
06-6181	gear, crosshaft, Mk3	EA
06-6183	brakeline, to caliper, Mk3	EA
06-6186	USE 06-6005 (pair)	ea
06-6187	spindle, crossover, LH shift	EA
06-6188	pedal, gearshift, Mk3 *	EA
06-6189	bush, shift, Mk3 outer pri.	EA
06-6190	washer, sealing, Mk3 oil pump	EA
06-6193	oil pump, Commando*	EA
06-6193/ER	oil pump, Comm, economy repl	EA
06-6195	body assy, press. rel. valve	EA
06-6198	spring, check valve, Mk3	EA
06-6199	plunger, check valve, Mk3	EA
06-6203	bush, gbx, 4th main, Mk3	EA
06-6204	mudguard, front, stainless, w/std. bridge*	EA
06-6204/A	mudguard, fr, all stainless, incl. bridge*	EA
06-6210	USE 523-100/LH *	ea
06-6213	USE 06-1441	ea
06-6216	brakeline, rear caliper Mk3	EA
06-6217	brakeline, master cyl, R. Mk3	EA
06-6218	brake hose, rear, 850 MK3 ES	EA
06-6218/A	brake hose, rear, 850 MK3, stainless	EA
06-6227	brakeline, upper, Mk3 front	EA
06-6228	fork yoke, lower, Nor MK3*	EA
06-6232	centre, drive, rear wheel, Mk3	EA
06-6235	USE 60-4177	ea
06-6236	brake hose, 18", Mk3 top*	EA
06-6236/A	brake hose kit, stainless	EA
06-6237	brake hose, 12-1/2", Mk3 top	EA
06-6241	bracket, brakeline	EA
06-6242	USE 345-1197	ea
06-6243	USE 60-4175	ea
06-6253	plate, seathing, Mk3	EA
06-6254	rubber cov, Mk3 seat hinge	EA
06-6257	stud, inner pri. mtg, Mk3	EA
06-6263	footrest mount, Mk3 R. hand	EA
06-6268	tray, battery carrier, Mk3	EA
06-6306	USE 526-066714	ea
06-6307	USE 06-4066	ea
06-6311	brush set, starter motor	ST
06-6314	USE 391-SR102 (kit)	ea
06-6315	USE 391-SR102 (kit)	ea
06-6317	washers, thrust, start. mtr.	ST
06-6329	side panel, LH, Mk3 Inter.	EA
06-6330	side panel, LH Mk3 Roadster	EA
06-6332	balance pipe, 850 exhaust	EA
06-6341	USE 526-066714 *	ea
06-6349	hinge, seat, Mk3 Commando	EA
06-6349/SS	seathing, Mk3, stainless	EA
06-6350	spacer plate, seathing, MK3	EA
06-6353	plate, seathing, MK3	EA
06-6357	sidestand w/mounting hardware	EA
06-6359	USE 06-3031	ea
06-6360	clip, caliper support	EA
06-6362	USE 323-66 *	ea
06-6364	washer, sealing, bonded	EA
06-6388	decal, 850 ELECT. START gold	EA
06-6389	decal, 850 ELECT. START silver	EA
06-6390	decal, 850 ELECT. START black	EA
06-6392	control unit, lights on, Mk3	EA

06-6393	control unit,warn.lt,Mk3	EA
06-6395	USE 391-30552	ea
06-6396	USE 345-1195	ea
06-6397	arm,kickstarter crank,Mk3	EA
06-6399	spring,detent,kick pedal	EA
06-6400	USE 422-316	ea
06-6401	circlip,crosshaft,Mk3	EA
06-6405	bolt,1/4x28,chain adjust.	EA
06-6406	clip,warning light retaining	EA
06-6407	USE 06-6431	ea
06-6408	lens only,warning light,amber	EA
06-6409	lens only,warning light,green	EA
06-6410	lens only,warning light,blue	EA
06-6411	lens only,warning light,red	EA
06-6415	mudflap,rear,"Norton-Tri"	EA
06-6416	USE 511-106 *	ea
06-6424	USE 391-54363522	ea
06-6426	USE 391-54363453	ea
06-6427	USE 391-54361250	ea
06-6431	bulb,850 Mk3 dash console	EA
06-6434	bolt,special,shock,Mk3	EA
06-6435	fastener,sidecover,Mk3 ES	EA
06-6438	USE 345-1196	ea
06-6447	latch,seatlock,Mk3	EA
06-6476	USE 526-812	ea
06-6477	USE 526-812/6	ea
06-6478	USE 526-812/10	ea
06-6484	plug,plastic,bar bolts	EA
06-6486	bolt,conrod	EA
06-6488	USE 543-6135 (pair,compl)	ea
06-6499	washer,5/16,flat	EA
06-6515	USE 335-05	ea
06-6541	stud,1/4UNF	EA
06-6544	spacer,chainguard,MK3	EA
06-6547	spacer,large headlight	EA
06-6565	USE 526-91 *	ea
06-6570	gasket,hydr.chain adj,Mk3	EA
06-6571	spacer,small headlight	EA
06-6580	plate,frame identif,Mk3	EA
06-6591	spacer plate,cyl.to cases,850cc	EA
06-6595	USE 06-1885	ea
06-6607	stud,crankshaft *	EA
06-6609	stud,crankshaft *	EA
06-6611	decal,OIL RECOMMENDATIONS	EA
06-6623	welch plug,swingarm,Mk3	EA
06-6625	USE 391-30825	ea
06-6649	forkyoke,top,Mk3	EA
06-6664	bush,1st gear lay	EA
06-6665	bush,gbx,3rd lay	EA
06-6666	layshaft	EA
06-6666/ER	layshaft,econ.replacement	EA
06-6726	USE 06-5186	ea
06-6972	mounting,eng/gbx.rear,pre75,cottered*	EA
06-6978	ball,rocker arm	EA
06-6982	USE 331-01	ea
06-7102	USE 06-0681/B	ea
06-7171	spacer plate,cyl.to cases,Dominator	EA
06-7177	grommet,wiring harness,1.5" OD *	EA
06-7501	pushrod,inlet,early type	EA
06-7502	pushrod,exhaust,earlyType	EA
06-7506	collar,valvespring,upper	EA
06-7506/A	collars,valvespring,alloy	ST
06-7507	collet,valve	EA
06-7508	nut,valve adjuster	EA
06-7508/A	nuts,valve adj.lightAlloy	ST
06-7509	stud,5/16	EA
06-7510	washer,sealing,oilpump	EA
06-7511	washer,fortube top nut	EA
06-7511/SS	washers,forknut,stainless	PR
06-7512	rubber grommet	EA
06-7514	washer,fibre	EA

06-7516	USE 82-4717	ea
06-7517	washer, flat	EA
06-7518	USE 01-2873	ea
06-7519	bush, fork, lower	EA
06-7520	gasket, forkseal	EA
06-7521	bush, fork, upper	EA
06-7522	washer, sealing	EA
06-7522/A	washer, sealing, GOODRIDGE*	ST
06-7523	USE 70-3858	ea
06-7524	USE 222-158	ea
06-7525	washer, back plate	EA
06-7526	washer, cupped, crank brg.	EA
06-7528	nut, 3/8x26	EA
06-7529	nut, 5/16x26	EA
06-7530	stud, 3/8x16x26	EA
06-7533	nut, 5/16x26	EA
06-7534	washer, tab	EA
06-7535	bolt, 5/16x26, crankshaft*	EA
06-7537	gear, timing pinion, 24T	EA
06-7538	bush, camshaft, pre72 R.H.	EA
06-7539	bush, camshaft LH	EA
06-7540	pressure rel. valve piston	EA
06-7541	washer, 3/4", sealing	EA
06-7542	washer, 7/8", sealing	EA
06-7543	cap, pressure rel. valve	EA
06-7544	spring, pressure rel. valve	EA
06-7545	collar, valvespring, lwr750	EA
06-7546	adjuster, valve	EA
06-7546/A	adj. set, valve, allen type	ST
06-7546/B	adj. set, valve, mushroom type*	ST
06-7547	breather plate, stationary	EA
06-7548	washer, 9/16, flat	EA
06-7549	washer, sealing	EA
06-7550	gasket, rocker plate, inner	EA
06-7551	gasket, rocker cover, inlet	EA
06-7552	nut, acorn, exh. rocker cov*	EA
06-7552/SS	nut, acorn, stainless steel	EA
06-7553	stud, 5/16x26, crankshaft	EA
06-7554	gasket, exh. rocker cover	EA
06-7556	gasket, cyl. base, 650 Norton	EA
06-7557	bolt, 3/8x26, cylinder head	EA
06-7558	pin, dowel, crankshaft	EA
06-7559	spring, crankcase breather	EA
06-7560	screw, 2BA, tappet retain	EA
06-7561	stud, 5/16x26	EA
06-7562	nut, 5/16x26, acorn, Irocker	EA
06-7562/SS	nut, acorn, stainless steel	EA
06-7563	sprocket, engine, 19T	EA
06-7564	sprocket, engine, 20T	EA
06-7565	sprocket, engine, 21T	EA
06-7566	sprocket, engine, 23T	EA
06-7567	oilseal, crank, LH, Norton	EA
06-7568	gasket, magneto to case*	EA
06-7569	washer, crank shim	EA
06-7570	USE 453-27/A	ea
06-7571	stud, 5/16 CEI/BSW	EA
06-7572	nut, 5/16x26	EA
06-7574	slipper, camchain, pre 1970	EA
06-7574/A	tensioner assy, camchain, automatic	EA
06-7575	plate, camchain adj, thin	EA
06-7576	plate, camchain adj, thick	EA
06-7577	washer, 1/4", flat	EA
06-7578	plate, rockershaft, inner	EA
06-7579	plates, rckrshaft, outer	EA
06-7579/SS	plates, rckrshft, stainless	ST
06-7580	gasket, rocker plate, outer	EA
06-7581	stud, magneto mounting	EA
06-7582	stud, 1/4x20x26	EA
06-7584	bolt, 5/16x26CEI	EA
06-7585	bolt, 5/16x26 *	EA
06-7586	stud, 5/16x26	EA

06-7588	nut,2BA	EA
06-7589	nut	EA
06-7590	USE 00-0003	ea
06-7591	USE 82-0879	ea
06-7592	USE 70-1310	ea
06-7595	key,engine sprocket	EA
06-7600	screw,1/4x26 setscrew	EA
06-7603	washer,flat	EA
06-7604	USE 37-7041	ea
06-7606	washer,5/16,flat	EA
06-7607	spring,brakeshoe,rear	EA
06-7609	nut,1x20,chrome	EA
06-7610	washer,cup,pri,Featherbed	EA
06-7611	washer,1",sealing	EA
06-7612	washer,cupped*	EA
06-7613	USE 06-0648	ea
06-7614	felt seal washer,wheelbrg	EA
06-7616	washer,wheel	EA
06-7617	screw,1/4x20	EA
06-7618	USE 422-1414	ea
06-7621	pin,dowel	EA
06-7622	washer,alloy	EA
06-7624	USE 222-234	ea
06-7627	gasket,rubber,pri.cov,Nor	EA
06-7629	spacer,speedo gearbox	EA
06-7630	USE 70-2615	ea
06-7631	USE 06-6007	ea
06-7632	bolt,5/16x26,small hex	EA
06-7633	damper valve	EA
06-7634	pin,fork damper valve	EA
06-7635	bolt,5/16x26	EA
06-7636	circlip,fork bush	EA
06-7637	rod,footpeg mount	EA
06-7639	USE 57-2703	ea
06-7640	washer,tab,brakeshoe,rear	EA
06-7641	cap,damper tube,early,26TPI	EA
06-7642	washer,sealing	EA
06-7643	cap,pri chain insp,Atlas	EA
06-7646	washer,shim,press.rel.vlv	EA
06-7647	USE 06-7827	ea
06-7648	screw,oilpump body	EA
06-7649	feed bush,oilpump	EA
06-7651	washer,dustcover,fork brg	EA
06-7652	nut,forkstem adjust,Atlas	EA
06-7655	grommet	EA
06-7657	rod,fork damper	EA
06-7664	nut,7/16x20,tall	EA
06-7666	USE 742-134/A	ea
06-7674	spacer,front axle	EA
06-7676	body,sump filter	EA
06-7676/A	sump filter assy,w/drain,complete	EA
06-7677	screen,sump filter	EA
06-7678	washer,flat,sump filter	EA
06-7679	circlip,sump filter	EA
06-7680	washer,sealing,sumpfilter	EA
06-7681	USE 06-2654 & 2) 14-0402	ea
06-7682	nut,fortube top,preComm.	EA
06-7682/SS	nut,fortube,stainless	PR
06-7685	washer,1",steering stem	EA
06-7686	key,oilpump,pre 1972	EA
06-7687	USE 06-5483	ea
06-7688	bearing,ball,double row	EA
06-7689	USE 552-110038/38	ea
06-7690	circlip,intermediateShaft	EA
06-7691	USE 552-110046/80	ea
06-7693	stud,5/16x26x22	EA
06-7694	cover,exhaust rocker*	EA
06-7694/7695/A	rocker cover set,finned	ST
06-7695	cover,inlet rocker*	EA
06-7696	bolt,rocker banjo	EA
06-7696/CHR	bolt,rocker banjo,chrome	EA

06-7696/SS	bolt,banjo,stainless	EA
06-7696/SS/A	bolt,banjo,for 065561/A kit	EA
06-7697	washer,thrust,rockers	EA
06-7698	washer,spring,rockers	EA
06-7699	footpeg,featherbed,LH	EA
06-7700	washer,5/16,lock	EA
06-7702	lockring,rear hub,early,26TPI	EA
06-7703	nut,brakedrum,CEI	EA
06-7704	spacer,rear wheel	EA
06-7705	USE 552-110037/42	ea
06-7706	USE 37-7041	ea
06-7708	washer,footpeg retaining	EA
06-7709	USE 06-0811	ea
06-7710	bearing,roller,LH lay.	EA
06-7711	cover,rear hub,w/3 holes	EA
06-7712	rim,WM2x19,Norton drumF&R*	EA
06-7712/A	rim,WM2x19,alloy w/shoulder*	EA
06-7712/SS	rim,WM2x19,Norton drum,stainless	EA
06-7713	USE 523-18053	ea
06-7714	forktube,AtlasType,21-7/8	EA
06-7715	brakeshoes,F,Norton SLS 8"	PR
06-7718	rubber plug,pre71 hub cov	EA
06-7720	beading,front numberplate,rubber	EA
06-7722	footpeg,featherbed,RH	EA
06-7723	spring,front fork	EA
06-7723/A	springs,HiPerf PROG.SUSP,street	PR
06-7723/B	springs,HiPerf PROG.SUSP,race	EA
06-7726	stud,3/8	EA
06-7727	clip,handlebar mounting	EA
06-7730	cover plt,gbx.mt,Atlas	EA
06-7730/SS	cover plt,gbx.mt,Atlas,stainless	EA
06-7733	sidepanel,bat.box,Atlas type *	EA
06-7734/SS	screw,batt.box cov,Atlas	ea
06-7736	USE 03-0500	ea
06-7738	washer,9/16,flat	EA
06-7739	nut,9/16x20,axle	EA
06-7742	spacer,steering hd.brg.	EA
06-7743	covers,forktube,upper	PR
06-7744	grommet,points wire,early	EA
06-7745	bolt,5/16x22,allen head	EA
06-7745/SS	bolts,top mtrMt,stainless	ST
06-7746	nut,13/16x26,forkyoke	EA
06-7746/SS	nut,fork crown,stainless	EA
06-7747	USE 06-3417	ea
06-7748	spacer,fr.hub,drum	EA
06-7749	USE 06-0364*	ea
06-7750	bush,brake cam,F wheel	EA
06-7751	washer,retaining	EA
06-7757	spring,brakepedal,Featherbed	EA
06-7760	USE 532-81	ea
06-7765	USE 06-2525	ea
06-7766	USE 06-2526	ea
06-7767	bush,silentbloc,swingarm	EA
06-7767/A	conversion kit,bronze swingarm bushes	EA
06-7769	damper tube,forks,Atlas type	EA
06-7771	USE 00-0203	EA
06-7772	nut,5/8x20,rotor	EA
06-7774	nut,3/4x20,camshaft sprocket	EA
06-7775	sprocket,camshaft,18T,early	EA
06-7776	USE 06-2580	ea
06-7777	housing,stator,Atlas type	EA
06-7778	tube assy,footrest,Atlas	EA
06-7779	gasket,inner pri,preComm.	EA
06-7780	USE 00-0340	ea
06-7781	nut,steering stem,71 on	EA
06-7781/SS	nut,strg.stem,stainless	EA
06-7782	cover plt,eng.mt,Atlas,front	EA
06-7782/SS	cover plt,eng.mt,Atlas,stainless	EA
06-7784	washer,shim,oilpump seal	EA
06-7785	bolt,5/16x18,allen head	EA
06-7786	dowel,hollow	EA

06-7788	stud,1/4x26x20	EA
06-7789	chainguard, slimline Featherbed	EA
06-7789/A	chainguard, featherbed, chr	EA
06-7790	rubber bushing, seat mount	EA
06-7791	rubber buffer, seat base	EA
06-7792	USE 57-0323	ea
06-7793	USE 623-13	ea
06-7797	nut, 3/16x32	EA
06-7799	washer, rubber, tank mt.	EA
06-7802	USE 60-2420	ea
06-7804	bolt, 2BA	EA
06-7808	washer, 3/8, flat	EA
06-7815/7816	kneepad set, Slimline	PR
06-7817	cam, pre70 Norton Twin	EA
06-7817/A	cam, pre70Nort.twin, Combat 2S profile	EA
06-7818	USE 40-8125	EA
06-7819	oring, gastank mounting	EA
06-7820	tappets, matched pair, Nort.twin	PR
06-7820/020	tappets, matched pair, +020	PR
06-7820/ER	tappets, econo replacement	PR
06-7820/U	tappet, reground, exch	PR
06-7820A/U	tappet, ground 3" radius, exch	PR
06-7822	USE 451-720 (set)	ea
06-7823	USE 451-720 (set)	ea
06-7824	USE 06-4188	ea
06-7826	USE 60-0985	ea
06-7827	nut, 3/8x26, lock, conrod	EA
06-7828	USE 06-6486	ea
06-7829	USE 82-3227	ea
06-7830	dzus fastener	EA
06-7834	circlip, wristpin	EA
06-7835	nut, 5/16x26, crankshaft	EA
06-7836	USE 621-54	ea
06-7838	rim, WM3x18 rear, Atlas etc	EA
06-7838/A	rim, WM3x18 R, alloy w/shoulder	EA
06-7838/SS	rim, WM3x18, rear, Atlas, etc, stainless	EA
06-7839	spoke, 18" rear wheel	EA
06-7840	spoke, 18" rear wheel	EA
06-7842	USE 06-3458	ea
06-7845	washer, heat insulating	EA
06-7846	bolt, 5/16x18, allen head	EA
06-7847	USE 14-0217	ea
06-7849	USE 06-2536	ea
06-7853	USE 633-04	ea
06-7854	grommet, airfilter	EA
06-7855	stud, 5/16x18x26	EA
06-7858	bracket, motormount top, Featherbed	EA
06-7862	USE 511-100	ea
06-7866	spring, centrestand, Featherbed	EA
06-7869	gasket, cylinder base, 750	EA
06-7870	nut, 3/8x26TPI	EA
06-7871	stud, 3/8x16x26	EA
06-7872	USE 06-4147	ea
06-7873	bolt, 5/16x26, cylinder hd.	EA
06-7877	decal, ATLAS 750cc	EA
06-7878	elbow, crankcase breather	EA
06-7879	valve, rotary breather*	EA
06-7882	gasket, insp.cap, Atlas pri	EA
06-7883	washer, rubber, primary, Featherbed	EA
06-7884	USE 453-240	ea
06-7885	stud, 3/8x26x20	EA
06-7885/A	stud, 3/8x26x16 For Helicoil*	EA
06-7886	USE 572-BG150805	ea
06-7887	USE 633-03	ea
06-7888	screw, 1/4x20, slotted	EA
06-7889	gear, crank, oilpump worm, 6start	EA
06-7890	gear, oilpump driven	EA
06-7891	USE 14-0103	ea
06-7892	nut, 5/16UNF, nyloc	EA
06-7894	USE 21-7024	ea
06-7896	spacer, forkspring location	EA

06-7899	USE 442-18020/010 (set)	ea
06-7900	USE 442-18020/020 (set)	ea
06-7901	USE 442-18020/030 (set)	ea
06-7902	USE 442-18020/040 (set)	ea
06-7903	mudguard,Atlas,rear	EA
06-7904	USE 571-69/A	ea
06-7905	screw,selftapping	EA
06-7906	bolt,magneto mounting	EA
06-7907	screw,1/4x20	EA
06-7908	decal,ROADHOLDER	EA
06-7908/A	badge,ROADHOLDER	EA
06-7918	bolt,3/8x26,cylinder head	EA
06-7919	gask,cyl.hd,asbestos,Atlas,late	EA
06-7920	gasket,cyl.hd,late 650,asbestos	EA
06-7920/A	gasket,cyl.hd,late 650,eyletted	EA
06-7922	plug,rubber,cl.inspection	EA
06-7924	shaft,rocker,non-scrolled	EA
06-7925	USE 432-261	ea
06-7934	USE 06-1180	ea
06-7940	pushrod,intake,Commando	EA
06-7940/7941	pushrod set,Commando,replacement*	ST
06-7940/7941/A	pushrod set,chromoly,Comman	ST
06-7940/7941/B	pushrodSet,alloy,Commando	ST
06-7941	pushrod,exhaust,Commando	EA
06-7942	valve,intake,Norton 650	EA
06-7944	USE 14-1201	ea
06-7950	screw,1/4UNF	EA
06-7951	bolt,1/4x20	EA
06-7953	USE 442-26260 (set)	ea
06-7955	USE 442-26260/020 (set)	ea
06-7956	USE 442-26260/030 (set)	ea
06-7957	USE 442-26260/040 (set)	ea
06-7958	USE 442-26730	ea
06-7960	USE 442-26730/020	ea
06-7961	USE 345-10/D	ea
06-7963	screw,10-32,philips	EA
06-7969	bolt,3/8UNFx1-1/8"	EA
06-7971	USE 14-1201	ea
06-7980	USE 523-16008	ea
06-8003	USE 691-622172	ea
06-8006	USE 691-928064	ea
06-8019	USE 392-410	ea
06-8024	USE 391-34660	ea
06-8028	USE 391-56513	ea
06-8029	USE 391-56513	ea
06-8033	USE 391-553738	ea
06-8039	USE 391-575189	ea
06-8042	USE 391-862217	ea
06-8046	USE 391-544415642 (pr)	ea
06-8047	USE 391-54426429	ea
06-8050	USE 391-54525212	ea
06-8056	USE 391-54584930	ea
06-8058	USE 391-54585314*	ea
06-8067	USE 345-1010	ea
06-8070	circlip	EA
06-8074	screw,3/16x32,sw. console	EA
06-8075	USE 14-0101	ea
06-8087	USE 526-91 *	ea
06-8088	circlip*	EA
06-8089	screw *	EA
06-8090	USE 557-WM2	ea
06-8099	USE 433-09/B	ea
06-8100	USE 391-60600684	ea
06-8101	USE 391-47194 *	ea
06-8102	USE 691-928104	ea
06-8103	USE 691-622197	ea
06-8104	USE 691-928107	ea
06-8105	USE 691-L932	ea
06-8106	USE 691-R932	ea
06-8107	USE 60-2416	ea
06-8110	USE 391-54425160	ea

07-	NORTON PARTS	*
07-----	-----	--
07-00099	USE 37-7041	ea
07-00100	USE 06-7742	ea
07-00101	USE 06-7781	ea
07-00106	USE 14-0217	ea
07-00117	USE 14-0103	ea
07-00184	USE 06-7892	ea
07-00267	USE 14-1201	ea
07-00272	USE 557-WM2	ea
07-00291	USE 06-7969	ea
12-	NORTON PARTS	*
12-----	-----	--
12-1015	USE 391-54335169 & 30552	ea
12-1018	kickstart crank assy,Comm,compl.	EA
12-1018/ER	kickstart crank assy,econ	EA
14-	NORTON,TRIUMPH &BSA PARTS	*
14-----	-----	--
14-0101	bolt,1/4UNF	EA
14-0102	bolt,1/4UNF	EA
14-0103	bolt,1/4UNF	EA
14-0104	bolt,1/4x28	EA
14-0105	bolt,1/4x28 UNF	EA
14-0106	bolt,1/4x28	EA
14-0107	bolt,1/4 UNF	EA
14-0113	bolt,5/16 UNF	EA
14-0113/SS	bolt,5/16 UNF, stainless	EA
14-0114	bolt,5/16 UNF	EA
14-0115	bolt,5/16x24 *	EA
14-0116	bolt,5/16UNF	EA
14-0118	bolt,5/16X24	EA
14-0119	bolt,5/16X24	EA
14-0120	USE 14-0222	ea
14-0126	bolt,3/8x24	EA
14-0128	bolt,3/8"UNF	EA
14-0129	bolt,3/8 UNF	EA
14-0132	bolt,7/16x20	EA
14-0133	bolt,7/16x20	EA
14-0145	bolt,1/2"UNF	EA
14-0147	bolt,1/2"UNF	EA
14-0201	USE 14-0105	ea
14-0202	bolt,1/4UNF	EA
14-0203	bolt,1/4"UNF	EA
14-0204	bolt,1/4x1-3/8 UNF	EA
14-0205	bolt,1/4"UNF	EA
14-0206	bolt,1/4x28	EA
14-0207	bolt,1/4"UNF	EA
14-0208	bolt,1/4x28UNF	EA
14-0211	bolt,1/4"UNF	EA
14-0213	bolt,1/4"x28, UNF	EA
14-0215	bolt,5/16"UNF*	EA
14-0216	bolt,5/16UNF	EA
14-0217	bolt,5/16"UNF	EA
14-0218	bolt,5/16 UNF*	EA
14-0219	bolt,5/16UNF	EA
14-0220	bolt,5/16X24 UNF	EA
14-0221	bolt,5/16UNF *	EA
14-0222	bolt,5/16X24 UNF	EA
14-0224	bolt,5/16x24	EA
14-0225	bolt,5/16UNF	EA
14-0226	bolt,3/8x24	EA
14-0228	bolt,5/16X24 UNF	EA
14-0230	bolt,5/16X24	EA
14-0232	bolt,3/8X24	EA
14-0233	bolt,3/8X24 UNF	EA
14-0234	bolt,3/8 UNF	EA
14-0235	bolt,3/8x24UNF	EA
14-0236	bolt,3/8 UNF	EA
14-0237	bolt,3/8 UNF	EA
14-0238	bolt,3/8x24	EA
14-0239	bolt,3/8 UNF	EA

14-0240	bolt,3/8 UNF	EA
14-0241	bolt,3/8X24UNF*	EA
14-0241/SS	bolts,cyl.head,stainless	ST
14-0242	bolt,3/8x24	EA
14-0246	bolt,7/16UNF	EA
14-0251	bolt,7/16 UNF	EA
14-0252	bolt,7/16UNF	EA
14-0254	bolt,7/16X20	EA
14-0259	bolt,1/2X20 UNF	EA
14-0261	USE 14-0262	ea
14-0262	bolt,1/2 UNF	EA
14-0301	nut,1/4UNF plain	EA
14-0302	nut,5/16UNF plain*	EA
14-0303	nut,3/8UNF plain	EA
14-0303/SS	nut,3/8 UNF,stainless	EA
14-0304	nut,7/16x20UNF,plain	EA
14-0305	nut,1/2x20 UNF	EA
14-0401	nut,1/4UNF,plain,thin	EA
14-0402	nut,5/16UNF,plain,thin	EA
14-0402/A	nuts,5/16UNF,light alloy,3cyl.	ST
14-0402/B	nuts,5/16UNF,light alloy,twin	ST
14-0403	nut,3/8 UNF,thin	EA
14-0404	nut,7/16x20,thin	EA
14-0405	nut,1/2x20,thin	EA
14-0503	screw,1/4x28	EA
14-0604	screw,1/4X28	EA
14-0605	USE 14-2205	ea
14-0609	screw,1/4 UNF	EA
14-0620	USE 14-6620	ea
14-0701	nut,1/4 UNF lock,thin	EA
14-0702	nut,5/16UNF,lock,thin	EA
14-0703	nut,3/8 UNF lock, thin*	EA
14-0801	USE 14-1901	ea
14-0802	USE 14-1902	ea
14-0803	USE 14-1903	ea
14-0804	USE 14-1904	ea
14-0901	USE 14-1901	ea
14-0902	USE 14-1902	ea
14-1019	bolt,5/16 UNF,allen head	EA
14-1022	bolt,5/16X24,allen head	EA
14-1034	bolt,3/8 UNF,allen head	EA
14-1051	bolt,7/16x20,allen	EA
14-1201	nut,1/4x28 UNF,lock	EA
14-1202	nut,5/16UNF,lock,thin	EA
14-1203	nut,3/8x24 UNF lock*	EA
14-1204	nut,7/16x20 lock,thin	EA
14-1301	nut,1/4x28 UNF,lock	EA
14-1302	USE 14-1202	ea
14-1303	USE 14-1203	ea
14-1304	USE 14-1204	ea
14-1305	nut,1/2x20UNF,lock*	EA
14-1306	nut,9/16x18,lock	EA
14-1307	nut,5/8x18,lock	EA
14-1401	stud,1/4"UNFxUNC	EA
14-1427	stud,5/16"UNF X UNC	EA
14-1431	stud,5/16UNFxUNC	EA
14-1435	stud,3/8x16x24	EA
14-1445	stud,3/8"X16X24	EA
14-1467	USE 14-1427	ea
14-1619	stud,5/16X18X24	EA
14-1620	USE 06-3383	ea
14-1621	stud,5/16X18X24	EA
14-1623	USE 14-0221	ea
14-1627	stud,5/16X18X24	EA
14-1635	stud,3/8x16x24	EA
14-1803	USE 14-1903	ea
14-1804	USE 14-1904	ea
14-1901	nut,1/4 UNF,lock	EA
14-1902	nut,5/16x24 UNF,lock	EA
14-1903	nut,3/8x24,lock	EA
14-1904	nut,7/16x20,lock	EA

14-2203	screw,1/4x28UNF	EA
14-2204	screw,1/4x28,philip	EA
14-2205	screw,1/4x28 UNF,chrome	EA
14-2219	screw,5/16UNF,philip	EA
14-6101	bolt,1/4X20	EA
14-6102	bolt,1/4UNC*	EA
14-6103	bolt,1/4X20*	EA
14-6104	bolt,1/4x20	EA
14-6107	USE 14-6102*	ea
14-6113	bolt,5/16x26,UNC	EA
14-6114	bolt,5/16 UNC	EA
14-6115	bolt,5/16X18	EA
14-6211	bolt,1/4"UNC	EA
14-6217	bolt,5/16x18UNC	EA
14-6218	bolt,5/16UNC	EA
14-6219	bolt,5/16 UNC	EA
14-6220	bolt,5/16x18	EA
14-6221	bolt,5/16 UNC	EA
14-6222	bolt,5/16X18UNC	EA
14-6223	bolt,5/16 UNC	EA
14-6226	bolt,5/16x18	EA
14-6242	bolt,3/8x16UNC	EA
14-6301	USE 06-0355	ea
14-6504	screw,1/4x20,countersunk	EA
14-6505	screw,1/4UNC,counter sunk*	EA
14-6509	screw,1/4x20,countersunk	EA
14-6515	screw,1/4"UNC,countersunk	EA
14-6605	screw,1/4x20UNC	EA
14-6606	screw,1/4x20	EA
14-6607	screw,1/4 UNC	EA
14-6608	screw,1/4x20,philip	EA
14-6609	screw,1/4 UNC	EA
14-6610	screw,1/4x20	EA
14-6611	bolt,1/4x20,Phillips	EA
14-6612	screw,1/4x20	EA
14-6613	screw,1/4 UNC	EA
14-6614	screw,1/4x20	EA
14-6615	screw,1/4x20	EA
14-6620	screw,5/16x18UNC,philip	EA
14-6623	bolt,5/16UNC	EA
14-7004	bolt,1/4x20,allen head	EA
14-7006	bolt,1/4x20,allen head	EA
14-7007	bolt,1/4 UNC,allen head	EA
14-7008	bolt,1/4 UNC,allen head	EA
14-7013	bolt,1/4 UNC,allen head	EA
14-7017	bolt,5/16UNC,allen head	EA
14-7018	bolt,5/16X18,allen head	EA
14-7019	bolt,5/16UNC,allen head	EA
14-7020	bolt,5/16X18,allen head	EA
14-7023	bolt,5/16UNC,allen hd	EA
14-7024	bolt,5/16UNC,allen head	EA
14-7804	screw,1/4UNC	EA
14-7805	screw,1/4x20UNC,philips	EA
14-7806	screw,1/4x20UNC,philips	EA
14-7819	USE 21-2025	ea
15-	TRIUMPH AND BSA PARTS	*
15-----	-----	---
15-0039	washer,1/2"flat	EA
15-0152	USE 06-7664	ea
15-0203	washer,fibre	EA
15-0431	USE 60-2323	ea
15-0447	nut,1/4x26,special	EA
15-0645	USE 57-0361	ea
15-0734	nut,7/16x20 BSC	EA
15-0804	washer*	EA
15-1560	sprocket,eng,4 lobe,21T	EA
15-1561	sprocket,eng,4 lobe,22T	EA
15-1562	sprocket,eng,4 lobe,23T	EA
15-1564	sprocket,eng,4 lobe,20T	EA
15-1565	sprocket,eng,4 lobe,19T	EA
15-1566	sprocket,eng,4 lobe,18T	EA

15-1567	sprocket,eng,4 lobe,17T	EA
15-1568	sprocket,eng,4 lobe,16T	EA
15-1569	sprocket,eng,4 lobe,25T	EA
15-2018	USE 82-2596	ea
15-2419	clutchplates,"FERODO" type,M20,etc.	EA
15-4179	kickstart crank assy,non-folding,chrome*	EA
15-4260	mainshaft,early B31/2/3/4	EA
15-5153	USE 97-2656	ea
15-5155	USE 82-8981	ea
15-5290	grease nipple,Tecalemit	EA
15-5753	USE 29-0905	ea
15-7563	USE 82-9092	ea
19-	NORTON,TRIUMPH &BSA PARTS	*
19-----	-----	--
19-0016	USE separate components	ea
19-0100	USE 341-3858	ea
19-0104	USE 341-3858	ea
19-0112	USE 341-3857	ea
19-0140	USE 341-3858 *	ea
19-0166	USE 393-S3611	ea
19-0192	USE 391-34289	ea
19-0198	USE 393-S0089	ea
19-0214	USE 341-3857	ea
19-0610	USE 391-534343	ea
19-0649	USE 391-36084*	ea
19-0701	USE 391-553248	ea
19-0706	USE 391-31563	ea
19-0709	USE 391-31563	ea
19-0738	USE 391-54525272	ea
19-0781	USE 391-34289	ea
19-0782	USE 391-34427	ea
19-0868	USE 391-36403	ea
19-0897	USE 345-1291	ea
19-0916	USE 391-34815	ea
19-0943	USE 391-57111	ea
19-0944	USE 391-57162	ea
19-0947	USE 345-1292	ea
19-0953	USE 391-33188	ea
19-0963	USE 391-36403	ea
19-0964	USE 391-31788	ea
19-0965	USE 391-38189	ea
19-0968	USE 345-1173	ea
19-0979	USE 345-1218	ea
19-0982	USE 391-38191	ea
19-0986	USE 345-1457 or 1498*	ea
19-0987	USE 391-57161	ea
19-1000	USE 391-53454	ea
19-1011	USE 391-53454	EA
19-1018	USE 393-S3611	ea
19-1024	USE 393-S3611	ea
19-1035	USE 391-57162 & 82-8271	ea
19-1064	USE 392-446	ea
19-1067	USE 391-56605	ea
19-1079	USE 391-35048	ea
19-1087	USE 391-31356	ea
19-1088	USE 391-54525272	ea
19-1095	USE 391-31356	ea
19-1099	USE 345-1013	ea
19-1106	USE 391-34755	ea
19-1123	USE 391-31827	ea
19-1124	USE 391-34257	ea
19-1125	USE 391-34448	ea
19-1150	USE 391-31563	ea
19-1152	USE 391-35835	ea
19-1153	USE 391-380459	ea
19-1164	USE 391-36421	ea
19-1166	USE 391-54953389	ea
19-1167	USE 392-233	ea
19-1178	USE 345-1218	ea
19-1191	USE 391-60600621	ea
19-1245	USE 391-53973	ea

19-1249	USE 391-188218	ea
19-1260	USE 391-60600684	ea
19-1262	USE 391-47205	ea
19-1269	USE 391-30552	ea
19-1280	USE 345-1012	ea
19-1281	USE 345-1015	ea
19-1288	USE 391-60600684	ea
19-1304	USE 345-1284	ea
19-1312	USE 345-1172	ea
19-1323	USE 345-1499	EA
19-1324	USE 345-1173	ea
19-1333	USE 391-39595	ea
19-1334	USE 391-54033666	ea
19-1335	USE 391-54340881	ea
19-1337	USE 391-54033667	ea
19-1338	USE 391-57160	ea
19-1345	USE 391-57183	ea
19-1348	USE 391-54959626	ea
19-1349	USE 391-54524048	ea
19-1371	USE 391-39596 *	ea
19-1373	USE 391-39595	ea
19-1472	USE 391-76204	ea
19-1473	USE 391-170109	ea
19-1492	USE 391-200380	ea
19-1515	USE 391-37144	ea
19-1577	USE 60-2331	ea
19-1665	USE 391-37225	ea
19-1666	USE 391-31763	ea
19-1684	USE 391-54415803	ea
19-1685	USE 391-425377	ea
19-1693	USE 391-37221	ea
19-1711	USE 391-45149	ea
19-1715	USE 391-49072	ea
19-1735	USE 391-49345	ea
19-1747	USE 391-60410181	ea
19-1775	USE 391-30608	ea
19-1776	USE 335-02 *	ea
19-1841	USE 391-54425160*	ea
19-1842	USE 391-54426429	ea
19-1845	USE 345-1233	ea
19-1847	USE 391-54420128	ea
19-1848	USE 391-54418528	ea
19-1849	USE 391-54419827	ea
19-1853	USE 391-54427182	ea
19-1854	USE 391-45110	ea
19-1861	USE 391-54418526	ea
19-1863	USE 391-54419327	ea
19-1864	USE 391-54419867	ea
19-1904	USE 391-39565	ea
19-1939	USE 345-1181	ea
19-1958	USE 391-54417992	ea
19-1961	USE 391-30781	ea
19-1962	USE 345-1066	ea
19-1964	USE 391-45276	ea
19-1965	USE 391-30707	ea
19-2002	USE 391-54068034/ER	ea
19-2012	USE 391-76204	ea
19-2016	USE 391-54068034	ea
19-2061	USE 391-70276 *	ea
19-2064	USE 391-70276*	ea
19-2086	USE 391-70276	ea
19-2107	USE 572-S5463L	ea
19-2432	USE 691-R928/300 *	ea
19-2452	USE 691-L930/93	ea
19-2453	USE 691-R930/92	ea
19-2454	USE 691-R930/94orR930/300	ea
19-2873	USE 691-376100/130	ea
19-2874	USE 691-376100/140	ea
19-2878	USE 691-376100/180	ea
19-2879	USE 691-376100/190	ea
19-2880	USE 691-376100/200	ea

19-2883	USE 691-376100/230	ea
19-2885	USE 691-376100/250	ea
19-2886	USE 691-376100/260	ea
19-3048	USE 691-376093	ea
19-3090	USE 691-622101	ea
19-3093	USE 691-622086	ea
19-3095	USE 691-622067	ea
19-3105	USE 691-622197	ea
19-3106	USE 691-622073	ea
19-3109	USE 691-928062	ea
19-3129	USE 691-622060/3.5	ea
19-3136	USE 691-622122/106	ea
19-3137	USE 691-622124	ea
19-3138	USE 691-622060/2.5	ea
19-4590	USE 99-1179	ea
19-4595	USE 99-1182	ea
19-4700	USE 99-7022	ea
19-5303	USE 543-64533645	ea
19-5305	USE 543-64533645	ea
19-5307	USE 543-54533654	ea
19-5593	USE 633-01	ea
19-5599	USE 512-3001	ea
19-5611	USE 512-3001	ea
19-5619	USE FS881	ea
19-5620	USE FS882	ea
19-5625	USE FS887	ea
19-5628	USE FS890	ea
19-5636	USE FS898	ea
19-5637	USE FS899	ea
19-5641	USE FS903	ea
19-5652	USE FS914	ea
19-5659	USE FS921	ea
19-5660	USE FS922	ea
19-5662	USE FS924	ea
19-5663	USE FS925	ea
19-5685	USE FS947	ea
19-5688	USE FS950	ea
19-5694	USE 391-54335169*	ea
19-5715	USE 551-997	ea
19-6048	USE 512-3003	ea
19-6049	USE 512-196050	ea
19-6504	USE 60-2133	ea
19-6508	USE 60-2133	ea
19-6901	oring,caliper seal,betw.halves	EA
19-7108	USE 691-2441048	ea
19-7115	USE 633-01	ea
19-7119	USE 551-983 (set)	ea
19-7203	USE 522-366011/012 (pr)	ea
19-7206	USE 522-366011/012 (pr)	ea
19-7221	USE 522-01 (set)	ea
19-7222	USE 522-01 (set)	ea
19-7227	USE 523-16009	ea
19-7405	USE 543-6210 *	ea
19-7418	USE 543-6213 (pair) *	ea
19-7420	USE 543-6210 *	ea
19-7429	USE 543-6210 *	ea
19-7448	USE 543-6213	ea
19-7452	USE 543-6210 (pair)	ea
19-7461	USE 543-64533645	ea
19-7466	USE 551-2030 (set)	ea
19-7472	USE 543-6214 (pr)	ea
19-7602	USE 336-L86	ea
19-7621	USE 345-10/C	ea
19-7700	USE 15-2419	ea
19-7707	USE 551-10511 (set)	ea
19-7708	USE 551-1027 (set)	ea
19-7710	USE 551-1008 (set)	ea
19-7711	USE 551-2031 (set)	ea
19-7713	USE 551-2031 (set)	ea
19-7716	USE 551-946 (set)	ea
19-7717	USE 551-946 (set)	ea

19-7718	USE 551-983	ea
19-7719	USE 551-983	ea
19-7720	USE 551-10581 (set)	ea
19-7726	USE 19-7738	ea
19-7732	USE 551-2009	ea
19-7734	USE 551-2009	ea
19-7735	USE 555-1095	ea
19-7736	brklinings,undrilled,7"DLS	PR
19-7738	brklinings,undrilled,BantamF&R	PR
19-7740	USE 551-2031 (set)	ea
19-7744	USE 37-3713	ea
19-7745	USE 37-3714	ea
19-7802	USE 57-3708	ea
19-7803	USE 57-3709	ea
19-7804	USE 57-3715	ea
19-7805	USE 57-3718	ea
19-7806	USE 57-3719	ea
19-7807	USE 57-3720	ea
19-7808	USE 06-5542	ea
19-7809	USE 57-3709/C	ea
19-8016	USE 391-47204	ea
19-8018	USE 391-47204	ea
19-8019	USE 391-60600684	ea
19-8023	USE 391-47197	ea
19-8024	USE 391-47197	ea
19-8027	USE 391-47204	ea
19-8113	USE 391-425379	ea
19-8301	USE 221-400935	ea
19-8613	USE 552-114038/70	ea
19-8639	USE 552-116038/80	ea
19-8683	USE 552-114038/72	ea
19-8687	USE 552-110054/110*	ea
19-8692	USE 552-116038/82	ea
19-9076	USE 571-33/A	ea
19-9080	USE 572-03	ea
19-9086	USE 571-69/A*	ea
19-9089	USE 571-63/A *	ea
19-9090	USE 571-69/A *	ea
19-9091	USE 571-25/C	ea
19-9095	USE 571-63/A *	ea
19-9098	USE 571-67/A	ea
19-9101	USE 391-54959626	ea
19-9103	USE 571-31/A	ea
19-9110	USE 571-32/F	ea
19-9217	USE 572-BG5330171	ea
19-9225	USE 571-BG5330164	ea
21-	NORTON, TRIUMPH &BSA PARTS	*
21-----	-----	---
21-0064	USE 21-0649	ea
21-0066	USE 60-4253	ea
21-0151	nut,5/16x26*	EA
21-0152	USE 60-4261	ea
21-0357	USE 60-3552	ea
21-0501	nut,4BA,lock	EA
21-0536	plug,drain,3/8 UNC	EA
21-0541	bolt,kickstart pedal,UNF	EA
21-0542	nut,1-1/4X28UNF	EA
21-0543	bolt,1/4x28 level plug	EA
21-0544	nut,5/16 UNF,acorn*	EA
21-0545	USE 21-0594	ea
21-0547	stud,1/4x28x20	EA
21-0548	stud,7/16X20*	EA
21-0549	nut,5/16UNF,conrod,6 point*	EA
21-0550	nut,3/8UNF,acorn,rocker feed*	EA
21-0557	stud,1/4xUNF/UNC	EA
21-0559	screw,3BA	EA
21-0567	nut,1/2 UNC	EA
21-0571	stud,7/16UNF	EA
21-0572	stud,5/16x20UNF	EA
21-0578	bolt,1/4 UNF,retaining*	EA
21-0579	bolt,5/8X18, special	EA

21-0580	bolt,5/8x18,swingarm	EA
21-0582	stud,5/16 UNF X UNC	EA
21-0583	bolt,7/16x20UNF	EA
21-0585	nut,3/4UNF	EA
21-0586	nut,9/16X20 lock,clutch	EA
21-0588	bolt,7/16UNF	EA
21-0589	bolt,5/16x24UNF,zinc	EA
21-0589/CHR	bolt,5/16 UNF,chrome	EA
21-0590	bolt,1/4x28	EA
21-0591	USE 21-0620	ea
21-0594	nut,9/16x18 UNF	EA
21-0602	washer,1/4",flat	EA
21-0620	bolt,swingarm pivot	EA
21-0621	bolt,1/4X28	EA
21-0644	bolt,5/16 UNF*	EA
21-0649	screw,4BA	EA
21-0650	screw	EA
21-0653	USE 83-0222	ea
21-0669	stud,5/16UNF	EA
21-0678	bolt,5/16UNC,allen head	EA
21-0680	screw,3/16X24,countersunk	EA
21-0681	nut,9/16X20	EA
21-0683	USE 83-0033	ea
21-0684	bolt,3/8UNF,pinch	EA
21-0685	nut,3/8x24UNF,spherical	EA
21-0686	stud,3/8	EA
21-0692	nut,3/8UNF,12point*	EA
21-0755	nut,3/4 UNF	EA
21-0761	screw,1/4x28UNF	EA
21-0762	screw,2BA	EA
21-0767	screw,1/4 UNF	EA
21-0774	screw,10-32 phillip,selftap	EA
21-0778	nut,2BA,lock	EA
21-0779	stud,7/16X20UNF,fr.eng.mt.	EA
21-0779/SS	stud,7/16X20UNF,stainless	EA
21-0785	bolt,3/8 UNF*	EA
21-1051	USE 00-0004	ea
21-1052	USE 60-4261	ea
21-1800	USE 14-0145	ea
21-1801	stud,3/8x24	EA
21-1802	bolt,7/16X20	EA
21-1804	USE 97-3894	ea
21-1809	nut,1/4x28 acorn*	EA
21-1811	screw,1/4x28,countersunk	EA
21-1813	stud,5/16UNFxUNC	EA
21-1819	bolt,5/16x18,allen head	EA
21-1822	bolt,5/16x24	EA
21-1823	bolt,5/16 UNF	EA
21-1827	USE 21-1992	ea
21-1832	USE 14-2205	ea
21-1833	nut,7/16UNF,thin	EA
21-1837	USE 14-0604	ea
21-1845	stud,5/16UNFxUNC	EA
21-1846	stud,5/16,stepped	EA
21-1848	stud,1/4UNFxUNC	EA
21-1849	stud,5/16x18x24	EA
21-1850	stud,5/16UNF/UNC	EA
21-1852	nut,5/16UNF,lock,smallHex	EA
21-1854	screw,1/4x20	EA
21-1856	USE 14-7804	ea
21-1857	plug,drain	EA
21-1863	stud,oil feed junction	EA
21-1864	stud,1/4x20x28	EA
21-1865	stud,3/8UNCxUNF,cyl.base	EA
21-1866	stud,stator,long,UNF/UNC	EA
21-1867	stud,stator,short,UNF/UNC	EA
21-1869	bolt,5/16 UNC	EA
21-1870	bolt,5/16 UNC	EA
21-1871	bolt,LHthr,tachdrive hole*	EA
21-1872	bolt,drain&timing plug,coarse	EA
21-1872/A	bolt,drain,stainless,magnetic	EA

21-1873	screw,1/4 UNC	EA
21-1875	bolt,1/4x20UNC	EA
21-1875/A	bolt,1/4x20,allen head	EA
21-1875/SS	bolt set,r.box,stainless	ST
21-1876	stud,1/4UNFxUNC	EA
21-1877	nut,1/4x28,small hex	EA
21-1878	screw,1/4UNC	EA
21-1879	screw,countersunk	EA
21-1883	stud,5/16 UNF	EA
21-1890	stud,5/16x18x24	EA
21-1892	bolt,5/16x18,small hex	EA
21-1893	stud,1/4UNFxUNC	EA
21-1894	stud,stator,unit singles	EA
21-1895	stud,stator,unit singles	EA
21-1903	bolt,5/16x18,in.manifold	EA
21-1906	nut,1/4UNF,oilpump mtg	EA
21-1907	bolt,5/16X18,small hex*	EA
21-1908	nut,5/16UNF tall,stator	EA
21-1910	bolt,3/8x24	EA
21-1912	stud,3/8UNFxUNC,stepped	EA
21-1914	nut,3/4x20,rotor,350/500	EA
21-1915	nut,UNF,rotor,unit 500	EA
21-1916	screw,1/4x20	EA
21-1917	screw,1/4UNC	EA
21-1918	screw,1/4UNC	EA
21-1919	bolt,5/16x18	EA
21-1920	bolt,1/4x20,slotted	EA
21-1921	stud,3/8UNFxUNC,cyl.base	EA
21-1922	stud,3/8UNFxUNC,cyl.base	EA
21-1925	stud,5/16x18x24	EA
21-1926	NOT REQUIRED	ea
21-1927	stud,5/16UNF/UNC	EA
21-1928	stud,1/4UNFxUNC	EA
21-1929	screw,1/4x20UNC,flathead	EA
21-1930	screw,10-32,philip	EA
21-1931	stud,3/8 UNFxUNC	EA
21-1932	nut,UNC,intake manifold	EA
21-1933	nut,5/16UNF,extended	EA
21-1940	screw,4BA	EA
21-1943	bolt,5/16x18,drainplug	EA
21-1951	screw,1/4x20	EA
21-1964	stud,7/16UNFxUNC	EA
21-1969	bolt,1/2UNF	EA
21-1971	bolt,pivot,footpeg,UNF	EA
21-1973	bolt,5/16 UNC	EA
21-1978	bolt,7/16UNF,centrestand	EA
21-1979	USE 21-0767	ea
21-1992	bolt,9/16UNF,swingarm,A50/65	EA
21-1993	bolt,gas tank,special	EA
21-1995	nut,3/4x20	EA
21-1996	stud,shouldered,intake manifold	EA
21-1998	screw,selftapping	EA
21-1999	nut,5/16UNF,shouldered	EA
21-2000	stud,3/8UNFxUNC,cyl.base	EA
21-2001	stud,3/8UNFxUNC,stepped	EA
21-2002	USE 14-7804	ea
21-2004	stud,3/8UNF	EA
21-2005	stud,5/16UNF	EA
21-2006	stud,5/16 UNF	EA
21-2007	bolt,5/16UNF?	EA
21-2008	stud,3/8UNF	EA
21-2009	stud,5/16UNF	EA
21-2010	bolt,1/4x28*	EA
21-2011	bolt,5/16UNF	EA
21-2012	nut,7/16x20	EA
21-2013	nut,3/4x20UNEF	EA
21-2014	nut,3/4x20	EA
21-2016	nut,5/16UNF,conrod,6 point*	EA
21-2019	stud,5/16UNF,stepped	EA
21-2024	stud,5/16UNF*	EA
21-2025	stud,5/16UNFxUNC	EA

21-2045	bolt,pivot,brake pedal	EA
21-2048	screw,pivot,control lever*	EA
21-2062	nut,3/8 UNF sleeve,chrome	EA
21-2064	screw,8-32,tank badge	EA
21-2066	nut,5/8x18,clutch	EA
21-2077	bolt,stepped,centrestand	EA
21-2079	screw,10-32	EA
21-2083	stud,5/16UNF,engine mount	EA
21-2087	bolt,5/8UNF,swingarmpivot	EA
21-2091	USE 21-2158	ea
21-2095	bolt,2BA	EA
21-2096	"U"bolt,skidplate	EA
21-2102	stud,5/16x18x24	EA
21-2109	stud,5/16UNF	EA
21-2112	bolt,7/16UNF	EA
21-2113	USE 21-2112 *	ea
21-2114	stud,3/8UNF	EA
21-2120	bolt,10-32	EA
21-2124	USE 453-12 *	ea
21-2125	USE 453-12	ea
21-2139	screw,1/4UNC	EA
21-2149	stud,5/16 UNF/UNC	EA
21-2157	bolt,1/4UNF	EA
21-2158	stud,7/16UNF	EA
21-2162	screw,1/4UNC	EA
21-2177	nut,5/16x24*	EA
21-2182	nut,7/16x20UNF,rotor	EA
21-2183	stud,7/16x20,rotor	EA
21-2185	stud,7/16x20,rotor	EA
21-2186	screw,2BA,finned clip	EA
21-2189	stud,caliper mounting	EA
21-2191	screw,1/4UNF,pivot,control lever	EA
21-2192	screw,10-24,console*	EA
21-2192/2194/SS	screw set,m.cyl,pre79 Tri	ST
21-2194	screw,10-24*	EA
21-2196	screw,countersunk	EA
21-2197	stud	EA
21-2198	stud,stator,short,T140	EA
21-2199	stud,stator,long,T140	EA
21-2200	stud,5/16,cyl.to head*	EA
21-2201	stud,3/8UNF	EA
21-2204	nut,3/8UNF,allen head	EA
21-2205	nut,5/16UNF,allen head	EA
21-2206	bolt,3/8UNF	EA
21-2207	bolt,3/8UNF	EA
21-2225	stud,tailight housing,73on	EA
21-2230	screw,2BA	EA
21-2309	USE 71-0003	ea
21-2310	screw,2BA	EA
21-2315	screw,retaining,steering lock*	EA
21-2318	USE 14-1051	ea
21-2335	USE 21-2196	ea
21-2341	stud,3/8UNFxUNC	EA
21-2813	USE 71-2813	ea
21-5102	USE 82-0879	ea
21-5160	USE 97-0745	ea
21-5161	nut,2BA,plain	EA
21-5370	bolt,2BA	EA
21-5370/SS	bolt,2BA,stainless	EA
21-5371	screw	EA
21-5375	screw,2BA,slotted	EA
21-5662	bolt,5/16x22*	EA
21-6050	bolt,5/16x22	EA
21-6187	screw,1/4x26	EA
21-6204	USE 70-7354	ea
21-6206	screw,2BA*	EA
21-7001	pivot,pass.peg mt,LH	EA
21-7002	pivot,pass.peg mt,RH	EA
21-7004	bolt,7/16x20,shoulder	EA
21-7005	USE 21-7041	ea
21-7006	nut,5/16UNF,shouldered	EA

21-7007	bolt,5/16, special	EA
21-7008	washer, stopswitch screw	EA
21-7009	nut,2BA, plain	EA
21-7010	screw,brake switch	EA
21-7020	nut, spire, sidepanel	EA
21-7022	nut, extended	EA
21-7024	washer, locking, rotor, 3/4"	EA
21-7025	washer, nylon 1/4"	EA
21-7026	USE 21-7001 *	ea
21-7027	USE 21-7002 *	ea
21-7028	screw, 1/4x26, grub	EA
21-7030	washer, 1/4", flat	EA
21-7036	screw, pivot	EA
21-7038	screw	EA
21-7041	bolt, 3/8x24	EA
21-7042	bolt, 5/16x24UNF	EA
21-7043	bolt, 5/16x24UNF	EA
21-7047	bolt, 3/8x24UNF	EA
21-7048	screw, black, tankbadge	EA
21-7050	nut, 1/4UNF, lock, thin	EA
21-7064	bolt, 1/4UNF	EA
21-7067	bolt, 5mm, allen hd, switch	EA
21-7068	bolt, 5mm, allen hd, switch	EA
21-7069	bolt, 4mm, allen hd, switch	EA
21-7072	nut, 5/8x18, mainshaft RH, lateT140E	EA
21-7073	washer, clutch centre, late T140	EA
21-7085	bolt, 3/8UNF	EA
21-7091	nut, 5/16x24 UNF, lock	EA
21-7114	USE 21-7139	ea
21-7139	nut, sidepanel mtg, T140ES	EA
22-	TRIUMPH PARTS	*
22-----	-----	--
22-0002	USE 57-1257	ea
22-0013	USE 391-54115106/CHR	ea
22-0040	bolt, 5/16x24, chrome, hdlgt	EA
23-	TRIUMPH PARTS	*
23-----	-----	--
23-1012	bolt, 3/16x32	EA
23-1015	bolt, 3/16x32	EA
23-1555	washer	EA
23-2001	nut, 3/16x32	EA
23-2161	nut, 3/16x32, lock	EA
24-	BSA PARTS	*
24-----	-----	--
24-0036	USE 00-0203	ea
24-0124	USE 37-2332	ea
24-0195	USE 391-173974	ea
24-0563	USE 70-0470	ea
24-0722	bearing, roller	EA
24-0724	USE 70-9974	ea
24-0732	USE 70-8003	ea
24-0978	USE 60-2427	ea
24-1088	USE 60-4263	ea
24-4065	USE 70-9494	ea
24-4217	USE 60-3552	ea
24-4227	USE NM24562	ea
24-4263	washer, tab, gbx. sprocket	EA
24-4393	clutch dog, sliding	EA
24-5160	USE 70-8196	ea
24-5610	USE 00-0004	ea
24-6035	washer, 5/16 double spring	EA
24-6040	USE 00-0074	ea
24-6790	washer, felt	EA
24-7000	USE 37-2325	ea
24-7012	USE 553-68/SS (set)	ea
24-7058	bearing, tapered roller	EA
24-7065	screw	EA
24-7068	USE 82-9172	ea
24-7148	USE 06-7635	ea
24-7178	screw, 1/4CEI	EA
24-7343	USE 70-3872	ea

24-8504	USE 82-9204	ea
24-8784	USE 60-4260	ea
24-8928	clip	EA
24-8931	USE 552-110046/68	ea
24-8932	USE 552-110046/80 *	ea
25-	BSA PARTS	*

25-5247	washer,star,steering damper	EA
26-	BSA PARTS	*

26-0650	USE 422-1414	ea
27-	BSA PARTS	*

27-1386	key,woodruff	EA
27-5135	USE 97-2645	ea
27-5156	USE 70-4165	ea
27-5676	USE 82-9046	ea
27-6275	USE 70-3812 *	ea
27-6276	USE 70-3812	ea
27-6808	USE 06-2595	ea
27-6810	USE 37-2294	ea
27-6812	USE 06-2595	ea
27-6813	USE 37-2294	ea
27-8059	USE 68-4085	ea
27-8560	USE 21-0602	ea
28-	BSA PARTS	*

28-0243	plug,drain,gbx,5/16x18	EA
28-2080	USE 37-2326	ea
28-2338	USE 82-9023	ea
28-5839	USE 82-9050	ea
29-	BSA PARTS	*

29-0410	collet, valve,A7/A10 type	EA
29-0541	USE 60-2427	ea
29-0905	nut,1/2x20	EA
29-0925	USE 60-4253	ea
29-1970	oilseal,crankshaft,LH	EA
29-1996	oilseal,cam,C11-C12,late	EA
29-2023	nut,5/8x20,A50&A65 alt.rotor*	EA
29-2024	USE 70-8043	ea
29-2053	USE 70-8146	ea
29-2054	USE 70-8043	ea
29-2089	USE 70-8110	ea
29-2975	USE 711-Z638/A	ea
29-3250	USE 532-11	ea
29-3307	spring,kick,C10/11/12	EA
29-3319	USE 60-4256	ea
29-3404	pawl carrier,gbx,C10/11	EA
29-3449	gasket,insp,gbx.	EA
29-3467	pressure plate,cl,C10/11/12	EA
29-3476	USE 67-3242	ea
29-3781	mainshaft	EA
29-3832	USE 65-3824	ea
29-3857	USE 57-0665	ea
29-5126	cowl	EA
29-5273	forktube,C11/12	EA
29-5283	USE 97-2710	ea
29-5289	USE 97-2673	ea
29-5293	USE 65-0109	ea
29-5310	forkseal holder,pre69 BSA,long*	EA
29-5310/ER	forkseal holder,pre69 BSA,long*	EA
29-5313	USE 97-2641	ea
29-5315	USE 97-2646	ea
29-5320	circlip,forks	EA
29-5335	USE 417-02 (set)	ea
29-5336	USE 417-02 (set)	ea
29-5337	USE 417-02 (set)	ea
29-5338	USE 97-2640	ea
29-5346	USE 97-2637/2638*	ea
29-5347	USE 97-2637/2638 (set)	ea

29-5776	rim,WM1x19,F&R,C10/11	EA
29-5839	USE 82-9050	ea
29-5850	brakeshoes,C10/11,fr&rear	PR
29-5852	USE 29-5850 (shoes complete)	ea
29-5871	USE 60-0963	ea
29-5991	rim,WM1x19,F&R,C12,56-58	EA
29-6187	bolt,5/16x26,special	EA
29-6238	USE 29-2023	ea
29-6554	bracket,fenderstay	EA
29-7368	USE 82-9039	ea
29-7549	footpeg assy,RH	EA
29-7551	USE 532-04	ea
29-7558	USE 68-4829	ea
29-7559	USE 68-4829	ea
29-7561	USE 68-4829	ea
29-7579	USE 42-4845	ea
29-7580	USE 42-4845	ea
29-7581	USE 83-7059	ea
29-7583	USE 532-38	ea
29-7796	USE 41-0639	ea
29-7868/7869	plates,kneepad mtg	PR
29-7898	USE 622-04	ea
29-7910	badge,tank,BSA preunit	EA
29-7962	USE 82-9071	ea
29-7971	USE 82-9070	ea
29-8813	USE 60-7026 & 14-1901	ea
29-8814	USE 523-18053	ea
29-9252	USE 221-15	ea
30-	BSA PARTS	*
30-----	-----	--
30-0729	washer,flat	EA
30-0733	USE 82-9010	ea
31-	TRIUMPH AND BSA PARTS	*
31-----	-----	--
31-0222	USE 70-8012	ea
35-	BSA PARTS	*
35-----	-----	--
35-0033	USE 60-4260	ea
35-4224	USE 82-8998	ea
35-5016	USE 15-5290	ea
35-6436	rivet,brake lining	EA
36-	TRIUMPH AND BSA PARTS	*
36-----	-----	--
36-0382	USE 70-2287	ea
36-0481	USE 06-3544	ea
36-4140	rubber,tank mt.	EA
37-	NORTON,TRIUMPH &BSA PARTS	*
37-----	-----	--
37-0005	nut,9/16x20,special	EA
37-0007	bearing,taper roller	EA
37-0011	pin,pivot,brakearm,no lip	EA
37-0062	USE 37-1690	ea
37-0063	washer,tab,brake drum	EA
37-0076	nut,3/8x26,thin	EA
37-0079	rim,WM2x19,pre con.Tri.R	EA
37-0079/A	rim,WM2x19,precon.Tri.R,alloy,w/shoulder	EA
37-0079/SS	rim,WM2x19,pre con.Tri.R,stainless	EA
37-0093	USE 37-1406/1407 (set)	ea
37-0103	nut,1/4x26,small hex	EA
37-0129	rivet,brake lining	EA
37-0135	spring,brakeshoe	EA
37-0270	rim,WM3x19,pre con.Tri.R*	EA
37-0270/A	rim,WM3x19 alloy w/shoulder	EA
37-0270/SS	rim,WM3x19,pre con.Tri.R,stainless	EA
37-0311	USE 37-0951	ea
37-0328	USE 37-0328/0329 (set)	ea
37-0328/0329	adj&nut set,brake cable,at brake	ST
37-0329	USE 37-0328/0329 (set)	ea
37-0351	rim,WM2x19,front,TRW etc.	EA
37-0351/A	rim,WM2x19,fr,TRW etc,alloy w/shoulder	EA
37-0351/SS	rim,WM2x19,front,TRW etc,stainless	EA

37-0544	nut, 9/16x20, axle, front	EA
37-0578	axle, fr. wheel, SV500, etc.	EA
37-0582	retainer, wheel bearing	EA
37-0583	USE 37-1654	ea
37-0592	spring, brake arm	EA
37-0593	USE 524-600638	ea
37-0610	race, outer, sprung hub Mk1	EA
37-0611	race, inner, sprung hub Mk1	EA
37-0630	nut, 3/8x26, thin	EA
37-0631	USE 551-951	ea
37-0643	rim, WM2x19, sprung hub	EA
37-0643/SS	rim, WM2x19, sprung hub, stainless	EA
37-0653	bearing, ball *	EA
37-0660	USE 553-69/SS or 67/SS (kit) *	ea
37-0661	USE 553-69/SS or 67/SS (kit) *	ea
37-0680	circlip	EA
37-0784	bolt, 3/8x26, stepped	EA
37-0866	shim, sprung hub, 002	EA
37-0894	rim, WM3x19, sprung hub	EA
37-0894/SS	rim, WM3x19, sprung hub, stainless	EA
37-0897	bearing, ball, sprung hub	EA
37-0903	sprocket&drum, sprung hub Mk2	EA
37-0932	bolt, 1/4x26 *	EA
37-0933	USE 553-67/SS (kit) *	ea
37-0934	USE 553-67/SS (kit) *	ea
37-0951	USE 37-0951/46	ea
37-0951/43	sprock&brakedrum assy, 43T	EA
37-0951/46	sprock&brakedrum assy, 46T	EA
37-0977	brakeshoes, Cub & Bantam	PR
37-0978	USE 551-997 (set)	ea
37-0999	plate, chain adj, Cub	EA
37-1002	rim, WM1x19, F, Cub, 60on	EA
37-1007	rim, WM3x18, pre con. Tri. R.	EA
37-1007/A	rim, WM3x18 alloy, w/shoulder	EA
37-1007/SS	rim, WM3x18, pre con. Tri. R, stainless	EA
37-1015	washer, endplate, chain adj	EA
37-1021	lockring, wheelbearing	EA
37-1022	washer, wheel hub	EA
37-1024	spacer, R. wheel, LH	EA
37-1025	USE 37-1281	ea
37-1026	nut, 3/4x20	EA
37-1034	bearing, tapered roller	EA
37-1039	sleeve, brg, QD wheel, RH	EA
37-1040	USE 37-1040/46	ea
37-1040/43	sprocket&drum assy, QD, 43T	EA
37-1040/43/ER	sprocket& drum assy, QD, 43T, econo	EA
37-1040/46	sprocket&drum assy, QD, 46T	EA
37-1040/46/ER	sprocket&brakedrum assy, QD, 46T	EA
37-1041	bearing, ball, sealed	EA
37-1042	washer, felt	EA
37-1044	circlip, bearing retaining	EA
37-1045	sleeve, brg, QD wheel, LH	EA
37-1052	nut, QD rear axle	EA
37-1055	axle, QD rear, CEI	EA
37-1058	USE 37-1691	ea
37-1083	USE 37-3592	ea
37-1086/1087	brakeshoe set, 8" front	PR
37-1090	spring, brake oper arm	EA
37-1091	rubber sealing ring, QDhub	EA
37-1104	spoke, 19" rear drum, early	EA
37-1106	spoke, 19" rear drum, early	EA
37-1107	spoke, 18" rear drum, early	EA
37-1108	spoke, 18" rear drum, early	EA
37-1112	USE 37-3590	ea
37-1128	cam, brake oper, Cub	EA
37-1134	USE 37-2089 & 14-1902	ea
37-1135	USE 37-2087 & 14-1902 nut	ea
37-1143	washer, grease retainer	EA
37-1166	USE 553-69/SS (kit) *	ea
37-1167	USE 553-69/SS (kit) *	ea
37-1197	weight, wheel, light	EA

37-1198	weight,wheel,heavy	EA
37-1230	rim,WM2x19,fullwidth hub *	EA
37-1230/A	rim,WM2x19 F,alloy w/shoulder	EA
37-1230/SS	rim,WM2x19,fullwidth,stainless	EA
37-1236	spoke,straight	EA
37-1237	washer,cup,wheel brg.	EA
37-1238	washer,ring,wheel brg	EA
37-1239	axle,front	EA
37-1243	cam,brake oper,SLS	EA
37-1246	nut,11/16x20	EA
37-1257	USE 37-1237	ea
37-1270	spoke,17"R,T21	EA
37-1271	spoke,17"R,T21	EA
37-1272	USE 37-1435	ea
37-1274	rim,WM2X17,3TA front	EA
37-1275	spoke,17"F,T21	EA
37-1276	USE 37-0951/43	ea
37-1278	spacer tube,wheel brg	EA
37-1280	washer,5/8,flat	EA
37-1281	USE 37-3589	ea
37-1282	nut,3/4x20,rear axle	EA
37-1320	sprocket,Cub,46T	EA
37-1328	spoke,5-5/8" str,8/10G*	EA
37-1331	arm,brake oper,SLS	EA
37-1332	cover,8"fr.hub,9"dia,1 rib	EA
37-1332/A	cover,front hub,9"dia.w/indents	EA
37-1332/B	cover,8"fr.hub,9"dia,2 ribs	EA
37-1334	cover,front hub,8"od(7"drum)	EA
37-1334/A	cover,front hub,8"od(7"drum)w.indents	EA
37-1336	USE 551-10581 (set)	ea
37-1337/1338	USE 37-1410/1411	ea
37-1340	USE 37-7042	ea
37-1373	USE 37-1374	ea
37-1374	rim,WM2x18,fullwidth	EA
37-1374/A	rim,WM2x18 alloy,fullwidth,w/shoulder	EA
37-1374/SS	rim,WM2x18,fullwidth,stainless	EA
37-1376	USE 37-1040/43	ea
37-1378	USE 37-1471	ea
37-1390	sleeve,brg,QD wheel,RH	EA
37-1393	sleeve,brg,QD wheel,LH	EA
37-1406	brakeshoe,leading,nonconical,7"	EA
37-1406/1407	brakeshoe set,nonconical,7"	ST
37-1406/1407/ER	brakeshoe set,nonconical,econo	PR
37-1407	brakeshoe,trailing,nonconical,7"	EA
37-1410	brakeshoe,8" front *	EA
37-1410/1411	brakeshoe set,8" front,repl.	PR
37-1414	USE 551-10581 (set)	ea
37-1415	pad,brakeshoe thrust	EA
37-1432	USE 06-5542	ea
37-1435	rim,WM2x17,3TA rear	EA
37-1457	USE 37-0977	ea
37-1458	USE 551-997 (set)	ea
37-1466	USE 37-2015	ea
37-1467	pin,pivot,brake rod	EA
37-1467/SS	pin,pivot,brake rod,stainless	EA
37-1471	rim,WM2x18,pre con.Tri.R.	EA
37-1472	USE 37-3586	ea
37-1474	washer,wheel hub	EA
37-1476	adaptor ring,speedo drCEI	EA
37-1477	spacer,rear,wheel	EA
37-1481	washer,cup,wheel brg.	EA
37-1488	spring,brake arm return	EA
37-1497	USE 553-58/SS	ea
37-1498	USE 37-3585 & 8)21-2010	ea
37-1499	USE 37-1499/46	ea
37-1499/46	sprocket,8 bolt Tri,46T	EA
37-1499/47	sprocket,8 bolt Tri,47T	EA
37-1499/48	sprocket,8 bolt TRI,48T	EA
37-1499/49	sprocket,8 bolt TRI,49T	EA
37-1499/50	sprocket,8 bolt Tri,50T	EA
37-1499/52	sprocket,8 bolt Tri,52T	EA

37-1499/53	sprocket,8 bolt TRI,53T	EA
37-1499/ER	sprocket,8 bolt Tri,46T econo	EA
37-1500	bolt,1/4x26	EA
37-1599	adaptor, speedodrive,QD,CEI	EA
37-1614	sleeve,brg,QD wheel,RH	EA
37-1635	washer,grease ret,hub	EA
37-1640	abutment,brake cable	EA
37-1641	axle,front,pre 69	EA
37-1641/SS	axle,front,pre 69,stainless	EA
37-1654	washer,grease ret,rearHub*	EA
37-1690	bolt,5/16 CEI*	EA
37-1691	nut,5/16x26,lock*	EA
37-1702	USE 37-1732/1733 (set)	ea
37-1703	USE 37-1732/1733 (set)	ea
37-1708	spoke,19"F hub,nonconical	EA
37-1709	spoke,19"F hub,nonconical	EA
37-1710	screw,2BA,setscrew	EA
37-1722	USE 37-1995	ea
37-1732	brakeshoe,leading	EA
37-1732/1733	brakeshoe set,8"SLS front	PR
37-1732/1733/ER	brakeshoe set,8"SLS front,econo repl.	PR
37-1734	USE 551-1095	ea
37-1798	nut,5/8x20CEI,thin	EA
37-1990	brakeplate,68 DLS 8"Front	EA
37-1991	screen,brakeplate 8" DLS	EA
37-1992	cover,front hub,11"od,8"drum	EA
37-1995	hub,fullwidth drum	EA
37-1996	brakeshoes,8"fullwidthDLS*	PR
37-1996/ER	brakeshoes,8"fullwidthDLS,econo	PR
37-1999	lever,brake cam oper,DLS*	EA
37-1999/2000	levers,brake cam,DLS,1968	PR
37-1999/2000/SS	levers,brake cam,DLS,1968,stainless	PR
37-2000	lever,brake cam oper,DLS,1968,F*	EA
37-2001	cam,brake op,DLS	EA
37-2003	rod,brake oper,DLS FR,8"	EA
37-2003/SS	rod,brake oper,DLS FR,8",stainless	EA
37-2005	clevis,brakerod,DLS front	EA
37-2005/SS	clevis,brakerod,DLS fr,stainless	EA
37-2006	USE 60-4252	ea
37-2014	lever,brake oper,rear,cast*	EA
37-2015	lever,brake cam oper,R.,flat	EA
37-2026	brakeshoe pad,DLS front	EA
37-2027	washer,1/2"flat	EA
37-2057	USE 37-3582	ea
37-2058	nut,3/4x26,front axle	EA
37-2087	adjust,R QD wheel,UNF	EA
37-2089	adjust,R wheel,UNF	EA
37-2091	USE 37-1995	ea
37-2092	screw	EA
37-2133	USE 553-59/SS (set)	EA
37-2134	USE 553-59/SS (set)	EA
37-2135	USE 553-59/SS (set)	EA
37-2136	USE 06-2595	ea
37-2137	USE 553-70/SS	ea
37-2138	spoke,19"DLS w/7"drum	EA
37-2139	spoke,19"DLS w/7"drum	EA
37-2207	USE 37-1230/A	ea
37-2210	plate,hub cover,7"brake,8" OD	EA
37-2211	plate,hub cover,9"OD,8"brake	EA
37-2240	cover,front hub,11"OD	EA
37-2243	cam,brake operating	EA
37-2245	cam,brake oper,190mmF.	EA
37-2279	USE 68-6114	ea
37-2290	wheel assy,WM3x18,QD	EA
37-2291	rim,WM3x18,BSA QD rear	EA
37-2291/A	rim,WM3x18 R,alloy,w/shoulder	EA
37-2291/SS	rim,WM3x18,BSA QD,stainless	EA
37-2292	spoke,18"rear,BSA QD hub	EA
37-2293	spoke,18"rear,BSA QD hub	EA
37-2294	nipple,spoke,10g.x.250	EA
37-2297	USE 68-6114	ea

37-2298	USE 37-1041	ea
37-2299	washer, wheel brg.	EA
37-2300	spacer tube, QD R. hub	EA
37-2301	washer, felt, BSA QD hub	EA
37-2302	retainer, brg, RH BSA QD	EA
37-2303	washer, retainer, BSA QD	EA
37-2304	lockring&hub cover, RH, QD*	EA
37-2305	lockring, LH side, BSA QD hub*	EA
37-2306	spacer, R wheel, RH	EA
37-2308	axle, dummy, unit singles	EA
37-2309	nut, rear axle, BSA QD hub	EA
37-2310	USE 37-1041	ea
37-2311	washer, shim	EA
37-2312	circlip, brakedrum	EA
37-2313	rubber seal ring, QD hub	EA
37-2314	adaptor, splined, QD hub	EA
37-2315	bolt, 3/8x26, splined adaptor	EA
37-2316	nut, 3/8x26, thin	EA
37-2317	washer, tab, BSA QD hub	EA
37-2318	brakedrum, BSA QD type *	EA
37-2319	bolt, 5/16x24, sprocket to drum	EA
37-2320	USE 60-4260	ea
37-2321/47	sprock, 10hole, 47T, singles	EA
37-2321/49	sprock, 10hole, 49T, singles	EA
37-2321/52	sprock, 10hole, 52T, singles	EA
37-2322	brakeplate, alloy, unit single QD	EA
37-2325	nut, 1/2x20 BSC*	EA
37-2326	nipple, lubrication, Alemite, 1/4x26	EA
37-2327	brakeshoes, 7"BSA 1/2 hub	PR
37-2327/A	brakeshoes, 7"BSA, 1/2 hub, replacement	PR
37-2327/ER	brakeshoes, 7"BSA 1/2 hub, econo*	PR
37-2328	spring, brake shoe	EA
37-2330	USE 60-2323	ea
37-2331	washer, 7/16, lock	EA
37-2332	nut, 7/16x20BSC*	EA
37-2334	spring, brake oper. arm	EA
37-2338	washer	EA
37-2339	USE 37-2089	ea
37-2354	USE 37-2321/52	ea
37-2363	USE 37-1041	ea
37-3337	washer, wheel hub	EA
37-3402	spoke, 18"rear drum, early	EA
37-3411	USE 37-1499/52	ea
37-3412	USE 37-1499/53	ea
37-3425	USE 21-2014	ea
37-3426	USE 21-2013	ea
37-3427	wheel, WM3x19, rear. w/brakes&52Tsprocket	EA
37-3428	wheel assy, WM3x19, rear, bare	EA
37-3429	brakeplate, DLS 7"	EA
37-3443	cover, front hub, 7"DLS	EA
37-3444	screen, brakeplate, 7" DLS	EA
37-3446	brakeshoe set, 7" DLS	PR
37-3450	rod, brake oper, DLS 7"front	EA
37-3450/SS	rod, brake oper, DLS 7"fr, stainless	EA
37-3453	lever, brake oper, DLS F, forward*	EA
37-3453/3454	levers, brake cam, DLS, late	PR
37-3453/3454/SS	levers, brake cam, DLS, late, stainless*	PR
37-3454	lever, brake oper, DLS F, rear*	EA
37-3455	USE 37-3429	ea
37-3458	wheel assy, F, WM2x19DLS fullwidth	EA
37-3460	cover, 8"fr. hub, 9"dia.	EA
37-3468	USE 557-WM3	ea
37-3522	spring, brake oper. lever	EA
37-3575	spoke, 19"rear, early	EA
37-3582	axle, DLS fullwidthF. hub	EA
37-3582/SS	axle, DLS fullwidthF. hub, stainless	EA
37-3583	USE 37-1499/53	ea
37-3585	brakedrum, pre-conicaltype *	EA
37-3586	hub, rear wheel, early type	EA
37-3587	lockring, wheelbrg	EA
37-3588	adaptor, speedodrive, UNF	EA

37-3589	axle, rear, nonconical	EA
37-3590	brakeplate, nonconical R*	EA
37-3592	cam, brake operating	EA
37-3594	USE 37-3428	ea
37-3597	adaptor, speedodrive, QD	EA
37-3600	axle, QD rear, UNF	EA
37-3610	wheel assy, WM3x18, rear, bare*	EA
37-3614	USE 37-3690	ea
37-3658	brakedrum assy, 8" conical F	EA
37-3690	rim, WM1x18, F&R, 59-71 Bantam	EA
37-3702	brakedrum assy, 6" conical F	EA
37-3713	brakeshoe set, 8" conical F	PR
37-3714	spring, brakeshoe, conical F	EA
37-3715	brake adjuster cage, conical F	EA
37-3716	adjuster, micram, conical fr. brk.	EA
37-3717	abutment pressing, conical DLS	EA
37-3724	spoke, conical 18" LH inner*	EA
37-3725	spoke, 18" conical R, LH out	EA
37-3726	spoke, 18" conical rear, RH	EA
37-3741	USE 37-3992/52	ea
37-3742	adjuster, rear chain	EA
37-3744	USE 37-7043	ea
37-3746	spacer, 1"x5/8, rear axle	EA
37-3747	sprocket, conical hub, 47 T	EA
37-3747/50	sprocket, 5 bolt rear, 50T	EA
37-3747/50/ER	sprocket, 5 bolt rear, 50T, econo	EA
37-3747/53	sprocket, 5 bolt rear, 53T	EA
37-3747/53/ER	sprocket, 5 bolt rear, 53T, econo	EA
37-3747/ER	sprocket, conical hub, 47T, econo	EA
37-3749	washer, ring, wheel hub	EA
37-3750	spacer, rear axle	EA
37-3751	adaptor, speedo dr, conical	EA
37-3752	retainer, wheel bearing*	EA
37-3753	spacer, axle, conical rear	EA
37-3759	retainer, wheel bearing	EA
37-3761	oring	EA
37-3773	USE 37-4179 *	ea
37-3782	USE 37-4182	ea
37-3784	rim, WM3x18, conical hub	EA
37-3784/A	rim, WM3x18, alloy w/shoulder	EA
37-3784/SS	rim, WM3x18, conical hub, stainless	EA
37-3785	rim, WM2x18, conical hub*	EA
37-3785/A	rim, WM2x18, alloy w/shoulder	EA
37-3785/SS	rim, WM2x18, conical hub, stainless	EA
37-3793	brakedrum assy, 6" conical F	EA
37-3796	axle, conical front wheel	EA
37-3796/SS	axle, conical front wheel, stainless	EA
37-3797	washer, grease ret, con. hub	EA
37-3800	USE 37-7064/43	ea
37-3804	brakeshoes, 6" conical fr.	PR
37-3818	rim, WM2x19, conical hub, F	EA
37-3818/A	rim, WM2x19 F, alloy, w/shoulder	EA
37-3818/SS	rim, WM2x19, conical hub, F, stainless	EA
37-3819	spoke, 19" conical, RH out F	EA
37-3820	spoke, 19" conical, RH in F	EA
37-3821	spoke, 19" conical, L-hand F	EA
37-3848	USE 37-3658 *	ea
37-3856	brakeplate, conical R, bare *	EA
37-3857	brakeplate, conical R, bare, 250/500oif	EA
37-3867	USE 37-3996	ea
37-3868	USE 37-3997	ea
37-3870	pivot, brakeshoe, conical R	EA
37-3872	cam, brake oper, conical R	EA
37-3873/3874	USE 37-3925/3926	ea
37-3877	lever, brake oper, conical R	EA
37-3880	spring, brake oper, conic. R	EA
37-3890	wheel assy, WM2x18F, B25/T25SS	EA
37-3891	USE 37-3890 *	ea
37-3892	rim, WM2x18, 6" conical fr.	EA
37-3901	spacer, wheel, conical R	EA
37-3903	USE 37-3747/53	ea

37-3907	USE 37-4179	ea
37-3908	USE 37-4179	ea
37-3916	lever,brake oper,conicalR	EA
37-3919	adj,R.wheel,pre'71 3cyl.	EA
37-3920	rim,WM3x19 conical hub R.	EA
37-3920/A	rim,WM3x19 R,alloy,w/shoulder	EA
37-3920/SS	rim,WM3x19conical rear,stainless	EA
37-3921	spoke,19"conical,LH in.R.	EA
37-3922	spoke,19"conical,LH out R	EA
37-3923	spoke,19"conical,R.hand R	EA
37-3925	brake shoe,leading,conical rear	EA
37-3925/3926	brake shoes,conical rear	PR
37-3925/3926/ER	brakeshoes,conical rear	PR
37-3926	brake shoe,trailing,conical rear	EA
37-3932	spacer,axle*	EA
37-3939	USE 37-3818/A	ea
37-3940	USE 37-3784/A	ea
37-3961	plate,chain adj,con.T150	EA
37-3965	USE 37-7043	ea
37-3969	weight,wheel bal,light	EA
37-3970	weight,wheel bal,heavy	EA
37-3976	spacer axle,3cyl.RH rear	EA
37-3980	axle,conical rear,3 cyl	EA
37-3982	USE 37-4179	ea
37-3985	USE 37-4179	ea
37-3986	arm,brake,8"conical,forward	EA
37-3987	arm,brake,8"conical,back	EA
37-3992/47	sprocket,conical 1cyl,47T,5bolt	EA
37-3992/52	sprocket,conical 1cyl,52T,5bolt	EA
37-3992/52/A	sprocket,conical 1cyl,52T,5bolt,alloy	EA
37-3992/56	sprocket,conical 1cyl,56T,5bolt	EA
37-3996	abutment,brake cable	EA
37-3997	abutment,brake cable	EA
37-4001	USE 37-2334	ea
37-4014	spring,brake cable	EA
37-4034	arm,rear brake operating	EA
37-4046	USE 37-3747/50	ea
37-4049	spring,brake oper,con.R.	EA
37-4071	pad,brakeshoe thrust	EA
37-4126	USE 37-7058	ea
37-4127	USE 37-7059	ea
37-4129	rim,WM2x19,Tri.disc.front	EA
37-4129/A	rim,WM2x19,alloy w/shoulder	EA
37-4129/B	rim,WM3x18,alloy w/shoulder	EA
37-4129/SS	rim,WM2x19,stainlessSteel	EA
37-4130	spoke,19"front disc,inner	EA
37-4131	spoke,19"front disc,outer	EA
37-4132	axle,front disc wheel	EA
37-4132/SS	axle,front disc wheel,stainless	EA
37-4133	nut,axle,front disc	EA
37-4134	lockring,disc hub	EA
37-4135	washer,cupped,wheel hub	EA
37-4136	USE 37-4275	ea
37-4140	sprocket,5 bolt rear,53T,w/holes	EA
37-4141	USE 37-7057	ea
37-4143	USE 37-7057	ea
37-4147	arm,rear brake operating	EA
37-4151	rim,WM1x21,F,TR5T,B50MX *	EA
37-4153	USE 37-4131	ea
37-4164	axle,BSA twin QD R.wheel	EA
37-4170	USE 37-4263	ea
37-4179	brakedrum assy,7"conicalR	EA
37-4180	spacer,wheel brg.	EA
37-4181	lockring,hub,late conical	EA
37-4182	wheel assy,WM3x18,conical,rear*	EA
37-4200	nipple,spoke,10gx.305" OD*	EA
37-4209	sprocket,rear,T160,50T	EA
37-4209/46	sprocket,rear,T160,46T	EA
37-4209/52	sprocket,rear,T160,52T	EA
37-4209/A	adaptor,T160 to 37-1499 type sprocket	EA
37-4215	adaptor,speedodrive,T160	EA

37-4236	washer, wheel hub	EA
37-4243	rim, WM3x19, T160 rear	EA
37-4243/A	rim, WM3x19, T160 rear, AKRONT alloy	EA
37-4243/SS	rim, WM3x19, T160 rear, stainless	EA
37-4244	spoke, 19" T160 rear, LH out	EA
37-4259	USE 37-7127	ea
37-4261	USE 37-7043	ea
37-4263	cover, caliper	EA
37-4270	spoke, 19" T160 rear, RH out	EA
37-4275	rotor, discbrake, 4hole, hardchrome *	EA
37-4275/SS	rotor, discbrake, 4hole, stainless	EA
37-4282	USE 37-4179	ea
37-4303	spoke, 19" T160 rear, inner	EA
37-4362	adjuster, rear chain, T160 LH *	EA
37-4369	washer, 3/8"	EA
37-4370	lever, rear mastercyl.oper	EA
37-6033	USE 37-2311	ea
37-7001	hub, LH rear disc, Smiths type	EA
37-7002	USE 37-7062	ea
37-7003	spacer, axle, RH rear disc	EA
37-7004	adaptor, speedo drive, disc	EA
37-7005	USE 37-7051	ea
37-7006	spacer, rear hub, left hand	EA
37-7007	spoke, 18" rear disc, RH out	EA
37-7008	spoke, 18" rear disc, LH out	EA
37-7009	spoke, 18" rear disc, inner	EA
37-7010	hub, rear disc, centre	EA
37-7016	USE 37-7064	ea
37-7018	USE 37-7030*	ea
37-7020	bracket, caliper, rear disc	EA
37-7021	spacer, axle, rear disc, RH	EA
37-7030	rim, WM3x18, Tri.disc, rear *	EA
37-7030/A	rim, WM3x18 alloy, w/shoulder	EA
37-7030/SS	rim, WM3x18, stainlessSteel	EA
37-7031	spoke, 18" rear disc, 1978on	EA
37-7032	spoke, 18" rear disc, 1978on	EA
37-7033	spoke, 18" rear disc, 1978on	EA
37-7034	nipple, spoke, 9g.x.300	EA
37-7036	USE 37-4129 *	ea
37-7038	USE 37-7030 *	ea
37-7041	bearing, sealed	EA
37-7041/A	bearing, taper, steering head, Norton*	EA
37-7042	bearing, ball, sealed	EA
37-7043	USE 37-7113	ea
37-7044	USE 37-7064/45	ea
37-7047	hub, LH rear disc, Veglia type	EA
37-7048	bracket, caliper, rear disc	EA
37-7051	spacer, wheel	EA
37-7052	spacer, wheel	EA
37-7053	spacer, wheel	EA
37-7054	washer, dustcover, wheelbrg.	EA
37-7055	lockring, wheel brg.	EA
37-7057	wheel assy, WM2x19 F.disc *	EA
37-7058	hub, front disc, LH	EA
37-7059	hub, front disc, RH	EA
37-7062	hub, RH rear disc, all twin	EA
37-7063	hub, rear disc, centre, late	EA
37-7064	USE 37-7064/47 (or2or5or6)	ea
37-7064/42	sprocket, R, disc, 42T	EA
37-7064/43	sprocket, rear disc, 43T	EA
37-7064/43/ER	sprocket, R.disc, 43T, econo	EA
37-7064/45	sprocket, R.disc, 45T	EA
37-7064/45/ER	sprocket, R.disc, 45T, econo	EA
37-7064/46	sprocket, R.disc, 46T	EA
37-7064/47	sprocket, R.disc, 47T	EA
37-7064/47/ER	sprocket, R.disc, 47T, econo	EA
37-7072	USE 37-7064/45	ea
37-7076	lockring, wheel brg.	EA
37-7079	rotor, disc, 6holeT140D, hardchrome	EA
37-7079/A	rotor, disc, 6holeT140D, cast	EA
37-7080	spacer, wheel	EA

37-7081	axle,front wheel,T140D	EA
37-7081/SS	axle,front wheel,T140D,stainless	EA
37-7089	sprocket,T140D rear,47T	EA
37-7089/45	sprocket,T140D rear,45T	EA
37-7089/ER	sprocket,T140D rear,47T,econo	EA
37-7094	spacer,caliper plate	EA
37-7100	washer,copper,brake hose	EA
37-7104	USE 37-7127	ea
37-7108	USE 37-7127	ea
37-7111	spacer,wheel	EA
37-7113	axle,rear,oil frame Twins	EA
37-7122	washer,rear wheel adj,T140D	EA
37-7124	bracket,caliper,rear disc,alloy	EA
37-7127	adjuster,rear chain,late	EA
37-7175	rotor,discbrake,cast iron,4 hole	EA
37-7178	spring,brake oper,83 TR65	EA
39-	MATCHLESS PARTS	*
39-----	-----	--
40-	TRIUMPH AND BSA PARTS	*
40-----	-----	--
40-0015	bush,RH crank,C15	EA
40-0020	USE 70-8008	ea
40-0025	USE 70-8025	ea
40-0026	bushing,layshaft,LH,C15	EA
40-0030	bush,camshaft	EA
40-0042	sleeve,mainshaft RH,C15 type *	EA
40-0047	conrod,C15	EA
40-0056	USE 71-1429	ea
40-0063	bush,small end C15	EA
40-0066	USE 70-8038	ea
40-0069	USE 70-8039	ea
40-0118	USE 70-8061	ea
40-0124	stud,cyl.hd.to rockerbox	EA
40-0127	USE 70-8229	ea
40-0131	stud	EA
40-0133	USE 452-461	ea
40-0134	USE 70-3209	ea
40-0148	USE 06-2583	ea
40-0156	USE 70-1574	ea
40-0157	USE 70-1330	ea
40-0158	USE 70-1575	ea
40-0159	USE 70-1335	ea
40-0162	USE 70-1435	ea
40-0164	USE 70-0470	ea
40-0165	USE 453-169	ea
40-0166	USE 453-170	ea
40-0167	USE 71-3748	ea
40-0169	spring, valve, inner	EA
40-0171	USE 70-1543	ea
40-0181	USE 41-0031	ea
40-0182	washer, fibre, rockercap	EA
40-0183	oline, rockerfeed, B40 type	EA
40-0208	cover, rocker insp, B50/B44/C15	EA
40-0209	USE 70-8089	ea
40-0210	USE 70-8139	ea
40-0222	USE 70-8150	ea
40-0229	USE 70-8160	ea
40-0230	screw, 1/4x26	EA
40-0234	USE 70-8168	ea
40-0235	USE 70-8161	ea
40-0236	USE 70-8169	ea
40-0238	USE 70-9816	ea
40-0239	washer, fibre insp. cap	EA
40-0240	USE 70-3789	ea
40-0241	USE 71-1419	ea
40-0243	USE 70-3833	ea
40-0244	USE 552-114038/70	ea
40-0245	USE 71-2025 *	ea
40-0246	USE 70-3821	ea
40-0292	rockerarm assy, inlet, 1cyl	EA
40-0294	shaft, rocker spindle, C15/B44/50	EA

40-0295	screw,2BA	EA
40-0296	rockerarm assy,exh,1cyl	EA
40-0309	USE 70-3231	ea
40-0323	USE 60-3530	ea
40-0327	USE 70-8142	ea
40-0381	USE 40-0385	ea
40-0385	spring,checkvalve,BSA1cyl	EA
40-0389	USE 40-0391	ea
40-0391	bush,RH crank,BSA B40 etc*	EA
40-0391/A	conversion,roller,RH crank,C15/B40*	ST
40-0392	tappet,C15&B40	EA
40-0392/U	tappet,reground,exch	EA
40-0394	USE 70-8011	ea
40-0414	USE 70-8071	ea
40-0415	rockerbox,C15/B40/B44roundbarrel	EA
40-0417	shaft,comp.release,1cyl.	EA
40-0418	USE 70-6299	ea
40-0437/0438	gearset,distributor/oilpump,C15/B40	PR
40-0454	nut,5/8x20,crankpin	EA
40-0455	USE 70-8043	ea
40-0477	camshaft,B40,w/gear	EA
40-0483	nut,3/8x26,special *	EA
40-0483/SS	nut,3/8x26,special,stainless	EA
40-0572	cage,conrod bearing,1cyl	EA
40-0655	USE 40-0183*	ea
40-0663	USE 70-8232	ea
40-0679	USE 70-8153	ea
40-0683	USE 70-4747	ea
40-0684	USE 70-8737	ea
40-0688	USE 71-1462	ea
40-0705	USE 70-8148	EA
40-0715	USE 57-2166	ea
40-0740	USE 70-8175	ea
40-0862	USE 70-8157	ea
40-0892	USE 70-8036	ea
40-0907	USE 421-68 (set)	ea
40-0915	USE 70-2922	ea
40-0916	USE 70-4003	ea
40-0917	USE 421-68/010 (set)	ea
40-0918	USE 421-68/020 (set)	ea
40-0919	USE 421-68/030 (set)	ea
40-0931	USE 452-539/PB	ea
40-0932	USE 452-539/PB	ea
40-0933	USE 70-8081	ea
40-0939	USE 70-8228	ea
40-0942	USE 70-8080	ea
40-0946	USE 70-8189	ea
40-0948	bracket,eng.mt,top,pre69B25	EA
40-0949	USE 70-9263	ea
40-0953	USE 70-7728	ea
40-0963	USE 71-1426	ea
40-0965	USE 70-8086	ea
40-0966	cover,insp, valve adjust.	EA
40-0967	USE 71-1425	ea
40-0968	USE 70-1564	ea
40-0969	USE 70-1577	ea
40-0977	USE 70-8154	ea
40-0978	USE 70-6861	ea
40-0979	USE 70-6869	ea
40-0989	rockerarm,C25,inlet	EA
40-0990	rockerarm,C25,x	EA
40-0993	USE 70-8107	ea
40-1001	USE 71-2025	ea
40-1007/1009	USE 451-647	ea
40-1010	USE 70-8055	ea
40-1020	USE 71-1418	ea
40-1021	USE 70-8053	ea
40-1033	USE 57-2695	ea
40-1034	USE 57-2696	ea
40-1037	USE 70-8106	ea
40-2021	skidplate,B44VS,early	EA

40-2700	USE 721-B68 ?	ea
40-2705	USE 60-4248	ea
40-2710	USE 71-2465	ea
40-2835	USE 721-B68 ?	ea
40-2844	bracket,muffler,B44SS,B25	EA
40-2845	USE 721-B89	ea
40-3007	USE 57-1391	ea
40-3009	layshaft,bare,C15,B40,dist.models	EA
40-3010	gear,2nd lay/3rd main,27T	EA
40-3016	bush	EA
40-3021	USE 57-2753 (2 OF)	ea
40-3022	USE 57-1279	ea
40-3024	USE 57-1118	ea
40-3025	USE 57-1281	ea
40-3026	USE 57-1282	ea
40-3028	USE 57-1162	ea
40-3032	USE 57-2688	ea
40-3033	USE 57-2689	ea
40-3042	USE 57-2691	ea
40-3043	USE 57-1249	ea
40-3044	USE 57-1076	ea
40-3045	USE 57-1180	ea
40-3049	sprocket,gbx,17T,C15 &B40	EA
40-3050	USE 57-2702	ea
40-3051	USE 57-1434	ea
40-3052	sprocket,gbx,16T,C15 &B40	EA
40-3061	USE 57-1109	ea
40-3071	USE 422-532	ea
40-3072	sprocket,gbx,15T,C15&B40	EA
40-3073	USE 57-1164	ea
40-3075	USE 532-15	ea
40-3084	USE 57-1169	ea
40-3085	USE 57-1167	ea
40-3089	USE 57-1257	ea
40-3091	USE 532-05	ea
40-3092	USE 57-7017	ea
40-3118	spring,kick,C15Trial&Scr.	EA
40-3121	USE 57-2702	ea
40-3123	sprocket,gbx,19T,C15&B40	EA
40-3124	sprocket,gbx,20T,C15&B40	EA
40-3127	USE 57-2680	ea
40-3131	gear,3rd main,28T	EA
40-3140	quadrant assy,shift,early Tribsa 1cyl.	EA
40-3150	USE 57-2714	ea
40-3178	USE 57-1279	ea
40-3190	plug,gbx.drain&level,C15/B40	EA
40-3201	USE 57-2713	ea
40-3203	USE 57-4198	ea
40-3206	USE 57-2719	ea
40-3207	USE 57-2720	ea
40-3210	USE 57-2721	ea
40-3217	USE 57-2727	ea
40-3218	USE 57-3951	ea
40-3219	USE 57-2748	ea
40-3220	USE 57-2725	ea
40-3221	USE 57-2732	ea
40-3222	USE 57-2728	ea
40-3226	USE 37-0103	ea
40-3227	USE 57-2730	ea
40-3229	pushrod,clutch,61-64 B40	EA
40-3230	USE 57-2729	ea
40-3231	USE 57-2727	ea
40-3233	USE 57-2726	ea
40-3234	USE 57-2731	ea
40-3235	clutch assy,compl,B25/B44	EA
40-3254	USE 57-2661	ea
40-3257	USE 57-2685	ea
40-3258	USE 57-2670	ea
40-3259	layshaft w/18T gear	EA
40-3260	gear,1st lay,32T	EA
40-3262	USE 57-2752	ea

40-3265	USE 57-2733	ea
40-3267	kick spindle assy,early B25,etc.*	EA
40-3271	USE 57-2683	ea
40-3272	USE 57-2682	ea
40-3273	USE 57-2684	ea
40-3275	USE 57-2687	ea
40-3276	USE 57-2657	ea
40-3279	USE 57-2681	ea
40-3281	USE 70-4568	ea
40-3282	USE 57-2699	ea
40-3289	USE 57-2659	ea
40-3292	USE 70-8005	ea
40-3294	USE 57-2690	ea
40-3315	USE 40-3267 *	ea
40-3321	USE 57-2692	ea
40-3330	USE 57-2722	ea
40-4074	brg.cup, forks, B40	EA
40-4209	USE 82-4076	ea
40-4241	USE 82-8993	ea
40-4528	battery carrier, 67B25/44	EA
40-4719	centrestand, C15	EA
40-4728	USE 40-4737	ea
40-4729	USE 40-4737	ea
40-4733	USE 82-3097	ea
40-4734	USE 82-3096	ea
40-4735	USE 82-2610	ea
40-4737	sidestand, unit singles, early	EA
40-4810	USE 82-9050	ea
40-4812	footpeg, LH	EA
40-4818	USE 82-9048	ea
40-4820	USE 82-9055	ea
40-4822	footpeg assy, rear	EA
40-4840	footpeg, RH	EA
40-4850	USE 532-21	ea
40-4853	footpeg, LH, B25 etc, pre 71	EA
40-4855	USE 82-9047	ea
40-4909	spacer, shock, RH	EA
40-4960	bars, BSA US A75, B25 etc.	EA
40-5004	forktube, C15	EA
40-5018	USE 97-2651	ea
40-5049	oilseal, forks, C15	EA
40-5069	USE 97-1062	ea
40-5090	USE 97-2654	ea
40-5143	USE 97-2647	ea
40-5144	USE 97-2648	ea
40-5145	USE 97-2650	ea
40-5190	USE 97-2709	ea
40-5525	brakeshoe set, B40&66B44, r	PR
40-5538	rim, WM1x20, F, 59-64 C15S&T	EA
40-5552	rim, WM2x18 Fr, 67 B44VR	EA
40-6020	axle, C15, early rear	EA
40-6029	brakeplate, C15/B40 rear	EA
40-6033	USE 37-2339	ea
40-6040	USE 37-1015	ea
40-6050	brakedrum, rear, C15/B40	EA
40-6051/52	sprocket, rear, 52T, C15Tetc	EA
40-6051/60	sprocket, rear, 60T, C15Tetc	EA
40-6080	rim, WM2x18, BSA QD rear	EA
40-6080/A	rim, WM2x18 R, Akront alloy	EA
40-6080/SS	rim, WM2x18, BSA QD rear, stainless	EA
40-6570	bracket, fr. mudguard, rear, chrome	EA
40-6601	USE 82-8393	ea
40-6910	USE 82-8997	ea
40-7701	chainguard, BSA C15 & B40	EA
40-7718	chainguard, C15SR	EA
40-7829	USE 40-7834	ea
40-7834	airfilter element, A10, 58-62	EA
40-7876	connector assy, airfilter	EA
40-7879	USE 40-7876 assy.	ea
40-8012/8013	kneepad set, BSA clipon, grey	PR
40-8014/8015	USE 40-8122/3 BLK, RD, OR WHITE	ea

40-8016	screw,3BA,tank badge	EA
40-8029/8030	kneepad set,BSA clipon,black	PR
40-8039	USE 42-8010	ea
40-8046	USE 82-9093	ea
40-8075	bolt,gas tank, special	EA
40-8085	USE 82-9064	ea
40-8107	rubber plug,tank,lg,BSA	EA
40-8108	USE 83-3069	ea
40-8121	USE 82-9134	ea
40-8122/8123/BLK	badges,tank,teardropBlack,plastic	PR
40-8122/8123/RED	badges,tank,teardrop,red,plastic*	PR
40-8122/8123/WHT	badges,tank,teardropWhite,plastic	PR
40-8122/BLK	badge,tank,blk,RH	EA
40-8122/RED	badge,tank,red,RH	EA
40-8123/BLK	badge,tank,blk,LH	EA
40-8123/RED	badge,tank,red,LH	EA
40-8124	USE 68-8152	ea
40-8125	USE 40-8016*	EA
40-8140	USE 82-9747	ea
40-8141	bolt,tank mt,centre	EA
40-8145	decal,BARRACUDA,250 BSA	EA
40-8325	USE 624-34 *	ea
40-8328	USE 82-3179	ea
40-8331	USE 82-1713	ea
40-8349	oilhose,braided steel	EA
40-8382	USE 624-34 *	ea
40-8435	USE 82-9067	ea
40-8436	USE 82-6039	ea
40-8439	fueline,braided steel	EA
40-8446	clamp,mounting	EA
40-8469	USE 624-34 *	ea
40-8516	USE 526-38/27X	ea
40-8538	USE 523-18951	ea
40-8539	USE 523-18952	ea
40-8560	USE 526-M40/27X	ea
40-8564	USE 526-114	ea
40-8582	USE 526-M40/27X	ea
40-8583	USE 526-M40/27X	ea
40-8587	USE 526-539	ea
40-8590	USE 526-539/3	ea
40-8608	USE 526-40/36 *	ea
40-8615	USE 526-733	ea
40-8620	USE 526-738	ea
40-8654	USE 526-733	ea
40-8657	USE 526-M38/35	ea
40-8769	USE 526-M40/27X	ea
40-9172	USE 82-9090	ea
40-9179	USE 83-1458	ea
40-9180	USE 82-8283	ea
40-9185	decal,STARFIRE 250,globe *	EA
40-9187	USE 82-9094	ea
41-	TRIUMPH AND BSA PARTS	*
41-----	-----	---
41-0017	USE 452-510	ea
41-0018	USE 41-0638	ea
41-0022	USE 453-211	ea
41-0023	USE 453-212	ea
41-0024	USE 453-223	ea
41-0026	USE 68-0931	ea
41-0031	cap,insp,C15,B40&B44valve*	EA
41-0043	stud,3/8x26 & 7/16x18	EA
41-0066	USE 41-0638	ea
41-0092	USE 442-15490 (set)	ea
41-0098	USE 442-15490 (set)	ea
41-0101	pin,piston,B44	EA
41-0143	USE 70-8184	ea
41-0178	conrod assy.w/pin&brgs,B40	EA
41-0182	USE 41-0233	ea
41-0183	brg,race,conrod	EA
41-0233	conrod,B40	ea
41-0470	flywheel,LH,C15,1965	EA

41-0539	USE 70-7727	ea
41-0540	stud,7/16x18x20,cyl&head,B44	EA
41-0546	flywheel assy.w/rod,B44	EA
41-0548	conrod assy.w/pin &brgs,B44	EA
41-0549	conrod w/bush,B44	EA
41-0549/A	conrod,CARILLO HiPerf.	EA
41-0560	USE 70-1580	ea
41-0565	washer,thrust,pump dr.gear	EA
41-0567	USE 70-8041	ea
41-0570	USE 441-17791 *	ea
41-0586	USE 423-B26 or 41-0548	ea
41-0588	nut,crankpin,7/8X20,B44/B50 etc.	EA
41-0590	USE 41-0592	ea
41-0592	pushrod,In&X,66-67 B44VS	EA
41-0603	USE 70-8094	ea
41-0615	sprocket,eng,B44,28T,dual	EA
41-0620	USE 70-8064	ea
41-0624	USE 70-8017	ea
41-0632	USE 452-510/PB	ea
41-0633	USE 452-510/PB	ea
41-0638	gasket,cylinder hd,B40&44	EA
41-0639	washer,7/16",flat	EA
41-0668	USE 70-7739	ea
41-0673	USE 60-4253	ea
41-0674	USE 06-4152	ea
41-0715	USE 70-8155	ea
41-0787	cylinder barrel,late B44	EA
41-0788	USE 453-268	ea
41-0789	USE 453-269	ea
41-0790	pushrod,In & X,late B44	EA
41-0790/A	pushrod set,chrome moly	ST
41-0793	USE 441-17791	ea
41-0795	USE 441-17791/010	ea
41-0797	USE 441-17791/020	ea
41-0801	USE 71-2227	ea
41-0804	USE 71-2115	ea
41-0805	USE 71-3001	ea
41-0807	oiline,rockerfeed,B44 etc*	EA
41-2747	USE 721-711408 *	ea
41-3022	USE 57-7017	ea
41-3027	gear,4th lay,17T,early*	EA
41-3029	gear,4th main,26T,C15/B40,early*	EA
41-3042	gear,4th main,26T,C15/B40,late*	EA
41-3044	gear,4th lay,17T,late*	EA
41-3045	USE 57-2753	ea
41-3054	USE 70-8015	ea
41-3058	sprocket,gbx,B44early,18T	EA
41-3059	kickspindle assy,B44pre68 *	EA
41-3061	USE 57-3872	ea
41-3068	USE 57-2667	ea
41-3069	USE 57-3877	ea
41-3070	USE 57-2668	ea
41-3072	USE 57-2672	ea
41-3074	USE 57-2671	ea
41-3078	USE 57-2669	ea
41-3091	spring,clutch,B44/B50	EA
41-3092	USE 57-2766	ea
41-3094	USE 57-2765	ea
41-3095	USE 57-2701	ea
41-3209	USE 57-2715	ea
41-3210	USE 57-2724	ea
41-3211	USE 57-2723	ea
41-3212	USE 57-2723	ea
41-3215	USE 57-2748	ea
41-4043	spacer tube	EA
41-4055	USE 83-3329	ea
41-4271	USE 82-8686	ea
41-4721	USE 82-8686	ea
41-4835	USE 82-9133	ea
41-4849	footrest,RH,B44GP	EA
41-5015	forktube,C15,21.8"	EA

41-5115	USE 41-5116	ea
41-5116	forktube,B44	EA
41-5129	USE 97-2652	ea
41-5130	USE 97-2708	ea
41-5134	USE 97-2667	ea
41-5135	USE 97-2662	ea
41-5137	USE 97-2637/2638	ea
41-5138	USE 06-7745	ea
41-5139	USE 97-2666	ea
41-5140	USE 97-2665	ea
41-5141	USE 97-2634	ea
41-5142	USE 97-2514	ea
41-5143	USE 97-2664	ea
41-5144	USE 97-2661	ea
41-5145	USE 97-2668	ea
41-5146	USE 97-2652	ea
41-5155	bracket,hdlt.mt,RH	EA
41-5156	bracket,hdlt.mt,LH	EA
41-5157	USE 97-2514 *	ea
41-5518	USE 553-40/SS kit	ea
41-5535	rim,WM1x20,F,64-67 B44GP	EA
41-6006	USE 37-1374	ea
41-6007	rim,WM3x18,fullwidth	EA
41-6009	USE 37-2290	ea
41-6016	USE 37-1041	ea
41-6017	USE 37-1041	EA
41-6019	USE 37-2306	ea
41-6021	USE 37-2303	ea
41-6027	lockring&hub cover,LH QD	EA
41-6031	USE 37-2334	ea
41-6032	USE 37-2308	EA
41-6051/60	sprocket,rear,60T,C15Tetc	EA
41-6073	USE 37-1406/1407 (set)	ea
41-6076	USE 37-1406/1407 (set)	ea
41-6078	USE 37-1415	ea
41-6090	USE 37-2318	ea
41-6091	USE 37-2321/49	ea
41-6092	USE 37-2321/47	ea
41-6093	USE 37-2322	ea
41-6503	bracket,fenderstay,9.5",chr.	EA
41-6533	USE 90-6580	ea
41-6782	bracket.Rmudguard support	EA
41-6791	bracket,tailight,alloy	EA
41-6792	USE 41-6791	ea
41-7037	USE 82-9036	ea
41-7712	chainguard,C25&early B25/44VS	EA
41-7713	USE 82-9059	ea
41-7858	element,airfilt,early B44,K&N	EA
41-7862	airfilter housing,67B44VS	EA
41-7864	hose,airfilter,B44VS,1966/67	EA
41-8004	badges,tank,round sm. BSA	PR
41-8010	bolt,gas tank,special	EA
41-8035	fueline assy,67 B44VS	EA
41-8051	decal,BSA,gastank,B44	EA
41-8052	decal,441VICTOR,tanktop	EA
41-8076	decal,ShootingStar tanktop	EA
41-8351	oiltank,fiberglas,B44	EA
41-8352	USE 41-8351	ea
41-8510	USE 526-44/38 *	ea
41-9034	grabrail,B40	EA
41-9131	bracket,seat mt,pre71 unitSingle	EA
41-9152	grabrail,B44&B25	EA
41-9158	decal,441 Shooting Star	EA
41-9159	USE 83-1458	ea
42-	TRIUMPH AND BSA PARTS	*
42-----	-----	---
42-0048	oiline assy,top,rockers,A7/10 *	EA
42-0052/3/4/5	bracket set,A10 topMtr.mt	ST
42-0055	bracket,head steady,A7/10*	EA
42-0074	USE 42-0048	ea
42-0139	oiline,bot,rockers,A7/10 *	EA

42-0155	oilpump,A10SR,w/tachdrive*	EA
42-0156	spindle& gear,pump,for tach	EA
42-0158	circlip,BSA oilpump	EA
42-0195	tachdrive housing,A10	EA
42-0196	spindle,tachdrive,A10SR	EA
42-2651	USE 711-Z662	ea
42-2652	USE 711-Z662	ea
42-2653	USE 711-Z662	ea
42-2654	USE 711-Z662	ea
42-2655	brackets,muffler,A7/10	PR
42-2660	USE 711-828857 (pair)	ea
42-2699	heatshield,BSA hipipes,pre69twin	EA
42-2701	screw,1/4x26	EA
42-2774	USE 711-422774/2775	ea
42-2775	USE 711-422774/2775	ea
42-2776	sprocket,engine,19T,2 lobe	EA
42-2848	clip,finned,Xpipe,BSAtwin,1-1/2"*	EA
42-2850	USE 721-B34	ea
42-2860	USE 742-158/A*	ea
42-2896	USE 711-Z624	ea
42-2963	USE 711-Z662	ea
42-2964	USE 711-Z662	ea
42-3013	shaft,gearshift,GoldStar	EA
42-3015	sprocket,gbx,16T,Brange,54-58	EA
42-3015/17	sprocket,gbx,17T,Brange,54-58	EA
42-3016	sprocket,gbx,19T,Brange,54-58	EA
42-3017	lever,shift,preunit BSA	EA
42-3019	layshaft,bare,preunit*	EA
42-3023	gear,2nd lay,23T	EA
42-3037	kickstart crank assy,preunit*	EA
42-3037/ER	kick crank assy,preunit,econo*	EA
42-3048	sprocket,gbx,20T,Brange,54-58	EA
42-3054	USE 42-3223	ea
42-3056	pressure plate,clutch,6 spring	EA
42-3074	USE 57-1606	ea
42-3075	bearing,needle	EA
42-3079	washer,thrust,.113"	EA
42-3082	USE 42-3097	ea
42-3097	gear,1st lay,27T,GS	EA
42-3101	USE 42-3163	ea
42-3102	USE 42-3163	ea
42-3107	clutch hub,6spring cl,A7/10	EA
42-3108	pushrod,clutch,A7/10	EA
42-3119	cl.plate,frict,late 6 spr	EA
42-3119/A	clutch kit,Barnett HiPerf	ST
42-3119/ER	cl.plate,frict,late 6 spr*	EA
42-3136	gear,3rd main,24T	EA
42-3137	gear,1st main,19T,GS	EA
42-3159	USE 532-74/A	ea
42-3160	kick spindle &quad,P-unit	EA
42-3163	kick spindle &quad,DBD34	EA
42-3167	USE 57-2764	ea
42-3170	clutch hub,late A10 type	EA
42-3170/A	clutch hub,late A10,performance	EA
42-3183	USE 57-1040	ea
42-3189	USE 57-4754	ea
42-3191	USE 57-1046	ea
42-3192	USE 57-1362	ea
42-3195	USE 57-1363	ea
42-3197	USE 57-1931	ea
42-3199	USE 57-2526	ea
42-3206	USE 57-0394	ea
42-3210	USE 42-3097	ea
42-3212	washer,thrust,.120	EA
42-3213	washer,thrust,.127"	EA
42-3220	USE 66-3903	ea
42-3223	clutch drum,late 6 spr.cl	EA
42-3223/ER	clutch drum,late 6 spr.cl,econo repl.	EA
42-3224	USE 42-3223	ea
42-3235	USE 57-0872	ea
42-3236	USE 57-0524	ea

42-3249	USE 70-3290	ea
42-3262	USE 57-1362	ea
42-3266	USE 57-1549	ea
42-3267	nut,5/8x20CEI,cl.centre,A10,late	EA
42-3273	USE 57-1560	ea
42-3274	pushrod,clutch,late A10	EA
42-4112	shaft,swingarm,solid	EA
42-4115	bush,silentbloc,swingarm	EA
42-4125	cover plate,eng,DBD34,fr.	EA
42-4272	cover,gbx.plates,preunit SA	EA
42-4281	bracket,eng.mt,bottomLH,A7/10	EA
42-4284	USE 42-4272 *	ea
42-4291	USE 543-64533025	ea
42-4292	USE 543-64532778	ea
42-4317	swingarm,A7/10 &Goldstar	EA
42-4340	shaft,swingarm,lateA10etc *	EA
42-4343	USE 82-8995	ea
42-4355	spring,brake pedal	EA
42-4362	bush,silentbloc,swingarm	EA
42-4364	USE 82-8996	ea
42-4472	bolt,3/8x26	EA
42-4475	USE 70-8194	ea
42-4476	USE 70-8137	ea
42-4502	strap,battery box,top	EA
42-4503	strap,battery box,back	EA
42-4504	USE 70-3872	ea
42-4505	trunnion,bat.box,plain	EA
42-4506	trunnion,bat.box,tapped	EA
42-4514	strap assy,bat,preunit A&B *	ST
42-4515	battery carrier,late A7/10	EA
42-4516	strap,battery box,front	EA
42-4573	hose,airfilter,A10	EA
42-4644	battery box,late A7/10	EA
42-4649	holddown,battery,A10,etc.	EA
42-4651	battery box,late A7SS/A10SR	EA
42-4719	centrestand,Gold Star	EA
42-4725	centerstand,A10,1954-57 swingarm	EA
42-4730	spring,centrestand,P.unit	EA
42-4744	shaft,centrestand pivot	EA
42-4745	spacertube,centerstand	EA
42-4761	centerstand,A10,1957on	EA
42-4769	sidestand assy,complete,A10	EA
42-4776	bracket,sidestand,preunit	EA
42-4778	sidestand,BSA,pre'71	EA
42-4792	USE 70-8215	ea
42-4793	bolt,7/16x20,sidestand	EA
42-4804	footpeg,preunit,RH	EA
42-4805	footpeg,preunit,RH	EA
42-4832	clamp,footpeg,GS,LH	EA
42-4833	clamp,footpeg,GS,RH	EA
42-4835	USE 68-4829	ea
42-4836	footpeg assembly,rear,DBD RH	EA
42-4845	footpeg assy,rear,w/rubber	EA
42-4857	mount,footpeg,A7/10 LH	EA
42-4919	spacer,saddlebag mt.	EA
42-4925	USE 532-75/A	ea
42-4926	USE 82-9043	ea
42-4968	bars,A65 USA,67-71	EA
42-4990	USE 42-4968	ea
42-4995	USE 42-4968	ea
42-5011	USE 42-5036	ea
42-5012	USE 97-3862	ea
42-5014	USE 68-5150	ea
42-5015	USE 97-3862	ea
42-5027	forktube,pre'69 BSA,chrome	EA
42-5036	forkyoke,top,A10SR,Goldstar	EA
42-5084	USE 97-1070	ea
42-5086	USE 97-3862	ea
42-5090	cover,forks,dual	EA
42-5093	cover,forkcrown,late A7/10	EA
42-5094	shell,hdl,t,cowl type,fibreglas	EA

42-5094/A	trim,chrome flash,nacelle	PR
42-5102	adaptor ring,nacelle,chr	EA
42-5141	USE 97-2501	ea
42-5142	USE 97-2504	ea
42-5145	spring,fork,50lb.rating	EA
42-5315	USE 97-2514	ea
42-5317	bracket,hdlt,pre66 BSA LH,CHROME*	EA
42-5320	USE 531-24 (pair)	ea
42-5321	bracket,hdlt,pre66 BSA RH,CHROME*	EA
42-5323	clip,fork gaiterRetaining	EA
42-5323/ER	clip,fork gaiterRetaining,econo	EA
42-5445	USE 82-6738	ea
42-5514	USE 67-5543	ea
42-5550	rim,WM1x19,190mmF	EA
42-5552	USE 553-66/A (set)	ea
42-5560	brakeplate,190mm	EA
42-5564	brakeshoes,190mm BSAfront	PR
42-5567	USE 37-2245	ea
42-5588	rim,WM2x19,190mmF	EA
42-5589	rim,WM2x19,190mmF,alloy w/shoulder	EA
42-5618	brakeshoes,Ariel type,BSA	PR
42-5620	USE 551-1008 (set)	ea
42-5635	USE 553-65/SS (set)	ea
42-5637	USE 06-7712	ea
42-5644	USE 06-7712	ea
42-5649	USE 06-7712	ea
42-5810	USE 37-1230	ea
42-5811	USE 37-1236	ea
42-5812	USE 37-4200	ea
42-5819	USE 37-0653	ea
42-5820	USE 37-1237	ea
42-5821	USE 57-0280	ea
42-5830	USE 37-1243	ea
42-5833	rim,WM3x19,BSA rear,fullwidth	EA
42-5836	USE 60-4252	ea
42-5837	USE 68-5515/5516 (set)	ea
42-5840	USE 37-0129	ea
42-5841	USE 37-0135	ea
42-5842	USE 37-1246	ea
42-5843	USE 37-2210	ea
42-5844	USE 37-2211	ea
42-5848	USE 37-1328	ea
42-5860	USE 37-1197	ea
42-5861	USE 37-1198	ea
42-5864	USE 37-1798	ea
42-5866	USE 37-1230	ea
42-5867/5868	brakeshoe set,8" front	PR
42-5869	USE 551-951	ea
42-5873	USE 37-3969	ea
42-5875	USE 37-3970	ea
42-5876	USE 68-5515/5516	ea
42-5878	USE 551-2031	ea
42-5882	arm,brake oper,front	EA
42-5883	USE 37-1798	ea
42-5905	USE 42-5589	ea
42-5906	USE 42-6002/A	ea
42-6002	rim,WM3x19,BSA rear,QD	EA
42-6002/A	rim,WM3x19 R,alloy,w/shoulder	EA
42-6002/SS	rim,WM3x19,BSA rear,QD,stainless	EA
42-6011	USE 37-2292	ea
42-6012	USE 37-2293	ea
42-6018	sprock&brakedrum assy,46T,5/8x3/8	EA
42-6019	USE 37-2314	ea
42-6022	USE 68-6114	ea
42-6024	sprock&brakedrum assy,42T,5/8x1/4	EA
42-6025	sprock&brakedrum assy,46T,5/8x1/4	EA
42-6036	bracket,brakeplate anchor	EA
42-6040	bolt,chain adj,A10 etc.	EA
42-6056	sprock&brakedrum assy,46T,5/8x1/4,finned	EA
42-6069	sprocket,42T,4 bolt,Ariel type	EA
42-6105	washer,cup,wheelbrg.	EA

42-6306	USE 67-6005	ea
42-6320	axle, rear, fullwidth iron hub	EA
42-6327	nut, special, rear sprocket	EA
42-6331	sprocket, 42T, 4 bolt hub, late	EA
42-6333	USE 42-6331	ea
42-6335	USE 37-0582	ea
42-6360	USE 37-2318 *	ea
42-6361	USE 37-2318 & SPROCKET *	ea
42-6362	USE 37-2318 & SPROCKET *	ea
42-6371	USE 37-2291	ea
42-6377	USE 67-6005/A	ea
42-6379	USE 40-6080/A	ea
42-6503/CHR	mudguard, F, DBD34, scrambler, 6 tab	EA
42-6505	bracket, mudguardStay, centre, chr	EA
42-6509	USE 42-6509/CHR	ea
42-6509/CHR	mudguard, F, DBD34, chrome, 6 hole	EA
42-6510	bracket, fenderstay, top&bot, Goldstar, chr.	EA
42-6511	bracket, mudguardStay, centre, Goldstar, chr	EA
42-6529	bracket, mudguard stay	EA
42-6536	mudguard, F, RGS, chrome, 6 tab	EA
42-6543	USE 68-6536	ea
42-6544	USE 68-6536	ea
42-6545	USE 68-6536	ea
42-6547	bracket, fenderstay, centre, R&L	EA
42-6548	USE 42-6560	ea
42-6550	bracket, fenderstay & stand	EA
42-6553	mudguard, fr, valanced, w/brackets, chrome	EA
42-6554	USE 57-2703	ea
42-6555	USE 42-6553	ea
42-6560	bracket, fenderstay, L&RH, chrome	EA
42-6560/A	bracket, fenderstay, L&RH, painted	EA
42-6564	USE 68-6548 or 68-6549	ea
42-6761/6762	brackets, mudguardstay, rear	ST
42-6782	plate, mudguard support	EA
42-6831/CHR	mudguard, R, DBD34, chrome*	EA
42-6834/6836	brackets, mudguard, rear, GSclubman, chrome	ST
42-6846/6848	brackets, mudguard, rear, Goldstar	ST
42-6858/6860	brackets, mudguard, rear, A10 swingarm	ST
42-6865	grab handle, A7/10 swingarm models	EA
42-6887	USE 67-6885	ea
42-6893/6895	brackets, mudguard, rear, A10, late	ST
42-6900	USE 06-0471	ea
42-6901	bolt, 3/8X26	EA
42-6901/CHR	bolt, 3/8X26, chrome	EA
42-6911	mudguard, R, RGS, chrome	EA
42-7005	pedal, brake, Gold Star Clubman rearset	EA
42-7007	brakerod, preunit*	EA
42-7027	pedal, rear brake, A10 type	EA
42-7030	USE 526-427030	ea
42-7032	USE 526-427030	ea
42-7034	USE 526-427042	ea
42-7039	USE 42-7027	ea
42-7042	USE 526-427042	ea
42-7504	washer, felt, inner primary	EA
42-7507	gask, pri, preunit s.armBSA	EA
42-7509	gask, pri. inner, preunit s.armBSA	EA
42-7518	plate, inner pri. support, preunit	EA
42-7520	bolt, special, sliding plt, long	EA
42-7701	chainguard, A7/10 SA, early type*	EA
42-7705	chainguard, DBD34*	EA
42-7705/CHR	chainguard, DBD34, chrome	EA
42-7706/CHR	chainguard, RGS, chrome*	EA
42-7722	chainguard rear section	EA
42-7730	chainguard, s.arm preunit, late type*	EA
42-7732	USE 42-7730	ea
42-7834	airfilter element, disc style	EA
42-8010	rubber plug, BSA gas tank	EA
42-8010/ER	rubber plug, BSA gas tank, econo repl.	EA
42-8011	bolt, stepped, gas tank	EA
42-8013	USE 83-4931	ea
42-8017	USE 83-0260	ea

42-8020	clip,round tankbadge mtng	EA
42-8033	metalastic,float chamber,etc.	EA
42-8034	nut,5BA	EA
42-8037	bolt,gas tank,special	EA
42-8051	pad,rubber,tank mt.	EA
42-8052	USE 82-9062	ea
42-8098	spacer	EA
42-8105	USE 65-8228	ea
42-8112	decals,A10 SPITFIRE SCRAMBLER	EA
42-8114	bracket,kneepad,LH*	EA
42-8114/8115	brackets,kneepad	PR
42-8115	bracket,kneepad,RH*	EA
42-8164	USE 41-8051	ea
42-8334	USE 42-8426	ea
42-8340	USE 83-0006	ea
42-8341	rubber bush,oiltank	EA
42-8344/8345	oiline set,preunit BSA,armoured	PR
42-8346/8347	oiline set,swingarm A7/10,armoured	ST
42-8385	bolt,"T",oiltank mount	EA
42-8422	oiline set,preunit BSA,armoured	PR
42-8426	filterscreen assy,oiltank,PU,chrome	EA
42-8426/SS	filter screen,oiltank,A10,stainless	EA
42-8611	compr.rel.lever,original	EA
42-8665	USA 523-18824	EA
42-8670	USE 526-527	ea
42-8674	USE 526-527	ea
42-8685	USE 523-18823	ea
42-8766	USE M40/27	ea
42-8769	USE 526-M40/29	ea
42-8771	USE 526-538	ea
42-8775	USE 526-733	ea
42-8802	USE 526-2/534/6 *	ea
42-9075	USE 42-9165	ea
42-9116	USE 42-9203/9304 (set)	ea
42-9165	grabrail,preunit swingarm,chrome	EA
42-9169	bolt,5/16x26	EA
42-9172	USE 42-9165	ea
42-9173	USE 42-9165	ea
42-9183	rubber buffer,seat base	EA
42-9187	USE 65-9267*	ea
42-9196	bracket,seat rear	EA
42-9203/9204	bracket set,hdlt,GS Clubman	ST
42-9204	bracket,hdlt,bot,GS Clubman	ST
42-9230	USE 511-307	ea
46-	TRIUMPH AND BSA PARTS	*
46-----	-----	---
46-0004	USE 523-18053	ea
46-0006	USE 14-0303	ea
47-	BSA PARTS	*
47-----	-----	---
47-3214	USE 57-4198	ea
47-4214	USE 82-8994	ea
47-5064	USE 97-2632	ea
47-5065	USE 97-2633	ea
47-6806	USE 82-9198	ea
47-9012	USE 60-1841	ea
53-	BSA PARTS	*
53-----	-----	---
53-0243	USE 82-9089	ea
53-5512	nipple,12Gx.250"	EA
54-	BSA PARTS	*
54-----	-----	---
54-0022	USE 60-4250	ea
54-0042	USE 97-0430	ea
54-0055	USE 60-4247	ea
54-0124	USE 97-0193	ea
54-2537	USE 70-7512 or 742-138/A	ea
54-4302	USE 60-4263	ea
54-4306	USE 60-4261	ea
54-4307	USE 60-2331	ea
54-5023	USE 391-189307	ea

54-5504	USE 82-4299	ea
54-6510	USE 97-0687	ea
54-8003	USE 60-4260	ea
54-9003	USE 83-0033	ea
54-9012	USE 70-7354	ea
54-9017	USE 82-4717	ea
54-9081	USE 60-4245	ea
57-	TRIUMPH AND BSA PARTS	*
57-----	-----	---
57-0023	bush,gearbox	EA
57-0024	USE 57-4756	ea
57-0025	USE 57-4117	ea
57-0031	spring,kickstart return	EA
57-0031/ER	spring,kickstart return,econo	EA
57-0044	plunger,shift detent	EA
57-0045	pin,kick quadrant stop	EA
57-0047	pin,anchor,kickspring	EA
57-0057	bush,gbx,shifter outer	EA
57-0224	nut,5/16x26,thin	EA
57-0260	USE 57-2596	ea
57-0280	circlip,mainshaft brg,RH,early*	EA
57-0290	bush,layshaft,pre1950	EA
57-0291	rod,shifter forks,early	EA
57-0323	stud,5/16x26x18	EA
57-0361	bolt,1/4x26	EA
57-0372	housing,det.plunger,18TPI	EA
57-0373	spring,camplate detent	EA
57-0394	bearing roller,clutch hub	EA
57-0397	quadrant,camplateOper,4sp	EA
57-0400	USE 70-1564 *	ea
57-0404	USE 57-7051	ea
57-0405	spring,quadrant plunger	EA
57-0406	plunger,gearshift quadrant	EA
57-0407	plate,guide,shift	EA
57-0408	shaft only,quadrant,gearshift	EA
57-0408/9	quadrant assy,gearshift,4spd. *	EA
57-0409	quadrant only,gearshift,4spd	EA
57-0412	bush,gbx,shifter inner	EA
57-0413	adjuster,cl.rod,preunit	EA
57-0414	USE 57-1362	ea
57-0415	USE 57-1363	ea
57-0417	clutch centre,4spring cl.	EA
57-0418	clutch hub,preunit 5/650*	EA
57-0420	washer,mainshaft	EA
57-0421	nut,mainshaft,9/16x20CEI	EA
57-0422	thrust button,cl.center	EA
57-0423	USE 57-4754	ea
57-0425	USE 57-1934	ea
57-0427	USE 57-2526	ea
57-0429	spring,clutch,SV500 etc	EA
57-0430	bolt,3/8x26,gearbox pivot	EA
57-0440	nut,gbx sprocket,4 speed	EA
57-0446	USE 57-1370	ea
57-0448	USE 60-3556	ea
57-0449	USE 532-49/B	ea
57-0451	USE 57-7018(folding type)	ea
57-0453	nut,3/8x26,unplated	EA
57-0454	USE 21-0547 & 14-0301	ea
57-0455	USE 57-1552	ea
57-0456	stud,5/16x26	EA
57-0461	nut,special,beveled	EA
57-0471	USE 57-1815	ea
57-0471/21	sprocket,gbx,preunit,21T	EA
57-0471/22	sprocket,gearbox,preunit,22T	EA
57-0472	USE 57-1715	ea
57-0480	cover,pri.outer,gen/rigid	EA
57-0484	USE 57-1381	ea
57-0487	lever,cl.oper,latePreunit	EA
57-0489	USE 70-0489	ea
57-0495	rubber boot,cl.oper.lever	EA
57-0496	screw,adjuster,oil	EA

57-0497	spring,chainoiler screw,pri.	EA
57-0500	USE 57-4055	EA
57-0503	gasket,pri,3T&TR5,gen/rig	EA
57-0504	gasket,pri.cov,rigid gen,6T	EA
57-0524	washer,tab,preunit clutch	EA
57-0530	USE 391-189307	ea
57-0665	bearing,ball	EA
57-0730	pinion,kickstart ratchet,18T*	EA
57-0731	ratchet,kick,T140/T150etc	EA
57-0732	USE 57-2240	ea
57-0766	chainguard,rigid frameTri,shallow	EA
57-0872	clutch centre,4spring cl.	EA
57-0891A	chainguard,TR5 sprung hub,shallow	EA
57-0903	gear,3rd lay,22T,early	EA
57-0911	USE 57-1367	ea
57-0912	USE 62-0072	ea
57-0913	shifter fork,lay,4speed,steel*	EA
57-0914	USE 57-2436;21-0586;21-0594;57-4794	ea
57-0916	gear,2nd main,early	EA
57-0917	gear,3rd main,24T,early	EA
57-0920	USE 57-1370	ea
57-0925	pin,speedodrive gear	EA
57-0926	USE 57-3862	ea
57-0928	bush,layshaft 1st gear	EA
57-0930	gear,3rd lay,22T,early	EA
57-0933	bush,speedo drive	EA
57-0940	clutch drum,preunit Tri,9 plate*	EA
57-0946	oilseal,gbx.sprocket,4spd	EA
57-0968	gear,2nd main,19T,early	EA
57-0974	gear,2nd lay,27T,early	EA
57-0981	disc,blanking,layshaft	EA
57-0985	USE 57-1549	ea
57-0986	pressure plate,cl,preunit Tri.	EA
57-0989	dowel,hollow	EA
57-0993	chainguard,TRW,deep	EA
57-0997	USE 57-1564	EA
57-0998	USE 57-1931	ea
57-0999	USE 57-1560 *	ea
57-1031	USE 57-1381	ea
57-1037	clutch centre,5T type	EA
57-1038	clutch centre,6T type	EA
57-1039	plate,clutch centre,inner,4spring	EA
57-1040	screw,1BA,countersunk,cl.centre	EA
57-1041	spider,clutch centre,4 spring	EA
57-1043	USE 57-1473	ea
57-1044	plate,clutch centre,outer,4spring	EA
57-1045	washer,cupped,clutch	EA
57-1046	washer,tab,clutch nut	EA
57-1047	nut,clutch,20TPI	EA
57-1055	cover,pri.inner,rigid alt.	EA
57-1056	cover,pri.outer,rigid alt.	EA
57-1057	gasket,pri.cov,rigid alt.	EA
57-1059	grommet,alt.wire,pre.unit	EA
57-1064	USE 57-3859	ea
57-1065	USE 57-3861	ea
57-1070	USE 37-7041	ea
57-1076	bolt,2BA	EA
57-1081	USE 57-1513/17	ea
57-1098	shifter fork,Cub	EA
57-1109	spring,shift quadrant	EA
57-1112	plug,drain/level,gbx,BSW	EA
57-1118	bush,kickstart	EA
57-1124	USE 422-532	ea
57-1132	rubber,cl.centre,Cub,lg.	EA
57-1140	pushrod,clutch,Tiger Cub	EA
57-1144	USE 57-3951	ea
57-1147	bush,inner timing cov,C15	EA
57-1150	screw,2BA,conical head	EA
57-1157	plate,stop,kick quadrant	EA
57-1160	USE 57-1282	ea
57-1161	spring,plunger,kickpawl	EA

57-1162	spring,kickstart,1 cyl.	EA
57-1163	plate,kick spring,Cub	EA
57-1164	lever,gearshift,BSA type *	EA
57-1164/ER	lever,gearshift,BSA type,econo	EA
57-1165	USE 57-1679	ea
57-1167	spring,detent,kick pedal	EA
57-1169	bolt,kickstarter pedal*	EA
57-1180	washer,tab	EA
57-1185	USE 57-1472	ea
57-1186	cover,pri.inner,gen/swingarm	EA
57-1189	gasket,pri.cov,gen/sw.arm	EA
57-1190	cover,pri.outer,gen/swingarm	EA
57-1194	lever,gearshift,pre.unit	EA
57-1222	USE 57-4356	ea
57-1226	gasket,pri.cov,alt/sw.arm	EA
57-1231	USE 57-1600	ea
57-1232	USE 57-1651	ea
57-1237	USE 57-1651	ea
57-1249	backing,leafspring,1cyl	EA
57-1250	spring,kick ratchetpinion	EA
57-1256	USE 57-2729	ea
57-1257	washer,sealing,gbx.drain	EA
57-1264	bearing ring,clutch,Cub	EA
57-1270	USE 57-7018 *	ea
57-1271	kickstart arm,pre.unit	EA
57-1272	USE 57-7017	ea
57-1273	bolt,5/16x26,kickstart,early	EA
57-1275	cover,pri.outer,TRW500	EA
57-1278	USE 57-2106	ea
57-1279	shaft,kick,C15/T20	EA
57-1281	pawl,kickstart,single cyl.	EA
57-1282	plunger,kick,pawl	EA
57-1314	clutch centre,Cub	EA
57-1315	clutch,plain steel,Cub	EA
57-1318	rubber,cl.centre,Cub,sm.	EA
57-1338	USE 57-1963	ea
57-1362	cl.plate,friction,Tri/BSA twin	EA
57-1362/A	clutch plate,Barnett hiPerf	EA
57-1362/B	clutch 1/2 plate,Barnett	EA
57-1362/C	clutch plate,Barnett Kevlar	EA
57-1362/D	clutch kit,HYDE hiPerf *	ST
57-1362/E	clutch plate,heavydutyUS made	EA
57-1362/ER	clutchplate,friction,econ	EA
57-1362/F	cl.plate,friction,Tri/BSA twin,alloy	EA
57-1363	clutchplate,plain steel	EA
57-1363/A	clutchplate,plain steel,BARNETT	EA
57-1363/B	clutchplate,plain alloy	EA
57-1367	bush,layshaft,Tri,50on	EA
57-1370	bush,gbx,4th main,twins	EA
57-1381	plate,inner pri	EA
57-1390	screw,1/4x20,special	EA
57-1391	bush,cl.rod,unit500&1cyl.	EA
57-1393	bush,1st lay,unit 350/500	EA
57-1395	bush,shift,outer cover	EA
57-1396	plunger,shift quadrant	EA
57-1399	stud,3/8xBSW/CEI	EA
57-1401	screw	EA
57-1402	screw,1/4x26	EA
57-1405	bush,4th gear,350/500	EA
57-1406	mainshaft assembly,early	EA
57-1410	gear,2nd main,early	EA
57-1411	spacer,mainshaft RH	EA
57-1414	gear,1st lay,32T,early	EA
57-1416	pointer,gearshift indic.	EA
57-1417	plate,gearshift indicator	EA
57-1418	shaft,camplate	EA
57-1422	plate,kick return spring	EA
57-1426	washer,thrust,gearbox	EA
57-1431	pawl,kickstart,TRI350/500	EA
57-1432	spring,shift quad.ret,early	EA
57-1433	button,thrust,cl.release,early	EA

57-1434	nut,gearbox sprocket	EA
57-1435	lever,gearshift,unit 500*	EA
57-1436	spring,shift quad plunger	EA
57-1439	bolt,5/16x26,small hex	EA
57-1440	pin,dowel,hollow	EA
57-1441	spring,kickstart,350/500	EA
57-1446	bush,kickstart spindle	EA
57-1448	USE 57-3754	ea
57-1457	shaft,shift fork,unit 350/500	EA
57-1459	clutch release worm,early	EA
57-1464	spacer,kickstart spring	EA
57-1466	pressure plate,cl,4spring*	EA
57-1469	bearing,ball	EA
57-1471	USE 57-0044	ea
57-1472	rubber,clutch shock abs.	EA
57-1472/1473/A	cl.rubber kit,2cyl,HEAVYDUTY,4spring	ST
57-1473	rubber,clutch shock abs.	EA
57-1476/16	sprock,gbx16T,unit350/500	EA
57-1476/18	sprock,gbx18T,unit350/500	EA
57-1476/18/ER	sprock,gbx,18T,unit350/500,econo	EA
57-1476/19	sprock,gbx19T,unit350/500	EA
57-1476/19/ER	sprock,gbx19T,unit350/500,econo	EA
57-1476/20	USE 57-1569	EA
57-1476/21	sprock,gbx21T,unit350/500	EA
57-1477	gasket,inner pri,preunit	EA
57-1478	oilseal,gbx.spr,350/500	EA
57-1480	shifter fork,mainshaft	EA
57-1481	shifter fork,layshaft	EA
57-1483	quadrant,gearshift,early	EA
57-1485	kickcrank assy,350/500unit,short	EA
57-1485/ER	kickstart crank assy,repr	EA
57-1503	clutch plate,friction,cub	EA
57-1503/A	clutchplate,friction,cub,BARNETT	EA
57-1512	rubber,kickshaft,preunit	EA
57-1513/16	sprocket,gbx,16T,Cub	EA
57-1513/17	sprocket,gbx,17T,Cub	EA
57-1513/18	sprocket,gbx,18T,Cub	EA
57-1534	cover,gbx outer,preunit,late	EA
57-1541	gasket,insp,gbx,preunit	EA
57-1542	cover,insp,gearbox,preunit	EA
57-1549	clutch drum,preunit 4spr.	EA
57-1549/ER	cl.drum,preunit 4spr,econo repl	EA
57-1552	pushrod,clutch,preunit	EA
57-1553	screw,1/4x26	EA
57-1555/13	sprocket,gearbox,Cub,13T	EA
57-1555/14	sprocket,gearbox,Cub,14T	EA
57-1555/15	sprocket,gearbox,Cub,15T	EA
57-1558	sprock,gbx17T,unit350/500	EA
57-1559	USE 57-0429	ea
57-1560	spring,clutch press.plate	EA
57-1564	lever,gearshift,heel &toe	EA
57-1568	sprocket,gbx,19T,Cub	EA
57-1569	sprocket,gbx,350/500,20T	EA
57-1569/ER	sprocket,gbx,350/500,20T,econo	EA
57-1570	clutch drum,duplex,58T	EA
57-1570/A	clutch drum,duplex,alloy*	EA
57-1570/ER	clutch drum,duplex,econo repl.	EA
57-1599	cap,slotted,gbx.fill,Cub,5/8x14	EA
57-1600	cover,pri.inner,alt/swingarm*	EA
57-1600/1601/A	cover set,pri.alt/swingarm	ST
57-1601	cover,pri.outer,alt/swingarm*	EA
57-1603	USE 57-1600	ea
57-1604	spring,camplate,strong	EA
57-1606	bearing,needle,closed end	EA
57-1607	washer,thrust,layshaft	EA
57-1607/A	washer,thrust,PM hi perf.	EA
57-1608	USE 57-1843	ea
57-1614	bearing,needle,open end	EA
57-1633	gear,1st lay,33T	EA
57-1637	cover,gearbox outer,early	EA
57-1644	adaptor,cl. cable,BSW*	EA

57-1645	USE 57-2062	ea
57-1646	rubber cover,cable to housing	EA
57-1651	cover,pri.outer,alt/swingarm	EA
57-1652	gear,4th main,25T,Cub	EA
57-1657	layshaft assy,20&25T,Cub	EA
57-1659	gear,3rd lay,22T,Cub	EA
57-1677	USE 57-3797*	ea
57-1678	USE 57-3742	ea
57-1679	kickstart crank assy,Cub,etc,short	EA
57-1680	arm,kickstart,Cub,etc,short	EA
57-1681	kickstart crank assy,Cub,etc,long	EA
57-1708	lever,clutch release mech	EA
57-1710	shaft,clutch release	EA
57-1711	USE 57-7035	ea
57-1712	spring,clutch release	EA
57-1713	screw,1/4x26,flathead	EA
57-1714	spoke,clutch release	EA
57-1715	sprocket,gbx,19T,preunit	EA
57-1715/ER	sprocket,gbx,19T,preunit,econo	EA
57-1717	USE 57-4435	ea
57-1719	clutch centre,early type *	EA
57-1720	plate,inner,clutch centre,early*	EA
57-1721	USE 57-2538	ea
57-1722	rubber,clutch centre,lg.	EA
57-1722/1723/A	cl.rubber kit,2cyl,HEAVYDUTY	ST
57-1723	rubber,clutch centre,sm.	EA
57-1723/A	cl.rubber kit,3Cyl,HEAVYDUTY	ST
57-1724	plate,clutch centre,outer,early*	EA
57-1727	USE 71-4072	ea
57-1734	USE 57-3929 *	ea
57-1735	washer,thrust,w/tabs*	EA
57-1735/A	washer,thrust,early,performance	EA
57-1736	clutch rod,Tri 650/750	EA
57-1736/A	clutch rod,Tri6/750,PM HiPerf.	EA
57-1738	washer,fibre	EA
57-1742	spring,clutch,Cub	EA
57-1745	gear,speedo drive,15T	EA
57-1749	sprocket,gbx,preunit,20 T	EA
57-1750	USE 57-3757	ea
57-1751	USE 57-3930 *	ea
57-1768	USE 57-4218	ea
57-1769	USE 57-1830	ea
57-1770	USE 71-7009	ea
57-1771	USE 422-38	ea
57-1778	bolt,5/16x22	EA
57-1779	bolt,5/16x22 allen	EA
57-1815	sprocket,gbx,preunit,18T	EA
57-1815/ER	sprocket,gbx,preunit,18T,econo	EA
57-1816	sprocket,gbx,preunit,17 T	EA
57-1830	spring,clutch	EA
57-1830/A	cl.springs,BARNETT HiPerf.	ST
57-1832	gear,2nd main,20T	EA
57-1837	USE 57-4031	ea
57-1839	USE 57-3997	ea
57-1842	gear,3rd lay,21T,CR	EA
57-1843	layshaft assy.w/20T gear	EA
57-1844	layshaft assy w/18T gear	EA
57-1845	layshaft assy w/22T gear	EA
57-1871	clutch release housing	EA
57-1874	spacer,cl.release,350/500	EA
57-1876	spacer,gearbox	EA
57-1877	spring,shift quad.return	EA
57-1878	button,thrust,cl.release,late	EA
57-1880	USE 57-4439	ea
57-1896	shaft,oper.quad,RH shift	EA
57-1897	bearing,needle	EA
57-1914	gear,4th main,26T*	EA
57-1916	sprocket,gbx,late4spd,17T*	EA
57-1917	sprocket,gbx,late4spd,18T*	EA
57-1917/ER	sprocket,gbx,late4spd,18T,econo*	EA
57-1918	sprocket,gbx,late4spd,19T*	EA

57-1918/ER	sprocket,gbx,late4spd,19T,econo	EA
57-1919	sprocket,gbx,late4spd,20T*	EA
57-1919/22	sprocket,gbx,late4spd,22T*	EA
57-1919/A	sprocket,gbx,late4spd,21T*	EA
57-1919/ER	sprocket,gbx,late4spd,20T,econo*	EA
57-1920	plug,welch,crankcase	EA
57-1922	USE 57-3994	ea
57-1927	USE 57-3951	ea
57-1928	clutch assy,duplex chain 650	EA
57-1929	USE 57-2156&2159& 14-0403	ea
57-1931	cup,clutch spring	EA
57-1934	cup,clutch spring	EA
57-1935	USE separate components	ea
57-1937	nut,cl.rel.spoke	EA
57-1938	USE 57-7018	ea
57-1939	USE 57-7018 (assy)*	ea
57-1942	USE 57-4888	ea
57-1945	spoke,clutch release mach	EA
57-1946	connector,cl.release mech	EA
57-1949	USE 57-4041	ea
57-1950	USE 57-3999	ea
57-1952	sprocket,gbx,late4spd,15T	EA
57-1953	sprocket,gbx,late4spd,16T	EA
57-1955	washer,cupped,seal housing	EA
57-1956	oilseal,kickstarter,etc.	EA
57-1960	USE 57-4042	ea
57-1961	USE 57-4033	ea
57-1962	washer,3/4",kick pinion	EA
57-1963	bush,steel,kick pinion	EA
57-1970	pushrod,clutch,unit 500	EA
57-1977	cover,return spring housing	EA
57-1981	shaft,kick,TRI 350/500*	EA
57-1997	kickstart hub,splined (assy)	EA
57-2006	USE 60-4252	ea
57-2009	nut,mainshaft RH,CEI	EA
57-2056	washer,tab,gbx. sprocket	EA
57-2060	USE 57-1844	ea
57-2062	adaptor,cl.cable,slottedS*	EA
57-2063	adaptor,cl.cable,slottedL	EA
57-2065	lever,cl.rel,internal,C15	EA
57-2093	USE 57-1843	ea
57-2095	USE 57-7018 (assy)*	ea
57-2106	spring,shift quad plunger	EA
57-2113	USE 57-7018	ea
57-2116	washer,tab.sprocket,4spd	EA
57-2137	cover,gearbox inner,T150	EA
57-2153	USE 57-3633	ea
57-2156	pressure plate,clutch*	EA
57-2156/A	pr.plt,alloy w/needle brg	EA
57-2156/B	pressureplate,alloy	EA
57-2159	screw,clutch rod adj.	EA
57-2159/A	screw with ball,clutch adjuster	EA
57-2159/B	screw,cl.rod adj,allen	EA
57-2163	USE 57-1845	ea
57-2165	USE 71-1451	ea
57-2166	cap,inspection,slotted*	EA
57-2166/A	cap,inspection,hex style*	EA
57-2166/B	cap,inspection,slotted,billet alloy*	EA
57-2167	plug,gbx.drain & level,UNC	EA
57-2168	plug,gbx.drain,UNC*	EA
57-2169	quadrant,kick,early 3cyl.*	EA
57-2170	kickstart ratchet pinion,early3cyl,22T*	EA
57-2172	housing,index plunger,UNF	EA
57-2173	USE 57-7018 *	ea
57-2174	mainshaft assy,16T,T150	EA
57-2176	gear,4th main,3 cylinder	EA
57-2191	USE 57-7034	ea
57-2214	washer,thrust,bronze*	EA
57-2215	washer,thrust	EA
57-2220	abutment,cl.cable,UNC	EA
57-2238	washer,cup,kickseal	EA

57-2239	oilseal,kick,Tri.350/500	EA
57-2240	washer,tab,mainshaft RH	EA
57-2244	USE 71-1455	ea
57-2245	USE 57-4225	ea
57-2250	USE 57-1723	ea
57-2251	USE 57-1723	ea
57-2252	USE 57-4004 *	ea
57-2259	plug,pri.drain & adj,7/16x14UNC	EA
57-2275	USE 57-4039	ea
57-2279	USE 57-4794	ea
57-2297	USE 57-4755 *	ea
57-2316	USE 57-3891	ea
57-2326	gear,1st lay,29T,Cub	EA
57-2330	USE 532-80	ea
57-2331	USE 532-49/A	ea
57-2335	USE 57-3797	ea
57-2378	USE 57-3889	ea
57-2379	gear,3rd lay,22T	EA
57-2436	mainshaft assy w/16T gear	EA
57-2439	USE 71-3555	ea
57-2440	cover plate,alt. rotor	EA
57-2440/A	cover,finned,alt.rotor	EA
57-2442	USE 71-1457	ea
57-2443	pointer,ign.timing	EA
57-2450	USE 532-15	ea
57-2465	thrust plate,inner,3cyl.cl.rel.	EA
57-2471	spider,cl,short,3cyl,69/70	EA
57-2473	spring,leaf,cl.release	EA
57-2474	washer,tab,3cyl.clRelease	EA
57-2478	spacer,clutch,3cyl	EA
57-2479	sleeve,oilseal,3cyl.cl*	EA
57-2480	nut,clutch,triple	EA
57-2480/A	nut,clutch,triple,heavy duty	EA
57-2526	nut,clutch spring adjust.	EA
57-2534	gear,4th main,23T wide ratio	EA
57-2536	nut,gbx.sprocket	EA
57-2537	pointer,ign.timing	EA
57-2538	USE 57-4636	ea
57-2540	abutment,cl.cable,68 650	EA
57-2547	lever,cl.rel,3cyl.	EA
57-2552	pullrod,clutch,3 cylinder	EA
57-2552/A	pullrod,clutch,conical end	EA
57-2553	nut,sleeve,cl.rel,3cyl.	EA
57-2554	housing,clutch,A75/T150	EA
57-2556	USE 71-1452	ea
57-2557	tube,breather hose,3cyl.	EA
57-2558	USE 71-1453	ea
57-2580	clutch hub,3 cylinder*	EA
57-2580/A	cl.hub,3cyl,Hyde HiPerf.	EA
57-2581	USE 71-1454	ea
57-2595	roller,shift fork,pre71	EA
57-2596	shifter fork,main,4speed,steel*	EA
57-2601	USE 57-4329	ea
57-2603	USE 57-2737	ea
57-2641	oilseal.kickstart shaft	EA
57-2642	bush,kickshaft,1 cylinder	EA
57-2643	USE 57-4592	ea
57-2645	USE 57-7017	ea
57-2646	pedal,kickstarter	EA
57-2648	USE 532-74	ea
57-2649	USE 57-2764	ea
57-2652	kickstart arm,BSA twin	EA
57-2653	arm,kickstart,A75 pre71	EA
57-2656	dipstick,gearbox,3cyl.*	EA
57-2657	pin,kickstart quad stop	EA
57-2659	pin,gearshift spring	EA
57-2661	mainshaft,unit singles	EA
57-2664	washer,thrust,.075"	EA
57-2665	washer,thrust,.070"	EA
57-2666	washer,thrust,.080"	EA
57-2667	layshaft assy,unit 1cyl.	EA

57-2668	gear,2nd lay,22T	EA
57-2669	circlip,gearbox	EA
57-2670	washer,shim,layshaft	EA
57-2671	washer,thrust,.083"	EA
57-2672	washer,thrust,.079"	EA
57-2677	washer,felt,gbx.sprocket	EA
57-2678	washer,thrust,.094"	EA
57-2679	washer,thrust,.098"	EA
57-2680	washer,thrust,.103"	EA
57-2681	kickstart ratchet,early	EA
57-2682	bush,steel,kick pinion	EA
57-2683	kickstart ratchet pinion	EA
57-2684	spring,kickstart ratchet	EA
57-2685	washer,tab,m.shaft,early	EA
57-2686	nut,1/2x20,small hex	EA
57-2687	spring,kickstart return	EA
57-2688	shaft,shift fork,1cyl.	EA
57-2689	shifter fork,1cylinder	EA
57-2690	camplate,gearbox,TRIBSA 1cyl,pre69	EA
57-2691	spring,leaf,gbx detent	EA
57-2692	quadrant assy,gearshift,TriBsa 1cyl*	EA
57-2695	dipstick,gbx,unit singles	EA
57-2696	plug,drain	EA
57-2697	oring	EA
57-2699	clutch release rack,1cyl.	EA
57-2701	sprocket,gbx,16T,unit1cyl	EA
57-2702	washer,tab,gbx.sprock,BSA	EA
57-2703	bolt,1/4x26 *	EA
57-2713	clutch hub,unit singles	EA
57-2714	key,woodruff	EA
57-2715	spider,cl,TriBSA 1cyl	EA
57-2719	bearing,roller,cl,3/16	EA
57-2720	plate,cl.centre inner,w/studs	EA
57-2721	plate,cl.centre outer	EA
57-2722	screw,clutch center,1cyl.	EA
57-2723	rubber,cl.centre,singles	EA
57-2724	USE 57-4186	ea
57-2725	clutchplate,plain steel	EA
57-2726	clutchplate friction,Tri.	EA
57-2726/A	clutch plt,Barnett HiPerf.	EA
57-2726/B	clutch plt,Barnett KevlarRacing	EA
57-2727	spring,clutch,unit single	EA
57-2727/A	springs,clutch,unit1cyl,strong	ST
57-2728	pressure plate,cl,unit single	EA
57-2729	screw,clutch adj,1/4X26CEI*	EA
57-2730	nut,1/2x20CEI,mainshaft,LH	EA
57-2731	washer	EA
57-2732	washer,tab,1 cyl. clutch	EA
57-2733	pushrod,clutch,unitsingle	EA
57-2737	cover,gearbox outer,A75R	EA
57-2748	nut,clutch spring	EA
57-2750	lever,clutch release,1cyl	EA
57-2752	bush,1st gear layshaft	EA
57-2753	bush,4th gear,1cyl.	EA
57-2759	USE 532-74	ea
57-2763	USE 57-2764	ea
57-2764	kickstart crank assy,A50/65,etc.	EA
57-2764/ER	kickstart crank assy,A50/65etc,econo	EA
57-2765	sprocket,gbx,15T,unit1cyl	EA
57-2765/11	sprocket,gbx,11T,unit1cyl	EA
57-2765/13	sprocket,gbx,13T,unit1cyl	EA
57-2766	sprocket,gbx,17T,unit1cyl	EA
57-2766/18	sprocket,gbx,18T,unit1cyl	EA
57-2766/19	sprocket,gbx,19T,unit1cyl	EA
57-2767	camplate,A50/65	EA
57-2773	clutch drum,A50/A65,1965on	EA
57-2773/A	clutch drum,alloy,A50/A65,1965on	EA
57-2774	USE 57-7017	ea
57-2776	sprocket,gbx,14T,unit1cyl	EA
57-3126	USE 57-2679	ea
57-3173	USE 57-7018	ea

57-3610	slipper,pri. chain,upper,triples	EA
57-3614	pin,pivot	EA
57-3615	USE 57-3983	ea
57-3617	nut,pri.chain adjuster	EA
57-3618	spring,pri.adjuster,early	EA
57-3619	USE 57-2259	ea
57-3620	USE 70-6299	ea
57-3621	USE 60-3552	ea
57-3629	USE 57-7033	ea
57-3632	USE 57-7018	ea
57-3633	housing,oilseal,gbx,3cyl.	EA
57-3634	oilseal,4speed 3cylinder	EA
57-3638	spacer,cl.release,3cyl.	EA
57-3639	gask,cl.insp.cov,T150/A75,1968	EA
57-3642	oilseal,clutch,3 cylinder*	EA
57-3643	bearing,needle	EA
57-3644	oilseal,cl.pullrod,3 cyl	EA
57-3645	USE 57-4593	ea
57-3646	bearing,needle thrust	EA
57-3647	bearing,ball	EA
57-3650	USE 57-4055	ea
57-3660	plunger,shift detent	EA
57-3661	USE 57-0373	ea
57-3668	plug,gbx drain&level,UNC	EA
57-3673	washer,flat	EA
57-3705	cover,end,3cyl.cl. assy.	EA
57-3708	clutch housing,3cylpre'75	EA
57-3709	clutchplate,3cyl,standard	EA
57-3709/A	clutchplate,3cyl,exchange *	EA
57-3709/B	clutchplate,3cyl,HydeIron	EA
57-3709/C	lining kit,clutch,triples	EA
57-3709/D	clutchplate,3cyl,sintered bronze	EA
57-3715	clutch pressure plate3cyl	EA
57-3717	USE 06-5542	ea
57-3718	spring,clutch diaphramSTD	EA
57-3718/A	spring,clutch,Hyde,+12%	EA
57-3718/B	spring,clutch,Hyde,+20%	EA
57-3718/C	spring,clutch,Hyde,+40%	EA
57-3719	USE 21-2120	ea
57-3720	washer,tab,cl,cov,3cyl	EA
57-3721	USE 57-7018 *	ea
57-3732	kick quadrant assy,early 3cyl.	EA
57-3733	oring	EA
57-3742	arm,kickstart,splinedType,long	EA
57-3745	plug,camplate plunger,A65	EA
57-3750	cover,gearbox outer,T150	EA
57-3751	lever,gearshift,T150	EA
57-3754	cover,gearbox inner,T100R style	EA
57-3755	cover,gearbox outer,T100	EA
57-3757	lever,shift,RH Tri.6/750	EA
57-3757/ER	lever,shift,RH Tri.6/750,econo*	EA
57-3758	shaft,shift quadrant,A75	EA
57-3759	bush,gearshift outer,A75	EA
57-3760	cover,gearbox out,RHshift	EA
57-3761	USE 57-7035	ea
57-3762	abutment,cl.cable,UNC	EA
57-3766	USE 57-4795 ?	ea
57-3784	abutment,cl.cable,UNC	EA
57-3785	bush,gbx,4th main,3 cyl.	EA
57-3797	kickcrank assy,350/500unit,long	EA
57-3797/ER	kickcrank assy,350/500unit,long,econo	EA
57-3850	camplate,gbx,TriBSA,1cyl,late	EA
57-3851	plug,gbx.drain&level,UNC	EA
57-3854	shifter fork,late main	EA
57-3856	gear,1st main,16T*	EA
57-3857	gear,2nd main,20T,4 speed	EA
57-3858	USE 57-0917 *	ea
57-3859	gear,4th lay,20T*	EA
57-3860	gear,3rd lay,22T	EA
57-3861	gear,2nd lay,26T	EA
57-3862	gear,1st lay,30T	EA

57-3864	USE 57-1843	ea
57-3866	kick crank assy,D14/4	EA
57-3869	clutch assy,compl,1969D14/4	EA
57-3870	clutch drum,1969D14/4	EA
57-3872	gear,4th main,22T	EA
57-3874	gear,1st lay,27T	EA
57-3876	gear,2nd main,21T	EA
57-3877	gear,3rd lay,19T	EA
57-3889	gear,3rd main	EA
57-3890	gear,3rd lay,22T	EA
57-3891	gear,4th main,26T	EA
57-3892	USE 57-3891	ea
57-3893	USE 57-2436	ea
57-3921	USE 57-3931	ea
57-3929	clutch hub,A50/65&T120/40*	EA
57-3930	clutch hub,Tri unit 500	EA
57-3931	washer,thrust,w/out tabs	EA
57-3931/A	washer,thrust,PM hi-perf.	EA
57-3940	bolt,2BAx5/8	EA
57-3941	washer,tab,3cyl.cl.sprock	EA
57-3951	cup,cl.spring,unit single,early	EA
57-3953	USE 57-4593	ea
57-3954	cover,insp,3cyl. cl.adj.	EA
57-3954/A	cover,clutch adjust,Hyde"3"	EA
57-3954/B	cover,insp,3cyl.cl.adj,billet alloy	EA
57-3955	USE 71-1449	ea
57-3958	USE 57-4593	ea
57-3978	washer,alloy	EA
57-3983	rod,pri chain adjust,3cyl	EA
57-3986	eyebolt,pri.adjuster,3cyl.	EA
57-3988	bush,clutch pushrod	EA
57-3989	shaft,shifter fork	EA
57-3990	washer,abutment,cl.cable	EA
57-3991	gear 4th main,22T	EA
57-3994	gear,2nd main,21T	EA
57-3997	gear,3rd lay	EA
57-3999	gear,1st lay,27T,w/bush	EA
57-4004	plate,inner,cl.shockabsorber,3cyl	EA
57-4004/A	plate,inner,cl.sprocket,A75/T150,alloy*	EA
57-4006	USE 57-1370	ea
57-4007	USE 57-1405	ea
57-4008	cup,gearshift,lateBSAtwin	EA
57-4009	spring,shift quad,lateA65	EA
57-4023	cover,gearbox inner,A65	EA
57-4026	camplate,A50/65,late type*	EA
57-4027	spring,shiftquad,earlyA65	EA
57-4028	stop plate,shift,late A65	EA
57-4031	gear,2nd main,20T	EA
57-4033	gear,1st lay,29T	EA
57-4036	lever,clutch release mech	EA
57-4037	clutch release plate,A65	EA
57-4038	clutch release shaft,A65	EA
57-4039	mainshaft assy,unit 500	EA
57-4041	layshaft assy,unit 500	EA
57-4042	layshaft assy,14&24T,wide,T100C	EA
57-4049	clutch release assy,A65	EA
57-4051	nut,1-1/4UNF	EA
57-4054	oring	EA
57-4055	camplate,4 speed *	EA
57-4059	USE 57-0373	ea
57-4070	USE 57-4592	ea
57-4113	circlip,mainshaft brg,RH,late*	EA
57-4114	USE 57-1396	ea
57-4116	quadrant assy,shift,A50/65,late*	EA
57-4116/A	quadrant repair section,gearshift*	EA
57-4117	quadrant,kickstart*	EA
57-4121	cup,cl.spring,unit single,late	EA
57-4140	belt,drive,Ariel 3	EA
57-4155	layshaft assy w/20T gear	EA
57-4158	mainshaft assy.w/16T gear	EA
57-4175	mainshaft assy,4spd.3 cyl	EA

57-4186	clutch centre,unit single*	EA
57-4189	screw,clutch adjust,1/4X28UNF	EA
57-4194	clip,clutch cable boot	EA
57-4198	clutch drum,unit singles,52T	EA
57-4198/A	clutch drum,unit singles,52T,alloy	EA
57-4198/ER	clutch drum,unit singles,52T,econo repl.	EA
57-4200	USE 57-2713	ea
57-4218	camplate,unit 350/500*	EA
57-4225	sprocket,clutch,3cylinder	EA
57-4225/A	sprocket,cl,alloy racing,3cyl.	EA
57-4226	plunger,shift detent	EA
57-4288	spring,leaf type detent	EA
57-4289	support,leafspring,detent	EA
57-4290	washer,plate,detent sprng	EA
57-4291	washer,tab,gbx spring	EA
57-4293	cover,gbx.inner,71/72 4spd	EA
57-4300	cover,gbx.in,T100,late*	EA
57-4301	USE 57-4300	ea
57-4306	USE 57-2776	ea
57-4307	shifter fork,lay,4speed,brass*	EA
57-4308	shifter fork,main,4speed,brass*	EA
57-4311	USE 57-4300	ea
57-4312	kick spindle & quad.assy,71on*	EA
57-4314	USE 57-3785	ea
57-4323	USE 57-4621	ea
57-4324	USE 57-1723	ea
57-4326	USE 68-0377	ea
57-4327	USE 57-2137	ea
57-4329	cover,gearbox inner,A75R	EA
57-4332	gear,4th main,25T	EA
57-4335	gear,2nd main,20T	EA
57-4336	pinion,kickstart ratchet,B50/TR5MXonly	EA
57-4337	USE 57-4344	ea
57-4338	spring,kickstart return,B50	EA
57-4339	kickstart ratchet,B50/TR5MXonly	EA
57-4341	kick spindle assy,B50,only*	EA
57-4343	washer,tab,B50 rh m.shaft	EA
57-4344	mainshaft,unit singles,late	EA
57-4345	layshaft assy,19T	EA
57-4346	gear,4th main,22T	EA
57-4356	pin,kickstarter,w/nut	EA
57-4356/A	pin,kickstarter,unmilled	EA
57-4357	pin,kickstart,oversize	EA
57-4360	USE 57-4889 *	ea
57-4363	USE 57-7019	ea
57-4364	shifter fork,4th main,5sp	EA
57-4366	shifter fork,3rd lay,5spd	EA
57-4368	USE 57-4660 *	ea
57-4370	mainshaft,5speed 3cyl.	EA
57-4371	USE 57-4900	ea
57-4372	USE 57-4779 & 60-4100	ea
57-4374	quadrant only,gearshift,5 spd	EA
57-4374/0408	quadrant assy,gearshift,5spd.RH*	EA
57-4376	gear,4th main,5 speed	EA
57-4377	gear,3rd main,18T,5 speed*	EA
57-4379	USE 57-4575	ea
57-4380	USE 57-4653 *	ea
57-4381	USE 57-4661 *	ea
57-4382	USE 57-4900	ea
57-4383	USE 57-4900	ea
57-4384	USE 57-4900	ea
57-4387	USE 57-4647 *	ea
57-4388	USE 57-4657 *	ea
57-4390	USE 57-4577	ea
57-4391	USE 57-4654*	ea
57-4393	USE 57-4578	ea
57-4394	housing,oilseal,5spd.3cyl	EA
57-4395	USE 57-4909	ea
57-4396	nut,gearbox sprocket,5sp	EA
57-4396/A	nut,gbx.sprocket,5spd,performance	EA
57-4397	USE 57-4783	ea

57-4398	USE 57-4784	ea
57-4400	housing,camplate plunger	EA
57-4403	plunger,gearshift quadrant	EA
57-4407	USE 57-4795 ?	ea
57-4423	USE 57-4779 & 60-4100	ea
57-4424	USE 68-0377	ea
57-4432	USE 57-7076&7,21-2072&3 &21-2066	ea
57-4432/ER	mainshaft,5sp twin,econo.	EA
57-4435	clutch shockabsorber assy,twin	EA
57-4436	plate,cl.centre,lateInner*	EA
57-4437	plate,clutch centre,outer*	EA
57-4438	clutch centre,late type*	EA
57-4439	lever,clutch releaseMech.	EA
57-4441	USE 57-7034	ea
57-4452	washer,shim	EA
57-4459	spring,camplate plunger	EA
57-4508	USE 57-2720	ea
57-4510	USE 57-2721 ?	ea
57-4511	USE 57-4186	ea
57-4531	clutch shockabsorber assy,1cyl	EA
57-4533	USE 57-4782	ea
57-4536	USE 57-4779 & 60-4100	ea
57-4548	USE 57-4900	ea
57-4549	USE 57-4900	ea
57-4550	USE 57-4900	ea
57-4561	USE 57-1435	ea
57-4575	bush,gearbox,3rd main*	EA
57-4576	bush,gbx,4th lay,5 speed	EA
57-4577	bush,gbx,5speed	EA
57-4578	bush,gearbox,5speed	EA
57-4587	USE 57-7033	ea
57-4588	USE 57-7034*	ea
57-4589	USE 57-7035	ea
57-4590	USE 57-2156	ea
57-4592	kick spindle assy,early 3/4"*	EA
57-4592/ER	kick spindle assy,early,econo	EA
57-4593	cover,primary,late 3cyl.	EA
57-4596	pin,pivot,pri.chain adj	EA
57-4597	slipper,pri chain adj,1974 T150	EA
57-4603	USE 57-3854	ea
57-4609	USE 57-4795	ea
57-4612	dipstick,gearbox,lateT100	EA
57-4613	USE 57-4300 *	ea
57-4614	USE 57-4300 *	ea
57-4621	spider,cl,long,A75/T150	EA
57-4624	USE 57-4889 & 57-7020	ea
57-4628	USE 57-4779 & 60-4100	ea
57-4636	spider,clutch centre	EA
57-4639	kick spindle assy,late B50,TR5MXonly*	EA
57-4640	clutch drum,triplex T140	EA
57-4640/A	clutch drum,triplex,alloy,TR7/140	EA
57-4640/ER	clutch drum,triplex T140,econo	EA
57-4643	pointer,ign.timing	EA
57-4644	spring,clutch,750 twins	EA
57-4644/A	cl.springs,PM HiPerf	ST
57-4645	USE 57-2440	ea
57-4646	USE 82-4129	ea
57-4647	gear,3rd lay,18T,5speed	EA
57-4653	gear,1st&2nd main,5speed*	EA
57-4654	gear,1st lay,w/bushing	EA
57-4656	USE 57-4663	ea
57-4657	gear,2nd lay w/bush,5 spd	EA
57-4659	USE 57-4662	ea
57-4660	shifter fork,1st lay,5spd	EA
57-4661	dog clutch,driving,5speed	EA
57-4662	bush,gearbox,2nd lay,5spd	EA
57-4663	bush,gbx,1st lay,5 speed	EA
57-4672	USE 82-4129	ea
57-4699	bush,crosshaft,T160	EA
57-4702	cover,insp,gbx,T160	EA
57-4753	gasket,insp.cov,T160 gbx.	EA

57-4754	bolt,clutch spring pin	EA
57-4755	kick quadrant assy,6/750	EA
57-4756	kick spindle,T120 type	EA
57-4760	kickcrank assy,500unit	EA
57-4761	arm,kickstart,splined,late	EA
57-4763	USE 57-1362	ea
57-4771	dipstick,gearbox,T160 type *	EA
57-4779	gear,5th main,5 spd,complete*	EA
57-4780	gear,5th main,5 spd,bare*	EA
57-4781	USE 57-4779 & 60-4100	ea
57-4782	sprocket gbx,20T,5 speed	EA
57-4782/ER	sprocket gbx,20T,5 speed,econo	EA
57-4783	sprocket,gbx,19T,5 speed	EA
57-4783/ER	sprocket,gbx,19T 5sp,econo	EA
57-4784	sprocket,gbx,18T,5 speed	EA
57-4784/ER	sprocket,gbx,18T,8sp,econo	EA
57-4785	USE 57-4900	ea
57-4787	gear,4th lay,5 speed	EA
57-4790	circlip,5 speed gearbox	EA
57-4791	gear,5th lay,5 speed	EA
57-4794	washer,clutch centre,early*	EA
57-4795	cover,gbx.inner,RHshift	EA
57-4861	springplate,T160kickstart	EA
57-4875	gasket,breather cov, T160	EA
57-4878	gasket,gbx outer,T160	EA
57-4879	cover,gearbox outer,T160	EA
57-4881	quadrant,gearshift,T160	EA
57-4888	quadrant,gearshift,late T100	EA
57-4889	camplate,5 speed gearbox	EA
57-4891	USE 57-4879	ea
57-4892	USE 57-4117 + 57-4756 (or 57-4755 assy)	EA
57-4900	layshaft assembly,5 speed	EA
57-4901	layshaft,bare,5 speed *	EA
57-4902	USE 57-4660	ea
57-4903	clutch assy,triplex chain T140	ST
57-4906	kickstart hub,T160	EA
57-4909	washer,tab,gbx.sprock,5sp *	EA
57-4910	USE 57-4374/0408	ea
57-4911	cover,insp,T160 cl	EA
57-4911/A	cover,insp,T160 cl,HYDE	EA
57-4911/B	cover,insp,T160 cl,billet alloy	EA
57-4913	gasket,insp.cov,T160 cl	EA
57-4916	tabwasher,cl.rel,T160	EA
57-4917	spider,clutch,T160	EA
57-4920	sprocket,clutch,T160	EA
57-4923	gearshift spindle,T160	EA
57-4926	quadrant,crosshaft,LH,T160	EA
57-4927	sleeve,shifter,T160	EA
57-4929	tabwasher,crosshaft,T160	EA
57-4930	spacer,shifter,T160	EA
57-4933	lever,cl.rel,T160 type	EA
57-4937	slipper,pri.chain adjT160	EA
57-4941	kickstart crank assy,T160	EA
57-4948	USE 57-2656	ea
57-4978	bush,gearshift,T160	EA
57-4979	dustcover,gearshift,T160	EA
57-5001	USE 57-1723	ea
57-5089	link,crosshaft,T160 gearshift	EA
57-5120	USE 57-5121 *	ea
57-5121	cover,primary outer,T160	EA
57-7001	USE 57-7013	ea
57-7003	USE 57-7062	ea
57-7007	USE 57-7021	ea
57-7008	bush,gbx.out.cov,LH shift	EA
57-7009	bush,gbx.in.cov,LH shift	EA
57-7010	lever,gearshift,T140 LH*	EA
57-7011	shaft,oper.quad,LH shift	EA
57-7012	gask,gbx in.cov,LH shift	EA
57-7013	cover,gbx.inner,LH shift	EA
57-7014	USE 57-7024	ea
57-7015	plug,blanking,gbx.in.cov	EA

57-7016	retainer,blanking plug	EA
57-7017	pedal,kickstarter	EA
57-7017/A	pedal,kickstarter,HD type *	EA
57-7018	kickstart crank assembly	EA
57-7018/ER	kickstart crank assy,econ	EA
57-7019	quadrant,operating,gbx,5speed,early	EA
57-7020	plunger,5Speed,camplate	EA
57-7021	gearshift quad.assy,LH sh	EA
57-7024	cover,gbx.outer,LH shift	EA
57-7033	clutch release assy	EA
57-7034	lever,thrust,cl.release *	EA
57-7035	plate,oper,cl.release	EA
57-7041	pin,neutral light switch	EA
57-7046	spacer,neutral switch	EA
57-7049	cover,gbx.inner,LH shift	EA
57-7050	USE 57-7024	ea
57-7051	spring,shifter return	EA
57-7052	quadrant,operating,gbx,5spd,late	EA
57-7055	bush,gbx outer cover,kick	EA
57-7058	USE 57-1362	ea
57-7060	USE 57-1363	ea
57-7062	spindle,crossover,LHshift	EA
57-7067	sprocket,gbx,5spd,21tooth*	EA
57-7067/A	sprocket,gbx,5spd,22tooth*	EA
57-7067/ER	sprocket,gbx,5spd,21T,econo*	EA
57-7076	washer,tab,late mainshaft	EA
57-7077	mainshaft,late T140E style*	EA
58-0001	USE 57-7033	ea
58-0002	USE 57-7034	ea
58-0003	USE 57-7035	ea
60-	NORTON,TRIUMPH &BSA PARTS	*
60-----	-----	---
60-0003	decal,MINIMUM OIL LEVEL	EA
60-0040	USE 60-1816	ea
60-0044	USE 60-1816	ea
60-0052	decal,"positive earth"	EA
60-0056	decal,WORLD SPEED RECORD	EA
60-0061	decal"Made In Engl"block,gold	EA
60-0061/A	decal"Made In Engl"block,black	EA
60-0068	decal,TRI.REG.TRD.MK,gold	EA
60-0068/A	decal,TRI.REG.TRD.MK,blue	EA
60-0083	USE 524-CX32	ea
60-0087	USE 221-09	ea
60-0100	USE 526-187	ea
60-0101	USE 524-CX11	ea
60-0106	USE 557-WM2	ea
60-0120	USE 552-110046/80 *	ea
60-0176	USE 571-54/B	ea
60-0177/9	USE 60-0708	ea
60-0203	USE 526-792	ea
60-0208	USE 60-4255	ea
60-0208-5	USE 60-4255	1
60-0224	USE 526-AM40/21	ea
60-0233	USE 526-AM40/21/6 *	ea
60-0245	USE 571-44/B	ea
60-0247	USE 526-617	ea
60-0255	USE 526-792/8/A	ea
60-0256	USE 526-617/5	ea
60-0257	USE 526-AM40/21/6 *	ea
60-0262	USE 345-10/A	ea
60-0273	USE 571-44/B *	ea
60-0276	USE 552-110038/62	ea
60-0286	USE 571-49/B	ea
60-0291	USE 221-16/TRI	ea
60-0301	USE 552-110046/70	ea
60-0307	USE 526-794	ea
60-0329	USE 526-21/36	ea
60-0340	USE 42-5323 *	ea
60-0343	USE 60-0978	ea
60-0343/7	USE 60-4258	ea
60-0344	USE 526-600252	ea

60-0358	USE 552-114038/78	ea
60-0366	USE 526-2/796 *	ea
60-0373	USE 572-BG5330287	ea
60-0374	checkwire, seat	EA
60-0382	USE 552-114038/62	ea
60-0383	USE 526-AM39/24	ea
60-0386	USE 526-625	ea
60-0387	USE 526-625/6 *	ea
60-0388	USE 526-797	ea
60-0398	USE 222-121	ea
60-0400	USE 222-109	ea
60-0402	lock, forks, w/keys, Neimann, early	EA
60-0402/0403	USE 60-0402	ea
60-0408	USE 526-2/796/6 *	ea
60-0416	USE 526-630	ea
60-0419	USE 526-616	ea
60-0422	USE 526-446	ea
60-0423	USE 526-447	ea
60-0425	USE 526-446/4	ea
60-0432	USE 526-799	ea
60-0435	USE 526-40/36	ea
60-0436	USE 526-630	ea
60-0438	USE 552-110056/110*	ea
60-0452	USE 526-2/792 *	ea
60-0466	USE 526-2/792	ea
60-0477	USE 552-114038/84	ea
60-0484	USE 222-190	ea
60-0486	USE 222-061359	ea
60-0490	USE 571-58/A	ea
60-0493	USE 572-01	ea
60-0494	clip, tach cable spade *	EA
60-0495	USE 526-M43/27	ea
60-0496	USE 222-602108	ea
60-0499	USE separate components	ea
60-0500	USE 526-96	ea
60-0507	USE 526-44/38	ea
60-0516	USE 526-96	ea
60-0519	USE 526-M43/29	ea
60-0525	USE 526-616	ea
60-0527	USE 222-616017	ea
60-0528	USE 526-M44/24D	ea
60-0529	USE 571-34.5/A	ea
60-0531	USE 526-M43/27	ea
60-0532	USE 526-M43/27 *	ea
60-0542	USE 571-44/A	ea
60-0543	USE 571-40/A	ea
60-0544	USE 572-BG5330287	ea
60-0553	USE 391-76204	ea
60-0558	USE 526-2/618	ea
60-0559	USE 526-619	ea
60-0560	USE 526-2/616	ea
60-0565	USE 526-2/796	ea
60-0566	USE 526-2/796 *	ea
60-0578	USE 571-28/C	ea
60-0607	USE 222-060949	ea
60-0609	USE 571-67/A*	ea
60-0622	USE 391-54335169/A	ea
60-0623	USE 82-6738	ea
60-0624	USE 526-619	ea
60-0637	USE 572-BG5330168	ea
60-0648	USE 571-28/C	ea
60-0653/4	USE 222-601859	ea
60-0660	USE 526-M44/30D	ea
60-0662	USE 222-127 *	ea
60-0664	USE 526-2/620	ea
60-0665	USE 526-2/620/5	ea
60-0667	USE 526-2/797	ea
60-0675	decal, TIGER 100	EA
60-0676	decal, TROPHY 500, script, tank&sidepanel	EA
60-0677	decal, DAYTONA SUPER SPORT	EA
60-0678	decal, "Trophy Sports" tank&sidepanel	EA

60-0680	decal,"BONNEVILLE" script	EA
60-0680/A	decal,BONNEVILLE TT SPECIAL,script*	EA
60-0683	USE 526-96	ea
60-0684	USE 526-452	ea
60-0685	USE 524-244104	EA
60-0691	USE 391-57161	ea
60-0692	USE 571-63/A	ea
60-0696	seat trim,chrome narrow	EA
60-0696/A	seat trim,chrome&black,wide	EA
60-0696/B	seat trim,black narrow	EA
60-0696/C	seat trim,black wide	EA
60-0696/D	seat trim,chrome wide	EA
60-0697	clips,seat trim	EA
60-0699	USE 552-116038/82	ea
60-0707	clamp,hose,1-3/4"	EA
60-0708	clamp,hose	EA
60-0732	USE separate components	ea
60-0733	USE 526-450	ea
60-0735	USE 526-M44/31	ea
60-0739	USE 526-449	ea
60-0740	USE 526-M44/26D	ea
60-0741	USE 526-453	ea
60-0742	USE 526-44/34 *	ea
60-0744	USE 526-315	ea
60-0745	USE 526-451	ea
60-0746	USE 526-M44/35	ea
60-0747	USE 526-M44/38	ea
60-0767	USE 221-062551	ea
60-0777	USE 60-4254	ea
60-0782	USE 222-190	ea
60-0786	USE 391-49072	ea
60-0801	USE 221-15	ea
60-0804	USE 526-M42/35	ea
60-0807	USE 526-M42/31	ea
60-0810	USE 526-40/30D/6 *	ea
60-0813	USE 526-40/30D *	ea
60-0815	USE 526-M42/38	ea
60-0818	USE 526-M42/34	ea
60-0820	USE 526-92	ea
60-0823	USE 526-96	ea
60-0826	USE 526-92	ea
60-0831	decal,QUEENS AWARD,1967	EA
60-0833	decal,ROYALSTAR500,w/flag,US	EA
60-0834	decal,THUNDERBOLT,w/flags,US	EA
60-0835	decal,LIGHTNING w.flags,US	EA
60-0836	USE 60-0895	ea
60-0837	decal,SPITFIRE MK.4w/flag,US	EA
60-0838	decal,ROYALSTAR500,w/flag,UK	EA
60-0839	decal,THUNDERBOLT,w/flags,UK	EA
60-0840	decal,LIGHTNING w.flags,UK	EA
60-0842	decal,SPITFIRE MK.4w/flag,UK	EA
60-0853	badge,sidepanel,ROCKET3,RH*	EA
60-0853/0854	badges,sidepanel,ROCKET3,aluminum	PR
60-0854	badge,sidepanel,ROCKET3,LH*	EA
60-0858	USE 526-662/4	ea
60-0861	USE 526-2/663/4	ea
60-0862	USE 526-665	ea
60-0865	USE 526-661	ea
60-0868	USE 526-662	ea
60-0871	USE 526-2/663	ea
60-0890	USE 526-455	ea
60-0893	USE 60-0984	ea
60-0895	decal,FIREBIRD SCR,w/flag	EA
60-0911	USE 336-N3C	ea
60-0927	decal,FLEETSTAR 250	EA
60-0951	USE 552-114038/70	ea
60-0962	USE 526-M38/35	ea
60-0963	yoke,brake cable*	EA
60-0965	USE 60-4264	ea
60-0966	USE 526-733	ea
60-0974	USE 221-689467	ea

60-0978	clip,cable tie,metal	EA
60-0982	oddie fastener	EA
60-0983	USE 60-0984	ea
60-0984	washer,rubber,oddie stud,long	EA
60-0985	washer,rubber,oddie stud,short	EA
60-0987	USE 391-49345	ea
60-0989	USE 391-30608	ea
60-0990	USE 391-34815	ea
60-0994	USE 391-76204	ea
60-0995	USE 391-60410181	ea
60-1006	oddie stud,long	EA
60-1053	USE 633-900/A	ea
60-1802	USE 70-4016	ea
60-1806	USE 526-M47/35	ea
60-1807	USE 526-M47/38	ea
60-1810	USE 222-617013	ea
60-1814	USE 222-616061	ea
60-1816	decal,DRAIN&REFILL EVERY	EA
60-1818	USE 526-96	ea
60-1819	USE 526-M47/30D	ea
60-1821	USE 526-454	ea
60-1822	USE 526-M46/26D	ea
60-1823	USE 526-M47/31	ea
60-1824	USE 526-44/34	ea
60-1841	grease nipple,1/4x28	EA
60-1860	USE 222-192	ea
60-1861	USE 222-110	ea
60-1864	USE 222-616070	ea
60-1900/A	cover,Clear Hooter horn,69T120etc.	EA
60-1903	USE 571-25/C	ea
60-1905	decal,"Trident"right hand	EA
60-1906	decal,"Trident",left hand	EA
60-1917	decal,TIGER 500,script	EA
60-1918	decal,TIGER 650,script,68 tank&sidepanel	EA
60-1920	decal,TROPHY650,script,tank&sidepanel,68	EA
60-1922	decal,Trophy 250 LH	EA
60-1923	decal,Trophy 250 RH	EA
60-1937	USE 391-35835	ea
60-1946	USE 526-800 *	ea
60-1959	USE 691-622115	ea
60-1960	USE 691-622113	ea
60-1968	USE 526-456	ea
60-1978	USE 524-2442080	ea
60-1984	USE 691-622119	ea
60-1987	USE 691-622116	ea
60-1990	USE 391-57160	ea
60-1991	decal,LIGHTNING,tank top	EA
60-1993	USE526-2/797or526-2/797/A	ea
60-1994	USE 526-2/796	ea
60-1995	USE 526-2/796 *	ea
60-1999	USE 60-2371	ea
60-2002	decal,THUNDERBOLT,tanktop	EA
60-2003	USE 60-0839	ea
60-2004	decal,ROYAL STAR	EA
60-2005	USE 60-2149	ea
60-2006	USE 60-2107	ea
60-2007	decal,FIREBIRD 650,w/bird	EA
60-2024	USE 543-6218	ea
60-2025	decal,Tiger 650,tanktop	EA
60-2026	decal,BONNEVILLE,small,tanktop	EA
60-2027	decal,"Trophy 650",small,tanktop	EA
60-2034	USE 526-668	ea
60-2041	decal,441 VICTOR SPECIAL	EA
60-2042	decal,441 VICTOR SPECIAL,tanktop	EA
60-2045	USE 71-2930	ea
60-2051	decal,STARFIRE250,tanktop	EA
60-2053	USE 526-667	ea
60-2060	USE 526-457	ea
60-2061	USE 526-458	ea
60-2062	USE 526-459	ea
60-2064	decal,TROPHY 500,tanktop	EA

60-2065	decal, DAYTONA 500, tanktop	EA
60-2071	USE 523-18838/839 (set)	ea
60-2071/2072	USE 523-18838/839 (set)	ea
60-2072	USE 523-18838/839 (set)	ea
60-2073	USE 523-18978	ea
60-2074	USE 523-18952	ea
60-2076	USE 526-666/5	ea
60-2077	USE 526-666	ea
60-2080	USE 526-2/729/6 *	ea
60-2081	USE 526-2/729	ea
60-2082	USE 526-2/733	ea
60-2083	USE 526-733	ea
60-2085	switch, front brake cable	EA
60-2086	cover, rubber, fr. brake sw.	EA
60-2087	checkwire, seat	EA
60-2090	USE 523-18951	ea
60-2102	decal, TIGER 650, sidepanels	EA
60-2103	decal, BONNEVILLE, lg	EA
60-2104	decal, TROPHY 650, lg.	EA
60-2105	decal, TROPHY 500	EA
60-2106	decal, DAYTONA	EA
60-2107	decal, FIREBIRD 650, w/bird	EA
60-2118	USE 552-110056/107	ea
60-2133	sw, oilpress, early Tri, taper thread	EA
60-2133/ER	sw, oilpress, BSA&early Tri, repl.	EA
60-2138	decal, POINTS GAP, in cover	EA
60-2149	decal, ROYALSTAR 500, 69on	EA
60-2150	decal, ROYAL STAR, tank top	EA
60-2159	USE 222-601859	ea
60-2184	USE 221-64947081	ea
60-2185	USE 222-602020	ea
60-2202	USE 526-460	ea
60-2206	USE 391-45276	ea
60-2213	USE 222-155	ea
60-2221	USE 222-617019	ea
60-2241	USE 523-19978	ea
60-2242	USE 523-19952	ea
60-2252	clamp, oil hose	EA
60-2253	clamp, 15/16"	EA
60-2294	USE 543-6007 (pair)	ea
60-2320	washer, 1/4", flat	EA
60-2321	washer, 5/16 flat, thick	EA
60-2322	washer, 3/8, flat, thick	EA
60-2323	washer, 7/16 flat, thick	EA
60-2329	washer, 1/4" flat	EA
60-2330	washer, 5/16 flat, thin	EA
60-2331	washer, 3/8" flat, thin	EA
60-2332	washer, 7/16, flat	EA
60-2333	washer, 1/2" flat, thin	EA
60-2338	washer, 1/4" flat	EA
60-2340	washer, 3/8", flat, thick	EA
60-2347	washer	EA
60-2348	washer, 5/16" flat	EA
60-2349	USE 60-2322	ea
60-2350	USE 60-2350/CHR	ea
60-2350/CHR	washer, flat, 7/16, chrome	EA
60-2362	USE 422-316	ea
60-2363	USE 422-732	ea
60-2364	USE 422-14	ea
60-2368	USE 422-38	ea
60-2370	USE 422-716	ea
60-2371	decal, LIGHTNING 650*	EA
60-2372	USE 60-2373	ea
60-2373	decal, FIREBIRD 650, sqType	EA
60-2374	USE 60-2149	ea
60-2375	decal, "Thunderbolt 650", LG	EA
60-2376	decal, STARFIRE 250, sqType	EA
60-2377	USE 60-2376	ea
60-2378	USE 60-2376	ea
60-2380	decal, sidecover, Trophy 250, 1970	EA
60-2380/A	decal, tanktop, Trophy 250, 1970	EA

60-2381	screw,self tapping,seat	EA
60-2391	washer,3/16 flat,small OD	EA
60-2394	USE 572-SSM500700	ea
60-2416	washer,3/16"lock,small OD	EA
60-2417	washer,1/4,lock,small OD	EA
60-2418	washer,5/16,lock	EA
60-2419	washer,3/8 lock	EA
60-2420	washer,3/16"lock	EA
60-2421	washer,1/2",lock	EA
60-2427	washer,1/4,lock	EA
60-2428	washer,5/16,lock	EA
60-2429	washer,3/8",lock	EA
60-2430	washer,7/16",lock	EA
60-2438	washer,5/16"spring	EA
60-2445	USE 526-800 *	ea
60-2452	decals,US safety stds,69 TRI	EA
60-2456	USE 526-2/739	ea
60-2564	decals,Trident,1971/72	EA
60-2565	decals,Trident,1971/72	EA
60-2567	airfilter assy,3cyl,oval,chrome*	EA
60-2567/A	screen assy,chrome,airfilter,fully perf.	EA
60-2568	badge,tank,BSA,71/72 A65 US	EA
60-2569	badge,tank,triumph,5"long	EA
60-2594	USE 60-4152	ea
60-2596	rubber cup,instr.mt,small	EA
60-2600	rubber cup,instr.mount	EA
60-2600/ER	rubber cup,instr.mount,econo.repl.	EA
60-2601	element,airfilter,B50etc.	EA
60-2604	USE 391-35048	ea
60-2627	USE 06-2702	ea
60-2628	USE 06-2553	ea
60-2630	grommet,headlight mount	EA
60-2632	circlip	EA
60-2639	oring	EA
60-2640	USE 60-3530	ea
60-2683/SS	cotter pin,1/16x3/8",stainless	EA
60-2771	USE 558-K19866TP	ea
60-3041	USE 391-575189	ea
60-3042	USE 391-57183	ea
60-3072	element,airfilter,open bk*	EA
60-3072/A	element,a/c,UNI foam,OIF	EA
60-3072/ER	element,airfilter,open bk,econo*	EA
60-3075	USE 526-669	ea
60-3077	USE 526-2/739	ea
60-3079	USE 526-2/797	ea
60-3122	USE 552-110056/110	ea
60-3143	USE 60-3980	ea
60-3144	USE 60-3994 *	ea
60-3148	gaiter,cable	EA
60-3157	decals,TRIUMPH,5" blk&silv	EA
60-3158	USE 60-3269	ea
60-3159	USE 60-1006	ea
60-3160	USE 60-0984	ea
60-3161	grommet,rubber *	EA
60-3166	USE 391-54419827	ea
60-3213	USE 572-BG5330164	ea
60-3215	USE 572-BG5330104	ea
60-3246	USE 523-100/RH	ea
60-3249	USE 571-67/A *	ea
60-3256	USE 60-3736	ea
60-3258	USE 60-3732	ea
60-3259	USE 60-3261 *	ea
60-3260	USE 60-3734	ea
60-3261	decals,GOLDSTAR 250 SS	EA
60-3262	USE 60-3734	ea
60-3264	decals,TRAILBLAZER SS	EA
60-3269	decals,gastank,BSA,4 inch	EA
60-3272	USE 526-454	ea
60-3273	wiper,oilseal,forks *	EA
60-3274	oilseal,forks,single lip*	EA
60-3275	USE 60-2567 *	ea

60-3276	USE 60-2567 *	ea
60-3278	USE 60-3727 *	ea
60-3282	USE 571-30/C	ea
60-3294	decal,LIGHTNING 650,small*	EA
60-3313	nut,pressed steel	EA
60-3355	oring	EA
60-3361	decal,"MadeInEngland;script	EA
60-3376	USE 571-69/A	ea
60-3390	USE 526-670	ea
60-3485	USE 526-96;2)526-452;524-244104	ea
60-3486	USE 526-452	ea
60-3490	USE 552-119058/110	ea
60-3493	USE 60-4100 & 57-4779	ea
60-3494	circlip,gearbox,5speed	EA
60-3499	USE 526-318	ea
60-3500	oilseal,clutch&5th gear	EA
60-3510	oilseal,sprocket,5sp.3cyl	EA
60-3511	bearing,needle	EA
60-3512	oilseal,gbx.sprocket,5spd	EA
60-3522	USE 57-2697	ea
60-3524	clamp,oiline,rockerfeed	EA
60-3530	oring	EA
60-3531	USE 60-4100 & 57-4779	ea
60-3535	USE 526-671	ea
60-3536	hoseclamp,airfilter hose	EA
60-3539	screw	EA
60-3541	washer,double spring	EA
60-3548	oring,rockershaft,large	EA
60-3550	screw,brake switch	EA
60-3552	bearing,ball	EA
60-3556	bearing,ball,LH mainshaft	EA
60-3556/ER	bearing,ball,LH mainshaft,econo*	EA
60-3557	USE 526-669	ea
60-3566	USE 526-468	ea
60-3567	USE 523-100/RH	ea
60-3583	USE 06-2553	ea
60-3585	adjuster,cam type*	EA
60-3585/3586	adj&nut set,gen.style	ST
60-3586	nut,adjuster,cam type*	EA
60-3614	USE 391-54386637	ea
60-3616	oring	EA
60-3618	element,a/c,rect,rnd.hole	EA
60-3627	grommet,rubber,electric box	EA
60-3632	oddie fastener	EA
60-3635	USE 526-319	ea
60-3638	USE 526-M44/30D	ea
60-3648	USE 60-3980	ea
60-3654	USE 391-54386637	ea
60-3657	USE 06-2702	ea
60-3658	cable,tach,73 B50MX*	EA
60-3659	clip,cable to side panel	EA
60-3669	USE 60-4152	ea
60-3676	USE 221-11	ea
60-3677	USE 222-198	ea
60-3719	switch,oil light,straight thread*	EA
60-3719/ER	switch,oilpressure light,reprl.	EA
60-3722	decal,BONNEVILLE 650	EA
60-3723	decal,TIGER 650	EA
60-3724	decal,TROPHY 650	EA
60-3727	decal,ROCKET THREE*	EA
60-3729	USE 60-2371	ea
60-3730	decal,THUNDERBOLT 650,small	EA
60-3732	decal,VICTOR 500,side pan	EA
60-3734	decal,GOLDSTAR 500 SS*	EA
60-3736	decal,VICTOR MX	EA
60-3748	decal,5 SPEED,round	EA
60-3752	USE 526-116	ea
60-3761	nut,5/16 UNF conrod,12 point	EA
60-3774	USE 60-3524	ea
60-3780	USE 60-7097	ea
60-3815	USE 526-669	ea

60-3900	USE 391-26518	ea
60-3925	USE 526-2/798/5	ea
60-3931	USE 60-1841	ea
60-3933	USE 571-28/C*	ea
60-3950	decal,BONNEVILLE 650 V	EA
60-3952	decal,TIGER 650 V	EA
60-3953	decal,BONNEVILLE 750 V	EA
60-3954	decal,TRIDENT 750 V	EA
60-3963	washer,1/4",flat,small OD	EA
60-3980	lever,RH console,chrome*	EA
60-3981	USE 60-3994	ea
60-3991	USE 523-12608	ea
60-3994	lever,LH console,chrome*	EA
60-4088	USE 526-673	ea
60-4100	bearing,roller,outer,5spd	EA
60-4101	caliper,cast iron *	EA
60-4101/U	caliper,cast iron,used	EA
60-4102	mastercyl.assy,front,early*	EA
60-4102/A	mastercyl.assy,fr,dualdisc,early*	EA
60-4102/SS	mastercyl.assy,fr,early,stainless	EA
60-4103	grommet,wiring	EA
60-4104	USE 391-56605	ea
60-4105	USE 391-56605	ea
60-4109	USE 391-56513	ea
60-4110	USE 391-56513	ea
60-4114	USE 526-672	ea
60-4118	USE 526-672	ea
60-4125	USE 552-116038/84	ea
60-4126	USE: 524-244104;526-470;2)526-495	ea
60-4127	USE 526-470	ea
60-4128	USE 526-495	ea
60-4139	USE 526-455	ea
60-4148	decal,750 BONNIE,red	EA
60-4149	decal,TRIDENT 750,red	EA
60-4150	backing plate,panel decal	EA
60-4151	backing plate,panel decal,T150	EA
60-4152	plug,rubber,blanking	EA
60-4153	rubber plug,airfilter cov	EA
60-4154	nut,captive,badge mounting	EA
60-4156	decal,caliper	EA
60-4157	USE 60-2106	ea
60-4160	USE 60-4352	ea
60-4167	bearing,ball,crankshaft *	EA
60-4168	USE 526-2/798	ea
60-4169	decal,TIGER 750,blue/silv	EA
60-4174	USE 60-4244	ea
60-4175	brakehose,14"	EA
60-4175/8	brakehose,20",extended forks	EA
60-4175/SS	brakehose,kit,stainless	EA
60-4176	USE 60-4244	ea
60-4177	brakehose,upper,6-1/2inch	EA
60-4177/SS	brakehose,stainless,UK bars	EA
60-4178	brakeline,fr.caliper to hose	EA
60-4178/SS	brakeline,fork to caliper,stainless	EA
60-4179	brakeline,upper,1973-78	EA
60-4180	USE 14-0403	ea
60-4181	USE 01-4119	ea
60-4182	washer,copper	EA
60-4183	bolt,brakehose banjo	EA
60-4184	washer,copper	EA
60-4185	USE 526-669/6 *	ea
60-4186	boot,rubber,brake hose	EA
60-4192	decal,X75,black	PR
60-4194	USE 526-469	ea
60-4206	lever,brake,chrome,disc *	EA
60-4208	USE 526-318	ea
60-4211	USE 391-26518	ea
60-4224	USE 391-33356	ea
60-4238	USE 391-54363453	ea
60-4240	USE 391-38191	ea
60-4244	brakehose,12"O/A,upper*	EA

60-4244/7	brakehose,20",apehangers	EA
60-4244/SS	brakehose kit,stainless*	EA
60-4245	washer,1/4" flat	EA
60-4246	USE 60-2331	ea
60-4247	washer,5/16",flat	EA
60-4248	washer,1/4",flat*	EA
60-4250	washer,1/4",lock,small OD	EA
60-4251	washer,7/16",lock	EA
60-4252	pin,pivot,brake clevis*	EA
60-4252/SS	pin,pivot,brake clevis,stainless*	EA
60-4253	key,woodruff	EA
60-4254	clip,cable,alloy 6 inch	EA
60-4255	screw,hammerdrive rivet,brass	EA
60-4255/SS	screw,hammerdrive rivet,stainless	EA
60-4256	washer,3/16",lock	EA
60-4258	clip,cable,"John Bull"rub,blk.	EA
60-4259	washer,3/8",lock	EA
60-4260	washer,5/16",lock	EA
60-4261	nut,3/8x26	EA
60-4262	washer,fibre,3/8" OD	EA
60-4263	washer,fibre,1/4" ID	EA
60-4264	nut,1/4x26CEI	EA
60-4264/A	nuts,1/4x26 light alloy	ST
60-4265	element,a/c,rec.w/sq.hole	EA
60-4266	cap,caliper bleed nipple	EA
60-4267	USE 60-2323	ea
60-4268	USE 97-0193	ea
60-4274	airfilter element,74 TR5T	EA
60-4307	USE 552-114513/70	ea
60-4315	USE 691-2442283	ea
60-4328	gasket,master cyl.cap	EA
60-4333	bearing,needle	EA
60-4335	rubber cover,ign.key hole	EA
60-4336	plate,backing,T160 LH cov	EA
60-4337	USE 60-4427	ea
60-4338	brakeline,steel,upperT160	EA
60-4352	decal,TROPHY TRAIL,TR5T	EA
60-4362	USE 526-800	ea
60-4365	cap,master cyl,plastic	EA
60-4365/A	decal,filler cap	EA
60-4366	diaphragm,master cylinder	EA
60-4374	oring,mastercyl.reservoir	EA
60-4384	decal,TIGER 750,blk/gld	EA
60-4385	decal,BONNIE 750,blk&gold	EA
60-4391	decal,TRIDENT 750,blkGold	EA
60-4393	circlip,throttle linkage,T160	EA
60-4397	reservoir,mastercyl,nylon	EA
60-4397/A	reservoir,mastercyl,alloy	EA
60-4398	spacer,master cyl.reserv.	EA
60-4399	USE 60-7050	ea
60-4401	mastercyl.assy,rear Tri.	EA
60-4401/SS	mastercyl.assy,rear,Tri,stainless	EA
60-4403	USE 572-BG5333164	ea
60-4409	hose,reservoir toR.m.cyl	EA
60-4414	USE 60-7028	ea
60-4415	USE 60-7007	ea
60-4419	oring	EA
60-4421	airfilter assy,3cyl,oval,painted*	EA
60-4427	plate,backing,T160 RH cov	EA
60-4429	clamp,oiline	EA
60-4440	grommet,wiring	EA
60-4442	oilseal,gearshift,T160	EA
60-4447	circlip,shifter,T160	EA
60-4454	USE 526-800/5	ea
60-4455	USE 571-71/A	ea
60-4456	USE 571-30/C	ea
60-4457	USE 526-497	ea
60-4458	USE 526-497/5	ea
60-4460	USE 523-364018	ea
60-4501	USE 97-5000	ea
60-4502	USE 60-4622	ea

60-4503	nut,captive,2BA	EA
60-4504	oilseal,cross shaft,T160	EA
60-4508	USE 391-30702	ea
60-4511	USE 621-137	ea
60-4512	USE 621-136	ea
60-4516	USE 391-47190	ea
60-4518	USE 60-4244	ea
60-4521	USE 523-12608	ea
60-4528	USE 70-9138	ea
60-4556	decal,NORTON/TRIUMPH,ENGL	EA
60-4561	USE 70-1335	ea
60-4569	decal,Trident 750,blk/gold,T160*	EA
60-4573	USE 691-622277	ea
60-4586	USE 391-30707	ea
60-4587	USE 391-30723	ea
60-4601	grommet,tach cable retaining,T160	EA
60-4614	USE 222-307	ea
60-4617	USE 60-7028	ea
60-4619	USE 60-4177	ea
60-4622	decal,dash console	EA
60-4626	USE 60-4186	ea
60-6128	USE 61-6128	ea
60-7001	USE 526-496	ea
60-7003	decal,IGNITION OFF*	EA
60-7003/7004/5	decal set,forks/hdlt,TR7V/T140V	ST
60-7004	decal,OIL/TURN/HI-BEAM*	EA
60-7005	decal,OFF/PARK/LIGHTS*	EA
60-7007	brakeline,R.disc,early	EA
60-7011	USE 572-04	ea
60-7012	USE 571-69/A	ea
60-7013	USE 571-28/C	ea
60-7014	USE 523-364018	ea
60-7015	USE 60-7023	ea
60-7016	washer,copper,brake res.	EA
60-7017	decal,safety standards,T140	EA
60-7018	USE 391-54420128	ea
60-7021	USE 523-19952	ea
60-7023	arm,clutch lever,"factory"*	EA
60-7024	USE 523-12595	ea
60-7026	screw,pivot,control lever	EA
60-7028	brakehose,rear,early type*	EA
60-7028/A	brakehose,stainless steel*	EA
60-7030	clamp,brake hose to reservoir,rear	EA
60-7050	washer,1/4"flat,m.cyl,res	EA
60-7052	USE 60-4366	ea
60-7054	decal,750 BONNIE,silv/blk	EA
60-7055	decal,TIGER 750,silv/blk	EA
60-7059	USE 526-499	ea
60-7060	USE 526-478	ea
60-7061	USE 526-478/3	ea
60-7067	USE 391-70276	ea
60-7076	USE 691-2928123	ea
60-7077	USE 691-2928146	ea
60-7078	clip,MK2 carb linkage	EA
60-7079	USE 391-83225	ea
60-7084	USE 526-477	ea
60-7097	forklock,Neiman type	EA
60-7097/A	keyblank,forklock,Neiman	EA
60-7108	USE 391-30552	ea
60-7118	rubber boot,throttleCable	EA
60-7130	USE 391-47270	ea
60-7131	USE 391-45275/A	ea
60-7132	USE 57-1257 *	ea
60-7149	USE 526-494	ea
60-7150	USE 526-490	ea
60-7155	USE 391-34619	ea
60-7156	USE 391-49589	ea
60-7158	pushrod,master cyl,1979on	EA
60-7163	mastercyl.assy,front79-83	EA
60-7164	mastercyl.housing,79-83	EA
60-7174	brakehose,15"overall,top*	EA

60-7176	fitting,"T",brakeline	EA
60-7177	brakeline,upper from "T"	EA
60-7178	brakeline,lower from "T"	EA
60-7180	USE 391-30702	ea
60-7182	screw,fr.brakesw.actuation	EA
60-7183	USE 526-480	ea
60-7184	USE 526-479	ea
60-7198	USE 345-1177	ea
60-7207	USE 572-04	ea
60-7210	USE 60-2569	ea
60-7215	lock w/keys,seat,1979 on	EA
60-7217	USE 391-35048	ea
60-7218	USE 06-3909	ea
60-7233	brakehose,rear,late type	EA
60-7233/SS	brakehose,stainless,21-1/2"	EA
60-7236	bolt,banjo,rear disc,late	EA
60-7238	insert,brake lever,disc brake	EA
60-7239	USE 391-54363522	ea
60-7240	USE 391-30702	ea
60-7248	hose,reservoir toR.m.cyl,late	EA
60-7268	washer,sealing,pri.adjust	EA
60-7269	circlip,forkseal,late	EA
60-7271	USE 60-7097	ea
60-7291	starter clutch,T140ES	EA
60-7292	circlip,"E"type	EA
60-7295	oring,starter to case	EA
60-7296	USE 391-26521	ea
60-7298	USE 333-02	ea
60-7303	USE 60-7537	ea
60-7304	USE 83-5361	ea
60-7305	USE 83-5361	ea
60-7326	USE 391-47266	ea
60-7327	USE 391-35317	ea
60-7328	USE 391-35318	ea
60-7329	USE 391-35316	ea
60-7333	bush,metalastic,pegs,8lon	EA
60-7335	cover,ign.key hole,8lon	EA
60-7336	grease nipple,angled	EA
60-7340	rubber bush,starter drive	EA
60-7362	bearing,roller,crankshaft	EA
60-7363	USE 06-2726	ea
60-7365	oring,rockershaft,TSS	EA
60-7386	decal,ELECTRO,T140ES,sidepanels	EA
60-7388	USE 526-470	ea
60-7400	rubber connector,Bing	EA
60-7414	USE 83-5361	ea
60-7415	USE 83-5361	ea
60-7427	USE 526-325	ea
60-7430	USE 526-328	ea
60-7437	USE 99-2769/B	ea
60-7448	turn signal w/o stem,79on	EA
60-7462	USE 391-35317	ea
60-7463	USE 391-35318	ea
60-7464	USE 391-35316	ea
60-7465	USE 345-1375	ea
60-7466	USE 392-382	ea
60-7469	USE 391-54361250	ea
60-7478	USE 60-4101	ea
60-7489	USE 526-327	ea
60-7505	USE 526-326	ea
60-7512	USE 391-83539	ea
60-7519	decal,NEGATIVE EARTH	EA
60-7537	badge,tank,6"long	EA
60-7538	USE 60-7537	ea
60-7552/A	keyblank,locking gascaps	EA
60-7570	USE 336-G63	ea
60-7625	rubber connector,TSS carb	EA
60-7627	rubber connector,airfilt,TSX	EA
60-7707	oring,sidepanel retaining	EA
61-	TRIUMPH&BSA SERVICE TOOLS	*
61-----	-----	--

61-1903	USE 222-108	ea
61-1912	SE 222-127*	ea
61-3006	USE 222-200B	ea
61-3007	USE 222-200B	ea
61-3188	USE 222-118	ea
61-3191	USE 222-106	ea
61-3256	USE 221-11	ea
61-3350	USE 222-191	ea
61-3362	USE 222-117	ea
61-3382	USE 221-301	ea
61-3503	USE 222-613503	ea
61-3583	USE 222-121	ea
61-3676	USE 222-613256	ea
61-3677	USE 222-613256	ea
61-3681	USE 222-613256	ea
61-3694	USE 222-617024	ea
61-3700	USE 222-180	ea
61-3707	USE 221-82/7580	ea
61-3766	USE 222-110	ea
61-3773	USE 222-613256	ea
61-3784	USE 222-198	ea
61-3801	USE 222-155	ea
61-3808	USE 221-11 *	ea
61-3824	USE 222-191	ea
61-5005	USE 222-190 *	ea
61-6014	USE 222-616046	ea
61-6019	USE 222-158	ea
61-6052	USE 221-82/6570	EA
61-6062	USE 222-260	ea
61-6128	USE 222-307	ea
61-6134	USE 221-82/7580	ea
61-6135	USE 221-82/7580	ea
61-7011	USE 222-307	ea
61-7012	USE 222-602108	ea
61-7013	USE 222-222617013	ea
61-7014	USE 222-110	ea
61-7022	USE 222-601859	ea
61-7023	USE 222-190	ea
62-	TRIUMPH AND BSA PARTS	*
62-----	-----	--
62-0006	grip,handlebar,LH,Matchl.	EA
62-0020	USE 60-4175	ea
62-0070	plug,blanking,filter cov.	EA
62-0072	pin,dowel	EA
62-0083	USE 391-35351	ea
62-0084	USE 391-83225	ea
62-0263	USE 60-3524	ea
63-	MATCHLESS PARTS	ea
63-0017	oring,gastank mt,Matchless,1987	EA
64-	BSA PARTS	*
64-----	-----	--
64-3106	gasket,gbx.insp,cover,PU	EA
64-6016	USE 97-2646	ea
65-	BSA PARTS	*
65-----	-----	--
65-0037	USE 452-355	ea
65-0109	bolt,5/16x26*	EA
65-0114	USE 336-I86	ea
65-0208	USE 453-12	ea
65-0292	bolt,5/16x26	EA
65-0306	USE 65-0317 *	ea
65-0311	nut,3/8x26,acorn,rocker shaft	EA
65-0317	bolt,banjo,rocker feed,sm.hole	EA
65-0318	bolt,banjo,rocker feed,lg.hole	EA
65-0440	pin,piston,BSA*	EA
65-0441	bush,small end & cam	EA
65-0597	USE 70-8259	ea
65-0615	plug,crank,early A10	EA
65-0645	USE 452-538/PB	ea
65-0646	USE 452-537/PB	ea
65-0647	USE 453-243	ea

65-1084	pushrod, In & Ex, GS, early	EA
65-1174	gear, idler, magdyno, GS	EA
65-1232	USE 71-3573	ea
65-1388	bearing, roller	EA
65-1397	plate, retaining, brg.	EA
65-1417	USE 71-3573	ea
65-1418	USE 06-3458	ea
65-1419	USE 06-3458	ea
65-1513	USE 452-457	ea
65-1514	USE 452-458	ea
65-1516	USE 452-460	ea
65-1624	collet, valve, A10SR	EA
65-1840	bolt1, cyl. holdown, DBD34, etc.	EA
65-1844	valve, in, BSA B34GS, 1954/55 *	EA
65-1858	pushrod, In & Ex, GS, late	EA
65-1875	guide, tappet, GS	EA
65-1879	gear, magdyno idler, Goldstar, late	EA
65-2045	USE 37-7041	ea
65-2060	hose, oil, 1/4" rubber	EA
65-2153	nut, 1/4x26, A10 rocker cov	EA
65-2240	circlip, brakedrum	EA
65-2316	oilseal, magdyno dr. gear	EA
65-2334	gear, magdyno idler, Goldstar, early, etc.	EA
65-2442	USE 463-543X1 (set)	ea
65-2446	USE 463-543X1 (set)	ea
65-2494	USE 451-488 (set)	ea
65-2494/2495	USE 451-488	ea
65-2495	USE 451-488 (set)	ea
65-2512	USE 453-244	ea
65-2521	washer, tab, cush, preunit	EA
65-2536	sprocket, engine, 16T, 2 lobe	EA
65-2537	sprocket, engine, 17T, late	EA
65-2538	sprocket, engine, 20T, 2 lobe	EA
65-2589	oilpump, preunit 1cyl, cast iron*	EA
65-2593	USE 422-732	ea
65-2611/A	plate, sump, BSA preunit single, alloy	EA
65-2612	gasket, sump, BSA preunit sing.	EA
65-2619	USE 65-2589	ea
65-3063	screw, cover	EA
65-3099	USE 67-0399	ea
65-3292	shift fork	EA
65-3337	bush, lay, preunit BSA, LH	EA
65-3360	lever, cl. oper, internal	EA
65-3364	cap, oiltank & pri. cov, blank*	EA
65-3365	USE 70-1577 or 82-4047	ea
65-3380	USE 42-3017*	ea
65-3381	USE 15-4179 or 42-3037 *	ea
65-3397	USE 532-05	ea
65-3403	adjust, clutch, screw & ball	EA
65-3417	USE 42-3017*	ea
65-3506	sprocket, gbx, 19T, B31 etc, rigid, plunger	EA
65-3507	sprocket, gbx, 16T, B31 etc, rigid/plunger	EA
65-3507/17	sprocket, gbx, 17T, B31 etc, rigid/plunger	EA
65-3507/18	sprocket, gbx, 18T, B31 etc, rigid/plunger	EA
65-3508	oilseal, gbx. sprocket, BSA	EA
65-3822	washer, tab, clutch, preunit	EA
65-3823	nut, mainshaft, special	EA
65-3824	clutch plate, plain dished	EA
65-3825	USE 42-3119	ea
65-3828	pressure plate, B range, pre53	EA
65-3831	USE 66-3800	ea
65-3833	collar, clutch sleeve	EA
65-3857	USE 42-3119	ea
65-3872	cl. plate, inner, 6spring cl.	EA
65-3873	clutch hub, 6spring cl, GS*	EA
65-3910	brg, caged balls, cl, 6spring type*	EA
65-3910/3911	brg. race, w/caged balls, cl, 6spring type*	ST
65-3911	race, inner, cl, 6spring type*	EA
65-3912	race, outer, cl, 6spring type*	EA
65-3940	pushrod, clutch, p. unit1cyl	EA
65-4182	USE 42-4472	ea

65-4185	bolt,3/8X26	EA
65-4185/CHR	bolt,3/8X26,chrome	EA
65-4727	spring,centrestand,B model	EA
65-4742	USE 82-8382	ea
65-4811	mount,splined,footpeg,B series	EA
65-4894	pivot,pass.peg mt	EA
65-4917	USE 82-9044	ea
65-4960	bars,BSA low rise,pre1971	EA
65-5126	cone,forks,BSA top *	EA
65-5127	cone,forks,BSA bot *	EA
65-5295	bolt,3/8x26	EA
65-5328	nut,splined,steering damp	EA
65-5331	nut,forktube top,20TPI *	EA
65-5331/SS	nuts,forktube top,20TP,stainless *	PR
65-5332	USE 97-2653	ea
65-5333	USE 97-2655	ea
65-5334	USE 97-2656	ea
65-5380	washer,friction,strg.damp	EA
65-5390	USE 89-5036	ea
65-5408	forkleg,LH, pinch	EA
65-5424	USE 97-2637/2638	ea
65-5426	plate,steering damper knob	EA
65-5445	USE 82-6738	ea
65-5446	screw,1/4x26,setscrew	EA
65-5448	forkyoke,top,plunger fr.A7/10	EA
65-5451	USE 97-2641	ea
65-5883	USE 37-1041	ea
65-5884	USE 37-2299	EA
65-5885	USE 37-2305	ea
65-5886	USE 37-2301	ea
65-5887	USE 37-2302	ea
65-5888	washer,cup	EA
65-5895	brakeplate,7"F,GS Scrambler	EA
65-5901	USE 37-2327	ea
65-5903	USE 551-946 (set)	ea
65-5904	USE 37-2328	ea
65-5907	lever,brake oper,8" drum	EA
65-5910	USE 553-68/SS (set)	ea
65-5940	USE 37-2327	ea
65-6274	USE 82-9038	ea
65-6294	sprock&brakedrum assy,42T,5/8x1/4	EA
65-6298	USE 67-6005	ea
65-6302	USE 553-61/SS (set)	ea
65-6303	USE 553-61/SS (set)	ea
65-6306	USE 67-6005	ea
65-6308	USE 67-6005/A	ea
65-6576	USE 324-92 *	ea
65-6612	USE 40-6570	ea
65-6623	bracket,support bridge,fr.mdgrd.	EA
65-6825	bracket,tailight&lic,open	EA
65-7720	chainguard,B31/33 plunger	EA
65-8032	rubber,tank mt.	EA
65-8171	USE 621-71	EA
65-8172	USE 571-38/D	ea
65-8193	USE 65-8228	ea
65-8205	kneepad,preunit BSA,RH	EA
65-8205/8206	kneepad set,preunit BSA,w/plates	PR
65-8205/8206/A	plates,kneepad mounting	PR
65-8206	USE 65-8205/8206 set	ea
65-8218	USE 82-9204	ea
65-8220	badge,tank,round sm.3 gun	PR
65-8220/ER	badge,tank,round sm.3 gun,econo.repl.	PR
65-8228	USE CORRECT COLOUR	ea
65-8228/BLK	badge,tank,rnd.g.star,blk	PR
65-8228/RED	badge,tank,rnd.g.star,red*	PR
65-8314/8315	kneepad set,preunit BSA,early	PR
65-8317	screw,5BA,tankbadge	EA
65-8500	cap,oiltank & primary cov	EA
65-8531	USE 526-M40/27X	ea
65-8532	USE 526-M40/27X	ea
65-8680	USE 526-723	ea

65-8714	USE 526-187	ea
65-9111	USE 99-3514	ea
65-9160	USE 571-46.75/B	ea
65-9164	USE 572-BG150804	ea
65-9167	bracket,chronometric mounting	EA
65-9171	bracket,instr.mount,dual*	EA
65-9172	USE 571-38/D	ea
65-9267	USE 571-46.75/B	ea
65-9270	decals,BSA Motorcycles piled arms	EA
66-	BSA PARTS	*
66-----	-----	---
66-0075	USE 443-821	ea
66-0139	USE 452-432 *	ea
66-0140	USE 452-432	ea
66-0235	USE 453-660235	ea
66-0236	USE 453-20	ea
66-0492	bush,small end,BSA single	EA
66-0694	USE 71-3700	ea
66-0954	USE 71-3700	ea
66-1920	gasket,timing cover,preunit single	EA
66-1923	washer,rubber sealing,oilfeed	EA
66-2620	spindle,oilpump,driving	EA
66-2904	USE 721-B26	ea
66-2940	USE 721-B26	ea
66-2944	USE 711-Z635	ea
66-2995	USE 721-B42	ea
66-3058	spring,kickstart,M20/M21	EA
66-3068	gasket,gbx.cov,outer	EA
66-3069	gasket,gbx.cov,inner	EA
66-3080	kickstart ratchet pinion	EA
66-3090	washer,cork,gbx/chaincase	EA
66-3131	gasket,gbx.cov,outer	EA
66-3211	bush,gbx,preunit single	EA
66-3259	rubber,kickstart stop,B31	EA
66-3290	shifter fork,preunit BSA	EA
66-3291	pin,tapered,gbx,preunit	EA
66-3781	cup,clutch spring,6spring type*	EA
66-3787	nut,clutch,6spring BSA	EA
66-3800	spring,cl,preunit 6spring type*	EA
66-3891	insert,friction,clutch dr	EA
66-3903	clutch centre,6 spring cl.	EA
66-3903/ER	clutch centre,6 spring cl,econo	EA
66-3906	clutch centre,B31	EA
66-3908	USE 42-3223	ea
66-4149	USE 82-8988	ea
66-4708	USE 37-2331	ea
66-4902	washer,cork,pri/footpeg	EA
66-5106	nut,fortube top,w/plug	EA
66-5203	USE 66-5204	ea
66-5204	dustcover, strg.hd.brgs	EA
66-7514	gasket,primary cover,cork	EA
66-7518	USE 70-2441	ea
66-7520	plate,sliding,BSA primary	EA
66-7523	bolt,special,sliding plt,short	EA
66-8091	rubber washer	EA
67-	BSA PARTS	*
67-----	-----	---
67-0028	gasket,cyl.head,A7,pre51	EA
67-0031	USE 452-478	ea
67-0032	USE 452-478	ea
67-0042	USE 82-4047	ea
67-0056	USE 70-1513	ea
67-0060	washer,1/2",rocker shaft	EA
67-0061	USE 70-8037	ea
67-0062	USE 70-8037	ea
67-0101	USE 70-6869	ea
67-0120	USE 67-0527	EA
67-0132	screw,1/4x20	EA
67-0133	screw,1/4x20	EA
67-0134	washer,cork,1/8"thick	EA
67-0135	washer,cork,5/32" thick	EA

67-0136	washer,cork,7/32" thick	EA
67-0137	washer,cork,3/32" thick	EA
67-0226	USE 421-60 (set)	ea
67-0244	USE 421-60/010 (set)	ea
67-0245	USE 421-60/020 (set)	ea
67-0246	USE 421-60/030 (set)	ea
67-0255	gasket,cylinder head,A10*	EA
67-0256	gasket,cyl.base,A7 & A10	EA
67-0263	cover,rocker insp,4 hole A7/10	EA
67-0276	USE 414-110/B (set)	ea
67-0277	USE 67-1583	ea
67-0278	USE 67-1582	ea
67-0279	gasket,rocker insp.cover	EA
67-0281	gasket,timing cover,inner	EA
67-0282	gasket,timing cover outer	EA
67-0283	bolt,3/8x20,cyl.hd,centre	EA
67-0286	bush,inner idler pinion	EA
67-0296	USE 552-110500/52	ea
67-0298	bush,small end,A10/50/65	EA
67-0298/A	bush,small end,A10/50/65,hi.performance	EA
67-0299	USE 414-110/A or 414-110/B (set)	ea
67-0303	USE 67-0298	ea
67-0320	USE 421-60 (set)	ea
67-0323	USE 453-17	ea
67-0324	USE 453-18	ea
67-0332	tappet,BSA A10,I	EA
67-0332/0333	tappet set,BSA A10,I & X	ST
67-0332/U	tappet,reground,exch	EA
67-0333	tappet,BSA A10,X	EA
67-0333/U	tappet,reground,exch	EA
67-0334	USE 37-0356	ea
67-0337	USE 67-0338 *	ea
67-0338	gear,camshaft,BSA Twins	EA
67-0339	gear,crankpinion,BSA Twin	EA
67-0356	camshaft,A7/10*	EA
67-0357	camshaft,A10,SUPEROCKET*	EA
67-0360	USE 67-0977/0979 (set)	ea
67-0362	USE 67-0977/0979 (set)	ea
67-0386	USE 67-1201	ea
67-0389	USE 67-1201*	ea
67-0393	bush,small end,A7	EA
67-0394	USE 453-15	ea
67-0395	USE 453-16	ea
67-0429	USE 441-11062 (set)	ea
67-0431	USE 441-11062/020 (set)	ea
67-0433	USE 441-11062/040 (set)	ea
67-0435	USE 441-11062/060 (set)	ea
67-0439/0440	USE 451-454	ea
67-0527	driptray,carb manifold	EA
67-0527/CHR	driptray,carb manifold,chrome	EA
67-0527/SS	driptray,carb manifold,stainless	EA
67-0531	USE 453-15	ea
67-0532	USE 453-16	ea
67-0540	gear,mag>manual adv,fibre	EA
67-0540/A	gear,mag>manual adv,alloy	EA
67-0643	nut,LH thread,RHcrank,BSA	EA
67-0644	washer,tab,crank,RH	EA
67-0645	USE 71-2500	ea
67-0648	USE 67-0790	ea
67-0670	bearing,roller	EA
67-0671	washer,shim,.005	EA
67-0674	USE 04-0132	ea
67-0685	washer,tab,cam pinion	EA
67-0686	bush,flanged	EA
67-0708	washer,cork	EA
67-0716	USE 68-0981	ea
67-0721	sprocket,driving,A10 dyn.	EA
67-0727	sprocket,dynamo,driven11T	EA
67-0729	washer,tab,dynamo gear	EA
67-0740	USE 453-15	ea
67-0741	USE 453-16	ea

67-0742	USE 453-17	ea
67-0743	USE 453-18	ea
67-0787	USE 67-0790/020	ea
67-0790	bush,RH crank,BSA A7/A10,bronze	EA
67-0790/010	bush,RH crank,A7/10 -.010,bronze	EA
67-0790/010/A	bush,RH crank,A7/10 -.010,2pc.	EA
67-0790/020	bush,RH crank,A7/10,-.020,bronze	EA
67-0790/020/A	bush,RH crank,A7/10-.020,2pc.	EA
67-0790/030	bush,RH crank,A7/10,-.030,bronze	EA
67-0790/030/A	bush,RH crank,A7/10,-.030,2pc.	EA
67-0790/040	bush,RH crank,A7/10 -.040,bronze	EA
67-0790/040/A	bush,RH crank,A7/10,-.040,2pc.	EA
67-0790/050	bush,RH crank,A7/10 -.050,bronze	EA
67-0790/050/A	bush,RH crank,A7/10,-.050,2pc.	EA
67-0790/060	bush,RH crank,A7/10 -.060	EA
67-0790/070	bush,RH crank,A7/10 -.070	EA
67-0790/080	bush,RH crank,A7/10 -.080	EA
67-0790/A	bush,RH crank,BSA A7/A10,2pc.	EA
67-0793	pin,crankcase bush dowel	EA
67-0799	USE 67-0790/010	ea
67-0883	USE 451-463 (set)	ea
67-0884	USE 451-463 (set)	ea
67-0949	USE 414-110/A (set)	ea
67-0967	USE 453-128	ea
67-0968	USE 453-127	ea
67-0974	bracket,head steady,A7/10 plunger	EA
67-0975	bracket,head steady,A7/10 plunger	EA
67-0977	pushrod,inlet,A10	EA
67-0977/0979	pushrod set,alloy,A10 I&X	ST
67-0979	pushrod,ex,A10	EA
67-1033	USE 67-1535 & 70-2922	ea
67-1034	USE 70-2922	ea
67-1110	USE 452-478/PB	ea
67-1114	USE 414-05	ea
67-1115	USE 414-05	ea
67-1116	USE 414-05	ea
67-1118	nut,5/16x26,sleeve	EA
67-1120	USE 71-3573	ea
67-1132	sprocket,engine,18T,2 lobe	EA
67-1133	sprocket,engine,21T,2 lobe	EA
67-1136	spring,cushdrive,BSA PU	EA
67-1176	USE 421-783 (set)	ea
67-1177	USE 421-783/010 (set)	ea
67-1178	USE 421-783/020 (set)	ea
67-1179	USE 421-783/030 (set)	ea
67-1181	USE 67-1536	ea
67-1201	conrod,A7,drilled*	EA
67-1202	USE 67-1201*	ea
67-1205	conrod,A10,w/oilhole,late	EA
67-1205/1206/A	conrods,CARILLO HiPerf.	ST
67-1206	USE 67-1205 *	ea
67-1211	plug,crank,7/8x11,plain *	EA
67-1211/1212/A	plug set,crank,allen type	ST
67-1212	plug,crank,7/8x11,spigot *	EA
67-1240	USE 70-1591	ea
67-1242	oilseal,cl,A7/10,semiunit	EA
67-1258	USE 06-7568	ea
67-1259	bolt,extended,A10 magneto	EA
67-1285	USE 70-8064 & 71-1126	ea
67-1286	USE 70-8064	ea
67-1288	USE 71-1424	ea
67-1370	USE 441-11062 (set)	ea
67-1372	USE 441-11062/020 (set)	ea
67-1374	USE 441-11062/040 (set)	ea
67-1389	spindle& gear,pump,no tachdr*	EA
67-1393	USE 71-2296	ea
67-1394	USE 71-2296	ea
67-1395	USE 68-0138 *	ea
67-1396	stud,1/4x20x26 *	EA
67-1400	spring,checkvalve,A10	EA
67-1402	oilpump,cast iron,A7/10*	EA

67-1402/A	oilpump,MORGO,A7/10	EA
67-1403	gear,oilpump,feed,w/shaft	EA
67-1404	gear,oilpump	EA
67-1405	gear,oilpump,scavenge drive	EA
67-1406	gear,oilpump scavenge	EA
67-1416	USE 441-11062 (set)	ea
67-1418	USE 441-11062/020 (set)	ea
67-1420	USE 441-11062/040 (set)	ea
67-1430	USE 421-783	ea
67-1431	USE 421-783/010 (set)	ea
67-1432	USE 421-783/020 (set)	ea
67-1433	USE 421-783/030 (set)	ea
67-1434	USE 421-783/040 (set)	ea
67-1496	spring,press.rel.valve	EA
67-1498	USE 70-8121	ea
67-1499	USE 70-1670	ea
67-1534	USE 70-2922	ea
67-1535	bolt,conrod,A7&early A10	EA
67-1536	bolt,conrod,26TPI	EA
67-1536/A	bolt,conrod,24TPI	EA
67-1537	USE 70-2922	ea
67-1551	USE 453-215	ea
67-1582	gasket,rockerbox,A10large	EA
67-1583	gasket,rockerbox,A10,sm.	EA
67-1601	USE 441-11062 (set)	ea
67-1603	USE 441-11062/020 (set)	ea
67-1605	USE 441-11062/040 (set)	ea
67-1702	gasket,pri,rigid &plunger	EA
67-1703	USE 552-114038/80	EA
67-1705	screw,1/4x26,slotted,cover	EA
67-1709	USE 70-8175	ea
67-1712	USE 552-116038/80	ea
67-2690	USE 42-2848	ea
67-2694	USE 42-2848	ea
67-3024	cover,insp,gbx,preunit BSA	EA
67-3028	circlip,gbx.bearing	EA
67-3033	gasket,gbx.insp,preunitBSA	EA
67-3034	USE 70-1310	ea
67-3055	sprocket,gearbox,16T,A10,etc.	EA
67-3064	sprocket,gearbox,18T,A10,etc.	EA
67-3065	sprocket,gearbox,19T,A10,etc.	EA
67-3065/A	sprocket,gearbox,20T,A10,etc.	EA
67-3067	oilseal,gbx.sprock,w/lip	EA
67-3068	sprocket,gearbox,17T,A10,etc.	EA
67-3073	USE 67-3073/3080	ea
67-3073/3080	bush set,4th main,preunit*	ST
67-3076	gear,4th main,26T	EA
67-3078	gear,sliding,18T	EA
67-3079	gear,main sliding,22T	EA
67-3080	USE 67-3073/3080	ea
67-3093	bush,gbx,1st gear lay	EA
67-3096	gear,lay,21T	EA
67-3099	bush,lay,preunit BSA,RH	EA
67-3151	bush,gbx cov,inner,kick	EA
67-3153	bush,gbx.cov,outer,kick	EA
67-3161	USE 57-1962	ea
67-3162	spring,kick ratchetPinion	EA
67-3163	nut,mainshaft,RH,preunit	EA
67-3164	USE 68-3301	ea
67-3166	USE 67-3169	ea
67-3167	kickstart ratchet	EA
67-3168	USE 67-3376	ea
67-3169	bush,kick ratchet pinion	EA
67-3170	bush,gbx.cov,inner,shift	EA
67-3171	USE 42-3017*	ea
67-3174	spring,kickstart return	EA
67-3241	clutch plate,plain	EA
67-3242	clutch plate,friction	EA
67-3245	pressure plate,A7/10,pre53	EA
67-3248	cup,clutch spring	EA
67-3264	gasket,clutch,plunger fr.	EA

67-3315	mainshaft,bare	EA
67-3330	mainshaft,bare	EA
67-3335	shaft,gearshift	EA
67-3346	gask,gbx.in,BSA swing arm	EA
67-3353	bush,gbx cov,outer,shift	EA
67-3354	gask,gbx out,BSA swingarm	EA
67-3374	USE 42-3160	ea
67-3375	USE 42-3160	ea
67-3376	kick ratchet pinion,17T	EA
67-3378	spring,shift return	EA
67-4041	stud,7/16x20,LH thread	EA
67-4596	connector,airfilter,A7&Star Twin	EA
67-4847	spring,centrestand,rigid/plunger fr.	EA
67-4851	footpeg,rigid/plunger,R&L	EA
67-4852	USE 82-7389	ea
67-4856	USE 82-9050	ea
67-5009	sleeve,forks,w/out hdlt.ears	EA
67-5014	USE 97-2636	ea
67-5021	USE 97-3875	ea
67-5023	sleeve,steering stem, BSA	EA
67-5024	nut,steering stem sleeve,w/hole*	EA
67-5024/SS	nut,strng.stem sleeve,w/hole,stainless	EA
67-5042	bracket,rh,hdlt,A10 type	EA
67-5042/5044	brackets,hdlt,A10 type	PR
67-5044	bracket,lh,hdlt,A10 type	EA
67-5088	grommet,speedo mounting,preunit BSA	EA
67-5543	USE 68-5556	EA
67-5544	spoke,19"front 1/2 width	EA
67-5545	spoke,19"front 1/2 width	EA
67-5555	brakeplate,pre56 A7/10	EA
67-5558	USE 67-5601	ea
67-5561	USE 68-5551	ea
67-5562	USE 68-5552	ea
67-5565	spacer sleeve,front axle	EA
67-5571	USE 551-983	ea
67-5576	pin,pivot,brakeshoe	EA
67-5578	bracket,brake stay,F	EA
67-5601	brakeshoe,65 A50,A65L&S,F,etc,8"front	PR
67-5601/ER	brakeshoes,65A50,A65L&S,F,econo	PR
67-6005	rim,WM2x19,BSA QD rear	EA
67-6005/A	rim,WM2x19 R,alloy,w/shoulder	EA
67-6005/SS	rim,WM2x19,BSA QD rear,stainless	EA
67-6027	USE 37-2300	ea
67-6033	USE 37-2311	ea
67-6034	USE 37-2312	ea
67-6038	USE 37-2315	ea
67-6039	USE 37-2317 *	ea
67-6051	USE 37-2313	ea
67-6061	spacer,wheel hub	EA
67-6121	sprock&brakedrum assy,46T,5/8x3/8	EA
67-6122	sprock&brakedrum assy,49T,5/8x3/8	EA
67-6123	sprock&brakedrum assy,46T,5/8x3/8	EA
67-6124	sprock&brakedrum assy,49T,5/8x3/8	EA
67-6128	cover plate,rear hub	EA
67-6133	cover plate,rear hub,QD	EA
67-6136	USE 68-6114	ea
67-6149	sprock&brakedrum assy,42T,5/8X3/8	EA
67-6150	sprock&brakedrum assy,42T,5/8x3/8	EA
67-6154	sprocket&brakedrum assy,45T,5/8X3/8	EA
67-6204	bolt,5/16CEI	EA
67-6530	stand,front,A10 SA	EA
67-6544	bracket,fender stay	EA
67-6557	bracket,fender stay	EA
67-6558	stand,front,A10,etc.	EA
67-6560	plate,stiffener	EA
67-6570	USE 60-3361	ea
67-6772	bracket,fender stay,RH rear	EA
67-6774	bracket,fender stay,LH rear	EA
67-6830	bracket,tailight&lic,A10,enclosed	EA
67-6839	USE 82-9028	ea
67-6861	mudguard,R,chrome	EA

67-6885	bracket,tailight&lic,A10,enclosed	EA
67-7725	USE 67-7726	ea
67-7726	chainguard,A7/10,rigid	EA
67-8060	nut,acorn,fueline banjo	EA
67-8070	badge,BSA GOLDEN FLASH,RH	EA
67-8071	badge,BSA GOLDEN FLASH,LH	EA
67-8116	USE 65-8228	ea
67-8313	USE 06-7635	ea
67-8610	USE 526-525	ea
67-8687	USE 526-723/13	ea
67-9002	toolbox,A7/10 plunger	EA
67-9067	USE 324-11	ea
67-9069	USE 324-11	ea
67-9089	bracket,seat,plunger frame	EA
67-9114	USE 222-179	ea
68-	BSA PARTS	*
68-----	-----	---
68-0013	USE 70-3717	ea
68-0014	stud,5/16x22x26	EA
68-0015	USE 68-0336	ea
68-0018	USE 70-8227	ea
68-0022	USE 70-3824	ea
68-0023	USE 60-3556	ea
68-0024	USE 70-0489	ea
68-0025	bush,cam,A50/65,RH in&out	EA
68-0026	oilseal,point,pre69A50/65	EA
68-0027	USE 57-0946	ea
68-0028	bush,idler,flanged,long	EA
68-0030	pin,dowel,gbx.inner cover	EA
68-0033	USE 68-0800 *	ea
68-0034	bearing,needle,closed end	EA
68-0035	bolt,5/16x22	EA
68-0036	stud,stator	EA
68-0043	USE 68-0886	ea
68-0046	USE 70-7823	ea
68-0048	cylinder barrel,A50,early	EA
68-0050	gear,oil pump drive,crank	EA
68-0053	USE 71-1105/1106/A (set)	ea
68-0065	USE 70-2922	ea
68-0066	stud,1/4x26	EA
68-0067	stud,1/4x26	EA
68-0068	USE 68-0066	ea
68-0071	USE 71-1430	ea
68-0079	stud,3/8x20x26,cyl.head	EA
68-0081	stud,3/8x20x26	EA
68-0087	USE 76-0013	ea
68-0098	plunger,shift detent,A65	EA
68-0099	USE 68-0827	ea
68-0100	USE 68-0828	ea
68-0101	USE 57-0373	ea
68-0103	camshaft,A50 & early A65	EA
68-0130	USE 70-3822	ea
68-0131	USE 70-2254	ea
68-0132	USE 70-2256	ea
68-0137	nut,1/4x26,acorn	EA
68-0138	stud,1/4x26x1-3/4"	EA
68-0139	cover,rockers,pre71A50/65,smooth	EA
68-0143	stud,1/4x26x1.5"	EA
68-0144	USE 71-1431	ea
68-0147	rocker arm,inlet LH,A65	EA
68-0149	rocker,arm,inlet RH,A65	EA
68-0151	rocker arm,exh.LH,A50/65	EA
68-0153	rocker arm,exh.RH,A50/65	EA
68-0155	USE 70-1513 *	ea
68-0156	USE 453-226	ea
68-0157	USE 453-254	ea
68-0158	collet,valve,A65 pre 1970*	EA
68-0159	USE 452-516	ea
68-0163	circlip,tappet,A50 & A65	EA
68-0166	collar,valvespring,top	EA
68-0167	USE 452-516	ea

68-0168	USE 453-255	ea
68-0169	USE 453-225	ea
68-0184	USE 70-3905	ea
68-0185	USE 70-3903	ea
68-0186	cup, shim retainer, crank	EA
68-0192	shaft, rockers, A50/65	EA
68-0205	sprocket, engine, triplex, 28T	EA
68-0209	USE 70-4144	ea
68-0213	bush, kick, in. timing cov.	EA
68-0214	bush, idler, flanged, short	EA
68-0216	USE 70-4096	ea
68-0217	USE 71-1437	ea
68-0224	manifold, inlet, A50/65	EA
68-0227	cover, timing, outer A65pre70	EA
68-0229	screw, 1/4x26	EA
68-0233	USE 70-8168	ea
68-0234	USE 70-8160	ea
68-0235	USE 70-4578	ea
68-0236	USE 70-4577	ea
68-0237	nut, 7/16x18	EA
68-0240	USE 71-1044	ea
68-0241	USE 71-1432	ea
68-0244	USE 70-8310	ea
68-0246	USE 70-7793 *	ea
68-0247	pri. chain adjuster peg	EA
68-0249	spacer, fiber, primary adj	EA
68-0263	pin, piston, BSA A50	EA
68-0272	USE 21-5662	ea
68-0282	USE 71-2413	ea
68-0283	USE 71-2413	ea
68-0289	USE 70-9430	ea
68-0293	USE 71-2296	ea
68-0304	screw, clutch insp. cover	EA
68-0306	cover, cl. adj, A50/65, early	EA
68-0310	spindle & gear, pump, for tach, A50/A65	EA
68-0314	gear, speedo drive, 11T	EA
68-0320	cover, points, BSA A50/65, no logo	EA
68-0324	washer, 5/8", flat, rotor	EA
68-0325	USE 70-8043	ea
68-0331	USE 70-8163	ea
68-0332	USE 68-0336/020	ea
68-0334	USE 68-0336/010	ea
68-0336	bush, RHcr, pre66 A65, STD, bronze*	EA
68-0336/010	bush, RHcr, pre66 A65, -.010, bronze	EA
68-0336/010/A	bush, RHcr, pre66 A65, -.010, 2pc.	EA
68-0336/020	bush, RHcr, pre66 A65, -.020, bronze	EA
68-0336/020/A	bush, RHcr, pre66 A65, -.020, 2pc	EA
68-0336/030	bush, RHcr, pre66 A65, .030, bronze	EA
68-0336/030/A	bush, RHcr, pre66 A65, -.030, 2pc.	EA
68-0336/040	bush, RHcr, pre66 A65, -.040, bronze	EA
68-0336/040/A	bush, RHcr, pre66 A65, -.040, 2pc.	EA
68-0336/050	bush, RHcr, pre66 A65, -.050, bronze	EA
68-0336/050/A	bush, RHcr, pre66 A65, -.050, 2pc.	EA
68-0336/060	bush, RHcr, pre66 A65, -.060	EA
68-0336/070	bush, RHcr, pre66 A65, -.070	EA
68-0336/080	bush, RHcr, pre66 A65, -.080	EA
68-0336/A	bush, RHcr, pre66 A65, STD, 2pc*	EA
68-0337	bolt, 3/8x20, cylinder head	EA
68-0338	bolt, 5/16x22 *	EA
68-0353	spring, checkvalve ball	EA
68-0360	cover plate, gbx sprocket, metal	EA
68-0362	tappet, In & Ex, BSA A50/65	EA
68-0362/U	tappet, reground, exch	EA
68-0365	pushrod, inlet, A50	EA
68-0367	pushrod, exh, A50	EA
68-0370	pushrod, inlet, A65	EA
68-0370/0372/A	pushrod set HiPerf, A65BSA	ST
68-0370/0372/B	pushrod set, chrome moly	ST
68-0372	pushrod, exh, A65	EA
68-0372/A	pushrod, exh, A65, dural 1 pc.	EA
68-0375	pin, pivot, pri. chain adj	EA

68-0376	spacer,pri.chain slipper	EA
68-0377	nut,cap,pri.adjuster	EA
68-0377/SS	nut,cap,pri.adjuster,stainless	EA
68-0383	USE 70-8179	ea
68-0427	USE 441-15933 (set)	ea
68-0429	USE 441-15933/020 (set)	ea
68-0431	USE 441-15933/040 (set)	ea
68-0434	USE 441-15934 (pr)	ea
68-0436	USE 441-15934/020 (pair)	ea
68-0438	USE 441-15934/040/ER(pair)	ea
68-0473	camshaft,BSA A65	EA
68-0475	spring, valve, outer	EA
68-0484	USE 441-19233 (set)	ea
68-0486	USE 441-19233/020 (set)	ea
68-0488	USE 441-19233/040 (set)	ea
68-0499	USE 441-19233 (set)	ea
68-0531	USE 68-0952	ea
68-0538	USE 57-2697	ea
68-0560	scavenge valve&pipe, sump	EA
68-0580	bolt,3/8X26CEI,flywheel,A50/65	EA
68-0581	bolt,3/8X26CEI,flywheel A50/65,ext.	EA
68-0582	USE 70-8037	ea
68-0585	tachdrive housing,A50/65	EA
68-0586	spindle,tachdrive,A50/A65	EA
68-0588	USE 71-4443	ea
68-0589	USE 71-1436	ea
68-0598	USE 70-8259	ea
68-0602	USE 68-0927	ea
68-0606	USE 70-9213	ea
68-0609	USE 37-2319	ea
68-0610	USE 70-8782	ea
68-0611	oring	EA
68-0625	bearing,roller,crank LH*	EA
68-0633	USE 417-05 (set)	ea
68-0634	USE 417-05 (set)	ea
68-0635	USE 417-05 (set)	ea
68-0636	USE 68-0657	ea
68-0638	cup,shim retainer,crank,early*	EA
68-0647	USE 68-0657/010	ea
68-0648	USE 68-0657/020	ea
68-0649	USE 71-1106	ea
68-0657	bush,RH cr,66onA50/65,std,bronze*	EA
68-0657/010	bush,RH cr,66on A65,-.010,bronze	EA
68-0657/010/A	bush,RH cr,66on A65,-.010,2pc.	EA
68-0657/020	bush,RH cr,66on A65,-.020,bronze	EA
68-0657/020/A	bush,RH cr,66on A65,-.020,2pc.	EA
68-0657/030	bush,RH cr,66on A65,-.030,bronze	EA
68-0657/030/A	bush,RH cr,66on A65,-.030,2pc.	EA
68-0657/040	bush,RH cr,66on A65,-.040,bronze	EA
68-0657/040/A	bush,RH cr,66on A65,-.040,2pc.	EA
68-0657/050	bush,RH cr,66on A65,-.050,bronze	EA
68-0657/050/A	bush,RH cr,66on A65,-.050,2pc.	EA
68-0657/060	bush,RH cr,66on A65,-.060	EA
68-0657/070	bush,RH cr,66on A65,-.070	EA
68-0657/080	bush,RH cr,66on A65,-.080	EA
68-0657/A	bush,RH cr,66onA50/65,std,2pc*	EA
68-0661	USE 453-255	ea
68-0662	USE 453-256	ea
68-0663	USE 453-254	ea
68-0665	USE 453-253	ea
68-0679	gasket,timing tool hole	EA
68-0680	flywheel only,A50	EA
68-0685	washer,thrust,crank,RH*	EA
68-0688	spacer,crank, A50/65,LH	EA
68-0749	USE 441-19233 (set)	ea
68-0751	USE 441-19233/020 (set)	ea
68-0753	USE 441-19233/040 (set)	ea
68-0781	USE 68-0827	ea
68-0782	USE 68-0828	ea
68-0784	USE 441-19233 (set)	ea
68-0786	USE 441-19233/020 (set)	ea

68-0788	USE 441-19233/040 (set)	ea
68-0792	USE 441-18732	ea
68-0800	stud, stator	EA
68-0805/0806	USE 451-641	ea
68-0805/0930	USE 451-641	ea
68-0808	USE 452-516	ea
68-0809	USE 452-516/PB	ea
68-0819	USE 441-19233 (pair)	ea
68-0820	USE 441-19233/020 (pair)	ea
68-0821	USE 441-19233/040 (pair)	ea
68-0827	gasket, cyl.hd.A65, copper	EA
68-0828	gasket, cylinder head, A50	EA
68-0830	cover, rockers, pre71A50/6, finned	EA
68-0837	USE 71-1044	ea
68-0839	cover, rotor, BSA A50/65, blank	EA
68-0840	USE 71-1420	ea
68-0841	pointer, ignition timing	EA
68-0860	USE 70-7793	ea
68-0861	washer, sealing	EA
68-0865	dipstick, gearbox, A50 &A65	EA
68-0875	USE 71-1432	ea
68-0876	USE 68-0143	ea
68-0879	cylinder head, A65L pre71	EA
68-0886	cylinder, A65 w.5/16 studs	EA
68-0888	cylinder barrel, A50, late	EA
68-0891	USE 441-18732	ea
68-0906	USE 441-19233 (pair)	ea
68-0908	USE 441-19233/020 (pair)	ea
68-0910	USE 441-19233/040 (pair)	ea
68-0919	stud, 1/4x26*	EA
68-0920	USE 71-2742	ea
68-0923	USE 70-8106	ea
68-0924	USE 70-8106	ea
68-0925	USE 68-0927 *	ea
68-0927	oiline, rockerfeed, BSA	EA
68-0930	spring, valve, outer	EA
68-0931	valvespring cup, bottom	EA
68-0934	body, oilpump, A50/65	EA
68-0938	USE 70-8104	ea
68-0939	USE 71-2296	ea
68-0941	USE 71-2413	ea
68-0942	USE 71-2742	ea
68-0951	USE 70-8227	ea
68-0952	stud, 5/16x22x26, stepped	EA
68-0981	bolt, 3/16x24	EA
68-0982	washer, tab, tachdr. adaptor	EA
68-2001	skidplate, A65F, pre 1971	EA
68-2732	USE 711-Z663	ea
68-2733	USE 711-Z663	ea
68-2773	USE 57-2773	ea
68-2780	bracket, muffler, A65, RH	EA
68-2781	bracket, muffler, A65, LH	EA
68-2789	USE 721-B87 (set)	ea
68-2791	USE 721-B87 (set)	ea
68-2794	bracket, x pipe tie, A50/65	EA
68-2802	bracket, exh.pipe, A65F	EA
68-3005	bush, kickstart, inner cov.	EA
68-3015	gear, 2nd lay or 3rd main	EA
68-3019	spacer, mainshaft	EA
68-3021	washer, thrust spacer, gbx	EA
68-3026	USE 68-3178 (TWO OF)	ea
68-3027	USE 57-3988	ea
68-3036	shaft, shifter fork, A50/65	EA
68-3043	camplate, pre65 A50/65	EA
68-3045	shaft, camplate pivot, A65	EA
68-3049	kick spindle&quad.assy, pre71*	EA
68-3053	spring, kickstart, A50/65	EA
68-3054	plate, kick return spring	EA
68-3056	kickstart ratchet, A50/65	EA
68-3058	pin, anchor, shifter spring	EA
68-3060	stud, 5/16x22x26TPI	EA

68-3065	plunger,clutch release	EA
68-3066	lever,oper,clutch release	EA
68-3067	washer,tab,clutch release	EA
68-3070	USE 68-3167 & 57-2697	ea
68-3072	sprocket,gbx,17T,A50/65	EA
68-3073	sprocket,gbx,20T,A50/65	EA
68-3073/ER	sprocket,gbx,20T,A50/65,econo	EA
68-3074	sprocket,gbx,16T,A50/65	EA
68-3076	USE 57-1436	ea
68-3078	sprocket,gbx,19T,A50/65	EA
68-3083	lever,shift quad.spring	EA
68-3084	USE 57-4027	ea
68-3088	key,woodruff,square	EA
68-3089	sprocket,gbx,21T,A50/65	EA
68-3089/22	sprocket,gbx,22T,A50/65*	EA
68-3089/ER	sprocket,gbx,21T,A50/65,econo	EA
68-3090	USE 57-2764	ea
68-3091	USE 57-2764	ea
68-3092	USE 57-2652	ea
68-3093	sprocket,gbx,18T,A50/65	EA
68-3095	kickstart ratchet pinion	EA
68-3096	USE 57-1396	ea
68-3098	quadrant,shift,A50/65,early	EA
68-3100	mainshaft,A50/65,w/gears	EA
68-3102	USE 68-3104	ea
68-3104	layshaft,assy,A50/65	EA
68-3107	gear,2nd lay,A65 cl.ratio	EA
68-3114	gear,2nd main,23T,c.ratio	EA
68-3115	gear,4th main,23T,w/bushes*	EA
68-3118	screw,2BA,setscrew,allen	EA
68-3120	gear,3rd lay&2nd main,22T	EA
68-3125	USE 57-4027	ea
68-3127	gear,1st main,16T,c.ratio	EA
68-3128	gear,1st lay,24T,c.ratio	EA
68-3135	gear,speedodrive,10 tooth	EA
68-3141	gear,speedodrive,11 tooth	EA
68-3150	gear,1st main,14T	EA
68-3151	gear,1st lay,26T	EA
68-3158	shifter fork,main,A50/65	EA
68-3160	shifter fork,lay,A50/65	EA
68-3163	nut,9/16CEI,mainshaft RH	EA
68-3167	plug,gbx.drain&level,A65	EA
68-3168	USE 57-2697	ea
68-3169	USE 57-1045	EA
68-3178	bush,gbx,4th gear main*	EA
68-3180	pin,kickstart stop,A50/65	EA
68-3181	gear,3rd lay,18T,c.ratio	EA
68-3182	gear,3rd main,22T,c.ratio	EA
68-3184	USE 57-4023	ea
68-3187	USE 57-2767	ea
68-3193	USE 532-74	ea
68-3194	washer,felt	EA
68-3195	USE 57-7017	ea
68-3202	USE 57-7017	ea
68-3203	USE 57-7017	ea
68-3217	bolt,clutch,4 spring A50/65	EA
68-3218	USE 60-4253	ea
68-3220	cl.centre,4spring A65	EA
68-3221	clutch plate,plain,earlyA50/65	EA
68-3224	pressure plate,cl,4spring,w/cups*	EA
68-3226	USE 68-3224	ea
68-3229	pushrod,clutch,A50 & A65	EA
68-3230	clutch drum,A50/A65,pre66	EA
68-3234	bolt,2BA,tachdrive housing	EA
68-3235	plate,steady,4spring cl.	EA
68-3236	spring,clutch,4spring A65*	EA
68-3237	USE 68-3236	ea
68-3238	rubber,clutch,4spring,lg.	EA
68-3239	rubber,clutch,4spring,sm.	EA
68-3246	USE 57-2526	ea
68-3252	clutch hub.4 spring A65	EA

68-3257	connector,clutch cable*	EA
68-3257/3259/63	adaptor kit,cl.cable,A50/65*	ST
68-3259	abutment,clutch cable*	EA
68-3259/3260/63	Changed 68-3257/3259/63	Jan 19 04 ST
68-3263	adaptor,slotted,cl. cable*	EA
68-3264	USE 57-1646	ea
68-3267	USE 57-1362	ea
68-3272	USE 57-2773	ea
68-3275	USE 57-1719	ea
68-3276	USE 57-2538	ea
68-3277	USE 57-3929 *	ea
68-3278	USE 57-1735	ea
68-3280	USE 57-1720	ea
68-3281	USE 57-1722	ea
68-3282	USE 57-1723	ea
68-3283	USE 57-1724	ea
68-3287	USE 57-1931	ea
68-3288	USE 57-1830	ea
68-3294	USE 57-4116	ea
68-3298	USE 57-4028	ea
68-3299	gear,4th lay,17T,A50/65	EA
68-3300	USE 57-1047	ea
68-3301	washer,tab,kick ratchet	EA
68-3303	layshaft,A50/65,1967 on	EA
68-3305	USE 57-2156	ea
68-3308	USE 57-2159	ea
68-3309	USE 14-0403	ea
68-3311	USE 68-3066 (assy)	ea
68-3312	pivot,clutch release	EA
68-3313	USE 68-3066 (assy)	ea
68-3315	USE 57-2764	ea
68-3318	USE 57-2764	ea
68-3320	USE 57-1047	ea
68-3321	USE 57-1830	ea
68-4080	bracket,eng.mt,R,A50/65	EA
68-4081	USE 82-9045	ea
68-4083	USE 68-4260	ea
68-4084	bolt,7/16x26	EA
68-4085	nut,7/16x26,lock	EA
68-4088	stud,7/16x20CEI,fr.engine mt	EA
68-4088/SS	stud,7/16",stainless*	EA
68-4090	bracket,engine mount	EA
68-4091	USE 68-4093	ea
68-4093	bracket,coil,1-7/8"	EA
68-4095	adjuster post,brake pedal	EA
68-4095/SS	adj.post,brakepedal,stainless	EA
68-4096	screw,brake pedal adjust.	EA
68-4150	bolt,5/16x26,axle adjuster*	EA
68-4228	swingarm,A50/65,pre 1969	EA
68-4235	nut,3/8x26	EA
68-4240	bolt,3/8x26,chrome	EA
68-4243	bolt,3/8x26	EA
68-4260	stud,3/8x26,eng.mt,bott.	EA
68-4260/SS	stud,3/8x26,stainless	EA
68-4286	spacer,seat	EA
68-4500	battery strap assy,6V.bat	EA
68-4559	rubber bush,battery box bottom	EA
68-4560	rubber bush,battery box	EA
68-4569	USE 68-4595	ea
68-4577	hook&battery strap assy*	EA
68-4578	plate,retaining,bat.box	EA
68-4595	battery carrier,pre71 BSA	EA
68-4597	USE 82-8091	ea
68-4598	USE 82-8091	ea
68-4606	USE 82-9001	ea
68-4628	USE 633-389/A	ea
68-4630	USE 82-5958	ea
68-4631	USE 82-6074	ea
68-4633	USE 633-389/A	ea
68-4635	USE 633-900/A	ea
68-4708	USE 83-2896	ea

68-4729	centerstand,pre71 A50/65	EA
68-4802	footpeg,A50/65 LH,pre'71	EA
68-4803	footpeg,A50/65 RH,pre'71	EA
68-4804	stud,LH thread,splined	EA
68-4804/ER	stud,LH thread,splined,econo.repl	EA
68-4805	stud,7/16x20	EA
68-4808	footpeg mount,LH folding	EA
68-4809	footpeg mt,folding,RH	EA
68-4820	USE 68-4829	ea
68-4828	mount,passenger peg,A65	EA
68-4829	footpeg assy,rear,A50/65,etc,w/rubber*	EA
68-4835	USE 83-7059	ea
68-4952	USE 42-4968	ea
68-4953	USE 42-4968	ea
68-4960	bars,A65 USA,pre67	EA
68-4961	USE 42-4968	ea
68-4962	USE 42-4968	ea
68-4963	cable guide tube,handlebars	EA
68-4971	USE 42-4968	ea
68-4980	USE 97-1511	ea
68-4982	USE 42-4968	ea
68-5030	forktube,pre'69 BSA,short,21.2"	EA
68-5040	spring,forks	EA
68-5042	spring,forks,10"	EA
68-5045	forklock assy,threaded,early A50/65	EA
68-5049	fork yoke,upper,A65,62-65	EA
68-5050	USE 82-6738	ea
68-5056	USE 97-2656	ea
68-5059	bracket,hdlt,A50/65,LH,CHROME*	EA
68-5059/5060/CHR	brackets,hdlt,A50/65,chrome,early	PR
68-5060	USE 97-2512	ea
68-5104	USE 97-2630	ea
68-5108	USE 97-2631	ea
68-5129	fork yoke,upper,1966-70	EA
68-5132	forkseal holder,pre69 BSA,short*	EA
68-5134	USE 97-2643	ea
68-5137	USE 97-2658	ea
68-5139	USE 68-5176	ea
68-5140	USE 68-5177	ea
68-5143	USE 97-2669	ea
68-5144	forktube,1966-68 BSA A50/65*	EA
68-5146	USE 68-5194	ea
68-5147	USE 68-5195	ea
68-5150	bracket,steering damper	EA
68-5170	USE 97-2670	ea
68-5171	USE 97-2671	ea
68-5174	USE 97-3862	ea
68-5176	bracket,hdlt,pre68 BSA LH,CHROME*	EA
68-5176/5177/CHR	brackets,hdlt,pre68 BSA,chrome	PR
68-5177	bracket,hdlt,pre68 BSA RH *	EA
68-5178	sleeve,forks,w/out hdlt.ears	EA
68-5180	USE 21-0785	ea
68-5185	USE 97-4005	ea
68-5194	forkleg,LH	EA
68-5195	forkleg,RH,threaded	EA
68-5197	USE 97-2635	ea
68-5198	USE 97-3893	ea
68-5515/5516	brakeshoe set,fullwidth7"	PR
68-5516	brakeshoe,trailing,fullwidth7"	EA
68-5524	brakeshoe,leading,fullwidth8"	EA
68-5524/5525	brakeshoe set,fullwidth8"	PR
68-5528	USE 551-10581 (set)	ea
68-5541/5543	brakeshoe set,1/2width 8"	EA
68-5541/5543/ER	brakeshoe set,1/2width,8",econo	PR
68-5543	brakeshoe,trailing,1/2width 8"	EA
68-5551	lockring,front wheel brg.	EA
68-5552	lockring,front wheel brg.	EA
68-5556	rim,WM2x19,BSA 1/2 widthF	EA
68-5556/A	rim,WM2x19 F,alloy w/shoulder	EA
68-5556/SS	rim,WM2x19,BSA 1/2 widthF,stainless	EA
68-5561	USE 68-5551	ea

68-5886	USE 37-2301	ea
68-5887	USE 37-2302	ea
68-6034	USE 42-6331	ea
68-6045	brakeplate,1963-65 A65 rear	EA
68-6066	USE 37-2309	ea
68-6081	USE 37-2305	ea
68-6086	USE 37-2291	ea
68-6088	sprocket,10hole A65,47T	EA
68-6088/46	sprocket,10hole A65,46T	EA
68-6088/54	sprocket,10hole A65,54T	EA
68-6088/ER	sprocket,10hole A65,47T,econo	EA
68-6090	USE 37-2318	ea
68-6091	USE 37-2319 *	ea
68-6092	USE 60-4260	ea
68-6095	USE 37-2319	ea
68-6100	USE 37-2309	ea
68-6103	USE 37-2318	ea
68-6110	spacer,rear axle	EA
68-6114	hub,rear BSA QD type	EA
68-6116	brakedrum,BSA QD type *	EA
68-6120	USE 37-4164	ea
68-6121	axle,dummy,BSA QD rear	EA
68-6130	brakeplate,alloy,unit twin,QD	EA
68-6131	washer,grease retain.shim	EA
68-6132	spacer,rear axle	EA
68-6132/SS	spacer,rear axle,stainless	EA
68-6134	USE 37-2334	ea
68-6135	USE 37-2317	ea
68-6142	USE 37-2304	ea
68-6524	USE 324-92	ea
68-6535	USE 68-6536 *	ea
68-6536	mudguard,F,pre71,unchromed,6 tab	EA
68-6536/CHR	mudguard,F,pre71,chrome,6 tab	EA
68-6539	mudguard,F,pre71,chrome,4 tab	EA
68-6540	bracket,fenderstay,USA65L style	EA
68-6542	USE 68-6548 or 68-6549	ea
68-6544	USE 68-6536	ea
68-6548	bracket,fenderstay,LH	EA
68-6549	bracket,fenderstay,RH	EA
68-6767	bracket,bridge,R.mudguard	EA
68-6768	USE 68-6770	ea
68-6770	plate,stiffener Rmudguard	EA
68-6773	bolt	EA
68-6788	USE 67-6885 *	ea
68-6798	bracket.Rmudguard support	EA
68-6802	bracket *	EA
68-6803	bracket,Rmudguard support	EA
68-6806	bracket,rear fenderstay	EA
68-6822	USE 68-6823	ea
68-6823	bracket,tailight,alloy	EA
68-6824	USE 82-6849	ea
68-6834	USE 83-1529	ea
68-6835	USE 82-6849	ea
68-6836	mudguard,R,pre71,short,unchromed	EA
68-6856	mudguard,R,pre71,unchromed	EA
68-6856/CHR	mudguard,R,pre71,chrome	EA
68-6906	USE 83-0250	ea
68-6919	bracket,pannier,LH	EA
68-6920	bracket,pannier,RH	EA
68-7013	lever,brakelight switch	EA
68-7020	lever,brake crossshaft	EA
68-7025	USE 526-687025	ea
68-7028	USE 526-687028	ea
68-7029	spring,brake linkage	EA
68-7042	rod,rear brake,early unit	EA
68-7050	pedal,brake,A50/65 pre71	EA
68-7052	arm,brake switch	EA
68-7055	bolt,pivot,brakepedal,BSA *	EA
68-7055/SS	bolt,pivot,brakepedal,stainless	EA
68-7061	USE 60-4252	ea
68-7062	rod,rearbrake,69 A65,etc.	EA

68-7702	chainguard,A50/A65,pre'65	EA
68-7710	chainguard top,A50/65,pre65	EA
68-7711	chainguard bot,A50/65,pre65	EA
68-7722	chainguard65-68,A50/65	EA
68-7722/CHR	chainguard65-68,A50/65,chrome	EA
68-7723	bolt,1/4x26	EA
68-8011	bolt,gas tank,special	EA
68-8012	spacer,tank mounting	EA
68-8013	USE 83-3321	ea
68-8014	nut,5/16x26,sleeve,tankMt	EA
68-8016	USE 83-3320	ea
68-8017	rubber,"U"shape,tank mt.	EA
68-8018	rubber,"U"shape,tank mt.	EA
68-8019	USE 83-3319	ea
68-8024	USE 621-121	ea
68-8035	USE 83-3318	ea
68-8038	beading,gastank,UK,front	EA
68-8039	beading,gastank,UK,rear	EA
68-8045	bolt,tank mt,centre	EA
68-8046	spacer tube,fuel tank mt.	EA
68-8049	USE 68-8054	ea
68-8050	USE 68-8176	ea
68-8054	rubber grommet,tank mt.	EA
68-8059	USE 68-0861	ea
68-8062	bracket,tank steady	EA
68-8067	USE 68-8176	ea
68-8073	USE 68-8122	ea
68-8080	bolt,tank mt,centre	EA
68-8083	cap,gas,flipup w/wing nut	EA
68-8087	USE 65-8228	ea
68-8088	USE 68-8152	ea
68-8090	screw,tankbadge,3BA	EA
68-8093	USE 68-8150	ea
68-8094	USE 68-8150	ea
68-8099	bracket,gastank,Spitfire	EA
68-8102	decal,tank,LH	EA
68-8103	decal,tank,RH	EA
68-8110	rubber,gastank,"U" type	EA
68-8111	decal,HORNET,1966	EA
68-8112	decal,SPITFIRE MK2SPECIAL	EA
68-8113	decal,LIGHTNING tank top	EA
68-8115	fueline assy,Spitfire Mk2	EA
68-8119	clip,carb,GP	EA
68-8122	fueline assy,A65L,pre68	EA
68-8138	USE 68-8176	ea
68-8145	tank,gas,A50/65 US,small	EA
68-8147	tank,gas,A65S,2gal,w/indent	EA
68-8150	tank,gas,A65S,2gal,smooth	EA
68-8152	rubber backing,tank badge	EA
68-8153	USE 68-8152	ea
68-8156	bracket,gastank steady	EA
68-8158	beading,gastank,short *	EA
68-8159	beading,gastank,long	EA
68-8162	decal,ROYAL STAR,crown	EA
68-8165	tank,gas,Spitfire.4gal.	EA
68-8166	badge,damper knob,BSA	EA
68-8169	USE 83-3068	ea
68-8170	USE 83-3069	ea
68-8173	USE 42-8037	ea
68-8174	spacer,tank mounting	EA
68-8175	USE 82-8409	ea
68-8176	bracket,gastank mt.bracing	EA
68-8179	decal,SPITFIRE MK3,1967	EA
68-8186	USE 82-9695/9696 (set)	ea
68-8187	USE 82-9695/9696 (set)	ea
68-8188	tank,gas,A50/65 US,small	EA
68-8189	tank,gas,A50/65 UK,large	EA
68-8190	USE 06-0681	ea
68-8191	USE 06-0882	ea
68-8315	rubber mt,oiltank,A50/65	EA
68-8317	spacer,oiltank mount,top	EA

68-8328	filter screen,oil tank	EA
68-8334	USE 82-5229	ea
68-8336	washer,fibre,tank screen	EA
68-8342	USE 70-4594	ea
68-8343	USE 70-6848	ea
68-8367	USE 82-6673	ea
68-8368	cap & dipstick,oiltank,chrome	EA
68-8371	USE 68-8378 *	ea
68-8378	tank,oil,A50/65 pre 1971	EA
68-8383	USE 70-4594	ea
68-8446	USE 68-8150	ea
68-8511	USE 526-M38/38 *	ea
68-8513	USE 526-M44/29X	ea
68-8514	USE 526-M42/38	ea
68-8518	USE 526-2/538/5 *	ea
68-8533	USE 526-2/538/5	ea
68-8540	USE 526-M43/27 *	ea
68-8546	USE 526-M43/27 *	ea
68-8551	USE 526-M38/38	ea
68-8552	USE 526 M38/38 *	ea
68-8558	USE 526-97	ea
68-8561	USE 524-244104	EA
68-8562	USE 526-315	ea
68-8570	clip,junct.box to frame	EA
68-8580	USE 526-315	ea
68-8593	USE 526-2/729	ea
68-8596	USE 526-2/535	ea
68-8600	USE 526-2/525/6	ea
68-8608	USE 526-2/729	ea
68-8611	USE 526-2/729	ea
68-8634	USE 523-18978	ea
68-8660	USE 526-2/525	ea
68-8663	USE 526-M38/29	ea
68-8671	USE 526-96	ea
68-8672	USE 526-91	ea
68-8678	USE 526-38/24D/6 *	ea
68-8679	USE 526-38/24D	ea
68-8684	USE 526-M42/38	ea
68-8690	USE 526-92	ea
68-8692	USE 526-306	ea
68-8696	USE 526-M43/29	ea
68-8699	USE 526-40/30D	ea
68-8702	USE 526-M42/38	ea
68-8706	USE 526-M42/31	ea
68-8708	USE 526-M42/31 *	ea
68-8743	USE 523-18084	ea
68-8745	USE 60-7026 & 14-1901	ea
68-8760	USE 526-92	ea
68-8770	USE 526-663/5	ea
68-8773	USE 526-2/729/6	ea
68-8776	USE 526-663	ea
68-9024	USE 511-301	ea
68-9045	grabrail,63/65 A65TR/LR	EA
68-9056	USE 511-301	ea
68-9060	bracket,horn,pre65 A50/65	EA
68-9103	bracket,horn,A50/65	EA
68-9104	USE 68-9428 *	ea
68-9105	USE 68-9428 *	ea
68-9115	oddie clip	EA
68-9121	USE 571-28/C	ea
68-9134	toolbag,zippered,A50/65	EA
68-9135	grabrail,1965 BSA A50/65	EA
68-9138	rubber mtg.grommet,instruments*	EA
68-9139	USE 68-9141	ea
68-9140	bracket,instr.mt,A50/65 w/hole	EA
68-9141	mounting cup,instr,pre67 A50/65	EA
68-9148	bracket,instrument mount,dual	EA
68-9151	bracket,speedo mounting,alloy	EA
68-9184	USE 68-9148	ea
68-9212	USE 68-9254	ea
68-9213	USE 68-9254	ea

68-9214	USE 68-9256	ea
68-9223	USE 60-0982	ea
68-9226	USE 60-0984	ea
68-9227	USE 60-0985	ea
68-9233	USE 68-9256	ea
68-9235	badge,BSA flash,LH	EA
68-9235/9236	badges,BSA flash	PR
68-9236	badge,BSA flash,RH	EA
68-9251	bracket,sidepanel mount,LH	EA
68-9254	sidepanel,singlecarb,LH,pre66	EA
68-9256	sidepanel,singlecarb,RH,pre66	EA
68-9262	sidepanel,twincarb,LH,pre66	EA
68-9264	sidepanel,twincarb,RH,pre66 *	EA
68-9277	USE 82-8291	ea
68-9281	USE 68-9497	ea
68-9287	USE 60-1006	ea
68-9290	clip,sidecover buffer	EA
68-9298	USE 68-9290	ea
68-9304	USE 391-54335169	ea
68-9307	USE 68-9496	ea
68-9309	USE 68-9494	ea
68-9310	USE 68-9494	ea
68-9311	USE 68-9495	ea
68-9312	USE 68-9495	ea
68-9325	USE 68-9327	ea
68-9327	grabrail,A50/65,1966-70	EA
68-9330	USE 511-364	ea
68-9331	USE 511-364	ea
68-9340	bracket,sidepanel mount F	EA
68-9344	USE 68-9494	ea
68-9345	USE 68-9494	ea
68-9347	USE 68-9494	ea
68-9348	USE 68-9495	ea
68-9351	USE 97-2034	ea
68-9401	USE 68-9428 *	ea
68-9412	USE 68-9496	ea
68-9413	USE 68-9497	ea
68-9415	USE 83-0281	ea
68-9418	USE 82-9174	ea
68-9427	bracket,speedo mount	EA
68-9428	heatsink,zener diode,finned style	EA
68-9429	clip,diode retaining	EA
68-9448	decals,LIGHTNING POWER	EA
68-9462	USE 221-64947081	ea
68-9463	USE 221-15	ea
68-9464	USE 221-09	ea
68-9465	USE 221-062551	ea
68-9466	USE 221-062551	ea
68-9468	decals,THUNDERBOLT POWER	EA
68-9469	decals,ROYAL STAR 500	EA
68-9471	USE 68-9478*	ea
68-9472	USE 68-9479*	ea
68-9478	sidepanel,2carb,66-70LH fibreglass	EA
68-9479	sidepanel,2carb,66-70RH fibreglass	EA
68-9480	sidepanel,1carb,LH,66-70, fibreglass	EA
68-9481	sidepanel,1carb,RH,66-70, fiberglass	EA
68-9494	sidepanel,LH1carb,recessed	EA
68-9495	sidepanel,RH1carb,recessed	EA
68-9496	sidepanel,LH twin,recessed	EA
68-9497	sidepanel,RH twin,recessed	EA
68-9498	USE 82-8291	ea
70-	TRIUMPH AND BSA PARTS	*
70-----	-----	--
70-0327	bolt,3/8x26,cyl.head	EA
70-0327/SS	bolt set,cyl.hd,stainless	ST
70-0329	USE 70-3436	ea
70-0370	cap,oiltank,threaded	EA
70-0375	shaft,idler gear,Twins	EA
70-0378	bush,timing cover,oilfeed	EA
70-0378/020	USE 70-3585	ea
70-0398	nut,crankshaft RH	EA

70-0400	bush,idler gear,twins	EA
70-0402	washer,fibre	EA
70-0403	spring,oilpumpcheckvalve	EA
70-0409	bolt,5/16x26,finned clip *	EA
70-0409/ER	bolt,5/16x26,finned clip,econo.repl*	EA
70-0410A	USE 70-8860	ea
70-0470	nut,5/16x26	EA
70-0470/A	nuts,5/16x26 light alloy	ST
70-0486	plate,sump,preunitTriumph	EA
70-0486/A	sump plate assy,finned,preunit	EA
70-0487	gasket,sump plate,preunit	EA
70-0489	circlip,gbx.brg,high gear*	EA
70-0495	block,oilpump drive	EA
70-0529	filterscreen,sump,preunit	EA
70-0534	trunnion,bat.box,plain	EA
70-0535	trunnion,bat.box,tapped	EA
70-0536	bolt,5/16x26,slotted,bat.box	EA
70-0672	stud,3/8x16x26,cyl.base	EA
70-0697	USE 70-8896	ea
70-0698	stud,5/16x18x26	EA
70-0732	USE 57-2166	ea
70-0984	bolt,banjo,pushrod tube	EA
70-1269	USE 71-0216	ea
70-1270	USE 70-4947	ea
70-1310	nut,5/16x26,small hex	EA
70-1330	washer,thrust,3/8" ID	EA
70-1335	washer,copper	EA
70-1396	stud,5/16x26	EA
70-1435	nut,3/8x26 acorn,r.shaft	EA
70-1457	rockerarm,LHinlet & RHexh	EA
70-1458	rockerarm,LHexh & RHinlet	EA
70-1463	nut,camshaft,inlet,early	EA
70-1471	USE 70-6159	ea
70-1472	USE 70-4564 & 70-4565 ?	ea
70-1473	USE 453-14	ea
70-1474	USE 453-14	ea
70-1477	tappet block,inlet & exh*	EA
70-1478	USE 71-7008	ea
70-1479	USE 71-0286	ea
70-1480	USE 452-420 (or 452-01)	ea
70-1483	USE 71-0070	ea
70-1484	bolt,3/8x26,cylinder hd	EA
70-1486	USE 70-4562	ea
70-1487/1488	USE 451-279	ea
70-1492	nut,5/8x19,LH thread,x cam,preunit	EA
70-1496	washer,rubber,pushrodTube	EA
70-1497	USE 70-3547	ea
70-1505	pushrod tube,p.unit iron hd.	EA
70-1509	clip,w/tabs	EA
70-1511	bush,small end,Tri.Twins	EA
70-1511/A	bush,small end,"PM"hi performance	EA
70-1512	shaft,rockers,26TPI *	EA
70-1513	adjuster,valve,26 TPI*	EA
70-1513/A	adj.set,valve,allen type	ST
70-1513/B	adj.set,valve,mushroom	ST
70-1516	USE 71-0287	ea
70-1523	washer,fibre	EA
70-1529	gask,oil junction,preunit	EA
70-1530	nut,castellated	EA
70-1532	dowel,hollow	EA
70-1534	USE 70-8751	ea
70-1535	dowel,hollow	EA
70-1536	stud,1/4x26	EA
70-1537	gasket,oilpump,preunit Tri.	EA
70-1539	stud,5/16x26	EA
70-1540	stud,1/4x26	EA
70-1543	collar,valve spring top	EA
70-1543/A	collars,valvespring,alloy	ST
70-1544	valvespring cup,pre 1966	EA
70-1545	bolt,1/4x26	EA
70-1553	stud,inlet manifold	EA

70-1555	bolt,5/16X22BSW	EA
70-1556	bolt,5/16X22BSW	EA
70-1558	key,camshaft	EA
70-1562	bolt,1/4x26, special, flywheel	EA
70-1564	cap, rockerbox, sump, etc, early	EA
70-1564/A	cap, rockerbox, finned	EA
70-1567	USE 711-Z695 (pr)	ea
70-1568	USE 711-Z695 (pr)	ea
70-1574	washer, spring, double coil	EA
70-1575	washer, thrust, large	EA
70-1577	washer, fibre, insp. cap	EA
70-1580	key, crank pinion	EA
70-1591	bearing, ball *	EA
70-1592	bearing, ball	EA
70-1595	patent plate, SPEED TWIN	EA
70-1596	bolt, cyl. hd, for motor mt*	EA
70-1596/SS	bolt set, cyl. hd, stainless	ST
70-1596A	bolt, cyl. hd. for motor mt	EA
70-1596A/SS	bolt set, cyl. hd, stainless	ST
70-1601	bolt, banjo, cyl. hd drain	EA
70-1604	USE 452-424 or 452-01	ea
70-1612	washer, 1/4", lock	EA
70-1650	gasket, rockerbox, iron hd.	EA
70-1670	washer, fibre	EA
70-1678	patent plate, TIGER 100	EA
70-1693	USE 70-2620	ea
70-1719A	USE 71-3749	ea
70-1762	bush, small end, Cub & 3TA	EA
70-1767	circlip, pistonpin, Cub&3TA	EA
70-1769	bush, crank, RH, std. Tri. 3T	EA
70-1769/010	bush, crank, RH-010, Tri. 3T	EA
70-1771	gear, crank pinion, T100etc	EA
70-1862	USE 71-1860	ea
70-1891	patent plate, 350 TWIN	EA
70-1955	USE 453-14	ea
70-1956	USE 453-14	ea
70-1992	USE 391-47502	ea
70-2022	stud, 5/16x18x26	EA
70-2113	bolt, 3/8x26	EA
70-2113/CHR	bolt, 3/8x26, chrome	EA
70-2113/SS	bolt, 3/8x26, stainless	EA
70-2226	gasket, dynamo	EA
70-2228	nut, sleeve, dynamo to crankcase	EA
70-2230	strap, dynamo mounting	EA
70-2248	gasket, cyl. hd, 5T&ironT100	EA
70-2249	gasket, cyl base, 500preunit	EA
70-2254	breather valve, rotary	EA
70-2256	spring, breather valve	EA
70-2260	USE 71-0288	ea
70-2269	clip, finned, xpipe, 1-1/2", bare*	EA
70-2271	clamp, exhaust, 1-5/8", bare	EA
70-2275	cover, eng. mt, frontPreunit	EA
70-2287	washer, 5/16, lock, shakeproof	EA
70-2288	washer, 3/8" lock	EA
70-2304	cap, pressure rel. valve	EA
70-2322	pin, piston, TRW *	EA
70-2323	circlip, pistonpin, TRW *	EA
70-2324	conrod w/bushings, TRW 500	EA
70-2325	bush, small end, SV500 TRW	EA
70-2326	bush, rod, TRW SV500, std.	EA
70-2326/010	bush, rod, -010, TRW SV500	EA
70-2331	bush, crank, RH, TRW 500, std	EA
70-2331/010	bush, crank, RH, TRW, -.010	EA
70-2331/020	bush, crank, RH, TRW, -.020	EA
70-2332	bush, camshaft RH, TRW	EA
70-2333	bush, camshaft LH, TRW	EA
70-2343	screen, sumpfilter, TRW	EA
70-2344	gasket, sump filter, TRW	EA
70-2351	USE 70-6559	ea
70-2354	oilpump assembly, TRW	EA
70-2360	plug, oilpump	EA

70-2387	gasket,cyl.head,SV500	EA
70-2412	nut,3/8x26,small hex*	EA
70-2412/SS	nuts,3/8x26,stainless,cyl.base	ST
70-2413	spring, valve,TRW	EA
70-2414	stud,3/16x26,dynamo mount	EA
70-2419	nut,9/16x20	EA
70-2425	washer,rubber,pushrod tube	EA
70-2441	washer,copper	EA
70-2451	gear,dynamo,Tri.twin,25T,alloy	EA
70-2490	bolt,5/16x26,conrod,T120*	EA
70-2534	washer,7/16",thrust,rockers	EA
70-2593	bolt,5/16x26	EA
70-2615	bolt,3/8x26	EA
70-2620	pushrod,In & Ex	EA
70-2620/A	pushrod set,"PM" Hi-Perf.	ST
70-2620/B	pushrod set,chromemoly	ST
70-2711	USE 70-2271	ea
70-2728	USE 60-4248	ea
70-2741	gear,mag,fibre,w/steel centre*	EA
70-2741/A	gear,mag,alloy,for repair*	EA
70-2767	bolt,banjo,hd.drain,3/8x20	EA
70-2788	spring,pressure rel.valve	EA
70-2789	spring,pressure rel.valve	EA
70-2790	cap,pressure rel.valve	EA
70-2791	shaft,indicator,oil press	EA
70-2792	nut,oilpressure indicator	EA
70-2793	rubber tube,oilpress.ind.	EA
70-2795	USE 71-3447	ea
70-2873	bolt,3/8x26,cylinder hd outer	EA
70-2873/SS	bolt kit,cyl.hd,stainless	ST
70-2874	bolt,3/8x26,cylinder hd.inner	EA
70-2876	patent plate,TROPHY	EA
70-2877	bearing,roller,crank	EA
70-2879	bearing,roller,crank LH*	EA
70-2888	stud,5/16"	EA
70-2888/SS	stud,5/16",stainless	EA
70-2891	USE 441-11564	ea
70-2899	USE 452-420 or 452-01	ea
70-2900	USE 452-424 or 452-01	ea
70-2903	USE 453-23	ea
70-2904	USE 453-24	ea
70-2905	USE 70-3614	ea
70-2909	patent plate,650 TWIN*	EA
70-2910	patent plate,TIGER 110	EA
70-2921	conrod,500/650 Tri,early	EA
70-2922	nut,5/16x26 lock,conrods	EA
70-2926	oilseal,crank,TRW LH	EA
70-2961	USE 70-9510	ea
70-2962	stud,5/16BSWXCEI	EA
70-2967	gasket,intake man.To hd	EA
70-2968	USE 06-3458	ea
70-2973	stud,1/4x20x26	EA
70-2980	stud,1/4"BSWXCEI*	EA
70-2982	bolt,1/4x26,rockerbox	EA
70-2982/SS	bolt set,r.box,stainless	ST
70-2999	bush,idler gear,TRW	EA
70-3001/3002	USE 451-510	ea
70-3003	gasket,cyl.hd,alloy T100	EA
70-3055	stud,3/8x26,cylinder base	EA
70-3059	USE 71-7008	ea
70-3059R	tappet,"R" type	EA
70-3059R/U	tappet,"R",reground,exch	EA
70-3072	oilpump,preunit Triumph	EA
70-3072/A	oilpump,preunit,MORGO plunger	EA
70-3072/B	oilpump,preunit,MORGO rotary*	EA
70-3082	USE 70-7574	ea
70-3108	sprocket,SPECIFY SIZE	ea
70-3108/17	sprocket,eng,preunit,17T	EA
70-3108/18	sprocket,eng,preunit,18T	EA
70-3108/19	sprocket,eng,preunit,19T	EA
70-3108/21	sprocket,eng,preunit,21T	EA

70-3108/22	sprocket,eng,preunit,22T	EA
70-3108/23	sprocket,eng,preunit,23T	EA
70-3108/24	sprocket,eng,preunit,24T	EA
70-3108/25	sprocket,eng,preunit,25T	EA
70-3110	cover,timing,preunit w/alt.	EA
70-3114	stud,7/16x26,crankshaft	EA
70-3115	key,rotor	EA
70-3116	washer,3/4"	EA
70-3119	washer,tab,engineSprocket	EA
70-3120	nut,7/16x26,crankshaft	EA
70-3131	USE 70-3975	ea
70-3134	USE 71-0040	ea
70-3136	USE 60-3548	ea
70-3146	USE 453-48	ea
70-3147	USE 453-49	ea
70-3152	bearing,ball	EA
70-3184	key,camshaft	EA
70-3197	bolt,2BA	EA
70-3204	screw,1/4x26	EA
70-3208	USE 452-461	ea
70-3209	circlip,valve guide *	EA
70-3220	screw,2BA	EA
70-3221	screw,2BA	EA
70-3222	USE 70-7651	ea
70-3223	adjuster,valve,350/500Cub	EA
70-3223/A	adj.set,valve,allen type	ST
70-3223/B	adj.set,valve,mushroom	ST
70-3223A	USE 70-3223	ea
70-3224	washer,spring,rockerarm	EA
70-3231	screw,3/16x32,phillips	EA
70-3244	oiline assy,rockers,Cub	EA
70-3249	USE 06-7522	ea
70-3253	oring,rocker shaft,small*	EA
70-3259	USE 70-4932	ea
70-3269	USE 742-138/A	ea
70-3275	camshaft,preunit int.&x	EA
70-3285	tappet,Cub	EA
70-3290	nut,1/4x26,nyloc	EA
70-3300	washer,clamping,crank,RH	EA
70-3302	washer,flat	EA
70-3309	USE 60-3530	ea
70-3310	USE 453-137	ea
70-3325	USE 70-4931	ea
70-3332	cylinder barrel,preunit 650	EA
70-3334	USE 70-5660	ea
70-3355	junction block,oil,P.unit	EA
70-3379	oilseal	EA
70-3382	cover,pri.outer,Cub*	EA
70-3385/A	cylinder barrel,alloy,round,Cub	EA
70-3391	washer,rubber,pushrodseal	EA
70-3411	gear,magneto,steel	EA
70-3411/A	gear,magneto,aluminium	EA
70-3421	bolt,5/16x26,hardened	EA
70-3434	spacer,top motor mount	EA
70-3435	nut,crank LH	EA
70-3436	screw,1/4x20	EA
70-3437	screw,1/4x20	EA
70-3439	USE 21-1916	ea
70-3446	washer	EA
70-3455	plug,crank tube,pre1959boltup crank	EA
70-3456	sludge trap tube,pre1959 500/650	EA
70-3460	washer,sealing,rubber	EA
70-3469	USE 70-5874	ea
70-3475	grommet	EA
70-3490	tappet,TRW	EA
70-3491	spring,tappet adj,TRW	EA
70-3492	cap,tappet adj spring,TRW	EA
70-3523	stud,3/8x16x26,cylinder	EA
70-3524	cylinder block,TRW	EA
70-3540	washer,rubber,pushrodseal	EA
70-3547	washer,rubber,pushrodTube	EA

70-3552	gask,r.box,alloyP.unit650	EA
70-3552/A	gask,r.box,alloyP.unit650,copper	EA
70-3583	USE 70-9516	ea
70-3585	bush,timing cover,-.020	EA
70-3586	USE 421-56 (set)	ea
70-3606T	USE 70-9525	ea
70-3610	USE 441-15897	ea
70-3614	gask,cyl.hd.,preunit 650	EA
70-3614/A	gask,cyl.hd.,preunit 650,.080" thick	EA
70-3646	pushrod tube,pre66alloyHd	EA
70-3646/A	pushrod tubes,alloy,pre66alloyHd	PR
70-3648	USE 453-702383	ea
70-3651	USE 711-Z623/D (set)	ea
70-3652	USE 711-Z623/D (set)	ea
70-3655	bush,RH crank,Cub,std,2 pc.	EA
70-3655/010	bush,RH crank,Cub,010,2 pc	EA
70-3655/015	bush,RH crank,Cub,015,2 pc	EA
70-3655/020	bush,RH crank,Cub,020,2 pc	EA
70-3655/025	bush,RH crank,Cub,025,2 pc	EA
70-3664	cover,crankcase inner,early Cub	EA
70-3665	USE 14-0242 & 14-1203	ea
70-3668	screw,1/4x26	EA
70-3685	nut,tachdrive,preunit	EA
70-3695	stud,5/16x26	EA
70-3705	bolt,5/16x26,conrod *	EA
70-3706	USE 421-68 (set)	ea
70-3711	USE 70-9492	ea
70-3716	dowel,hollow	EA
70-3717	stud,5/16x22x26	EA
70-3718	stud,1/4x26	EA
70-3719	oiline,scavenge pickup	EA
70-3722	screen,sump filter,500	EA
70-3723	washer,sealing,scavenge pipe	EA
70-3724	spring,sump screen,500	EA
70-3727	USE 70-9502	ea
70-3728	screw,1/4CEI,countersunk	EA
70-3730	USE 71-1461	ea
70-3732	nut,1/4x26,oilpump mtg.	EA
70-3734	USE 70-4141	ea
70-3735	nut,rotor	EA
70-3736	tappet block,350/500pre64	EA
70-3738	USE 453-135	ea
70-3739	USE 453-136	ea
70-3740	valvespring cup,1959-66	EA
70-3742	valvespring collar350/500	EA
70-3742/A	collars,valvespring,alloy	ST
70-3743	USE 70-9511	ea
70-3744	rockerbox,exh,unit350/500	EA
70-3745	rockerbox,int,unit350/500	EA
70-3748	shaft,rockers,350/500unit,26TPI	EA
70-3749	rockerarm,350/500,Lin&Rex	EA
70-3750	rockerarm,350/500,Rin&Lex	EA
70-3751	washer,fibre,rocker cap	EA
70-3752	USE 71-2744	ea
70-3753	tappet,350/500,non "R"	EA
70-3753/U	tappet,reground,exch	EA
70-3755	pushrod tube,3TA/5TAp64	EA
70-3758	washer,rubber,pushrodseal	EA
70-3759	pushrod,in & exh,350 unit	EA
70-3763	USE 71-3754	ea
70-3767	USE 742-178 (assy)	ea
70-3768	washer,"D" type	EA
70-3769	USE 70-4674	ea
70-3789	cover plate,gbx.sprocket	EA
70-3790	USE 70-4322	ea
70-3793	bolt,3/8x26,cyl.head	EA
70-3794	bolt,3/8x26,cylinder head	EA
70-3795	bolt,3/8x26,for motor mt.	EA
70-3796	stud,intake manifold	EA
70-3797	stud,intake manifold	EA
70-3798	gasket,cylinder base,500	EA

70-3798/A	gask,cyl base,500,copper,016"	EA
70-3798/B	gask,cyl base,500,copper,020"	EA
70-3800	screw,1/4x26	EA
70-3801	screw,1/4x26	EA
70-3802	screw,1/4x26	EA
70-3804	stud,5/16x26 TPI	EA
70-3805	oiline assembly,rockers,350/500	EA
70-3809	bolt,rockerfeed,350/500Tr	EA
70-3810	spacer,stator	EA
70-3812	stud,3/8x26	EA
70-3819	stud,3/8x20x26	EA
70-3820	stud,3/8x20x26	EA
70-3821	screw,2BA,countersunk	EA
70-3822	breather disc,stationary	EA
70-3823	bush,cam	EA
70-3824	bush,camshaft	EA
70-3827	USE 452-420/PB or 452-01	ea
70-3828	USE 452-424/PB or 452-01	ea
70-3832	USE 71-1419	ea
70-3833	oilseal,clutch cover	EA
70-3835	bearing,ball,crankshaft *	EA
70-3838	camshaft,inlet,for distr.	EA
70-3851	key,crankshaft	EA
70-3852	USE 70-3975	ea
70-3857	washer,flat	EA
70-3858	stud,1/4x26	EA
70-3861	bracket,muffler,preunit	EA
70-3863	boot,rubber,distributor sheath	EA
70-3872	bolt,1/4x26	EA
70-3876	oilseal,crank,pre 70,LH*	EA
70-3878	USE 70-9421	ea
70-3880	stud,manifold	EA
70-3887	washer,conical,oilpump mt	EA
70-3902	pin,dowel	EA
70-3903	sludge trap tube	EA
70-3905	plug,crank tube,7/8X20CEI,thick	EA
70-3905/A	plug,crank tube,allen,thick	EA
70-3905/B	plug,crank tube,allen,thicker	EA
70-3907	bolt,3/8x26,flywheel to crank	EA
70-3927	USE 453-138	ea
70-3932	oilseal,gbx,Cub	EA
70-3935	USE 711-2605 (pr)	ea
70-3936	USE 711-2605 (pr)	ea
70-3963	USE 453-191	ea
70-3965	USE 451-466 (set)	ea
70-3966	USE 451-466 (set)	ea
70-3974	USE 71-0082	ea
70-3975	washer,tab,rotor nut	EA
70-3976	spacer,crankshaft,LH,preunit	EA
70-3977	nut,rotor,CEI	EA
70-3978	USE 70-4531	ea
70-3979	bolt,5/16x22,special	EA
70-3999	sludge trap tube,350/500	EA
70-4000	USE 70-9719	ea
70-4001	USE 70-9915	ea
70-4003	bush,smallEnd,Tri 250&500	EA
70-4006	spacer,engine sprocket	EA
70-4008	pushrod,Tri.unit 500	EA
70-4008/A	pushrod set,HiPerf,TRI500 *	ST
70-4010/4011	USE 451-615	ea
70-4011/5946	USE 451-615	ea
70-4012	USE 453-187	ea
70-4013	USE 453-188	ea
70-4014	USE 70-4689	ea
70-4015	gasket,cyl.hd,Tri.uc 500,thick	EA
70-4016	patent plate,alloy	EA
70-4016/B	patent plate,brass	EA
70-4016/C	patent plate,BONNEVILLE	EA
70-4016/D	patent plate,TIGER 90	EA
70-4016/E	patent plate,THUNDERBIRD	EA
70-4016/F	patent plate,TWENTYONE	EA

70-4016/G	patent plate,GP	EA
70-4022	camshaft,inlet,for distr.	EA
70-4023	camshaft,exhaust,for dist	EA
70-4038	camshaft,intake,for dist	EA
70-4039	camshaft,exhaust,for dist	EA
70-4040	tappet,T100R,"R"type	EA
70-4040/U	tappet,reground,exch	EA
70-4059	screw,1/4x20,philips	EA
70-4083	oilfeed junct.block,unit 350/500,bathtub	EA
70-4092	cover,timing,Cub,early	EA
70-4096	screw,1/4x26	EA
70-4097	screw,2BA	EA
70-4098	bolt,5/16x22	EA
70-4098/SS	bolt,5/16x22,stainless	EA
70-4100	USE 70-4871	ea
70-4103	USE 70-5897	ea
70-4137	USE 70-4322	ea
70-4139	plate,locking,crank bush	EA
70-4140	screw,crankcase bush lock	EA
70-4141	sprocket,eng,unit 500,26T*	EA
70-4143	USE 70-4772	ea
70-4144	grommet,alternator wire	EA
70-4147	abutment,pri.chain adj.F	EA
70-4148	trunnion,pri.chain adj,R	EA
70-4149	USE 70-6061	ea
70-4152	rod,primary chain adjust.	EA
70-4153	USE 70-9703	ea
70-4154	plug,primary drain&adjust	EA
70-4156	USE 71-1456	ea
70-4157	USE 711-Z605 (pr)	ea
70-4158	USE 711-Z605 (pr)	ea
70-4159	oiline assembly,rockers	EA
70-4165	bolt,5/16x26	EA
70-4167	cover,timing,w/tachdr.mount	EA
70-4182	cover,timing,pre63 350/500,w/tachdr.	EA
70-4183/4184	extensions,xpipe,T120C	PR
70-4191	USE 71-3447	ea
70-4204	heatshield,TR6C,pre69*	EA
70-4207	clamp,heatshield,chrome	EA
70-4221	USE 451-646 (set) *	EA
70-4221/4222	USE 451-574	ea
70-4221/7400	USE 451-646	ea
70-4322	bush,crank,RH,std.Tri.500,bronze	EA
70-4322/010	bush,crank,RH,-.010Tri500,bronze	EA
70-4322/010/A	bush,crank,RH,-.010Tri500,2pc.	EA
70-4322/020	bush,crank,RH,-.020Tri500,bronze	EA
70-4322/020/A	bush,crank,RH,-.020Tri500,2pc.	EA
70-4322/030	bush,crank,RH,-.030Tri500,bronze	EA
70-4322/030/A	bush,crank,RH,-.030Tri500,2pc.	EA
70-4322/040	bush,crank,RH,-.040Tri500,bronze	EA
70-4322/040/A	bush,crank,RH,-.040Tri500,2pc.	EA
70-4322/050	bush,crank,RH,-.050Tri500	EA
70-4322/060	bush,crank,RH,-.060Tri500	EA
70-4322/070	bush,crank,RH,-.070Tri500	EA
70-4322/080	bush,crank,RH,-.080Tri500	EA
70-4322/A	bush,crank,RH,std.Tri.500,2pc.	EA
70-4449	cover,gbx.inner,Cub	EA
70-4456	bolt,3/8x26,cylinder hd.	EA
70-4458	spacer	EA
70-4501	clip,finned,xpipe,1-3/4",CEI	EA
70-4504	USE 06-3458 *	ea
70-4531	adaptor plate,stator mt.	EA
70-4535	stud,5/16x22x26	EA
70-4536	stud,CEI/BSW,stator,long	EA
70-4537	stud,CEI/BSW,stator,short	EA
70-4539	bolt,1/4x22,oilway plug	EA
70-4540	bolt,5/16x22CEI	EA
70-4541	bolt,5/16x22	EA
70-4542	stud,3/8x20x26	EA
70-4546	USE 70-6304	ea
70-4547	gasket,cyl head,9 bolt650	EA

70-4547/A	gasket,cyl hd,9 bolt650,080"thick	EA
70-4549	USE 70-9348	ea
70-4550	rockerbox,inlet,1963-70	EA
70-4550/4551	rockerbox set,pre71 unit650	PR
70-4551	rockerbox,exhaust,1963-70	EA
70-4552	USE 71-2354	ea
70-4562	USE 71-3666*	ea
70-4563	nut,LH thread,exhaust cam	EA
70-4564	gear,crankshaft pinion,std.duty	EA
70-4565	nut,crankshaft,RH	EA
70-4567	USE 71-7318	ea
70-4568	oilseal,timing cover,etc,replacement	EA
70-4568/A	oilseal,timing cover,UK made	EA
70-4569	circlip,oilseal retaining	EA
70-4571	USE 70-8737	ea
70-4572	USE 70-5450	ea
70-4573	spacer,engine sprocket	EA
70-4576	adaptor,airfilter,376&600	EA
70-4577	cover plate,gbx.sprocket	EA
70-4578	oilseal,clutch	EA
70-4587	plug,blanking,distr.hole	EA
70-4590	USE 70-6930	ea
70-4594	hose,5/16x13",oil*	EA
70-4603	USE 453-245	ea
70-4608	nut,intake manifold,CEI	EA
70-4609	clip,rocker cap retaining	EA
70-4610	USE 71-2744	ea
70-4630	cover,timing,350/500,63-68	EA
70-4637	cover,timing,late Cub*	EA
70-4638	screw,2BA	EA
70-4640	USE 453-232	ea
70-4671	clip,rocker cap retaining	EA
70-4674	gasket,cyl.hd,unit 350	EA
70-4675	gasket,cyl.hd,Tri.uc 500,thin	EA
70-4676	tappet block,undrilled	EA
70-4678	cam,unit350/500in	EA
70-4689	manifold,intake,sing.carb,early	EA
70-4699	USE 70-5667	ea
70-4700	tachdrive thimble,PressIn	EA
70-4704	USE 71-1078	ea
70-4705	clip,oilhose,pri.drive	EA
70-4706	plug,blanking,crankcase	EA
70-4707	grommet,pointswire	EA
70-4711	bracket,footrest mt.plate	EA
70-4716	USE 721-T63 (set)	ea
70-4718	USE 721-T63 (set)	ea
70-4746	washer,cup,pushrod tube	EA
70-4747	pillar bolt,points plate*	EA
70-4751	pushrod tube,64-68 Tri500	EA
70-4751/A	pushrod tubes,64-68 Tri500,billet alloy	PR
70-4752	washer,rubber,pushrod tube	EA
70-4771	bolt,cyl. head,centre	EA
70-4771/SS	headbolt,stainless,w/wash	EA
70-4772	nut,7/16x18,sleeve	EA
70-4778	bracket,head steady*	EA
70-4791	connector balance pipe	EA
70-4792	hose,balance*	EA
70-4803	washer,rubber,shift ind,etc.	EA
70-4806	screw	EA
70-4812	USE 70-4576	ea
70-4819	USE 71-0040	ea
70-4849	pin,dowel,auto advance	EA
70-4855	cam,E3325type,unit x ,650	EA
70-4856	stud,5/16x26	EA
70-4871	gasket,primary,Cub	EA
70-4912	spacer,rotor	EA
70-4918	USE 06-3458	ea
70-4919	USE 71-3573	ea
70-4922	plug,pri.drain,extended,7/16X18BSF	EA
70-4931	cam,E3325 type.preunit int&x.	EA
70-4932	clip,finned,xpipe,1-5/16",Cub*	EA

70-4947	clip,finned,Xpipe,1-5/8"bare*	EA
70-4947/A	clip,finned,xpipe,1-5/8"complete	EA
70-4947/SS	clips,finned,xpipe,1-5/8"compl,stainless	PR
70-4949	USE 711-Z664/A	ea
70-4951	bracket,muffler,POIF,650	EA
70-5047	USE 70-9989	ea
70-5049	USE 71-1462	ea
70-5072	spacer,motor mount	EA
70-5085	slipper,primary chain adj	EA
70-5087	pri.chain adjust.trunnion	EA
70-5088	pri.chain adjust.abutment	EA
70-5153	bolt,1/2x16,tachdr,w/bush	EA
70-5155	bush,flanged,tachdrive bolt	EA
70-5156	USE 70-5153	ea
70-5157	gear,tach driving	EA
70-5163	USE 71-1064 *	ea
70-5194	adaptor,airfilter,375&289	EA
70-5232	screw,crankcase spigot	EA
70-5262	airfilter assy,T120 W.Coast,1965-67*	EA
70-5267	USE 70-9138 *	ea
70-5268	hose,airfilter,T120 W.Coast,1965-67	EA
70-5312	filter,crankcase sump,CEI	EA
70-5315	washer,sealing,copper*	EA
70-5316	USE 70-2254	ea
70-5324	nut,5/16x26,lock,small OD	EA
70-5347	sleeve,headbolt hole	EA
70-5348	USE 71-2356	ea
70-5349	USE 70-5351	ea
70-5350	USE 70-5352	ea
70-5351	manifold,int,LH T120,CEI	EA
70-5352	manifold,int,RH T120,CEI	EA
70-5370	fitting,"T",breather hose,curved	EA
70-5375	USE 71-2349	ea
70-5376	USE 624-63 *	ea
70-5434	USE 70-7203	ea
70-5446	USE 70-5450	ea
70-5449	USE 71-1078	ea
70-5450	sprocket,eng,unit 650,early,29T*	EA
70-5451	bolt,1/4x26	EA
70-5473	USE 70-6848	ea
70-5512	USE 71-7555 *	ea
70-5578	gear,tachdrive gbx,driven,early*	EA
70-5616	plug,crankcase	EA
70-5660	gasket,manifold to head,TR6,etc.	EA
70-5667	tachdrive adaptor assy,direct*	EA
70-5676	bracket,muffler stay,T120	EA
70-5727	USE 71-2356	ea
70-5755	tachdrive gbx,63-68 350/500	EA
70-5756	tachdrive gbx,63-68 650*	EA
70-5757	tachdrive body	EA
70-5758	tachdrive body	EA
70-5759	plug,tachdrive housing	EA
70-5802	crankpin,Cub,late	EA
70-5861	tappet block,exhaust	EA
70-5866	USE 711-Z623	ea
70-5872	nut,sleeve,alt.wires,1/2x16BSF	EA
70-5874	clamp,exh,1-1/2" bare	EA
70-5881	bolt,tachdrive unit	EA
70-5896	USE 71-3447	ea
70-5897	nut,cylinder head,Cub	EA
70-5914	USE 70-9516	ea
70-5946	spring,valve,inner	EA
70-5957	USE 721-T68 (set)	ea
70-5958	USE 721-T68 (set)	ea
70-5959	USE 724-02/B	ea
70-5963	stud,5/16x26	EA
70-5964	bracket,xpipe,T120TT,LH*	EA
70-5964/5965	brackets,xpipe,T120TT	PR
70-5965	bracket,xpipe,T120TT,RH*	EA
70-5966	clamp,xpipe,T120TT	EA
70-5976	USE 70-5088	ea

70-5977	pri.chain adjust.trunnion	EA
70-5998	USE 421-91484 (set)	ea
70-6000	pushrod tube,T120,1966-68	EA
70-6000/A	pushrod tubes,T120,66-68,billet alloy	PR
70-6018	bushing,rocker spindle	EA
70-6023	USE 421-91495 (set)	ea
70-6025	circlip,bearing retainer	EA
70-6026	circlip	EA
70-6029	gear,idler pinion,3cyl,early	EA
70-6039	gear,pump,scavenge driven	EA
70-6052	bracket,exh.pipes,chrome	EA
70-6061	slipper,primary chain adj *	EA
70-6062	spring,pressure rel.valve*	EA
70-6068	USE 421-68 (set) *	ea
70-6088	washer,thrust,idler gear	EA
70-6094/A	cylinder barrel,alloy,sq,Cub	EA
70-6122	tachdrive cable adaptor	EA
70-6124	bush,tachdrive	EA
70-6130	spring,oilfilter,3cyl.	EA
70-6131	washer,fibre	EA
70-6159	gear,idler pinion,650/750	EA
70-6160	gear,idler pinion,unit500	EA
70-6173	spacer,crankshaft,3cyl.	EA
70-6179	screw,1/4x26 CEI,chrome *	EA
70-6186	USE 70-7571 & 14-1201	ea
70-6283	slipper,pri.chain,T100etc	EA
70-6299	oring	EA
70-6300	oring,tachdrive body plug	EA
70-6301	USE 452-461/PB	ea
70-6304	cylinder barrel,unit 650	EA
70-6309	gasket,cyl base,650&750	EA
70-6309/A	gask,cyl base,6/750,copper,016"	EA
70-6309/B	gask,cyl base,6/750,copper,020"	EA
70-6309/C	spacer plt,cyl.to cases,6/750,032"	EA
70-6328	bolt,flywheel*	EA
70-6329	USE 70-8895	ea
70-6347	plug,pri.drain & adj,7/16x18BSF*	EA
70-6349	oiline assy,rockers*	EA
70-6349/ER	oiline assy,rockers,economy*	EA
70-6351	USE 70-7576	ea
70-6353	oiline*	EA
70-6356	hose,vent	EA
70-6387	oilseal,timing cov,.020undersize	EA
70-6388	USE 391-45276/A	ea
70-6389	USE 391-54419974	ea
70-6420	USE 452-540/PB	ea
70-6422	USE 453-270	ea
70-6423	USE 453-271	ea
70-6425	USE 70-9782	ea
70-6426	USE 70-9781	ea
70-6432	cover,timing,T150 & T160	EA
70-6439	valvespring collar,bot650	EA
70-6454	spindle,oilpump driven gear	EA
70-6463	USE 70-9558	ea
70-6465	USE 70-9780	ea
70-6466	USE 70-9779	ea
70-6486	oilpump,Cub,66-67	EA
70-6488	bush,conrod big end,Cub	EA
70-6490	USE 70-8801	ea
70-6496	gasket,cylinder base,3cyl	EA
70-6496/A	gasket,cyl.base,3cyl,copper	EA
70-6501	screen,sump filter,3cyl.	EA
70-6502	plate,oilpump base,3cyl.	EA
70-6503	USE 71-1442	ea
70-6506	pushrod,valve,pre71 3cyl	EA
70-6508	tappet block,lhole,3cyl.	EA
70-6509	tappet block,2hole,3cyl.	EA
70-6516	USE 71-1444	ea
70-6519	cover,points,3 cylinder	EA
70-6519/A	cover,points,finned,3cyl.	EA
70-6521	USE 70-4747	ea

70-6522	stud, stator, 3cyl.	EA
70-6523	nut, 3/4X20, LH thread, cam	EA
70-6524	gear, crankpinion, 3cyl.	EA
70-6529	USE 71-3935	ea
70-6559	washer, pillar bolt	EA
70-6560	oring	EA
70-6561	USE 71-4245	EA
70-6562	USE 71-4246	EA
70-6563	cover, rockerbox, 3 cyl.in.	EA
70-6563/6564	covers, rocker insp, triples, billet alloy	PR
70-6563/6564/A	covers, rocker insp., Hyde	PR
70-6564	cover, rockers, 3 cyl.x, heavyduty	EA
70-6565	USE 71-1445	ea
70-6567	spring, oilcontrol valve	EA
70-6570	oring, oilpump, triple	EA
70-6571	element, oilfilter, 3 cyl.	EA
70-6571/ER	element, oilfilter, econo.	EA
70-6572	USE 71-1441	ea
70-6573	stub, oilreturn pipe, 3cyl.	EA
70-6574	stub, oilfeed pipe, A75/T150	EA
70-6576	bolt, 5/16x24, conrod, T120*	EA
70-6577	screw, oilway	EA
70-6580	plate, sump, 3cyl.	EA
70-6580/A	plate, sump, 3cyl, w/drain, billet*	EA
70-6582	USE 71-1270 & 71-1070	ea
70-6584	plug, crankcase, 3cylinder	EA
70-6595	valve, pressure rel, 3cyl, med.coarse *	EA
70-6596	cap, pressure release valve	EA
70-6611	stud, stator, 5/16x18, T100R	EA
70-6681	oilpump plunger, .485"	EA
70-6743	clip, finned, Xpipe, 1-5/8", 3cyl, bare	EA
70-6743/A	clip, finned, Xpipe, 1-5/8", compl.	EA
70-6743/SS	clips, finned, Xpipe, 1-5/8" compl, stainless	ST
70-6744	bolt, 5/16 UNF, finned clip	EA
70-6772	gasket, manifold to head	EA
70-6836	pin, piston, 3 cylinder	EA
70-6840	USE 06-7834	ea
70-6848	clamp, oilhose	EA
70-6849	clamp, oilhose	EA
70-6853	USE 453-265	ea
70-6854	USE 453-266	ea
70-6855	valvespring cup, 350/500	EA
70-6856	USE 70-9915	ea
70-6857	bracket, exh.pipe to eng, TR6/120 type	EA
70-6857/A	bracket, exh.pipe to eng, TR7/140	EA
70-6857/ER	bracket, exh.pipe to eng, repl.	EA
70-6857/SS	bracket, exh.pipe to eng, stainless	EA
70-6861	pin, piston, short (2.15")	EA
70-6863	pin, piston, long (2.4")	EA
70-6866	USE 441-18786	ea
70-6867	USE 441-18514	ea
70-6868	USE 441-17844 (pair)	ea
70-6869	circlip, piston pin	EA
70-6869/A	circlip, piston pin, w/tongue	EA
70-6884	USE 441-18786	ea
70-6885	bush, inter.oilpump gear, 3 cyl.	EA
70-6889	gear, oilpump, w/earlyShaft	EA
70-6890	sprocket, eng, 23T, A75/T150*	EA
70-6895	USE 441-17844 (pair)	ea
70-6897	USE 441-15123	ea
70-6899	USE 441-16986 (pr.)	ea
70-6901	screw, 2BA	EA
70-6906	USE 441-15123	ea
70-6916	connector, balance pipe	EA
70-6923	USE 70-3798	ea
70-6928	USE 70-9421	ea
70-6930	oilfeed junction block, unit 650	EA
70-6955	pushrod tube, triples	EA
70-6961	USE 70-7351	ea
70-6978	bracket, x, TR6C	EA
70-6981	bracket, x, T100C	EA

70-7031	USE 71-2354	ea
70-7037	plate,inner pri cover	EA
70-7050	tachdrive thimble,ScrewIn	EA
70-7072	adaptor,breather hose	EA
70-7119	spacer,motor mount	EA
70-7136	manifold,intake,LH T100R	EA
70-7137	manifold,intake,RH T100R	EA
70-7203	oilfeed junction block,unit 350/500	EA
70-7246	gear,oilpump intermediate,w/bush	EA
70-7246/A	gear,pump inter,3cyl,perf,w/bush	EA
70-7248	gear,crank,LH,3cylinder	EA
70-7248/A	gear,crank,LH,3cyl,performance	EA
70-7249	gear,oilpump,3cyl,early	EA
70-7249/A	gear,oilpump,3cyl,early,performance	EA
70-7250	screw,oilpump gear	EA
70-7299	clamp,1-1/2",hipipe,top	EA
70-7310	USE 71-1283	ea
70-7327	USE 71-3941 or 71-4250	ea
70-7331	USE 71-2600	ea
70-7351	washer,sealing,bonded*	EA
70-7354	screw,2BA	EA
70-7359	USE 70-9249	ea
70-7400	USE 451-646 (set) *	ea
70-7431	USE 70-6299	ea
70-7471	nut,1/4x26 CEI,lock	EA
70-7505	USE 70-9843	ea
70-7512	clamp,exh,1-3/8",bare	EA
70-7563	USE 70-8782	ea
70-7565	oilseal,clutch	EA
70-7571	protector,crankcase,500cc	EA
70-7573	rubber plug,blanking	EA
70-7574	oiline assembly,rockers	EA
70-7574/A	oiline manifold,finned	EA
70-7576	oiline assembly,rockers,350/500	EA
70-7578	manifold,int,69on T100S&C	EA
70-7590	pressure rel.valve body,bare	EA
70-7591	USE 70-6062	EA
70-7603	USE 441-15123 (pair)	ea
70-7632	USE 633-02	ea
70-7633	USE 71-1303 *	ea
70-7637	USE 721-T72 (set)	ea
70-7638	USE 721-T72 (set)	ea
70-7641	bracket,Xpipe,T100,LH*	EA
70-7641/7642	brackets,Xpipe,T100	PR
70-7642	bracket,Xpipe,T100,RH*	EA
70-7645	USE 21-2083 *	ea
70-7650	bearing,needle	EA
70-7651	ball,rocker arm	EA
70-7680	pillar bolt,points plate	EA
70-7727	gasket,cylinder base,B44	EA
70-7728	gasket,cyl.base,250single,early	EA
70-7738	cover,timing,A75	EA
70-7739	USE 71-2513	ea
70-7777	USE 453-256	ea
70-7778	stud,1/4x26&5/16x22,stator	EA
70-7790	rocker,in,Tri/BSA 250,68on	EA
70-7791	rocker,x,Tri/BSA 250,68on	EA
70-7793	bolt,7/16x18,pri.chainAdj	EA
70-7819	USE 06-3458	ea
70-7820	USE 06-3458	ea
70-7821	USE 06-3458	ea
70-7823	gasket,cyl.base,A50/65,early	EA
70-7829	USE 70-8232	ea
70-7831	bolt,1/4x26,auto advance	EA
70-7837	USE 70-8737	ea
70-7850	bearing,needle,B50 conrod	EA
70-7853	USE 71-1437	ea
70-7854	USE 71-1432	ea
70-7856	USE 71-1418	ea
70-7857	USE 71-1427	ea
70-7858	USE 71-1426	ea

70-7869	crankcases,A75,1969	ST
70-7878	clip,alternator wire	EA
70-7879	cover,inspection,A75rotor	EA
70-7880	USE 71-1443	ea
70-7882	USE 71-1462	ea
70-7958	USE 71-1192	ea
70-7959	USE 71-1193	ea
70-7960	USE 71-1194	ea
70-7968	USE 70-9800	EA
70-7990	USE 721-711157	ea
70-8003	bearing,ball	EA
70-8005	bearing,needle	EA
70-8008	stud,cylinder head,250	EA
70-8011	pin,dowel,	EA
70-8012	stud,1/4CEI/BSW*	EA
70-8014	USE 57-0665	ea
70-8015	oilseal,gbx.sprocket	EA
70-8017	scavenge valve & pipe, sump	EA
70-8019	USE 422-732	ea
70-8025	oilseal,gbx & LH crank	EA
70-8036	plug,sludge trap,B44	EA
70-8037	washer,rockershaft,A10	EA
70-8038	washer,shim,.010	EA
70-8039	washer,shim,.015	EA
70-8040	gear,crank pinion,1cyl.	EA
70-8041	gear,pump drive worm,1cyl	EA
70-8043	washer,tab,crank nut	EA
70-8053	pushrod,X,Tri,BSA 250	EA
70-8055	pushrod,I,Tri,BSA 250	EA
70-8058	USE 71-1276	ea
70-8061	key,camshaft	EA
70-8064	plate, sump, BSA*	EA
70-8064/A	plate, sump, finned, Wscreen, magnetic*	EA
70-8065	USE 70-8064	ea
70-8070	USE 71-1424	ea
70-8071	USE 523-18053	ea
70-8072	washer,1/4,flat	EA
70-8080	stud,1/4x26	EA
70-8081	gasket,cyl.head,unit 250	EA
70-8082	adaptorFitting,rockerfeed	EA
70-8083	washer,sealing	EA
70-8084	washer,3/8"flat	EA
70-8085	USE 71-1425	ea
70-8086	screw,2BA,philip	EA
70-8087	USE 00-0074	ea
70-8088	USE 60-2321	ea
70-8089	nut,1/4x26,lock	EA
70-8090	oilpump,TriBSA 250,2 bolt*	EA
70-8094	gear,oilpump driven,1cyl.	EA
70-8101	USE 82-0879	ea
70-8103	USE 71-2115	ea
70-8104	washer,1/4",flat	EA
70-8106	hose,rockerfeed	EA
70-8107	USE 68-0927	ea
70-8109	USE 70-8107	ea
70-8110	nut,oiline,1/8 BSP	EA
70-8111	USE 60-3524	ea
70-8112	USE 453-255	ea
70-8114/8115	USE 451-647	ea
70-8121	washer,fibre	EA
70-8122	USE 422-516	ea
70-8124	spring,checkvalve,BSA1cyl	EA
70-8132	USE 06-2583 *	ea
70-8133	nut,5/16x26 thin	EA
70-8135	USE 06-3544	ea
70-8137	nut,5/16x26,nyloc	EA
70-8139	sprocket,engine,250 1cyl.	EA
70-8140	spacer,eng.sprocket,.325	EA
70-8141	spacer,eng.sprocket,.315	EA
70-8142	spacer,eng.sprocket,.295	EA
70-8144	USE 60-4253 *	ea

70-8146	nut,5/8x20,rotor	EA
70-8148	grommet	EA
70-8150	bush,cam,outer unit 1cyl.	EA
70-8151	USE 04-0099	ea
70-8152	circlip,bearing	EA
70-8153	oilseal,points,TriBSA1Cyl	EA
70-8154	oilseal,crankRH,TriBSA1Cy	EA
70-8155	boot,points wire,1cyl.	EA
70-8157	circlip	EA
70-8158	oring	EA
70-8160	screw,1/4x26	EA
70-8161	screw,1/4x26	EA
70-8163	washer,1/4",flat	EA
70-8164	washer,alloy	EA
70-8165	USE 60-4256	ea
70-8167	screw,1/4x26	EA
70-8168	screw,1/4x26	EA
70-8169	screw,3/16x32	EA
70-8175	washer,sealing	EA
70-8176	pointer,timing indicator	EA
70-8177	USE 82-4129	ea
70-8179	fitting,chain oiler,BSA	EA
70-8180	USE 70-2441	ea
70-8184	slipper,pri.ch.adj,1cyl	EA
70-8189	bracket,top motor mt,B25	EA
70-8193	bolt,3/8x26	EA
70-8194	nut,3/8x26,nyloc	EA
70-8196	USE 00-0004	ea
70-8213	hose,manifold balance	EA
70-8214	connector,balance hose,22TPI	EA
70-8215	washer,5/16 flat	EA
70-8224	USE 70-8043	ea
70-8225	USE 452-539/PB	ea
70-8226	USE 452-539/PB	ea
70-8227	stud,5/16BSF/BSW	EA
70-8228	stud,1/4x26	EA
70-8229	USE 70-4535	ea
70-8231	USE 57-2166	ea
70-8232	cover,timing outer,1cyl.	EA
70-8256	USE 00-0203	ea
70-8259	oring,oilfeed junction	EA
70-8287	screw,2BA	EA
70-8310	slipper,pri chain,A50/65	EA
70-8315	bush,cam,inner unit 1cyl.	EA
70-8319	USE 71-1431	ea
70-8382	USE 71-1419	ea
70-8720	valvespring collar,3cyl.	EA
70-8737	cover,points*	EA
70-8737/A	cover,points,finned,shallow	EA
70-8739	USE 71-1439	ea
70-8740	tachdrive housing,A75/T150	EA
70-8741	gear,tachdrive,A75/T150,19T	EA
70-8742	tachdrive cable adapter	EA
70-8744	bolt,1/4x20,retaining	EA
70-8745	stud,stepped,mainbrg.cap,3cyl.	EA
70-8750	USE 422-716	ea
70-8751	pin,dowel,hollow,cylinder	EA
70-8752	pressure rel.valve piston*	EA
70-8753	washer,metal,press.release valve	EA
70-8754	washer,fibre	EA
70-8755	bolt,9/16x12,timing plug	EA
70-8756	grommet,points wire,3 cyl	EA
70-8757	cover,alternator wires,T150	EA
70-8760	nut,sleeve,1/2X13UNC,alt.wire	EA
70-8761	USE 71-1440	ea
70-8762	cover,timing mark,T150/60	EA
70-8763	nut,7/16x20UNF,rotor	EA
70-8764	camshaft,inlet,3cylinder*	EA
70-8765	camshaft,exhaust,A75&T150*	EA
70-8768	circlip,idler gear,3cyl.	EA
70-8770	washer,3/8,flat	EA

70-8771	USE 71-3573	ea
70-8773	gasket,rockerbox to head *	EA
70-8773/A	gasket,rockerbox to head,copper	EA
70-8774	pin,dowel	EA
70-8776	washer,sealing	EA
70-8777	USE 70-9740	ea
70-8779	USE 71-1070	ea
70-8780	bearing,roller,3cyl.RH cr	EA
70-8781/A	cyl.hd,HYDE HiPerf,3cyl.	EA
70-8782	oring	EA
70-8783	adjuster,valve,3cyl,short	EA
70-8783/A	adj.set,valve,allen type	ST
70-8783/B	adj.set,valve,mushroom hd,short	ST
70-8784	USE 71-1446	ea
70-8785	washer,tab,eng sprkt,3cyl	EA
70-8786	USE 71-1078	ea
70-8787/8788	USE 451-724	ea
70-8789	collar,valvespring,bottom	EA
70-8797	USE 71-7318	ea
70-8801	tappet,exhaust,Tri.6/750,"R",drilled*	EA
70-8801/A	tappet,exhaust,Tri650,std,drilled	EA
70-8801/U	tappet,reground,exch	EA
70-8817	pillar bolt,cyl.hd,3cyl.	EA
70-8819	bolt,5/16x24,cylinder hd.	EA
70-8820	bolt,5/16x24,cylinder hd.	EA
70-8828	bolt,1/4x26*	EA
70-8834	USE 70-9915	ea
70-8836	conrod,T100/B&T25,early style	EA
70-8860	washer,conical,for x clip*	EA
70-8892	protection blade,650	EA
70-8895	tappet,x,1966 650 only*	EA
70-8895/U	tappet,reground,exch	EA
70-8896	washer,sealing	EA
70-8902	bracket,muffler,earlyT150	EA
70-8914	USE 443-176	ea
70-8917	USE 71-3213	ea
70-8955	cover plate,rotor,T25	EA
70-8960	heatshield,B44 Victor muffler	EA
70-8981	gaskt,heat insul,manifold,T150/A75	EA
70-8992	USE 70-9360	ea
70-9001	USE 71-1351	ea
70-9023	USE 421-91484/010 (set)	ea
70-9024	USE 421-91484/020 (set)	ea
70-9025	USE 421-91484/030 (set)	ea
70-9026	USE 421-91484/040 (set)	ea
70-9027	USE 421-91495/010 (set)	ea
70-9028	USE 421-91495/020 (set)	ea
70-9029	USE 421-91495/030 (set)	ea
70-9030	USE 421-91495/040 (set)	ea
70-9036	USE 711-2629 (set)	ea
70-9037	muffler,T150/A75raygun,RH	EA
70-9060	hose,manifold to hd.3 cyl	EA
70-9073	bush,throttle arm,3cyl.	EA
70-9074	airfilter assy,3cyl,oval,chr,part perf*	EA
70-9074/A	screen assy,chrome,airfilter,part perf.	EA
70-9104	gear,idler pinion,A50/65,69on	EA
70-9112	USE 71-1044	ea
70-9114	cover,rotor,BSA A50/65,w/logo	EA
70-9126	cover,points,BSA A50/65,w/logo	EA
70-9138	airfilterelement,A75/T150	EA
70-9138/A	airfilter element,K&N3cyl*	EA
70-9143	USE 711-412725	ea
70-9213	pressure release valve,UNF	EA
70-9237	nut,sleeve,rocker cover	EA
70-9239	USE 70-1335	ea
70-9240	washer,5/16"flat	EA
70-9242	arm,support,thr.linkage	EA
70-9243	trunnion,throttle linkage	EA
70-9245	cov,pri,6/750 RH shift*	EA
70-9245/ER	cov,pri,6/750 RHshift,econo	EA
70-9246	USE 71-7318	ea

70-9249	pri.cover, Tri.unit350/500*	EA
70-9250	cover, timing, unit 500	EA
70-9253	nut, lock, throttlerod, triple	EA
70-9254	spring, throttle stopscrew	EA
70-9255	circlip, 3 cyl.thr.linkage	EA
70-9256	pri.chain adjust, trunnion	EA
70-9257	washer, saddle, pri.adjust.	EA
70-9258	washer, saddle, pri.adjust.	EA
70-9263	cylinder barrel, TriBSA250	EA
70-9266	washer, sealing	EA
70-9267	USE 71-3311*	ea
70-9269	plunger, oilpump, .405"	EA
70-9271	oiline assembly, rockers, A75/T150*	EA
70-9274	fitting, "T", rocker feed *	EA
70-9278	arm, throttle linkage, A75/T150	EA
70-9307	USE 70-3907	ea
70-9330	plug, blanking, crankcase	EA
70-9331	USE 71-7011	ea
70-9332	bolt, LH thr, w/bush, tachdr	EA
70-9334	plate, cover, baffle	EA
70-9335	elbow, breather outlet, alloy	EA
70-9336	filter plug, sump, UNF	EA
70-9345	USE 71-2354	ea
70-9348	gask, rockerbox, 63-70 T120*	EA
70-9348/A	gask, rockerbox, 63-70 T120, copper	EA
70-9349	pushrod tube, 1969on 650	EA
70-9349/A	pushrod tube, 1969on 650, alloy billet	PR
70-9349/B	pushrod tubes, 1969on650, W/early hd, alloy	PR
70-9352	tappet block, inlet, 1969on*	EA
70-9352/9353/A	tappet block, in&ex, 1969on, racing	EA
70-9353	tappet block, exh, 1969on	EA
70-9360	nut, sleeve, 1/2x13UNC, alt.wire*	EA
70-9362	USE 71-2354	ea
70-9368	USE 70-9888	ea
70-9381	shaft, tachdrive, 1cylinder	EA
70-9418	USE 71-2356	ea
70-9421	oilpump, unitTri.Twin, w/block	EA
70-9421/A	oilpump, Morgo Rotary, unit twin*	EA
70-9421/A/NUT	nut, driving, Morgo Rotary pump	EA
70-9421/B	oilpump, unitTri, MORGO plunger	EA
70-9421/ER	oilpump, unitTri.Twin, replacement	EA
70-9427	USE 71-2025	ea
70-9428	tachdrive assy, TRIBSA1cyl*	EA
70-9430	oring	EA
70-9438	USE 71-4138 *	ea
70-9465	pin, dowel, tappet block	EA
70-9467	USE 721-709677	ea
70-9480	cover, timing inner, A50/65	EA
70-9488	USE 441-17844 (pair)	ea
70-9492	plug, cranktube, slotted	EA
70-9492/A	plug, cranktube, allen hd	EA
70-9493	bearing, roller*	EA
70-9494	bearing, ball*	EA
70-9495	stud, UNF/UNC, stator, T100	EA
70-9496	oiline, scavenge pickup	EA
70-9501	cap, sump, unified thread	EA
70-9502	plate, camshaft retaining	EA
70-9503	spacer, engine sprocket	EA
70-9507	cylinder hd w/spigots, 500	EA
70-9510	spigot, exhaust, alloy hd.500&3cyl.	EA
70-9510/A	spigot, exhaust, oversize.	EA
70-9511	gask, rockerbox, unit 500 *	EA
70-9511/A	gask, rockerbox, unit500, copper	EA
70-9512	USE 71-2576	ea
70-9516	spigot, exhaust, 650&T140E*	EA
70-9516/A	spigot, exhaust, oversize.	EA
70-9516/B	spigot, exh, repair, weld-in	EA
70-9517	tachdrive housing, unit singles	EA
70-9525	conrod, 650 Tri, late type*	EA
70-9525/A	conrods, Morgo Hi-Perf	PR
70-9525/B	conrod, CARILLO HiPerf.	PR

70-9525/C	conrods,billet Hi-Perf	PR
70-9526	plug,1/8NPT,blanking	EA
70-9547	USE 70-9848	ea
70-9550	manifold,intake,LH,UNC*	EA
70-9550/9551	manifolds,intake,UNC,w/nuts*	PR
70-9551	manifold,intake,RH,UNC*	EA
70-9554	washer,rubber	EA
70-9555	washer,cup,In.manifold	EA
70-9558	shaft,rocker spindle,3cyl.	EA
70-9564	USE 711-Z690	ea
70-9586	sleeve,airfilter,3 cyl	EA
70-9601	USE 21-2310	ea
70-9626	washer,balance tube clamp	EA
70-9627	clamp,balance tube,BSA type	EA
70-9634	washer,shim,eng.sprocket	EA
70-9654	USE 711-Z690	ea
70-9673	connector,"H"shape,x pipe	EA
70-9680	heatshield,muffler,T100C/TR6C	EA
70-9686	USE 71-2600	ea
70-9688	clip,heatshield,TR6C/100C,69on	EA
70-9691	bracket,muff,T100C	EA
70-9692	bracket,muff,TR6C	EA
70-9696	bracket,exhaust,TR6C/100C,69on	EA
70-9698	connector,"H"shape,x pipe,chrome	EA
70-9698/A	connector,"H"shape,x pipe,unchromed	EA
70-9699	USE 70-9995	ea
70-9703	adj.nut,primary tensioner	EA
70-9711	oring, carb,thick	EA
70-9716	heatshield,muffler,A65F*	EA
70-9719	cylinder barrel unit 500	EA
70-9719/A	cyl.barrel unit500,alloy*	EA
70-9725	USE 721-711408 *	ea
70-9727	bolt,conrod,3cylinder	EA
70-9737	USE 71-2211	ea
70-9738	USE 70-8754	ea
70-9740	conrod,3 cylinder	EA
70-9740/A	conrod set,HYDE Hi-Perf.	ST
70-9740/B	conrod set,3cyl,CARRILLO hi perf	ST
70-9741	USE 441-19916 (set of 3)	ea
70-9762	USE 441-19916/010 (set)	ea
70-9763	USE 441-19916/020 (set)	ea
70-9764	USE 441-19916/040 (set)	ea
70-9779	rockerarm,RHinlet,centreX	EA
70-9780	rockerarm,RH ex,centre in	EA
70-9781	rockerarm,LHinlet,3cyl.	EA
70-9782	rockerarm,LHexhaust,3cyl.	EA
70-9800	cap.insp,vented & baffled*	EA
70-9802	USE 70-4562 ?	ea
70-9807	grommet,alternator,A75R/T160	EA
70-9809	bush,idler,69onA50/65 L&R	EA
70-9816	USE 57-2166 or 70-9800	EA
70-9818	heatshield,muffler,B25	EA
70-9821	washer,cup,throt.spring	EA
70-9843	rubber sealing bush	EA
70-9848	crankshaft assy,compl,B25/T25	EA
70-9856	sleeve,oilfilter,3cyl.	EA
70-9880	USE 71-3311*	ea
70-9885	cover,oilpump outer,3cyl.	EA
70-9886	USE 71-4237	ea
70-9887	gear,oilpump,w/shaft,3cyl	EA
70-9888	balance tube,x pipe,Tri.	EA
70-9890	USE 70-9888 & 2) 742-138	ea
70-9899	USE 71-1448	ea
70-9900	USE 71-1450	ea
70-9901	USE 71-1447	ea
70-9910	plug,tachdrive	EA
70-9911	USE 70-9915	ea
70-9914	bolt,5/16x24,conrod*	EA
70-9915	conrod,T100/B&T25,late style*	EA
70-9915/A	conrod,CARILLO HiPerf.	PR
70-9972	USE 71-3941	ea

70-9973	USE 71-7555	ea
70-9974	bearing,roller*	EA
70-9979	screen, sump filter,1cyl.	EA
70-9984	cam,E3134 type,x,unit 500	EA
70-9988	tachdrive thimble,screwIn	EA
70-9989	cam,E3134 type,unit x*	EA
70-9995	bracket,muffler,A65F	EA
71-	TRIUMPH AND BSA PARTS	*
71-----	-----	---
71-0003	screw,oilpump	EA
71-0006	screw,pointer,aperture4BA	EA
71-0007	screw,4BA	EA
71-0017	USE 721-T73X (pair)	ea
71-0019	USE 721-T73X (pair)	ea
71-0022	USE 721-T74X	ea
71-0024	USE 721-T74X	ea
71-0037	key,woodruff,3cyl.	EA
71-0040	cam,E3134 type.unit int*	EA
71-0041	USE 70-9989	ea
71-0046	cam,X,T100C,E3325 type	EA
71-0070	ball pin,rocker arm*	EA
71-0070/A	ball pins,rocker,offset	ST
71-0071	USE 70-7651	ea
71-0082	key,crankshaft	EA
71-0216	clip,finned,xpipe,1-3/4",bare*	EA
71-0216/A	clip,finned,xpipe,1-3/4",compl*	EA
71-0216/SS	clips,finned,xpipe,1-3/4"compl,stainless	PR
71-0229	USE 452-461	ea
71-0245	washer	EA
71-0280	bolt,cyl.hd,extended,5/16x24	EA
71-0286	bush,cam,Tri.650/750 RH*	EA
71-0286/7/8/A	bush set,cams,Hi-Perf.	ST
71-0286/A	bush,cam,Tri.6/750 RH,PM	EA
71-0287	bush,cam,Tri.650/750 LH*	EA
71-0287/A	bush,cam,Tri.6/750 LH,PM	EA
71-0288	bush,cam,Tri.650LHin,pre70*	EA
71-0827	USE 68-0827	ea
71-1003	washer,3/8",flat	EA
71-1007	nut,cam,inlet,w/peg,UNF	EA
71-1036	USE 71-1433	ea
71-1044	cover,primary,A50/A65	EA
71-1051	spindle,oilpump,3cyl.	EA
71-1058	USE 71-2025	ea
71-1059	cover,timing,inner,250	EA
71-1063	cam,E3134 type,int.,70on	EA
71-1064	cam,E3134 type,unit500in	EA
71-1065	washer,sealing	EA
71-1070	oring,sprocket&filter cap	EA
71-1072	breather plate assy	EA
71-1075	screw,breather outlet,long	EA
71-1076	USE 71-1460	ea
71-1077	screw,breather outlet,short	EA
71-1078	oilhose,pri.chain	EA
71-1105	conrod,A50/65,RH	EA
71-1105/1106/A	conrods,steelcap,Hi-Perf.	PR
71-1105/1106/B	conrods,CARRILLO Hiperf	PR
71-1106	conrod,A50/65,LH	EA
71-1118	cover,timing,in,A65,70on	EA
71-1126	screen, sumpfilter,BSA2cyl	EA
71-1129	washer,tab,3cyl.brg.caps	EA
71-1130	screw	EA
71-1131	cover,timing,outerA50/65,1970on	EA
71-1133	USE 71-2227	ea
71-1134	USE 71-3001	ea
71-1135	oilpump,std.A50/65	EA
71-1136	USE 71-2413	ea
71-1137	body,oilpump,A50/65	EA
71-1144	gear,oilpump driven,scav.	EA
71-1149	hose,breather,short*	EA
71-1153	USE 71-1347	ea
71-1165	valvespring collar,late	EA

71-1166	collet, valve, BSA, late	EA
71-1168	USE 70-9271	ea
71-1172	fitting, "T", rocker feed	EA
71-1175	oil line*	EA
71-1176	USE 71-4250	ea
71-1177	USE 451-641 (kit)	EA
71-1178	USE 721-711408	ea
71-1184	clamp, exh, 1-3/8", w/boss	EA
71-1190	gasket, pushrod tube	EA
71-1192	shim, cylinder sleeve, .015	EA
71-1193	shim, cylinder sleeve, .027	EA
71-1194	shim, cylinder sleeve, .030	EA
71-1195	USE 71-1464	ea
71-1196	cylinder barrel, A50, 1970 *	EA
71-1199	race, conrod brg, B50*	EA
71-1210	USE 71-3447	ea
71-1218	USE 443-234	ea
71-1238	pushrod, I&X, late T150/A75	EA
71-1238/A	pushrod set, alloy Hi-Perf	ST
71-1270	cap, oilfilter, 3cylinder	EA
71-1270/A	cap, oilfilter, 3cylinder, billet	EA
71-1276	cam, w/gear, 250 1cylinder	EA
71-1283	oring, pushrod tube	EA
71-1287	USE 70-9780 & 71-0070	ea
71-1288	USE 70-9779 & 71-0070	ea
71-1289	USE 70-9781 & 71-0070	ea
71-1290	USE 70-9782 & 71-0070	ea
71-1303	adaptor, carb to AC, A75/T150	EA
71-1327	pressure release valve, A65, coarse	EA
71-1345	grommet, alternator wire	EA
71-1347	flywheel only, A65	EA
71-1348	gasket, timing cover, A75	EA
71-1349	stud, sump plate, 3cyl.	EA
71-1350	gasket, timing cov, T15/160	EA
71-1351	oilpump assy, 3cyl.	EA
71-1351/A	oilpump assy, 3cyl, racing, w/dr.gear*	EA
71-1353	washer, tab, oilpump, late	EA
71-1416	USE 71-3573	ea
71-1418	gasket, primary, TriBSA1cyl*	EA
71-1419	gasket, sprocket cvr plate	EA
71-1420	gasket, rotor cov, BSA 1&2	EA
71-1421	USE 71-3573	ea
71-1423	USE 71-1462	ea
71-1424	gasket, sump filter, BSA	EA
71-1425	gasket, rocker insp, 250	EA
71-1426	gask, rockerbox, TriBSA 1cyl, pre71	EA
71-1427	gasket, rockerbox, B44	EA
71-1428	USE 71-2115	ea
71-1429	gasket, rocker insp, B44/50	EA
71-1430	gasket, man. to hd, A50/A65T	EA
71-1431	gasket, rockercov, pre71A65	EA
71-1432	gasket, pri. cover, A50 & A65	EA
71-1433	gask, cyl. base, A50/65, late	EA
71-1435	USE 71-2296	ea
71-1436	gasket, tachdrive, A50/65	EA
71-1437	gasket, timing cov, in, A65	EA
71-1439	gasket, tachdrive, A75/T150	EA
71-1440	gask, timingHole, T150/T160	EA
71-1441	gasket, points cover, 3 cyl	EA
71-1442	gasket, oilpump, 3cylinder	EA
71-1443	gasket, rotor insp cov, A75	EA
71-1444	gasket, sump cover, 3cyl.	EA
71-1445	gasket, rocker cover, 3cyl.	EA
71-1446	gasket, manifold, 3 cyl.	EA
71-1447	gask, gbx. inner, all 3cyl	EA
71-1448	gask, gbx outer, T120/40/50	EA
71-1449	gask, cl. insp. cov, T150/A75	EA
71-1450	gasket, gbx. cov, outer, A75	EA
71-1451	gask, sprock. seal housing	EA
71-1452	gask, breatherCov, A75/T150	EA
71-1453	gask, inner pri, T150/A75	EA

71-1454	gasket,primary cover,3cyl	EA
71-1455	gasket,inner pri mount	EA
71-1456	gasket,pri.cover,unit 500	EA
71-1457	gasket,rotor cover	EA
71-1458	USE 71-3754	ea
71-1459	USE 71-3573	ea
71-1460	gasket,breather elbow	EA
71-1461	USE 71-3910	ea
71-1462	gasket,points cover	EA
71-1463	USE 71-7009	ea
71-1464	cylinder,A65,late,3/8stud	EA
71-1464/U	cyl.A65,late,3/8stud,reconditioned	EA
71-1467	stud,3/8x20x26,cyl.head	EA
71-1468	USE 68-0079	ea
71-1616	crankpin,B50	EA
71-1619	pointer,ignition timing	EA
71-1620	pushrod,in&ex,B50,1971&72	EA
71-1620/A	pushrod set,B50,chromemoly	ST
71-1623	gasket,rockerbox,B50	EA
71-1624	gasket,cylinder base,B50	EA
71-1625	gasket,cylinder head,B50	EA
71-1626	USE 452-510/PB	ea
71-1627	USE 452-539/PB	ea
71-1634	sprocket,engine,B50	EA
71-1635	USE 71-2586 assy.	ea
71-1635/A	conrod,B50,Carrillo HiPerf.	EA
71-1643	USE 441-19257	ea
71-1679	key,woodruff,1/8X.168X.370"	EA
71-1707	sleeve,pushrod tube seal	EA
71-1731	USE 70-8043	ea
71-1733	USE 71-3941	ea
71-1735	USE 453-272	ea
71-1736	USE 453-273	ea
71-1742	hose,oil	EA
71-1743	hose,oil	EA
71-1801	USE 441-16945	ea
71-1847	bracket,muffler,T150,RH	EA
71-1848	bracket,muffler,T150,LH	EA
71-1860	adaptor,airfilter,Amal900	EA
71-1957	USE 70-2922	ea
71-2017	USE 711-Z605 (pr)	ea
71-2018	USE 711-Z605 (pr)	ea
71-2019	USE 711-709669/9670	ea
71-2020	USE 711-709669/9670	ea
71-2025	cover,pri,BSAunit1cyl. *	EA
71-2026	cover,pri,T25*	EA
71-2043	xpipe,LH,7lon A65,bal.type	EA
71-2045	USE 71-B65 (set)	ea
71-2075	rockerbox,int,unit500,late	EA
71-2076	rockerbox,x,unit500,late	EA
71-2079	plug,insp,rockerbox side	EA
71-2080	washer,copper,insp.cap	EA
71-2086	USE 70-4576	ea
71-2114	heatshield,muffler,B50	EA
71-2115	gasket,oilpump,unit 1cyl.	EA
71-2148	USE 441-19257/020	ea
71-2150	USE 441-19257/040	ea
71-2165	USE 71-1451	ea
71-2198	gasket,rockerbox,250 1cyl	EA
71-2207	gasket,rockerInsp,7lonA65	EA
71-2210	USE 71-3447	ea
71-2211	washer,sealing	EA
71-2222	spring,valve,outer	EA
71-2223	spring,valve,outer	EA
71-2226	USE 452-606/PB	ea
71-2227	oilpump,unit 250,3 bolt	EA
71-2228	USE 71-3001	ea
71-2231	USE 452-607/PB	ea
71-2233	gasket,cyl.base,250single,late	EA
71-2240	USE 71-2656	ea
71-2243	USE 71-2658	ea

71-2246	gear, idler pinion, 3cyl, late	EA
71-2248	bush, idler pinion, 3cylinder	EA
71-2249	washer, thrust, idler gear	EA
71-2280	USE 71-1131	ea
71-2282	bracket, muffler, L&RH, 2cyl*	EA
71-2283	bracket, muffler, A65, 7lon	EA
71-2284	USE 70-9848*	ea
71-2296	gasket, oilpump, A50/A65	EA
71-2299	washer, thrust, camshaft	EA
71-2300	USE 452-542/PB	ea
71-2315	USE 68-0827	ea
71-2333	cover, rocker, A65, 1970 on	EA
71-2345	hose, oil	EA
71-2347	hose, breather	EA
71-2349	hose, breather	EA
71-2350	USE 71-3668	ea
71-2351	USE 71-3669	ea
71-2354	cylinder head, TR6, bare*	EA
71-2356	cylinder head assy, T120, w/man.	EA
71-2361	pin, dowel	EA
71-2362	bolt, cyl. hd, w/int. 7/16 thr. *	EA
71-2365	USE 71-2599	ea
71-2369	valve, pressure rel, 3cyl, coarse	EA
71-2370	USE 71-1327	ea
71-2382	USE 711-Z604	ea
71-2400	USE 711-712400	ea
71-2401	USE 711-712400	ea
71-2402	heatshield, 7lonTriBSA1cyl	EA
71-2409	USE 71-2427	ea
71-2413	oilpump, castiron, A50/65	EA
71-2413/A	oilpump, MORGO, A50/65	EA
71-2417	gear, oilpump scavenge, driving	EA
71-2427	hose, 9mm black rubber	FT
71-2428	oiline assy, rockers	EA
71-2428/ER	oiline assy, rockers, econo. repl.	EA
71-2449	USE 71-2413	ea
71-2450	USE 71-2413	ea
71-2451	xpipe, LH, 71/72 T150, 1-1/2"outlet*	EA
71-2453	xpipe, RH, 71/72 T150, 1-1/2"outlet*	EA
71-2460	USE 71-1848	ea
71-2465	clip, finned, xpipe, 1-3/8"	EA
71-2466	clip, finned, xpipe, 1-1/4"	EA
71-2475	USE 71-7011	ea
71-2476	tachdrive gbx, late T100R	EA
71-2480	plug, tachdrive gearbox	EA
71-2481	welch plug, tach drive	EA
71-2482	spacer, thrust, tachdrive	EA
71-2500	washer, flat	EA
71-2501	USE 21-7025	ea
71-2505	washer, fibre, 5/16"	EA
71-2513	tappet, in &x, unit singles	EA
71-2513/U	tappet, reground, exch	EA
71-2545	cover, timing, in, 1cyl, late	EA
71-2569	USE 71-3668	ea
71-2570	USE 71-3669	ea
71-2572	cover, rocker insp, 4 bolt	EA
71-2574	gask, rocker cover, 4 hole*	EA
71-2575	USE 70-9349	ea
71-2576	pushrod tube, 1969onTri500	EA
71-2576/A	pushrod tubes, T100R, billet alloy	PR
71-2586	USE 423-B28 and 71-1635/A	ea
71-2592	USE 06-3458	ea
71-2597	USE 37-2338	ea
71-2598	USE 82-2184 *	ea
71-2599	gask, rockerbox, 7lon 6/750*	EA
71-2599/A	gask, rockerbox, 7lon 6/750, copper*	EA
71-2643	USE 71-3605	ea
71-2644	USE 71-3605	ea
71-2653	gear, tachdrive gbx, driven, late	EA
71-2654	USE 711-Z604/A	ea
71-2656	fitting, return line, 3/8"	EA

71-2658	fitting,feed line,3/8"UNF	EA
71-2660	washer,shim,030	EA
71-2662	sprocket,eng,unit 650,late,29T *	EA
71-2663	spacer,engine sprocket	EA
71-2664	spacer,eng.sprocket	EA
71-2673	USE 71-1105/1106/A (set)	ST
71-2677	USE 71-1105/1106/A (set)	ST
71-2717	USE 70-4562	ea
71-2718	gear,camshaft,71on3cyl	EA
71-2718/A	gear,cam,3cyl,alloy	EA
71-2719	USE 71-3666	ea
71-2742	oilfeed junction,A50/A65	EA
71-2744	cap,rocker insp,slotted*	EA
71-2744/A	caps,rocker insp,finned,BARNETT	ST
71-2744/B	cap,rocker insp,slotted,billet alloy*	EA
71-2744/C	cap,rocker insp,slotted,econo	EA
71-2744/ER	caps,rocker insp,finned,econo*	ST
71-2745	USE 441-19257	ea
71-2748	hose,vent,58",71onA65	EA
71-2749	USE 441-19257/020	ea
71-2751	USE 441-19257/040	ea
71-2765	USE 441-19257	ea
71-2767	USE 441-19257/020	ea
71-2769	USE 441-19257/040	ea
71-2790	heatshield,muffler,A65F,1971	EA
71-2792	washer,copper	EA
71-2793	USE 71-1455	ea
71-2800	plug,crankSludgeTrap,thin,7/8x20UNEF	EA
71-2800/A	plug,crank tube,allen,thick	EA
71-2800/B	plug,crank tube,allen,thin	EA
71-2806	USE 71-2354 *	ea
71-2807	USE 71-2356 *	ea
71-2811	manifold,In,boltOn T120,L	EA
71-2812	manifold,in,boltOn T120,R	EA
71-2813	stud,stepped,carb man.	EA
71-2839	USE 70-9428	ea
71-2840	USE 70-9428	ea
71-2841	USE 70-9428	ea
71-2851	skidplate,TR6C,710on	EA
71-2877	nut,crank,RH,UNF	EA
71-2888	bolt,cylinder hd,inner*	EA
71-2889	bolt,5/16,rockerbox inner*	EA
71-2930	rubber cover,oil pres. sw	EA
71-2932	USE 71-2025	ea
71-2970	USE 71-3700	ea
71-3001	oilpump,B44&B50,less gear	EA
71-3006	conrod,Triumph T140/TR7	EA
71-3006/A	conrod,CARILLO HiPerf.	PR
71-3010	USE 71-7017	ea
71-3011	USE 71-7016	ea
71-3013	stud,stepped,cylinderBase	EA
71-3023	USE 71-7007	ea
71-3030	USE 72-0002	ea
71-3054	USE 71-3097*	ea
71-3062	USE 71-713793*	ea
71-3096	gask,inner gbx.cov650/750*	EA
71-3097	crankshaft,bare,lateTR6/120*	EA
71-3174	USE 71-1078	ea
71-3175	clip,oilhose,primary case	EA
71-3178	USE 441-19257/020	ea
71-3179	USE 441-19257/040	ea
71-3185	USE 71-3700	ea
71-3209	USE 71-3935	ea
71-3213	tappet,I & X, A75 & T150	EA
71-3213/U	tappet,reground,exch	EA
71-3213A/U	tappet,ground3/4"radius,exch	EA
71-3221	USE 68-0249	ea
71-3222	USE 68-0861	ea
71-3231	USE 70-9428*	ea
71-3288	cup,shim retainer,crank,late	EA
71-3292	USE 452-01	ea

71-3293	USE 452-01	ea
71-3294	USE 452-01	ea
71-3295	USE 452-01	ea
71-3296	collar, valvespring, bot750	EA
71-3298	USE 72-0002	ea
71-3301	shaft, rockers, 350/500unit, 24TPI*	EA
71-3302	manifold, in, bolt on T120	EA
71-3307	crankshaft, 3 cylinder	EA
71-3311	spring, thr. linkage, 3 cyl, exc. T160	EA
71-3312	spring, throttle slide	EA
71-3313	USE 71-7103	ea
71-3316	USE 71-7584, 211872&373761	ea
71-3329	pushrod tube, T140, pre80	EA
71-3329/A	pushrod tube, alloy, T140, pre80,	PR
71-3330	pushrod, In & Exh, TR7/T140	EA
71-3330/A	pushrod set, PM Hi-Perf.	ST
71-3330/B	pushrod set, chromemoly	ST
71-3335	USE 71-4005&441-19255&4) 14-0241	ea
71-3338	manifold, intake, T140, RH	EA
71-3339	manifold, intake, T140, LH	EA
71-3349	USE 441-18998 (set)	ea
71-3354	pin, piston, TR7/T140	EA
71-3358	adjuster, valves, ball type	EA
71-3358/A	adj. valves, "mushroom" type, long*	ST
71-3361	USE 453-282	ea
71-3362	USE 453-283	ea
71-3369	heatshield, muffler, Hurricane	EA
71-3446	USE 70-2356 *	ea
71-3447	valve, pressure rel, twins, fine	EA
71-3463	dipstick assy. w/cap, T140	EA
71-3464	dipstick, bare, T140	EA
71-3478	USE 71-7176	ea
71-3487	USE 71-2282	ea
71-3530	USE 70-7578	ea
71-3541	sprocket, engine, 23T, T160	EA
71-3542	sprocket, engine, TR7/T140	EA
71-3544	spacer, rotor	EA
71-3549	shaft, rockers, UNF *	EA
71-3550	oiline. assy, rockers, T140	EA
71-3550/ER	oiline assy, rockers, T140 style, econo	EA
71-3551	hose, oil	EA
71-3552	bolt, 3/8x24, flywheel to crank	EA
71-3553	washer, double, head bolt	EA
71-3555	USE 70-9245*	ea
71-3555/A	cover, pri, finned, RH shift*	EA
71-3556	USE 71-7555	ea
71-3558	USE 71-7505	ea
71-3573	gasket, intake manifold	EA
71-3577	hose, 5/16"	EA
71-3587	rockerarm, RHinlet, centreX	EA
71-3588	rockerarm, RH ex, centre in	EA
71-3589	rockerarm, LHexhaust, 3cyl.	EA
71-3590	rockerarm, LHinlet, 3cyl.	EA
71-3596	cam, exhaust, T160*	EA
71-3605	cylinder head, T100Rpushin	EA
71-3657	pushrod, in&ex, B50, 1973 type	EA
71-3666	gear, cam, T140 type	EA
71-3667	USE 70-9915	ea
71-3668	rockerbox, inlet, 6bolt cov	EA
71-3669	USE 71-7050	ea
71-3671	cover, rocker insp, 6 bolt	EA
71-3673	gasket, rocker cov, 6 bolt*	EA
71-3674	USE 72-0002	ea
71-3676	USE 441-19255 (pair)	ea
71-3679	USE 71-4005	ea
71-3681	gasket, cyl. hd, T140 copper	EA
71-3681/A	gasket, cyl. hd, T140 copper, 080"thick	EA
71-3686	USE 441-19255/010	ea
71-3687	USE 441-19255/020 (pair)	ea
71-3689	USE 441-19255/040 (pair)	ea
71-3700	circlip, piston pin	EA

71-3700/A	circlip,piston pin,econo pistons	EA
71-3723	USE 711-Z610*	ea
71-3748	collet, valve, Triumph 2&3	EA
71-3749	washer, 5/16, flat, alloy	EA
71-3754	gasket, oil junction block	EA
71-3755	USE 721-T85 (set)	ea
71-3758	USE 721-T85 (set)	ea
71-3761	bracket, muffler, L&RH, 2cyl	EA
71-3778	USE 441-19255	ea
71-3786	hose, oil	EA
71-3793	USE 711-713793	ea
71-3810	bracket, muffler, LH, 74 T150	EA
71-3811	bracket, muffler, RH, 74 T150	EA
71-3812	xpipe, LH, T150, 1-3/8"outlet*	EA
71-3815	xpipe, RH, T150, 1-3/8"outlet*	EA
71-3884	spring, thr. linkage, T160	EA
71-3892	pointer, ign. timing	EA
71-3895	cap, inspection, pri. cover*	EA
71-3895/ER	cap, inspection, pri, econo*	EA
71-3896	oring	EA
71-3910	gasket, oilpump, unit Tri. twin	EA
71-3935	cylinder barrel, 3cylinder	EA
71-3941	gask, cyl. hd, 3cyl, asbestos*	EA
71-3947	gasket, in. manifold, T160	EA
71-3948	gasket, heat insul, in. man, T160	EA
71-3974	pushrod, in&ex, T160	EA
71-3974/A	pushrod set, HYDE Hiperf	ST
71-3975	USE 70-3975	ea
71-3976	tappet, i & x, T160	EA
71-3987	gasket, inner primary, T160	EA
71-3989	dowel, hollow	EA
71-3995	USE 441-19255/010	ea
71-3996	USE 441-19255/020 (pair)	ea
71-3999	USE 711-Z610	ea
71-4000	USE 71-4378	ea
71-4005	cylinder barrel, TR7/T140	EA
71-4020	USE 71-7505	ea
71-4029	USE 71-7505	ea
71-4044	elbow, breather outlet, plastic	EA
71-4072	USE 71-3555 *	ea
71-4116	USE 57-4116	ea
71-4131	plug, tachdrive assy, T160	EA
71-4136	USE 71-7011	ea
71-4138	tachdrive assy, T160&T100	EA
71-4139	tachdrive body, T160	EA
71-4159	USE 711-Z610	ea
71-4182	fitting, rockerfeed, T160	EA
71-4237	gear, pump, 3cyl, late	EA
71-4237/A	gear, pump, 3cyl, late, performance	EA
71-4245	rockerbox, 3cyl, inlet	EA
71-4246	rockerbox, 3cyl, exh.	EA
71-4250	gasket, cyl. hd, 3cyl, copper	EA
71-4250/A	gasket, hd, 3cyl, flame ring, HYDE	EA
71-4251	bolt, 7/16x20, pri. chainAdj	EA
71-4252	cap, plastic, pri. adj., T160	EA
71-4276	USE 71-4246	ea
71-4356	cyl. hd, T160, bare	EA
71-4378	pushrod tube, triples*	EA
71-4433	stub, oilfeed pipe, T160	EA
71-4434	screw, 4BA	EA
71-4435	spacer, rotor, 3cylinder	EA
71-4443	oring	EA
71-4458	clamp, ex. pipe to box, bare, T160	EA
71-4459	finned clip, T160 RH	EA
71-4472	clip, tach cable retaining, T160	EA
71-4604	USE 71-1105/1106/A (set)	ea
71-4605	USE 71-1105/1106/A (set)	ea
71-4619	gask, cyl. hd, T140 eyelett*	EA
71-6890	USE 70-6890	ea
71-7003	USE 71-7465	ea
71-7007	cylinder head, T140V	EA

71-7008	tappet, not "R" type	EA
71-7008/U	tappet,reground,exch	EA
71-7009	gask,pri.cov,unit650/750	EA
71-7011	tachdrive gearbox assy,6/750twin *	EA
71-7012	spacer,thrust,tach drive *	EA
71-7013	USE 71-7176	ea
71-7014	hose,24"	EA
71-7015	hose,oil	EA
71-7016	camshaft,inlet,TR7/T140	EA
71-7017	camshaft,exhaust,TR7/T140	EA
71-7017/A	cam,exh,T140,Spitfire profile	EA
71-7018	clamp,airfilter hose	EA
71-7019	hose,airfiltr,late Bonnie	EA
71-7042	USE 71-7318	ea
71-7043	rockerarm,LHexh.& RHinlet,UNF	EA
71-7044	rockerarm,LHinlet & RHexh,UNF	EA
71-7045	adjuster, valve,UNF	EA
71-7045/A	adj.set, valve,mushroom,24 TPI*	ST
71-7045/B	adj.set, valve,allen type	ST
71-7046	USE 71-7503	ea
71-7049	USE 71-7050	ea
71-7050	rockerbox,ex,6 bolt cover	EA
71-7052	bracket,carbs,T140E	EA
71-7053	linkage,carb enricher,MK2	EA
71-7054	pin,carb linkage,T140E	EA
71-7055	USE 71-7166	ea
71-7090	USE 441-19255/010	ea
71-7091	USE 441-19255/020 (pair)	ea
71-7103	connector,balance hose,18TPI	EA
71-7120	collar,xpipe,T140D*	EA
71-7120/SS	collar,xpipe,T140D,stainless*	EA
71-7121	washer,sealing,T140D exh.	EA
71-7143	USE 71-4131	ea
71-7159	cover,ignition,finned,sballow	EA
71-7166	rubber connector,airfilt,MK2	EA
71-7176	oilfeed junction block,1t.T140	EA
71-7179	USE 71-3329	ea
71-7183	USE 71-7503	ea
71-7191	pushrod tube,T140E,1980on	EA
71-7191/A	pushrod tube,T140E,1980on,alloy	PR
71-7194	USE 71-7195*	EA
71-7195	tappet block,drilled,TR7/140,80on*	EA
71-7196	collar,pushrod tube,81 on	EA
71-7201	USE 452-02	ea
71-7202	USE 452-02	ea
71-7203	valvespring cup,1979onTri	EA
71-7206	collector,T140D exhaust	EA
71-7224	USE 721-01 (set)	ea
71-7225	USE 721-01 (set)	ea
71-7244	washer,starter sprag ret.	EA
71-7245	spacer,starter clutch	EA
71-7254	plug,oilpump body,4valve,slotted	EA
71-7255	pri.adj.rod,T140ES type	EA
71-7258	pri.adj.pivot pin,T140ES	EA
71-7259	pri.adj.plug,T140ES type	EA
71-7260	spring,oilpump checkball,4valve	EA
71-7263	gasket,timing cov,650/750	EA
71-7270	washer,sealing,exh,TSS	EA
71-7274	ball pin,rocker arm,TSS	EA
71-7275	adjuster, valve,TSS 8valve	EA
71-7276	gasket,rocker cov,ex,TSS	EA
71-7277	gasket,rocker cov,in,TSS	EA
71-7284	spring, valve, inner,TSS	EA
71-7291	exhaust pipe flange,TSS	EA
71-7314	plug,oilpump body,4valve,square hd.	EA
71-7317	oilpump,Twins,4valve type	EA
71-7318	cover,timing,6/750 unit*	EA
71-7328	gasket,starter cov,T140ES	EA
71-7339	conrod,TSS 8valve	EA
71-7354	plug,cranktube,TSS 8valve	EA
71-7357	bolt,tappet block	EA

71-7367	collet, valve, TSS 8valve	EA
71-7382	pushrod, In&X, TSS 8valve	EA
71-7385/A	pushrod tubes, TSS, alloy	PR
71-7400	pillar bolt, ign. plate, ES	EA
71-7418	washer, starter bush, T140ES	EA
71-7445	USE 421-5400 (set)	ea
71-7451	washer, sealing, cyl. hd, TSS	EA
71-7455	spring, valve, outer, TSS	EA
71-7458	oiline assy, rockerfeedTSS	EA
71-7464	USE 71-7465	ea
71-7465	cover, pri, T140 LH shift*	EA
71-7474	cover, rocker insp, ex, TSS	EA
71-7491	crankcases, TR7/140, LH shift*	PR
71-7492	bush, idler gear, late T140	EA
71-7503	cylinder head, T140E, late *	EA
71-7505	cylinder head, TR7, late*	EA
71-7506	USE 452-02	ea
71-7507	USE 721-T90 (set)	ea
71-7508	USE 721-T90 (set)	ea
71-7526	starter cl. assy, T140ES	EA
71-7527	rubber adaptor, a/c, Bing	EA
71-7555	manifold, intake, TR6 &TR7	EA
71-7560	USE 441-20895 (pair)	ea
71-7584	sump plate, Tri 750 2cyl.	EA
71-7609	USE 71-7011	ea
71-7627	USE 71-7628	ea
71-7628	bush, idler spindle, T140ES	EA
71-7634	gasket, cylinder base, TSS	EA
71-7644	USE 71-7008	ea
71-7661	collet, X pipe, TSS 8valve	EA
71-7679	gear, crankpinion, heavy duty	EA
72-	TRIUMPH PARTS	*
72-	-----	--
72-0002	crankshaft, w/flywheel, late	EA
72-0013	tappet block, alloy, for alloy cyl*	EA
72-0026	cover, ignition, finned, deep	EA
72-0027	pillar bolt, points cover, long	EA
72-0076	USE 72-0026	ea
75-	BSA PARTS	*
75-	-----	--
75-0003	USE 57-2526	ea
75-0039	USE 83-3320	ea
75-0053	USE 14-1303	ea
75-0124	USE 60-3548	ea
75-0223	USE 70-3975	ea
75-2719	USE 70-3768	ea
75-2725	USE 70-2271 or 742-158/A	ea
75-3121	USE 57-1279	ea
75-3143	USE 57-4356	ea
75-3144	USE 70-8137	ea
75-4909	USE 97-1425	ea
75-5042	USE 97-1928	ea
75-5043	USE 97-1036 & 97-0845	ea
75-5045	USE 97-1036	ea
75-5088	USE 97-0431	ea
75-5091	USE 97-3672	ea
75-5097	USE 97-3633	ea
75-5099	USE 97-1500	ea
75-5104	USE 97-0443	ea
75-5105	USE 97-0441	ea
75-5109	USE 82-4047	ea
75-5110	USE 531-25 (pair)	ea
75-5119	USE 97-2083	ea
75-5199	USE 97-2119	ea
75-5529	USE 37-0592	ea
75-6594	USE 70-2922	ea
75-6595	USE 37-1691	ea
75-6762	USE 68-6823	ea
75-8009	USE 622-04	ea
75-9045	USE 60-4254	ea
76-	BSA PARTS	*

76-----	-----	--
76-0011	USE 70-1310	ea
76-0012	USE 70-8215	ea
76-0013	stud,1/4x26,rockercov,A65x1"	EA
76-0101	USE 83-1829	ea
76-0138	washer,tab,oilpump mt,BSA	EA
76-0219	screw,tachdrive housing	EA
76-0271	USE 57-2686	ea
76-0290	USE 70-1545	ea
76-0291	USE 70-4568	ea
76-0293	USE 70-6559	ea
76-0308	USE 70-8082	ea
76-0378	USE 70-8083	ea
76-0528	USE 70-8152	ea
76-0543	USE 82-9171	ea
76-0546	USE 70-8167	ea
76-2514	USE 97-3894	ea
76-4116	USE 70-8177	ea
76-4120	USE 82-9063	ea
76-9110	rubber buffer,seat base	EA
76-9222	USE 42-8034	ea
76-9325	USE 97-2659	ea
82-	TRIUMPH AND BSA PARTS	*
82-----	-----	--
82-0623	USE 82-6738	ea
82-0839	stud,3/8x26,engine mount	EA
82-0847	stud,3/8x26	EA
82-0879	nut,1/4x26,plain *	EA
82-0929	bolt,5/16x26*	EA
82-0946	stud,double ended	EA
82-0966	bolt,shouldered,fuel tank	EA
82-0967	washer,rubber,tank mount	EA
82-0969	bolt,5/16x26,chain adjust	EA
82-0975	spring,rear stand,rigid	EA
82-0976	washer,double spring	EA
82-0977	bolt,9/16",pivot,rigidRearStand	EA
82-0987	footpeg,preunit,LH	EA
82-0991	stud,1/2x20CEI	EA
82-0994	stud,1/2x20	EA
82-1008	USE 70-1310	ea
82-1015	rod,rear brake,rigid,18-1/2" OA	EA
82-1015/A	USE 82-1015 *	ea
82-1015/B	USE 82-1015/A	ea
82-1015/C	USE 82-1015	EA
82-1015/D	rod,rear brake,rigid,11-1/2" OA	EA
82-1015/E	rod,rear brake,rigid,10-1/2" OA	EA
82-1015/SS	rod,r.brake,rigid,18-1/2" OA,stainless	EA
82-1022	USE 83-0222	ea
82-1031	bolt,3/8x26,thin head	EA
82-1213	USE 37-1690	ea
82-1335	spacer,bar mounts	EA
82-1369	bolt,1/4x26	EA
82-1511	USE 623-02	ea
82-1561	stud,3/8x26	EA
82-1605	kneepad,clipon,RH	EA
82-1605/1606	kneepad set,clip on,Tri, repl.	PR
82-1606	kneepad,clipon,LH	EA
82-1607	USE 82-3915/3916 (set)	ea
82-1607A	USE 82-3915/3916 (set)	ea
82-1667	strap,battery,curved	EA
82-1668	strap,battery,straight	EA
82-1680	stud,7/16x26	EA
82-1694	pedal,passenger peg*	EA
82-1695	USE 532-44/A	ea
82-1699	clip,muffler to frame	EA
82-1700	clip,skidplate to frame	EA
82-1711	stud,3/8x26,engine mount	EA
82-1713	washer,fibre	EA
82-1717	USE 621-54	ea
82-1730	chainguard,lower,rigidTRI	EA
82-1731	footpeg,rigid Tri,RH	EA

82-1736	tube, footpeg mount, tapered, RH	EA
82-1747	USE 21-0585	ea
82-1760	bolt, 3/8x26	EA
82-1760/SS	bolt, 3/8x26, stainless	EA
82-1792	USE 82-5343	ea
82-1808	bolt, stepped, gastank mt.	EA
82-1813	USE 82-5228	ea
82-1814	USE 532-51/A	ea
82-1823	badge, gastank, TRIUMPH, sm.	EA
82-1824	nut, 5/16x26, special	EA
82-1834	stand, rear, rigid frame Triumph	EA
82-1880	washer, copper	EA
82-1915	screw, 4BApoints&tankbadge	EA
82-1926	USE 70-3800 *	ea
82-1953	screw, 1/4x26, kneepad mtg.	EA
82-2184	washer, 3/8 flat	EA
82-2261/A	pannier frame & saddlebag set, repl.*	PR
82-2262/2263	saddlebags, TRW, L&R, repl.*	ST
82-2268	USE 82-9370	ea
82-2271	USE 82-9371 & 14-0302	ea
82-2277	USE 60-2438	ea
82-2310/2311	straps, saddlebag, L&R	ST
82-2335	bolt, 5/16x26	EA
82-2351	USE 70-2351	ea
82-2414	stud, 7/16x26, engine mount	EA
82-2551	kneepad, screwtype, LH	EA
82-2551/2552	kneepads, screwtype*	PR
82-2596	bolt, 5/16x26	EA
82-2603	bolt, 5/16x26	EA
82-2610	spring, sidestand	EA
82-2610/SS	spring, sidestand, stainless	EA
82-2687	USE 37-1690	ea
82-2698	numberplate, fr, w/chr.trim *	EA
82-2698/ER	numberplate, fr, w/alloy trim *	EA
82-2725	nut, 1/2x20	EA
82-2728	USE 82-6435	ea
82-2761	bracket, LH centre, R.mdgrd*	EA
82-2761/3/4	bracket set, rear mudguard	ST
82-2763	bracket, RH centre, R.mdgrd*	EA
82-2764	bracket, L&RH back, R.mdgrd*	EA
82-2825	stud, 3/8x26*	EA
82-2842	stud, 3/8x26	EA
82-2896	nut, brakerod, GP	EA
82-2933	parcel grid, gastank, pre56Triumph	EA
82-2936	screw, 1/4x26, parcel grid	EA
82-2936/SS	screw, 1/4x26, parcel grid, stainless	EA
82-2996	number plate, front, UKtype*	EA
82-2999	bracket, R.mudguard, centre	EA
82-3001	bracket, rearMudguard, back	EA
82-3017	USE 82-7071	ea
82-3057	USE 621-71 or 621-115	ea
82-3069	USE 82-9092	ea
82-3078	bracket, sump shield	EA
82-3080/3081	bands, tankbadge, 1949-51	PR
82-3083/3084	bands, tankbadge, 1949-54 3gal.	PR
82-3096	washer, tab, sidestand	EA
82-3097	bolt, sidestand	EA
82-3098	clip, cable	EA
82-3108	bolt, 3/8x26, gearbox pivot	EA
82-3114	hose, airfilter to carb	EA
82-3116	USE 621-71 or 621-115	ea
82-3126	mudguard, rear, SV500 army, etc.	EA
82-3158	USE 391-315738	ea
82-3179	screen, oiltank*	EA
82-3182	nut, spigot, oinline	EA
82-3186	USE 82-6628	ea
82-3187	USE 82-6628	ea
82-3216	USE 622-06	ea
82-3217/18	jackchain, oiltank cap	EA
82-3217/21	jackchain, gastank cap	EA
82-3219	USE 622-04	ea

82-3220	USE 622-04	ea
82-3223	airfilter element&cov,TRW	EA
82-3227	retainer,fastener	EA
82-3248	bolt,3/8x26,sm.head	EA
82-3281/3282	bands,tankbadge,1952-56	PR
82-3287	tank,gas,SV500 TRW	EA
82-3315	airfilter assy,rigid fr.	EA
82-3334	spigot,oiline,w/male end	EA
82-3335	spigot,fueline,90 degree	EA
82-3337	nut,spigot,fuel/oiline	EA
82-3353	spigot,fueline,25 degree	EA
82-3363	USE 82-6435	ea
82-3372	bracket,tank mt,rear,preunit	EA
82-3430	bolt,5/16x26,sm.head	EA
82-3493	sidepanel,w/screw,Cub	EA
82-3494/3495	bands,tankbadge,T15/20 3gal.	PR
82-3496	USE 82-1823	ea
82-3497	screw,3BA,tankbadge	EA
82-3498	bolt,fuel tank	EA
82-3506	USE 621-71 or 621-115	ea
82-3508	bracket,tailite&lic,T15/20,1953-61	EA
82-3564	spindle,swingarm,preunit*	EA
82-3567	USE 82-3798	ea
82-3570	chainguard,preunit s.arm,early	EA
82-3571	cover,plt,eng.mt,R,P.unit	EA
82-3574	washer,1x1-1/2"	EA
82-3575	bolt,7/16x26,gearboxPivot	EA
82-3592	stud,1/2x20CEI	EA
82-3593	footpeg,swingarm preunit,RH	EA
82-3597	rod,rear brake,CEI*	EA
82-3597/SS	rod,rear brake,CEI,stainless*	EA
82-3601	handle,lifting,54T100/110	EA
82-3617	spring,centrestand	EA
82-3617/SS	spring,centrestand,stainless	EA
82-3618	link,centrestand	EA
82-3619	bolt,1/2x20,centrestand	EA
82-3641	stud,5/16x26	EA
82-3647	USE 511-201	ea
82-3655	spigot,oiline,female end	EA
82-3658	USE 622-04/B	ea
82-3665	stud,3/8x26	EA
82-3667	nut,brakerod,CEI,knurled	EA
82-3685	mudguard,rear,1954-59,bare	EA
82-3690	bushing,swingarm,preunit Tri*	EA
82-3723	sidestand,early Triumph,9-1/2"	EA
82-3730	USE 82-4763	ea
82-3767	eyebolt,pivot pin,gbx.adj	EA
82-3770	washer,special,eng.mount	EA
82-3771	nut,flanged,mtr.mt	EA
82-3772	nut,sleeve,gbx.adjuster	EA
82-3774	bracket,torque stay,rear wh.	EA
82-3780	bolt,7/16x26	EA
82-3785	USE 511-200	ea
82-3797	rod,swingarm spindle retainer	EA
82-3798	cap,swingarm spindle retaining	EA
82-3799	USE 21-5161	ea
82-3805	bolt,5/16x26	EA
82-3808	P clamp,chainguard mtg,etc.	EA
82-3814	washer,cupped	EA
82-3815	USE 82-5229	ea
82-3857	airfilter assy,1954-59	EA
82-3861	USE 82-4141	ea
82-3874	sidepanel,preunit s.a.Tri,fbrgls.	EA
82-3875	screw,toolbox lid,chrome	EA
82-3879	fueline assy,SV500 TRW	EA
82-3896	handle,lifting,55-62preunit	EA
82-3915/3916	plates,clipon kneepad mtg*	PR
82-3917	parcel grid,gas tank,56on	EA
82-3919/3920	bands,tankbadge,late55-56 3gal.	PR
82-3955	USE 70-8194	ea
82-3967	beading,tank,1955-59 twin	EA

82-4019	washer	EA
82-4047	washer, cork	EA
82-4048	washer, cork, gas cap	EA
82-4076	bush, swingarm, T100R & Cub	EA
82-4078	washer, thrust, swingarm	EA
82-4089	chainguard, Cub, shallow	EA
82-4093	rod, rear brake, Cub	EA
82-4107	USE 82-5229	ea
82-4108	USE 82-5229	ea
82-4127	badge, tank, 57-65, LH	EA
82-4127/4128	badges, tank, 57-65 sm.tank	PR
82-4128	badge, tank, 57-65, RH	EA
82-4129	screw, 2BA	EA
82-4129/A	screw, 2BA allen, stainless	EA
82-4130	chainguard, preunit s.arm, late	EA
82-4131	USE 82-7375 ?	ea
82-4134	bracket, chainguard, front	EA
82-4136	bolt, stepped, chainguard	EA
82-4139	USE 82-4129	ea
82-4141	bracket, muffler, preunit	EA
82-4146	trim, chrome, tank, LH rear	EA
82-4148	trim, chrome, tank, LH front*	EA
82-4148/4151	trim set, tank, unit650, 1963-65	ST
82-4149	trim, chrome, tank, RH rear	EA
82-4151	trim, chrome, tank, RH front*	EA
82-4190	USE 82-7375 ?	ea
82-4195	spindle, s.arm, 500, 1959-66*	EA
82-4196	cap, swingarm spindle retainer	EA
82-4197	spacer, engine mount	EA
82-4198	USE 82-5409	ea
82-4214	footpeg, fr, LH, unit350/500	EA
82-4215	footpeg, fr, RH, unit350/500	EA
82-4222	seathing, early, hook type	EA
82-4226	plunger, seat catch*	EA
82-4226/7/8	plunger/knob assy, seat catch, compl.	EA
82-4227	knob, seat catch plunger, early*	EA
82-4228	spring, seat catch plunger	EA
82-4229	bracket, eng.mt, T100, LH, R	EA
82-4230	bracket, eng.mt, T100, RH, R	EA
82-4235	trim, chrome, tank, LH front*	EA
82-4235/6/7/8	trim set, tank, 650, 1960-62, 3gal. Imperial	ST
82-4235/7/4323/4	trim set, tank, 350/500, 1957-65	ST
82-4236	trim, chrome, tank, LH rear*	EA
82-4237	trim, chrome, tank, RH front*	EA
82-4238	trim, chrome, tank, RH rear*	EA
82-4239	USE 511-202	ea
82-4249	beading, rubber	EA
82-4275	USE 82-7333	ea
82-4276	USE 82-7334	ea
82-4283	bracket, Xpipe, early500, RH	EA
82-4284	USE 82-7706 w/14-1305 nut	ea
82-4299	washer, flat	EA
82-4304	USE 82-4763	ea
82-4309	stud, 3/8x26	EA
82-4312	USE 82-6947	ea
82-4317	clip, retaining	EA
82-4321	USE 82-6947	ea
82-4323	trim, chrome, tank, LH rear	EA
82-4324	trim, chrome, tank, RH rear	EA
82-4327	USE 82-9369	ea
82-4332	spacer, front numberplate	EA
82-4366	spacer, coil bracket	EA
82-4369	bolt, 7/16x26	EA
82-4370	washer, flat, 3/8"	EA
82-4384	rubber plug, blanking	EA
82-4385	washer, shim, swingarm, .003*	EA
82-4385/4386	shim kit, swingarm	ST
82-4386	washer, shim, swingarm, .005*	EA
82-4398	beading, tank, early3TA, etc	EA
82-4402	USE 82-5153	ea
82-4468	USE 40-8125	EA

82-4484	washer,tab,centrestand	EA
82-4497	mudguard,Cub,R,unpainted,ribbed	EA
82-4523	USE 82-6950	ea
82-4524	USE 82-6949	ea
82-4550	airfilter assy,Trials Cub,D shape	EA
82-4551	USE 691-376419	ea
82-4570	badge,tank,Tiger Cub,LH	EA
82-4571	badge,tank,Tiger Cub,RH	EA
82-4585	nut,brakerod,CEI,4 wing	EA
82-4641	rubber buffer,tank mount	EA
82-4655	strap,gastank,preunit,24-1/2"	EA
82-4656	pin,gastank mounting yoke	EA
82-4657	rubber strap,gastank mt.	EA
82-4658	mounting yoke,gastank,fr	EA
82-4659	eyebolt,gastank mounting	EA
82-4661	strap,bat.box,6V,late	EA
82-4663	USE 82-6946	ea
82-4664	badge,TIGER 110,chrome	EA
82-4665	trim,chrome,tank,LH rear	EA
82-4667	trim,chrome,tank,RH rear	EA
82-4670	link,centrestand spring	EA
82-4671	spring,centrestand	EA
82-4671/SS	spring,centrestand, stainless	EA
82-4672	hose,airfilter	EA
82-4673	airfilter assy,bathtub650	EA
82-4682	stud,3/8x26CEI	EA
82-4686	bracket,tailight&lic,bathtub	EA
82-4687	mudguard,rear,1960-62,bare	EA
82-4691	USE 511-209	ea
82-4698	airfilter assy,duplex 650	EA
82-4699	strap,gastank,preunit,23-3/4"	EA
82-4707	bracket	EA
82-4712	sidestand,early Tri,8-1/4"	EA
82-4715	USE 70-7354	ea
82-4717	nut,2BA	EA
82-4744	USE 04-0105	ea
82-4763	centerstand,preunit Tri	EA
82-4766/4767	badges,tank,60-65,lg.tank*	PR
82-4768/4769	bathtub set,3TA/5TA,steel	EA
82-4771	bolt,2BA	EA
82-4810	clip assy airfilterScreen	EA
82-4811	USE 633-01	ea
82-4812	USE 70-4576	ea
82-4852	USE 83-1279*	ea
82-4875	toolbox,T100SS	EA
82-4882	cover,toolbox,T20SM	EA
82-4891	USE 82-5153	ea
82-4893	USE 82-4655	ea
82-4898	rubber buffer,seat base,etc.	EA
82-4908	USE 621-71 or 621-115	ea
82-4916	USE 82-4699	ea
82-4917	USE 82-4655	ea
82-4971	USE 621-131	ea
82-4972	USE 621-132	ea
82-4985	USE 622-04/B	ea
82-5038	hose,airfilter toCarb,Cub	EA
82-5053	chainguard,Cub,deep	EA
82-5087	bracket,pass.peg,T100R.LH	EA
82-5088	bracket,pass.peg,T100R,RH	EA
82-5142	hose,airfilter,Cub	EA
82-5147	battery carrier,T100,60-62	EA
82-5153	centrestand,350/500,pre67w/18"	EA
82-5155	USE 622-06	ea
82-5228	rubber washer,tank mt	EA
82-5229	rubber washer,tank mt,fr.	EA
82-5247	rubber buffer,battery box	EA
82-5311	USE 82-6730	ea
82-5312	USE 82-6821	ea
82-5313	spacer tube,swingarm	EA
82-5316	bolt,5/16x26	EA
82-5333	batterybox,late 6V Tri.	EA

82-5334	USE 633-600	ea
82-5336	rubber washer,tank mt	EA
82-5337	bolt,fuel tank rear,early	EA
82-5338	nut,1/4"	EA
82-5339	fueline assy,TR6 w/Mono	EA
82-5343	bolt,3/8X26CEI,oil drain plug	EA
82-5343/A	bolt,oil drain plug,magnetic	EA
82-5343/SS	bolt,oil drain plug,magnetic,SS	EA
82-5372	USE 82-6948	ea
82-5394	sidepanel,preoilframe,LH,2hole	EA
82-5394/A	sidepanel,preoilframe,LH,no holes	EA
82-5398	beading,gastank,650,UK	EA
82-5401/5402	kneepad set,63-67 TriTwin	ST
82-5409	chainguard,350/500unit	EA
82-5412	clip,brakelight sw.spring	EA
82-5413	washer,brakelight sw.clip	EA
82-5424	handle,lifting,T100R/T120 early	EA
82-5466	rubber grommet,sidepanel	EA
82-5469	stud,7/16x26,engine mount	EA
82-5472	USE 83-0040	ea
82-5529	centrestand,3TA/5TAw/17"rim	EA
82-5532	spacer,engine mount*	EA
82-5535	bolt,3/8x26	EA
82-5536	rubber plug,chainguard	EA
82-5552	USE 82-9369	ea
82-5559	sidepanel,LH,w/2 sw.holes	EA
82-5559/A	sidepanel,LH,no sw.holes*	EA
82-5564	beading strip,small tank	EA
82-5605	bolt,7/16x26	EA
82-5665	tooltray,unit Tri,early	EA
82-5673	USE 82-6673	ea
82-5678	bolt,centrestand,1/2"	EA
82-5679	washer,centerstand	EA
82-5687	USE 82-5412	ea
82-5694	USE 633-01	ea
82-5737	USE 82-7067	ea
82-5753	grommet,turn signal,81on	EA
82-5764	USE 633-01	ea
82-5786	USE 82-7357	ea
82-5908	bracket,rear eng.mt,RH	EA
82-5909	USE 82-6069	ea
82-5910	USE 82-9624	ea
82-5924	bracket,tailight,early	EA
82-5928	USE 83-1267	ea
82-5932	centerstand,63-68 T120*	EA
82-5939	bracket,sidepanel	EA
82-5942	stud,footpeg,CEI*	EA
82-5943	pin,dowel,footpeg	EA
82-5944	washer,tab,swingarm bolt	EA
82-5955	mudguard,preoil Tri.R,alloy,straight	EA
82-5956	USE 633-389	ea
82-5957	USE 633-389	ea
82-5958	adaptor,air filt,Amal#389	EA
82-5968	mudguard,preoil Tri.R,alloy,beaded	EA
82-5983	bracket	EA
82-5984	USE 82-8144	ea
82-5994	clip,rear mudguard mount	EA
82-6031	plate,backing,R.mudguard	EA
82-6039	rubber mount	EA
82-6042	bush,swingarm,1963-70 650*	EA
82-6046	chainguard extension,fr	EA
82-6064	lever,brake rod operating	EA
82-6066	bracket,rear eng.mt,LH,w pedal boss*	EA
82-6066/A	bracket,rear eng.mt,LH,no pedal boss*	EA
82-6069	footpeg,fr,1963-70 650,LH	EA
82-6070	nut,brakerod,CEI,2 wing	EA
82-6074	clamp,airfilter,389/900	EA
82-6103	USE 82-3655	ea
82-6147	bracket,oiltank	EA
82-6150	USE 21-0620 w/21-0545	ea
82-6195	USE 82-6946	ea

82-6257	USE 82-7067	ea
82-6310	washer,1/4",large dia.	EA
82-6313	beading,gastank,5TA etc.	EA
82-6409	mount,folding peg,fr,LH	EA
82-6410	mount,folding peg,fr,RH	EA
82-6411	pedal,footrest,folding F	EA
82-6430	USE 633-600	ea
82-6431	USE 633-389	ea
82-6432	USE 633-389	ea
82-6433	USE 633-600	ea
82-6435	bracket,tailight,early	EA
82-6470	number plate,front,UKtype,w/mtg.clips	EA
82-6498	stud,7/16x26	EA
82-6628	oiltank,rigid frame Tri.	EA
82-6653	USE separate components	ea
82-6654	USE separate components	ea
82-6655	bolt,pivot,footpeg,CEI *	EA
82-6659	USE 82-4227	ea
82-6664	USE 82-5665	ea
82-6672	USE 82-7510 (+14-0301)	ea
82-6673	grommet,rubber	EA
82-6730	washer,swingarm,standard thickness*	EA
82-6738	lock,forks,w/keys	EA
82-6738/A	keyblank,forklock,EJR type	EA
82-6738/ER	lock,forks,w/keys,econo.repl.	EA
82-6784	grommet,cables & wire	EA
82-6821	swingarm pivot sleeve	EA
82-6847	bracket,tailight,alloy	EA
82-6849	plate,tailight housing	EA
82-6850	bracket,licence plate	EA
82-6851	bracket,fender,rear	EA
82-6866	USE 633-01	ea
82-6877	USE 83-3290	ea
82-6887	badge,tank,65-68 twin,LH,repl.*	EA
82-6888	badge,tank,65-68 twin,RH,repl.*	EA
82-6897	bracket,retaining,bat box,top,66/67	EA
82-6898	bracket,oiltank mt,bottom	EA
82-6901	tooltray,plastic	EA
82-6915	bracket,mudguard bridge,R	EA
82-6916	bracket,mudguard,rear	EA
82-6930	USE 82-6962 *	ea
82-6931	sidepanel,LH,2hole,1966 650cc only*	EA
82-6931/A	sidepanel,LH,2hole,1966 500cc only	EA
82-6936	USE 82-7375	ea
82-6940	USE 82-7357	ea
82-6943	bracket,coil,LH	EA
82-6944	bracket,coil,RH	EA
82-6946	badge,THUNDERBIRD,chrome	EA
82-6947	badge,TWENTYONE,chrome	EA
82-6948	badge,TIGER 90,chrome	EA
82-6949	badge,TIGER 100,chrome	EA
82-6950	badge,SPEEDTWIN,chrome	EA
82-6962	sidepanel,LH,no holes,TR6C,etc.	EA
82-6964	sidepanel,LH,no holes,T100C,etc.	EA
82-6965	mudguard,preoil Tri.R,bare	EA
82-6967	mudguard,preoil Tri.R,stainless	EA
82-6968	rubber washer	EA
82-6981	USE 391-54335169	ea
82-6986	mudguard,Cub,R,unpainted	EA
82-7018	USE 83-1590	ea
82-7019	USE 83-1591	ea
82-7021	bolt,3/8x24,sidestand	EA
82-7036	eyebolt,sidepanel,T102TT,etc.	EA
82-7067	chainguard,POIF T120,deep	EA
82-7067/CHR	chainguard,POIF T120,chrome	EA
82-7071	spacer tube,7lon A65 tank	EA
82-7129	USE 511-204	ea
82-7155	steering stop	EA
82-7270	gaiter,swingarm pivot,500	EA
82-7290	bracket,rear brake stay	EA
82-7333	bracket,engine mt,frontLH	EA

82-7334	bracket,engine mt,frontRH	EA
82-7342	spindle,swingarm,500,66on*	EA
82-7343	washer,tab,swingarm,T100R	EA
82-7352	hose,chainoiler,30"	EA
82-7353	hose,vent	EA
82-7354	sidestand,pre 68 Triumph	EA
82-7356	USE 82-3723	ea
82-7357	sidestand,pre 68 Triumph	EA
82-7359	sidepanel,LH,1sw.hole	EA
82-7359/ER	sidepanel,LH,1sw.hole,fbrgls	EA
82-7361	sidepanel,LH,lhole,67 500cc only	EA
82-7365	bracket,torqueStay,Rwheel	EA
82-7373	USE 82-7357	ea
82-7375	swingarm,350/500 unit	EA
82-7380	USE 83-7235	ea
82-7383	bracket,bat.box fr,66/67 style	EA
82-7384	bracket,bat.box rear,66/67 style	EA
82-7386	rod,rear brake,UNF	EA
82-7386/SS	rod,rear brake,UNF, stainless	EA
82-7387	nut,UNF,brakerod adj.	EA
82-7388	bolt,tank mount,rear	EA
82-7389	nut,7/16X20,flanged,rear eng.mt	EA
82-7390	USE 83-1279*	ea
82-7395	beading,tank,T100R,early	EA
82-7482	USE 511-257/D	ea
82-7489	USE 512-07	ea
82-7510	stud,oiltank mt.	EA
82-7549	clamp,mounting	EA
82-7550	clamp,mounting	EA
82-7552	USE 344-01	ea
82-7560	knob & plunger,seat catch*	EA
82-7632	USE 633-02	ea
82-7675	washer,swingarm pivot,oversize*	EA
82-7692	USE 82-7693	ea
82-7693	centrestand,1967onTri.500	EA
82-7703	pedal,rear brake,unit 500	EA
82-7705	abutement,threaded	EA
82-7706	spindle,brake pedal pivot	EA
82-7707	USE 82-5409	ea
82-7772	USE 633-600	ea
82-7774	spacer,swingarm	EA
82-7776	USE 511-211	ea
82-7826	protector,mudguard wiring	EA
82-7835	rubber buffer	EA
82-7836	USE 83-3290	ea
82-7848	washer,cup,swingarm pivot*	EA
82-7849	USE 83-1560	ea
82-7850	USE 82-7860	ea
82-7860	handle,lifting,T100R/T120 late	EA
82-7862	seathing,short,rear	EA
82-7888	screw,2BA,Philip	EA
82-7888/A	screw,2BA allen,stainless	EA
82-7994	rubber plug,ign.sw.	EA
82-8018	USE 633-900/A	ea
82-8024	battery carrier,preoil12V	EA
82-8026	seathing,long,front	EA
82-8028	bracket,battery box	EA
82-8031	rubber strip	EA
82-8032	buckle,battery strap	EA
82-8033	USE 82-9353	ea
82-8034	nut,sleeve,battery box	EA
82-8042	USE 83-1358	ea
82-8044	USE 83-1357	ea
82-8046	USE 82-6673	ea
82-8082	bracket,cond.pk.to frame	EA
82-8090	oring,swingarm pivot	EA
82-8091	rubber tray,battery box	EA
82-8121	bracket,tailight & licence	EA
82-8126	USE 82-8144	ea
82-8132	spacer,sidepanel knob	EA
82-8139	bracket,tailight,alloy	EA

82-8140	rubber pad,reflector	EA
82-8143	mudguard,preoil Tri.R,unpainted	EA
82-8143/CHR	mudguard,preoil Tri.R,chrome *	EA
82-8144	mudguard,preoil Tri.rear,SS	EA
82-8192	USE 82-8192/8193 (set)	ea
82-8192/8193	kneepad set,1968on T120	PR
82-8193	USE 82-8192/8193 (set)	ea
82-8194	housing,reflector,fr,68-70 style*	EA
82-8195	retainer clip,reflector	EA
82-8196	USE 633-900	ea
82-8198	USE 70-7351	ea
82-8204	USE 511-257/A	ea
82-8245	clip,retaining	EA
82-8250	screw,1/8x40BSW	EA
82-8253	USE 83-0254	ea
82-8255	rubber,battery box	EA
82-8271	bracket,reflector mount	EA
82-8273	USE 391-57111	ea
82-8283	bracket,speedometer,BSA	EA
82-8291	bracket,sidepanel,A65L	EA
82-8319	USE 391-54170009	ea
82-8320	USE 391-54483156	ea
82-8347	bracket,mudguard,LH rear	EA
82-8348	bracket,mudguard,RH rear	EA
82-8366	USE 68-6856/CHR *	ea
82-8367	USE 68-6856/CHR *	ea
82-8382	spring,sidestand	EA
82-8382/CHR	spring,sidestand,chrome,econo	EA
82-8382/SS	spring,sidestand,stainless	EA
82-8386	USE 82-9850	ea
82-8387	USE 82-9851	ea
82-8392	bracket,fenderstay,70B44SS*	EA
82-8393	bracket,fender stay,centre	EA
82-8394	bracket,fenderstay,70B44V	EA
82-8396	bracket,muffler,68A65F,LH	EA
82-8397	bracket,muffler,68A65F,RH	EA
82-8398	sidepanel,A75 LH,early *	EA
82-8399	sidepanel,A75,RH,early *	EA
82-8401	USE 633-900/A	ea
82-8402	USE 633-600/A	ea
82-8408	fueline assy,A50R/65Tto71	EA
82-8409	fueline assy,A65L,pre1971	EA
82-8413	USE 83-1628	ea
82-8436	USE 82-6039	ea
82-8446	USE 68-8150	ea
82-8448	mount,folding peg,fr	EA
82-8459	USE 414-113/A (set)	ea
82-8463	batterybox,A75/X75	EA
82-8468	spindle,swingarm,A75	EA
82-8475	bush,swingarm,A75	EA
82-8476	spacer tube,swingarm,A75*	EA
82-8477	dustcover,swingarm,A75	EA
82-8478	washer,thrust,swingarm,bronze	EA
82-8485	grabrail,A75,early	EA
82-8490	chainguard,A75,early type	EA
82-8495	toolbox,A75	EA
82-8498	bracket,fenderstay,1 hole	EA
82-8513	pin,brakepedal stop,A75	EA
82-8518	bracket,bridge,r.mudguard,A75	EA
82-8519	rod,muffler support,A75R	EA
82-8520	USE 82-9772	ea
82-8528	mudguard,rear,pre71 A75,unpainted	EA
82-8549	bracket,coil,A75,X75	EA
82-8581	USE 83-1535	ea
82-8582	coupling,centrestand,A75	EA
82-8583	bracket,muffler,A75 RH	EA
82-8584	bracket,muffler,A75 LH	EA
82-8588	panel,gastank,A75 LH	EA
82-8589	panel,gastank,A75 RH	EA
82-8590/8591	kneepad set,A75	PR
82-8592	USE 623-10	ea

82-8609	tankstrip,A75 large tank	EA
82-8610	badge,gastank,LH,A75	EA
82-8611	badge,gastank,RH,A75	EA
82-8614	sidepanel,Victor style,LH, fibreglas *	EA
82-8627	USE 68-8368	ea
82-8628	cover,oilcooler,A75,LH*	EA
82-8628/8629	covers,oilcooler,A75,pre71	PR
82-8629	cover,oilcooler,A75,RH	EA
82-8631	clip,beading	EA
82-8657	rubber bush,oilcooler,A75	EA
82-8660	USE 42-4778	ea
82-8686	centrestand,pre71 1cyl.	EA
82-8718	fueline assy,unit 1cyl.	EA
82-8743	hose,breather,A75	EA
82-8819	skidplate,B44VS,1968-70	EA
82-8850	USE 82-8398	ea
82-8873	USE 391-57111	ea
82-8889	USE 82-8409	ea
82-8918	bush,brakepedal,A75	EA
82-8946	USE 70-8086	ea
82-8950	USE 82-9743	ea
82-8969/9675	airfilter box assy,A75 pre71	EA
82-8975	USE 742-112/A	ea
82-8976	USE 71-2465	ea
82-8977	screw,finned clip	EA
82-8978	USE 82-4717	ea
82-8981	washer,5/16"flat,small OD	EA
82-8986	USE 60-2429	ea
82-8987	USE 00-0003	ea
82-8988	cup,steering head,BSA *	EA
82-8993	bush,silentbloc,swingarm	EA
82-8994	spindle,swingarm,POIF1cyl	EA
82-8995	nut,swingarm spindle,BSA	EA
82-8996	washer,13/16"lock	EA
82-8997	bolt,3/8x26	EA
82-8998	washer,3/8"flat	EA
82-9000	USE 633-900	ea
82-9001	oring,airfilter*	EA
82-9003	USE 92-8091	ea
82-9004	hook,battery strap *	EA
82-9005	strap,battery,18 inch *	EA
82-9010	washer,3/8"flat	EA
82-9016	USE 90-6580	ea
82-9017	USE 03-1156	EA
82-9019	USE 04-0137	ea
82-9020	USE 60-2427	ea
82-9023	USE 82-2335	EA
82-9028	grommet	EA
82-9029	USE 06-7635	ea
82-9031	pedal,rear brake,POIF1cyl	EA
82-9033	nut,7/16x20CEI*	EA
82-9034	washer,lock	EA
82-9036	rod,rear brake,pre71 1cyl	EA
82-9038	pin,brake arm,BSA	EA
82-9039	nut,brakerod,pre71 BSA	EA
82-9041	USE 60-2427	ea
82-9042	nut	EA
82-9043	pedal,footrest,folding F	EA
82-9044	pivot,footpeg,rear	EA
82-9045	bolt,3/8x26	EA
82-9046	washer,3/8" flat	EA
82-9047	stud,LH thread,splined,footpeg,1cyl*	EA
82-9048	plate,locking,footrest,LH	EA
82-9048/ER	plate,locking,footrest,LH,econo	EA
82-9049	USE 60-2323	ea
82-9050	nut,7/16x20,LH thread	EA
82-9050/ER	nut,7/16x20,LH thread,econo.repl.	EA
82-9051	USE 532-75	ea
82-9053	USE 83-7059	ea
82-9054	USE 532-38	ea
82-9055	pivot,pass.peg,pre71 1cyl,LH	EA

82-9057	USE 65-0109	ea
82-9059	chainguard,TriBSA 1cyl,pre69	EA
82-9060	bolt,1/4x26	EA
82-9061	USE 82-9690	ea
82-9062	rubber,gastank steady,convex	EA
82-9063	spacer tube,tank mounting	EA
82-9064	rubber,gas tank mounting	EA
82-9065	washer,5/16"flat	EA
82-9067	bolt,	EA
82-9068	USE 70-3290	ea
82-9070	washer,fibre	EA
82-9071	filter screen,oiltank1cyl	EA
82-9075	USE 82-9659	ea
82-9076	USE 82-4047	ea
82-9089	washer,9/16"	EA
82-9090	tooltray,pre71 TriBSA1cyl	EA
82-9092	spacer,5/16x.232	EA
82-9093	rubber buffer	EA
82-9094	bracket,sidepanel,1cyl.	EA
82-9124	pivot bar,centrestand	EA
82-9128	bolt,"T",muffler clamp*	EA
82-9130	USE 06-0681	ea
82-9131	tooltray,A50/65,1965-70	EA
82-9133	bracket,R.peg,RH,B44	EA
82-9134	rubber,"U"shape,gastank mt	EA
82-9146	USE 70-4594	ea
82-9171	screw,2BA	EA
82-9172	USE 60-4256	ea
82-9173	USE 21-5161	ea
82-9174	spacer,instr.mt,pre71 BSA	EA
82-9192	chainguard69-70,A50/65	EA
82-9192/CHR	chainguard,pre'71,A50/65,chrome	EA
82-9196	spacer	EA
82-9198	bracket,licence plate	EA
82-9204	washer,fibre,fueltap,lg.	EA
82-9222	USE 83-4931	ea
82-9224	USE 624-34 *	ea
82-9255	bracket,bat.box.	EA
82-9266	USE 21-2083, w/21-7091 nut	ea
82-9279	USE 532-23/A	ea
82-9298	USE 82-1808	ea
82-9308	USE 83-1761	ea
82-9315	oilcooler,3cylinderTriBSA	EA
82-9317	bracket,oilcooler mount,Trident	EA
82-9321	rubber washer,oil cooler	EA
82-9322	rubber buffer,oil cooler	EA
82-9323	bolt,shoulder,oilcooler	EA
82-9343	battery carrier,T150	EA
82-9351	grommet,rubber	EA
82-9353	strap,battery holddown,12"*	EA
82-9354	USE 82-9355	ea
82-9355	buckle,battery strap	EA
82-9356	grabrail,T150,pre70	EA
82-9360	badge,tank,T150UK,LH	EA
82-9360/9361	badges,tank,T150,UK type	PR
82-9361	badge,tank,T150UK,RH	EA
82-9362	sidepanel,early T150,LH	EA
82-9363	sidepanel,early T150,RH	EA
82-9365	USE 83-1267	ea
82-9369	footpeg assembly,rear,w/rubber	EA
82-9369/ER	footpegs,rear,w/rubber,econo repl.	PR
82-9370	mounting lug,rear footpeg *	EA
82-9371	screw,footrest pivot,UNF	EA
82-9372/3	kneepad set,T150 UK tank	PR
82-9383	USE 83-3231	ea
82-9387	bolt,stepped,chainguard	EA
82-9430	USE 82-3179	ea
82-9435	screw,oil metering	EA
82-9436	fueline assy,3cylinder	EA
82-9440	rod,muffler support,T150	EA
82-9442	USE 82-6968	ea

82-9445	knob,LH sidecov,T150/T160	EA
82-9446	USE 21-1883 & 14-1202	ea
82-9449	tensioner,tank band,T150	EA
82-9450	tankstrip,T150 UK,plastic	EA
82-9451	beading strip,tank trim	EA
82-9472	USE 511-208	ea
82-9477	sidepanel,LH TR25W,68&69	EA
82-9478	sidepanel,RH TR25W,68&69	EA
82-9480	tankstrip,TR25W	EA
82-9498	grabrail,1968 T120,etc.	EA
82-9502	USE 511-257/A	ea
82-9530	spring,protective,5/16"oiline*	EA
82-9530/A	spring,protective,3/8"oiline	EA
82-9531	spring,protective,7/16" oiline	EA
82-9532	swingarm,A50/65,1969&70	EA
82-9536	spacer,swingarm,LH,A50/65	EA
82-9537	spacer,swingarm,RH,A50/65	EA
82-9538	spacer tube,swingarm,A65	EA
82-9539	nut & lockplate,swingarm	EA
82-9541	USE 82-5944	ea
82-9543	rubber washer,tank mt*	EA
82-9561	grommet,ignition coil mt.	EA
82-9562	grommet,airfilter to carb	EA
82-9563	hose,breather,T150	EA
82-9571	rubber backing,reflector*	EA
82-9573	nut,4BA,flat,reflector mt	EA
82-9588	bracket,oiltank,T150 bot.	EA
82-9590	nut,fixed,side panel,3cyl	EA
82-9591	beading,LH sidepanel,T150	EA
82-9592	beading,RH sidepanel,T150	EA
82-9600	USE 68-6803 & 68-9327	ea
82-9602	USE 532-21/A	ea
82-9603	USE 532-38/A	ea
82-9608	USE 532-75/A	ea
82-9609	tank,gas,69A65F,B25	EA
82-9610	bracket,mudguard,LH	EA
82-9611	USE 621-121	ea
82-9623	footpeg,front,T150,LH	EA
82-9624	footpeg,fr,650 & 3 cyl,RH	EA
82-9625	footpeg,front,Rocket 3,LH	EA
82-9629	USE 82-5908	ea
82-9630	USE 532-23/C	ea
82-9635	pedal,rear brake,T150	EA
82-9637	USE 83-1810	ea
82-9642	bracket,mtr.mt,A75,LHrear	EA
82-9650	toolbox,T150,pre69	EA
82-9652	bush,metalastic,frame	EA
82-9653	bolt,anchor,rear pegs,A75	EA
82-9654	sleeve,ign. coil mounting	EA
82-9659	cap & dipstick,oil tank,zinc	EA
82-9665	shaft,brake pedal,A75	EA
82-9667	USE 82-7386	ea
82-9675	airfilter housing,A75	EA
82-9682	bracket,airfilter mt,A75	EA
82-9684	skidplate,A75	EA
82-9686	USE 532-21 *	ea
82-9687	bracket,oilcooler,A75early	EA
82-9690	rubber,"U"shape,tankmount	EA
82-9695	badge,tank,LH	EA
82-9695/9696	badges,tank,BSA diecast,gold	PR
82-9695/9696/ER	badges,tank,BSA economy	PR
82-9696	badge,tank,RH	EA
82-9700	badge,gastank,RH,repl.	EA
82-9700/9701	badges,gastank,genuine*	ST
82-9701	badge,gastank,LH,repl.	EA
82-9708	tank,gas,TR6,Pre 1971,lg	EA
82-9715	USE 512-07	ea
82-9721	beading,fuel tank,B25type	EA
82-9722	kneepad,B25 type tank,LH	EA
82-9722/9723	kneepad set,B25 type tank	ST
82-9724	sidepanel,LH A65Firebird,steel	EA

82-9729	tank,gas,B44SS	EA
82-9732	USE 511-306	ea
82-9736	USE 82-6069	ea
82-9743	oiltank,B25,etc.	EA
82-9746	bracket,gastank steady	EA
82-9747	rubbers,"U"shape,tankmount*	ST
82-9748	rubbers,"U"shape,tankmount*	EA
82-9753	USE 82-7067	ea
82-9770	rubber buffer,side panel	EA
82-9771	bracket,mudguard,RH	EA
82-9772	bracket,fender to forkleg	EA
82-9773	frame assy,BSA Rocket 3	EA
82-9782	USE 83-3318	ea
82-9784	bolt,tank mount,centre	EA
82-9788	bracket,engine mount	EA
82-9791	rubber,"U"shape,tankmount	EA
82-9792	rubber,"U"shape,tankmount	EA
82-9796	bracket,fuel tank mount	EA
82-9805	sidepanel,A65L/S,LH steel	EA
82-9806	sidepanel,A65L/S/F,RH steel	EA
82-9845	USE 70-9138 *	ea
82-9846	USE 82-9850	ea
82-9847	USE 82-9851	ea
82-9850	sidepanel,1carb,LH,66-70,steel	EA
82-9851	sidepanel,1carb,RH,66-70,steel	EA
82-9907	USE 82-9571	ea
82-9918	clip,wiring,metal	EA
82-9919	rubber,"U"shape,tank mt	EA
82-9920	rubber,"U"shape,tank mt.	EA
82-9945	bracket,muffler,1cylPre71	EA
82-9950	chaingrd,TRIBSA1cyl,69-70	EA
82-9952	USE 82-9950 *	ea
82-9963	swingarm,A75R	EA
82-9964	USE 83-1829	ea
82-9967	USE 68-6803 & 68-9327	ea
82-9988	USE 68-6856/CHR	ea
82-9989	USE 68-6856/CHR	ea
82-9996	USE 511-257/A	ea
83-	TRIUMPH AND BSA PARTS	*
83-----	-----	---
83-0002	washer,flat	EA
83-0006	nut,1/4BSP,fuel tap locknut	EA
83-0007	beading,tank,T100R	EA
83-0007/SS	beading,tank,T100R,stainless	EA
83-0008	hook,tank beading*	EA
83-0031	beading,gastank,T120R,US	EA
83-0031/SS	beading,gastank,T120R,US,stainless	EA
83-0032	tankstrip,pre71 650UK	EA
83-0032/SS	tankstrip,pre71650UK,stainless	EA
83-0033	screw,2BA	EA
83-0035	lug,mounting,sidestand,weldon*	EA
83-0035/A	lug,mounting,sidestand,clampon*	EA
83-0035/B	tab,mounting,sidestand,weldon*	EA
83-0037	spacer,plastic,swingarm	EA
83-0040	skidplate,TR6C,pre71	EA
83-0045/A	swingarm,T150,63-70T120,box section	EA
83-0216	numberplate,fr,UK type *	EA
83-0222	nut,1/4UNF,captive	EA
83-0245	USE 71-0245	ea
83-0250	spacer	EA
83-0251	USE 83-0254	ea
83-0254	bracket,tailight,alloy	EA
83-0256	footrest,B25,pre'71	EA
83-0260	rubber grommet,tank mt.	EA
83-0270	USE 83-0254	ea
83-0281	rubber cup,instr mt,reinforced	EA
83-0281/ER	rubber cup,instr mt,econo.replacement*	EA
83-1254	bracket,large,dual horn,T120*	EA
83-1254/A	bracket,small,dual horn,T120*	EA
83-1267	centerstand,69/70 T120+T150/160	EA
83-1270	washer,tab,centrestand	EA

83-1279	skidplate,T100C	EA
83-1284	USE separate components	ea
83-1285	USE separate components	ea
83-1286	USE 82-6409 *	ea
83-1287	USE 82-6410 *	ea
83-1318	rubber,swingarm sealing*	EA
83-1339	screw,2BA	EA
83-1339/A	screw,2BA allen,stainless	EA
83-1340	USE 82-9701	ea
83-1341	USE 82-9700	ea
83-1348	clip,sidepanel knob	EA
83-1356	bracket,eng.mount,front	EA
83-1356/A	brackets,eng.mt,fr,70TR6/120,alloy	PR
83-1357	knob,sidepanel	EA
83-1358	sidepanel,LH,w/tool tray*	EA
83-1358/ER	sidepanel,LH,fibreglas	EA
83-1377	washer,rubber	EA
83-1384	bracket,coil,A75	EA
83-1387	USE 68-8328	ea
83-1428	mount,footpeg,folding,singles,RH	EA
83-1430	oddie stud,A75 sidepanel	EA
83-1450	USE 82-9695	ea
83-1451	USE 82-9696	ea
83-1452	USE 83-1458	ea
83-1454	USE 83-1459	ea
83-1458	sidepanel,LH B25 & B44SS	EA
83-1459	sidepanel,RH B25 & B44SS	EA
83-1461	rubber buffer,long	EA
83-1512	chainguard,POIF T120,shallow	EA
83-1513	bracket,eng.mt,top,69/70 B25	EA
83-1515	USE 42-4778 *	ea
83-1517	USE 82-5944	ea
83-1529	bracket,licence plate,bot	EA
83-1533	bracket,coil	EA
83-1535	pivot bar,centrestand,A75,stainless	EA
83-1536	USE 633-900	ea
83-1537	USE 633-900/A	ea
83-1538	USE 83-1458	ea
83-1539	USE 83-1459	ea
83-1547	USE 622-09	ea
83-1549	bracket,oiltank top,T160	EA
83-1560	sidestand,2&3 cyl,1968-82	EA
83-1560/CHR	sidestand,2&3 cyl,1968-82,chrome	EA
83-1560/SS	sidestand,2&3 cyl,1968-82,stainless*	EA
83-1564	USE 83-1779	ea
83-1565	USE 82-7365	ea
83-1566	USE 83-1780	ea
83-1567	USE 83-1780	ea
83-1571	grabrail assembly,chrome&blk.	EA
83-1571/A	grabrail assembly,chrome	EA
83-1571/ER	grabrail assy,chrome&blk,econo	EA
83-1573	USE 511-257	ea
83-1576	frame,A50/65,pre 1971*	EA
83-1585	rubber spacer,oiltank mt.	EA
83-1590	footpeg,front,folding,LH	EA
83-1591	footpeg,folding,front,RH	EA
83-1594	bracket,rear engine mount	EA
83-1597	bracket,r.eng.mt,LH,POIF	EA
83-1603	bracket,coil,1-1/2"	EA
83-1604	USE 83-1606	ea
83-1606	sidestand,TriBSA1cylpre71	EA
83-1609	USE 633-600	ea
83-1610	fitting,"T",breather,stepped	EA
83-1613	hose,breather	EA
83-1614	hose,breather,rear mudguard,39"*	EA
83-1615	clip,breather hose	EA
83-1618	USE 82-8144	ea
83-1619	USE 82-8144	ea
83-1628	centerstand,A75	EA
83-1632	USE 82-8528	ea
83-1636	USE 82-8121	ea

83-1641	USE 83-1810	ea
83-1651	USE 68-8368	ea
83-1658	rubber,gastank,"U" type	EA
83-1660	USE 621-121	ea
83-1673	tankstrip,T150 UK,alloy	EA
83-1687	bracket,torqueStay,Rwheel	EA
83-1710	USE 06-0847	ea
83-1752	USE 82-7386	ea
83-1761	oiltank,T150,all	EA
83-1763	USE 83-3290	ea
83-1779	bracket,torquestay,Rwheel	EA
83-1780	bracket,torquestay,Rwheel	EA
83-1810	pedal,brake,Rocket 3	EA
83-1829	washer,rubber	EA
83-1925	USE 82-7386 & 82-7387	ea
83-2006	grommet	EA
83-2007	washer,steering head brg.*	EA
83-2012	sleeve,swingarm bearing	EA
83-2013	USE 83-3554	ea
83-2018	battery carrier,250/500 OIF	EA
83-2029	USE 83-4856	ea
83-2031	USE 83-4857	ea
83-2034	beading,gastank,T150,US	EA
83-2035	toolbox,T150,73on	EA
83-2039	USE 511-257	ea
83-2040	pedal,brake,71onB25/50	EA
83-2042	USE 83-3541	ea
83-2110	bracket,mtr.mt.LHrear,71onA65	EA
83-2111	bracket,mtr.mt.RHrear,71onA65	EA
83-2204	grommet,rubber	EA
83-2209	rubber mt,hdlight bracket	EA
83-2210	washer,headlight mount	EA
83-2211	spacer,headlight bracket	EA
83-2216	USE 83-2210	ea
83-2224	chainguard,250/500 OIF	EA
83-2228	skidplate,71on 1 cylinder	EA
83-2233	washer,thrust,swingarm	EA
83-2239	USE 512-07 *	ea
83-2244	oilseal,swingarm spindle	EA
83-2245	bearing,needle	EA
83-2263	USE 83-4092	ea
83-2266	washer,rear axle	EA
83-2502	USE 83-4673	ea
83-2504	USE 83-4675	ea
83-2507	hose,airfilter,B50 etc.	EA
83-2508	screw,shouldered,bat.box	EA
83-2512	USE 83-3325	ea
83-2521	bush,swingarm,oil frame*	EA
83-2569	grommet,flasher control	EA
83-2571	USE 83-7502	ea
83-2597	spring,leaf,seat latch	EA
83-2602	spacer,footpeg bolt	EA
83-2616	rod,rear brake,71on 1cyl.	EA
83-2621	USE 511-305	ea
83-2623	hose,LH airfilter,71-A65L	EA
83-2624	hose,RH airfilter,71-A65L	EA
83-2625	connector,airfilter,TR6	EA
83-2626	hose,airfilter,T120,71on	EA
83-2627	USE 83-4941	ea
83-2640	chainguard,71on A65	EA
83-2641	chainguard,71on 650/750,black*	EA
83-2641/CHR	chainguard,71on6/750,chrome	EA
83-2641/ER	chainguard,71on6/750,econo repl.	EA
83-2647	USE 83-7040 *	ea
83-2656	bracket,torque stay,rear wh.	EA
83-2666	pedal,brake,71-74 6/750 2	EA
83-2671	tooltray,B25/B50,71on	EA
83-2674	chainguard extension,B50	EA
83-2689	spacer,swingarm,LH	EA
83-2690	spacer,swingarm,RH	EA
83-2691	pivot shaft,swingarm,OIF*	EA

83-2692	rubber sleeve,swingarm	EA
83-2693	housing,tailamp,singles,1971/72	EA
83-2716	hose,filter,7lon 250	EA
83-2726	number plate,rear,UK	EA
83-2727	bracket,licence plate,LH	EA
83-2728	bracket,licence plate,RH	EA
83-2736	housing,tailamp,A75,1971on	EA
83-2751	cover,filter,T120 &A65L,L	EA
83-2752	cover,filter,T120 &A65L,R	EA
83-2768	grabrail,oilframe650,w/refl.gussets*	EA
83-2768/A	grabrail assy,oilframe650,w/refl.tabs*	EA
83-2776	bolt,gastank,71 A65&B50	EA
83-2786	housing,tailamp,71/72 650	EA
83-2796	bracket,mudguard,rear	EA
83-2799	USE 82-8245	ea
83-2800	USE 621-132	ea
83-2801	USE 621-131	ea
83-2826	USE 83-3815,3642 &14-0113	ea
83-2829	gasket,oilframe sump	EA
83-2834	USE 324-92	ea
83-2839	cover,filter,TR6 &A65T,LH	EA
83-2840	cover,filter,TR6 &A65T,RH	EA
83-2841	footpeg assembly,rear*	EA
83-2844	bracket,eng.mt,top,A65,OIF	EA
83-2846	spacer,eng.mt,rear LH	EA
83-2847	spacer,eng.mt,rear RH	EA
83-2848	spacer,eng.mt,front LH	EA
83-2849	spacer,eng.mt,front RH	EA
83-2854	USE 83-7040	ea
83-2855	USE 83-7040	ea
83-2856	USE separate components	ea
83-2857	USE separate components	ea
83-2858	mount,folding peg,fr,LH	EA
83-2859	mount,folding peg,fr,RH	EA
83-2860	rod,rear brake,oilframe	EA
83-2860/SS	rod,rear brake,stainless	EA
83-2867	USE 83-4782	ea
83-2874	USE 83-0222*	ea
83-2876	USE 83-2995	ea
83-2877	housing,tailamp,T150/T100,1971/72	EA
83-2879	USE 83-5147 *	ea
83-2896	spring,stand	EA
83-2898	USE 83-2896	ea
83-2903	housing,reflector,fr,7lonT100 style	EA
83-2937	sidepanel,LH,lcyl,7lon,fbrgls	EA
83-2938	sidepanel,RH,lcyl,1971 on,fbrgls	EA
83-2980	rubber,"U"shape,tank mt	EA
83-2995	mudguard,R.71 T100,stain.	EA
83-2996	tank,gas,TR6/T120,1971/72	EA
83-3013	footrest assy,folding,RH	EA
83-3014	oilseal,sw.arm,71 on lcyl&TR5T	EA
83-3021	USE 83-4932	ea
83-3023	bracket,eng.mt,LH rear	EA
83-3024	bracket,eng.mt,RH rear	EA
83-3031	USE 83-4857	ea
83-3042	bolt,tank mt,centre	EA
83-3046	dipstick,oilframe singles	EA
83-3055	USE 83-3147	ea
83-3056	beading,gastank,7lon lcyl	EA
83-3057	tankstrip,alloy,71-A65	EA
83-3061	seatcatch assy,7lon 650	EA
83-3068	rubber plug,tank centre,blank	EA
83-3068/A	rubber plug,tank centre,w/TRIUMPH logo	EA
83-3068/ER	rubber plug,tank centre,blank,econo	EA
83-3069	rubber plug,tankCentre,lg	EA
83-3082	plate,chain adjuster	EA
83-3092	pedal,footrest,folding F	EA
83-3095	spring,folding footrest	EA
83-3133	spacer,tank mounting	EA
83-3134	beading,gastank,front,US,chrome	EA
83-3134/SS	beading,gastank,front,US,stainless	EA

83-3135	beading,gastank,rear,chrome	EA
83-3135/SS	beading,gastank,rear, stainless	EA
83-3136	skidplate,A65F,1971on	EA
83-3139	footrest assy,folding,RH	EA
83-3140	USE 83-2859	ea
83-3142	dipstick,oilframe 650	EA
83-3146	USE 68-8158	ea
83-3147	beading,gastank,11" long	EA
83-3154	fueline assy,T150 US	EA
83-3158	USE 83-3858*	ea
83-3160	mudguard,rear,71/2 A75,chrome	EA
83-3162	USE 83-4278	ea
83-3174	grabrail assy,250/500,71on	EA
83-3181	beading,gastank,fr,UK	EA
83-3182	beading,gastank,rear,UK	EA
83-3207	USE 83-7602	ea
83-3211	USE 83-3213/A	ea
83-3212	USE 83-3213/A	ea
83-3213	beading,tailamp,71/72 type	EA
83-3213/A	beading,tailite,numberplate,etc.	FT
83-3227	USE 82-7386	ea
83-3231	chainguard,T150,pre1974	EA
83-3236	USE 83-4856	ea
83-3239	USE 83-3985	ea
83-3242	rod,brake,Rocket 3	EA
83-3246	USE 83-3443	ea
83-3259	USE 82-8490 *	ea
83-3270	USE 82-9695	ea
83-3271	USE 83-9696	ea
83-3275	USE 83-3213/A	ea
83-3290	tank,oil,preoilframe twin	EA
83-3318	beading holder,tank mount	EA
83-3319	washer,ring	EA
83-3320	washer,7/16 flat	EA
83-3321	oring,beading holder	EA
83-3325	battery box,oilframe	EA
83-3329	spacer	EA
83-3355	USE 82-9436	ea
83-3418	USE 511-210	ea
83-3443	grabrail,A75,71on	EA
83-3447	chainguard,X75 Hurricane	EA
83-3486	grabrail,X75 Hurricane	EA
83-3508	USE 83-3927	ea
83-3522	rubber,reflector mtg	EA
83-3525	USE 391-60600092	ea
83-3537	bracket,head steady	EA
83-3541	airfilter housing,B/T25	EA
83-3548	USE 532-21/A	ea
83-3554	spindle,swingarm,B50 etc*	EA
83-3556	camplate adjuster,swingarm,B50,etc.	EA
83-3563	rubber,"U"shape,tank mt	EA
83-3565	mudguard,R,oilframe650,chrome*	EA
83-3566	mudguard,R,oilframe650,unpainted*	EA
83-3596	housing,tailamp,X75	EA
83-3625/A	metalastic repl.kit,elect.box cov.	ST
83-3633	USE 511-302	ea
83-3634	USE 511-260	ea
83-3637	USE 512-2044 (kit)	ea
83-3642	filter screen,71 on 650	EA
83-3643	USE 83-3815	ea
83-3665	bracket,chokelever to man	EA
83-3764	bracket,reflector	EA
83-3793	spring,centerstand,OIF	EA
83-3793/SS	spring,centerstand,OIF,stainless	EA
83-3814	USE 82-3814	ea
83-3815	plate,ump,oilframe 650	EA
83-3833	USE 83-4932	ea
83-3849	buckle,battery strap*	EA
83-3850	cover,filter,T120 LH	EA
83-3851	cover,filter,T120 RH*	EA
83-3858	bracket,oilcooler mt,A75R/X75	EA

83-3859	USE 83-4673	ea
83-3860	USE 38-4675	ea
83-3864	USE 83-2839	ea
83-3865	USE 83-2840	ea
83-3875	USE 622-04	ea
83-3927	fueline assy,T140 US	EA
83-3985	pedal,brake,A75,late	EA
83-4085	USE 42-4778	ea
83-4086	nut,captive	EA
83-4092	mudguard,R,oilframe1Cyl,unpainted	EA
83-4092/CHR	mudguard,R,oilframe1Cyl,chrome	EA
83-4118	bracket,tank brace,UK	EA
83-4122	hose,breather,silver,B50	EA
83-4256	USE 83-3057	ea
83-4268	USE 512-2075	ea
83-4278	sidestand,oilframe 250/500	EA
83-4287	USE 511-365	ea
83-4288	USE 511-260	ea
83-4291	USE 512-04	ea
83-4299	USE 82-4299	ea
83-4318	USE 83-4092 *	ea
83-4355/4356	kneepad set,71-81 UK tank	PR
83-4395	bracket,tank brace,USA*	EA
83-4437	USE 83-3858*	ea
83-4550	hose,breather	EA
83-4600	bracket,bridge,R.mudguard	EA
83-4601	USE 83-7502	ea
83-4606	filter housing,LH T120/40	EA
83-4607	filter housing,RH T120/40	EA
83-4608	USE 83-4845	ea
83-4609	filter housing,RH,TR6/7	EA
83-4610	USE 83-3325	ea
83-4614	USE 83-5161	ea
83-4615	USE 83-4941 *	ea
83-4618	tank,gas,T100R,74 type	EA
83-4623	USE 83-2996	ea
83-4673	sidepanel,650,71on,LH	EA
83-4675	sidepanel,650,71on,RH	EA
83-4758	handle,lifting,TR5T,chrome	EA
83-4763	USE 97-5061	ea
83-4772	tank,gas,TR7/T140V,US,bare*	EA
83-4774	USE 83-7094	ea
83-4776	badge,tanktop,gold/silver*	EA
83-4776/A	badge,tanktop,red/silver	EA
83-4776/B	badge,tanktop,gold/black	EA
83-4782	seathing,oilframe twins	EA
83-4783	screen,frame sump,TR7/140*	EA
83-4784	bracket,licence,top	EA
83-4789	USE 512-2044	ea
83-4800	nut,sleeve,tailamp mtg.	EA
83-4802	USE 83-2867	ea
83-4803	sidepanel,750 twin,RH	EA
83-4805	mudguard,R,73-75 T140,chr.*	EA
83-4806	protector,wiring,mudguard	EA
83-4807	cover,filter,TR7 type,LH	EA
83-4808	cover,filter,TR7 type,RH	EA
83-4809	USE 83-7067	ea
83-4810	USE 83-7068	ea
83-4813	hose,breather,rear mudguard,44"*	EA
83-4814	USE 83-5147	ea
83-4820	mudguard,R,T100R,72on	EA
83-4822	mudguard,rear,73/4 T150,chrome	EA
83-4823	USE 324-92	ea
83-4845	filter housing,LH,TR6/7	EA
83-4854	sidepanel,750 twin,LH	EA
83-4856	sidepanel,late T150,LH*	EA
83-4857	sidepanel,late T150,RH*	EA
83-4887	fueline assy,TR6/7,71on	EA
83-4898	bracket,choke	EA
83-4906	sidepanel,TR5T,LH	EA
83-4907	sidepanel,TR5T,RH	EA

83-4925/4926	decals,Hurricane tank/seat	PR
83-4930	bolt,5/16UNF,tank centre	EA
83-4931	rubber,gastank steady,concave	EA
83-4932	rubber,"U"shape,tank mt.	EA
83-4933	rubber,"U"shape,tank mt.	EA
83-4934	rubber,tank mount,centre	EA
83-4940	USE 83-4941	ea
83-4941	centerstand,oilframe twin,early*	EA
83-5001	bracket,tailamp support	EA
83-5092	element,airfilter,T160	EA
83-5096/CLIP	clip,airbox,T160	EA
83-5105	grommet,U shape,tailight housing	EA
83-5114	hose,breather,silver,B50,short	EA
83-5115	hose,breather,silver,B50,long	EA
83-5145	grabrail assembly	EA
83-5145/ER	grabrail assembly,econo repl.	EA
83-5147	grabrail,T160 Trident type	EA
83-5150	bracket,fender &brakeline,LH	EA
83-5151	bracket,fender mt,RH	EA
83-5161	connector,airfilter,TR7*	EA
83-5164	spindle,brake pedal pivot	EA
83-5237	chainguard,T160	EA
83-5237/CHR	chainguard,T160,chrome	EA
83-5270	bracket,rear eng.mt,LH,T160	EA
83-5285	hose,breather,fr,7-1/2"*	EA
83-5290	fitting,"T",breather,straight	EA
83-5322	USE 06-0648	ea
83-5353	rubber mt,T160 gastank	EA
83-5361	badge,tank,T160,T140D etc	EA
83-5362	cover,oiltank styling,T160	EA
83-5366	spring,brake pedal,T160	EA
83-5368/A	swingarm,T160,box section	EA
83-5378	USE 512-2093 (kit)	ea
83-5388	screw,2BA,Philip	EA
83-5395	tank,gas,T160 US	EA
83-5401	USE 37-4370	ea
83-5418	tank,gas,T140 UK,bare	EA
83-5429	chainguard,T150,1974on	EA
83-5434	hose,breather,T160	EA
83-5448	intake tube,square,LH	EA
83-5449	intake tube,square,RH	EA
83-5465	reservoir assy,m.cyl,rear	EA
83-5466	USE 83-7501	ea
83-5467	USE 83-7055	ea
83-5473	bracket,rear eng.mt,RH,T160	EA
83-5474	toolbox/mudguard section,T160	EA
83-5477	footpeg,fr,T160,RH	EA
83-5485	USE 82-9004	ea
83-5529	cover,starter motor,T160	EA
83-5529/SS	cover,starter motor,T160,stainless	EA
83-5581	footpeg,fr,T160,LH	EA
83-5610	spacer tube,tank mt,T160	EA
83-5616	USE 82-3814	ea
83-5617	washer,rubber,tank,T160	EA
83-5618	rubber bush,tank mtg,T160	EA
83-5690	sidepanel,T160,left hand*	EA
83-5704	pedal,brake,T160	EA
83-5857	USE 83-1560	ea
83-5860	cover,oilcooler side,T160	EA
83-5863	USE 82-9315	ea
83-5864	USE 82-9315	ea
83-5869	USE 82-9315	ea
83-5870	adjuster plate,rear chain,LH	EA
83-5874	mudguard,rear T160,stainless	EA
83-5890	fitting,hose to oiltank	EA
83-5891	nut,oiline to tank screen	EA
83-5892	screen,oiltank feed,large	EA
83-5895	USE 83-7600	ea
83-5899	bracket,fr.eng.mt,LH,T160	EA
83-6182	USE 82-3335	ea
83-6209	fueline assy,T140V UK	EA

83-7003	lever, rear mastercyl.oper	EA
83-7009	bracket, eng.mt, LH rear	EA
83-7011	bracket, eng.mt, RH rear	EA
83-7016	spring, brake pedal return	EA
83-7018	bracket, master cyl.mount	EA
83-7021	USE 83-7021/7022 (pr)	ea
83-7021/7022	brackets, muffler, cranked	PR
83-7022	USE 83-7021/7022 (pr)	ea
83-7024	pin, pivot, m.cyl oper.arm	EA
83-7025	USE 83-7600	ea
83-7026	USE 83-7600	ea
83-7028	bracket, torquearm, caliper	EA
83-7031	mudguard, rear, TR7/140V, chrome	EA
83-7032	frame, T140V	EA
83-7035	swingarm, T140, 1976-79*	EA
83-7040	footrest, rider, oil frame*	EA
83-7041	USE 83-7502	ea
83-7044	pedal, brake, T140, 1977-79	EA
83-7046	spindle, brake pedal pivot	EA
83-7048	USE 83-7501	ea
83-7049	clip, hose, reserv.to m.cyl	EA
83-7053	pivot bolt w/bush, R.brake*	EA
83-7055	fitting, brake reservoir, 1/2x20TPI	EA
83-7056	USE 83-7501	ea
83-7057	USE 82-8245	ea
83-7058	USE 82-7888	ea
83-7059	pedal, passenger peg	EA
83-7064	bracket, fender & brakeline, LH	EA
83-7065	USE 511-259	ea
83-7066	USE 512-2044	ea
83-7067	cover, filter, LH, T140 type	EA
83-7068	cover, filter, RH, T140 type	EA
83-7070	spring, sidepanel retainer	EA
83-7072/7075	sidepanels, Silver Jubilee	PR
83-7078/7079	badges, ONE OF A 1000, sidepanel, Jubilee	PR
83-7093	badge, tanktop, Jubilee	EA
83-7094	housing, tailamp, 73on Tri	EA
83-7097	sidepanel, T140V, LH *	EA
83-7097/7098	sidepanels, T140V, 1978	PR
83-7098	sidepanel, T140V, RH *	EA
83-7103	sidepanel, TR7V, LH*	EA
83-7103/7104	sidepanels, TR7RV, 1978*	PR
83-7104	sidepanel, TR7V, RH*	EA
83-7127	USE 511-203	ea
83-7129	USE 511-203 *	ea
83-7131	USE 512-2107	ea
83-7133	USE 512-2107/A	ea
83-7148	banjo, breather pipe, T140E	EA
83-7155	fueline assy, T140E, US	EA
83-7161	USE 82-9355	ea
83-7163	pivot bolt w/bush, R.brake, late*	EA
83-7198	USE 83-7103	ea
83-7199	USE 83-7104	ea
83-7221	USE 60-4263	ea
83-7235	rubber pad, battery box	EA
83-7252	badge, BONNIE 750, silv/gry	EA
83-7253	badge, TIGER 750, silv/blk.	EA
83-7256	USE 532-837256	ea
83-7259	USE 532-837259	ea
83-7261	USE 83-9001	ea
83-7263	USE 83-9001	ea
83-7271	USE 511-203	ea
83-7284	grabrail&carrier, 79 T140E type*	EA
83-7302	tank, gas, T140US, red w/blk	EA
83-7303	USE 83-7305 *	ea
83-7304	USE 83-7306 *	ea
83-7305	sidepanel, T140E, LH, blk.*	EA
83-7305/7306	sidepanels, T140E, 79on	PR
83-7306	sidepanel, T140E, RH, blk.*	EA
83-7307	USE 83-7305 *	ea
83-7308	USE 83-7306 *	ea

83-7309	USE 83-7305 *	ea
83-7310	USE 83-7306 *	ea
83-7316	badge,BONNIE 750,silv/blk	EA
83-7317	badge,BONNIE 750,gold/blk	EA
83-7317/ER	badge,BONNIE 750,gold/blk,econo	EA
83-7328	seatlock catch plate	EA
83-7329	catch,seat latch	EA
83-7334	badge,TIGER 750,gold/blk.	EA
83-7355	USE 83-7305	ea
83-7356	USE 83-7306	ea
83-7357	badge,sidepanel750SPECIAL	EA
83-7371	USE 82-9701	ea
83-7372	USE 82-9700	ea
83-7374	USE 82-9701	ea
83-7387	hose,breather,rear mudguard,52"*	EA
83-7390	grabrail,T140D*	EA
83-7460	bush,centrestand bolt	EA
83-7467	bracket,head steady	EA
83-7490	mudguard,R,T140E	EA
83-7501	mount,reservoir,m.cyl,R *	EA
83-7501/A	mount,reservoir,m.cyl,R,billet	EA
83-7502	coil&tool tray,oilframe twins	EA
83-7504	battery box,oilframe,ES type*	EA
83-7521	USE separate components	ea
83-7532	centerstand,oilframe twin,late *	EA
83-7533	USE 60-4398	ea
83-7537	frame,T140E	EA
83-7542	seathing,1980on T140,rear	EA
83-7544	sleeve,seathing	EA
83-7547	USE 83-7284	ea
83-7553	sidestand,T140E,1980 on	EA
83-7555	grabrail,T140,w/single rear tab	EA
83-7560	pedal,brake,T140E	EA
83-7582	bracket,muffler,L&R hand	EA
83-7600	footpeg assembly,rear,w/rubber*	EA
83-7601	USE 83-7602	ea
83-7602	pivot,pass.peg mount*	EA
83-7644	cover,solenoid,T140ES	EA
83-7645	USE 83-7305 ?	ea
83-7695	USE 83-7600	ea
83-7736	spindle,brake pedal,TR65	EA
83-7780	USE 83-4609	ea
83-7882	washer,breather tower cap	EA
83-7970	adaptor,female fuel tap	EA
83-7997	pedal,brake,TR65	EA
83-7998	rod,rear brake,TR65	EA
83-8023	stanchion,signal,long	EA
83-8026	stanchion,signal,short	EA
83-8034	footpeg mt,rub.mt.type,LH	EA
83-8036	footpeg mt,rub.mt.type,RH	EA
83-8038	footpeg,rubber mt type	EA
83-8062	bracket,fender & brakeline,RH,dualdisc	EA
83-8156	USE 83-2641/CHR	ea
83-8255	bracket,mtr.mt,LH,TSX	EA
83-8272	badge,TSS,gold/black	EA
83-8282	bracket,mtr.mt,RH,TSX	EA
83-8287	spacer,mtr.mt,bot.RH,TSX	EA
83-8288	spacer,mtr.mt,bot.LH,TSX	EA
83-8289	spacer,mtr.mt,RH fr,TSX	EA
83-8290	spacer,mtr.mt,LH fr,TSX	EA
83-8298	USE 83-7094 *	ea
83-8387	bracket,muffler,TSX	EA
83-8428	sidepanel,TSX,LH	EA
83-8429	sidepanel,TSX,RH	EA
83-8656	USE 83-4776/B	ea
83-9000	USE 83-2641/CHR	ea
83-9001	mudguard,R T140,stainless	EA
83-9907	USE 82-9571	ea
84-	TRIUMPH PARTS	*
84-----	-----	--
84-0016	mudguard,R.T140E,stainless	EA

84-0026	USE 83-4776/A	ea
84-0027	screen,frame sump,deep	EA
85-	MATCHLESS PARTS	*
85-----	-----	--
85-0056	sidepanel,LH,G80,blk/gold	EA
85-0057	sidepanel,RH,G80,blk/gold	EA
85-0062	tank,gas,G80,Black/Gold	EA
87-	NORTON PARTS	*
87-----	-----	--
89-	BSA PARTS	*
89-----	-----	--
89-0060	USE 422-38	ea
89-0149	USE 60-4253	ea
89-3022	bearing,ball	EA
89-3023	USE 60-3552	ea
89-3208	USE 532-15	ea
89-4240/41/48/49	cover set,plungers,preunitBSA	ST
89-5015	USE 422-14	ea
89-5036	USE 97-3678	ea
89-5061	USE 97-2636	ea
89-5727	USE 37-1041	ea
89-9010	USE 391-45152	ea
90-	BSA PARTS	*
90-----	-----	--
90-0010	USE 04-0100	ea
90-0011	USE 04-0099	ea
90-0012	bearing,ball	EA
90-0037	clutch plate,plain,Bantam	EA
90-0088	shaft,kickstart,Bantam	EA
90-0134	USE 552-110038/50	ea
90-0135	USE 532-19	ea
90-0241	USE 422-516	ea
90-0262	USE 00-0203	ea
90-0749	oilseal,forks,Bantam	EA
90-0802	USE 00-5158	ea
90-0932	USE 00-5158	ea
90-0966	kickstarter crank,Bantam	EA
90-1318	cl.plate,friction,Bantam	EA
90-1458	bearing,needle	EA
90-1582	gear,3rd main,26T	EA
90-1633	gear,1st lay,30T,D14/4	EA
90-1692	gear,lay,25T,D14/4	EA
90-1696	gear,mainshaft,26T,D14/4	EA
90-1737	clutch centre,D14/4	EA
90-1744	USE 40-7876 assy.	ea
90-1995	USE 90-5286	ea
90-3059	washer,sealing,muffler,D14/4	EA
90-3061	USE 742-112/A	ea
90-3063	USE 82-9128	ea
90-3139	nut,5/16X22,acorn,deep,chrome	EA
90-3165	heatshield,Bantam D14/4	EA
90-4142	skidplate,D14/4	EA
90-4350	bracket,eng.mt,rear,D14/4	EA
90-4774	sidestand assy,Bantam Bushman	EA
90-4805	USE 532-904805	ea
90-4812	USE 90-4805	ea
90-4970	USE 90-4976	ea
90-4976	handlebars,Bantam/C11,w/welded brackets	EA
90-5044	oilseal,forks,BantamD1/3	EA
90-5081	USE 531-20 (pr)	ea
90-5229	USE 97-0845	ea
90-5230	USE 97-1046	ea
90-5252	USE 90-5286	ea
90-5258	forktube,Bantam D7on	EA
90-5286	USE 97-1044	ea
90-5583	spoke,10G,Bantam D3	EA
90-5681	spoke,LH F,68 D14/4	EA
90-5682	spoke,inner RH F,68 D14/4	EA
90-5683	spoke,outerRH F,68 D14/4	EA
90-5684	rim,WM1x19,F,Bantam	EA
90-5715	USE 19-7738	ea

90-5719	USE 37-0977	ea
90-6042	USE 553-40/SS kit	ea
90-6063	USE 391-189307	ea
90-6074	USE 57-2677	ea
90-6203	USE 37-3690	ea
90-6288	rim,WM2x19,R,67/68 Bantam	EA
90-6580	mudguard,F,chrome,B25/44,D14/4	EA
90-6748	bracket,tailight &licence	EA
90-6794	bracket,tailight &licence	EA
90-6839	USE 82-8121 ?	ea
90-6959	bracket,tailight &licence	EA
90-6961	USE 90-6748	ea
90-7029	USE 82-9039	ea
90-7709	chainguard,Bantam,D1-D3 rigid	EA
90-7711	chainguard,Bantam,D1-D3plunger	EA
90-7736	chainguard,Bantam,D7-D10-D14	EA
90-7743	chainguard,Bantam,D14/4	EA
90-8078	gascap,w/measure,Bantam	EA
90-8120	fueline & tap assy,D14/4	EA
90-8123	decal,BUSHMAN	EA
90-9083	USE 06-7830	ea
96-	MATCHLESS PARTS	*
96-	-----	--
97-	TRIUMPH AND BSA PARTS	*
97-	-----	--
97-0095	spring plate,strg.damper	EA
97-0111	bearing cup,forks*	EA
97-0193	nut,7/16x26,plain*	EA
97-0200	bolt,retaining	EA
97-0211	bolt,3/8x26	EA
97-0225	bars,1938-48 Speed Twin	EA
97-0230	grips,TRIUMPH,1"nacelle bars*	PR
97-0230A	grips,TRIUMPH logo,7/8"bars*	PR
97-0234	stop,thr.cable,early Tri	EA
97-0237	screw,set,Tri.throttle *	EA
97-0251	USE 83-3213/A (bulk)	ea
97-0331	USE 97-1461	ea
97-0379	nut,3/8x26,extended	EA
97-0382	forktube,pre1960 Triumph	EA
97-0382A	forktube,pre1960,nacelle	EA
97-0384	springs,fork,pre60,solo	PR
97-0390	forkseal holder,pre60fork	EA
97-0391	felt seal,forks	EA
97-0394	damper tube,forks,early	EA
97-0397	retainer,damper rod,top	EA
97-0398	bolt,3/8x26,flanged	EA
97-0399	damper rod,forks,earlyTri	EA
97-0400	nut,5/16x26,acorn,zinc	EA
97-0405	nut,steering stem,w/hole,CEI	EA
97-0405/SS	nut,steering stem,w/hole,CEI,stainless	EA
97-0407	washer,dustcover,fork brg	EA
97-0408	nut,splined,strng.damper,CEI	EA
97-0412	stand,front,1946-62 type	EA
97-0420	washer,sealing,foam,forks	EA
97-0426	bolt,3/8x26	EA
97-0428	clip,mudguard to forkleg	EA
97-0430	washer,fibre	EA
97-0431	washer,flat,forkseal hldr	EA
97-0432	nut,forktube,top,chrome	EA
97-0432/SS	nuts,forktube top,stainless	PR
97-0432A/SS	nuts,forktube,top,nacelle,stainless	PR
97-0435	washer,friction,strg.damp	EA
97-0436	USE 97-1340	ea
97-0437	brg.cup,forks,rigid,top *	EA
97-0438	bearing cone,top,rigid fr*	EA
97-0439	bearing cone,forks,bottom	EA
97-0440	bars,preunit,1949-54TR5&6,low	EA
97-0441	bush,forktube,top	EA
97-0441/0443/A	bush set,forks,PM performance	ST
97-0441/B	bush,forktube,top,extended 1"	PR
97-0443	bush,forktube,bottom	EA

97-0444	USE 97-1058	ea
97-0445	washer, forksealholder	EA
97-0451	bolt, 3/8x26	EA
97-0452	restrictor, forkleg	EA
97-0453	USE 97-1764	EA
97-0505	springs, fork, pre60, sidecar	PR
97-0506	clip, handlebar mt, 1"	EA
97-0518	USE 00-0004	ea
97-0519	bolt, 2BA, forkdrain	EA
97-0536	USE 97-1142	ea
97-0565	washer, steering damperRod	EA
97-0566	mudguard, fr, 48-57 TriTwin	EA
97-0569	bracket, fenderstay, fr. L&R	EA
97-0570	bolt, 5/16x26, chrome	EA
97-0623/0624	trim, chrome, nacelle, long	ST
97-0659	bars, p. unit nacelle, holes, low	EA
97-0660	Ubolt, handlebar mount	EA
97-0669	grommet, handlebar, nacelle, 1"	EA
97-0685	spring, throt. control adj.	EA
97-0686	spring, thr. control frict.	EA
97-0687	screw, 2BA	EA
97-0688	screw, 4BA	EA
97-0689	screw, 4BA*	EA
97-0690	nut, flat, nacelle rim	EA
97-0691	USE 42-8034	ea
97-0697	throt. contr. assy, Tri, repl, 15/16"	EA
97-0717	bracket, fenderstay, centre	EA
97-0719	bracket, fenderstay, forwr	EA
97-0722	clip, handlebar mounting, 7/8"	EA
97-0741	mount, front numberplate	EA
97-0745	nut, 2BA	EA
97-0799	nacelle cover, LH, TRW, etc.	EA
97-0799/0800/A	nacelle cover set, fibreglas	ST
97-0800	nacelle cover, RH, TRW, etc.	EA
97-0811	bars, preunit T120, 60on, low*	EA
97-0826	USE 06-5542	ea
97-0833	USE 99-3721 (set)	ea
97-0835	USE 99-3721 (set)	ea
97-0843	USE 97-1036 & 97-0845	ea
97-0845	forkbush, bot, Bantam/T20	EA
97-0860	USE 97-1046	ea
97-0865	Ubolt, handlebar mount	EA
97-0877/0878	trim, chrome, nacelle, short	PR
97-0881	grommet, handlebar, nacelle, 7/8"	EA
97-0904	plate, shift indicator, Terrier	EA
97-0917	top, nacelle *	EA
97-0919	nut, 4BA	EA
97-0921	plate, shift indicator, Cub	EA
97-0932	bars, preunit, 1955 TR5/TR6	EA
97-0941	bolt, 3/8x26, chrome	EA
97-0958	USE 522-01	ea
97-0961	USE 391-199002	ea
97-0962	USE 531-23 (or 531-37) (set)	ea
97-0963/0964	brackets, hdlt, preunit	PR
97-0975	nut, 3/8x26, forkstop	EA
97-0987	bearing cup, forks, X75	EA
97-0992	horn grille, nacelle	EA
97-0993	USE 83-1339	ea
97-1001	dustcover, press on, fork brg.	EA
97-1003	bars, preunit, 56on TR5/TR6, USA	EA
97-1009	bars, preunit nacelle, 56on	EA
97-1018	bearing cone, forks, top	EA
97-1035	USE 97-1036 & 97-0845	ea
97-1036	forktubes, Cub lightweight	EA
97-1044	forkseal, T20/Bantam	EA
97-1046	forkbush, top, Bantam/T20	EA
97-1051	tube, guide, forkdamper	EA
97-1058	nut, forktube, bottom, CEI	EA
97-1062	washer, sealing, alloy	EA
97-1063	bolt, restrictor, forks	EA
97-1065	nut, forktube top, 26TPI, chrome	EA

97-1065/SS	nut,fortube top,26TPI,stainless	PR
97-1070	bolt,5/16x26	EA
97-1071	bolt,drain plug,forks	EA
97-1083	bracket,instr.mt,dual,chrono	EA
97-1086	bolt,1/4x26,small hex	EA
97-1087	bush,metalastic,instr.mt.	EA
97-1097	mudguard,F,bathtub models,fiberglas	EA
97-1100	stand,front,bathtub type	EA
97-1110	bearing cone,forks,bot,sm	EA
97-1123	forktube,nacelle type,21"	EA
97-1126	sleeve,damping,early	EA
97-1127	springs,fork,internal	PR
97-1130	bearing cup,forks*	EA
97-1131	bars,1",T100A,3TA,5TA	EA
97-1140	bearing cone,forks,top	EA
97-1141	nut,forkstem,6T	EA
97-1142	steering damper rod &knob	EA
97-1168	USE 97-1461	ea
97-1179	bars,preunit,USA style*	EA
97-1194	USE 97-1474	ea
97-1195	USE 97-1474	ea
97-1271	bracket,fenderstay,frwr.	EA
97-1280	USE 97-1928	ea
97-1285	plate,steering damper	EA
97-1287	USE 97-2072	ea
97-1290/1291/A	nacelle cover set,fibreglas	ST
97-1292	springs,fork,6T/T110 duplex,solo	PR
97-1294	mudguard,front,1960-62 T120	EA
97-1295	bracket,fender mt,centre	EA
97-1299	forktube,1960 on preunit,22-3/16"	EA
97-1300	springs,fork,internal	PR
97-1301	springs,fork,6T/T110duplex,sidecar	PR
97-1305	springs,fork,TR6/120duplex,sidecar	PR
97-1340	bolt,5/16x22*	EA
97-1340/CHR	bolt,5/16x22,chrome,domed	EA
97-1388	washer	EA
97-1425	sleeve,handle bar mounts	EA
97-1461	oilseal,forks & crank	EA
97-1466	plug,insp,clutch,Cub	EA
97-1474	forkseal holder,1960on int.spr.fork	EA
97-1474/SS	forkseal holder,60on int.spr,stainless*	PR
97-1482	bracket,F.fender & stand	EA
97-1484	bars,UK Tri.twin,63-64	EA
97-1499	restrictor,fork damper	EA
97-1500	oilseal,forks,genuine	EA
97-1500/A	oilseal,forks,LEAKPROOF	PR
97-1500/B	oilseal,forks,LEAKPROOF,moly	PR
97-1500/ER	oilseal,forks,econo	EA
97-1510	USE 531-37 (pair)	ea
97-1511	bars,USA,Tri/BSA	EA
97-1523	USE 97-2291 w/14-1903 nut	ea
97-1527	bush,metalastic,bar mount *	EA
97-1529	washer,concave,bar mt.	EA
97-1531	acorn nut,5/16x26,CEI,chrome	EA
97-1540	bracket,front mudguard	EA
97-1580	washer,rubber	EA
97-1581	spacer,bar mounts	EA
97-1596	bracket,instr.mt,dual	EA
97-1616	spacer,solid,bar mounts*	EA
97-1618	rubber bush,strng.damper	EA
97-1645	USE 531-25 (pr)	ea
97-1649	USE 97-1889	ea
97-1653	sleeve,damping,forks,alloy	EA
97-1654	forkseal holder,chrome,early *	EA
97-1656	washer,flat,spring supp.	EA
97-1657	collar,forkspring,top,w/groove	EA
97-1657/A	collar,forkspring,top,no groove*	EA
97-1658	nut,forktube top,26TPI,chrome	EA
97-1658/ER	nut,forktube top,econo,chrome	EA
97-1658/SS	nuts,fortube top,26TPI,stainless	PR
97-1659	USE 97-1658	ea

97-1668	bracket, speedo mt, T100C	EA
97-1669	USE 97-2259	EA
97-1670	USE 97-2034	ea
97-1677	mudguard, F, unpainted, 63-67	EA
97-1678	USE 97-3688 *	ea
97-1681	bracket, fenderstay, forward, blk	EA
97-1683	bracket, fenderstay, centre, black	EA
97-1685	brack, fenderstay to fork, road	EA
97-1687	mudguard, F, alloy, 63-67	EA
97-1688	bracket, fenderstay to fork, "C"	EA
97-1695	USE 97-1889	ea
97-1696	cover, forktube, w/out hdl. bracket, TT	EA
97-1701	nut, shoulder, speedo, T100C/TR6C	EA
97-1702	spacer, speedo mount, T100C/TR6C	EA
97-1708	washer, flat	EA
97-1760	bolt, 3/8X26, pinch*	EA
97-1762	nut, forktube top, 26TPI	EA
97-1763	USE 97-1762	ea
97-1764	cup, damper tube, forks	EA
97-1794	top, nacelle *	EA
97-1797	bracket, steering damper	EA
97-1842	USE 97-4170	ea
97-1843	USE 97-4171	ea
97-1844	forkcap, lower leg	EA
97-1870	bars, US Bonnie, pre71	EA
97-1870/ER	bars, US Bonnie, pre71, econo	EA
97-1871	bars, UK Tri. twin, 65-70	EA
97-1872	bars, UK T90/100 pre67	EA
97-1876	screw, 4BA	EA
97-1887	bracket, headlight, earlyRH*	EA
97-1887/1888	brackets, headlight, early	PR
97-1888	bracket, headlight, earlyLH*	EA
97-1889	forktube, CEI Tri. w/4holes, 22"*	EA
97-1889/10	forktubes, CEI Tri, +10"	PR
97-1889/12	forktubes, CEI Tri, +12"	PR
97-1889/4	forktubes, CEI Tri, +4"	PR
97-1889/6	forktubes, CEI Tri, +6"	PR
97-1889/8	forktubes, CEI Tri, +8"	PR
97-1890	USE 97-1889	ea
97-1891	forkspring, 16-1/2lbRating	EA
97-1891/A	forksprings, HiPerf, Prog. Susp.	PR
97-1891/B	forksprings, multi-rate	PR
97-1892	forkspring, 32-1/2lbRating	EA
97-1896	sleeve, damping, forks	EA
97-1896/A	sleeve, damping, forks, alloy	EA
97-1897	rod, fork damper, 15-7/8"	EA
97-1928	forktubes, Cub heavyweight, 20-3/4"*	EA
97-1929	bush, metalastic, instr. mt.	EA
97-1932	spacer, hdl. mtg.	EA
97-1938	plug, rubber	EA
97-1946	bracket, instr. mt, dual	EA
97-1994	screw, self tapping*	EA
97-1996	USE 97-4439	ea
97-1997	mudguard, F, stainless, 63-67	EA
97-2033	USE 97-2259	ea
97-2034	clip, kill switch to bars	EA
97-2072	forkyoke, top, narrow, solid	EA
97-2083	clip, fork gaiters, 1967/1968	EA
97-2090	restrictor, fork leg	EA
97-2091	nut, forktube bottom, UNF	EA
97-2092	USE 97-3904 *	ea
97-2099	USE 97-2101	ea
97-2100	forkyoke, top, narrow, rubMt	EA
97-2101	forkyoke, top, narrow, solid	EA
97-2107	screw	EA
97-2108	nut, steering stem, w/hole, UNF	EA
97-2108/SS	nut, steeringstem, w/hole, UNF, stainless	EA
97-2111	fork assy, twins, 1967 type, rubber mt.	EA
97-2119	oring, oilseal holder	EA
97-2124	USE 522-01	ea
97-2125	USE 522-01	ea

97-2126	bolt,fork restrictor	EA
97-2127	circlip	EA
97-2138	bracket,speedo mt,T100C,TR6C	EA
97-2154	damper valve,shuttle type	EA
97-2154/A	damper valves,performance	PR
97-2161	bracket,headlight,LH*	EA
97-2161/2162	brackets,headlight,late	PR
97-2162	bracket,headlight,RH*	EA
97-2208	rubber spacer,hdlight mtg	EA
97-2209	grommet,headlight bracket	EA
97-2210	washer,1/8"	EA
97-2221	washer,cup	EA
97-2236	USE 97-4262	ea
97-2237	heatsink,zener diode*	EA
97-2245	nut,forktube top,UNF,28TPI,chrome	EA
97-2245/ER	nut,forktube top,econo.	EA
97-2245/SS	nuts,forktube top,Stainless	PR
97-2245/SS/A	nuts,forktube top,69/70 A50/65stainless	PR
97-2259	cup,killswitch mounting*	EA
97-2262	rubber cover,ign.switch	EA
97-2263	nut,forkstem,no hole	EA
97-2263/SS	nut,forkstem,stainless *	EA
97-2266	plug,welch	EA
97-2268	USE 97-3677	ea
97-2270	cable guide,bare	EA
97-2273	clip,cl.cable toSidepanel	EA
97-2275	plug,plastic,heat sink	EA
97-2276	USE 97-4439/SS	ea
97-2283	USE 97-2285	ea
97-2284	fork assy,twins,1968 type,solid mt.	EA
97-2285	fork assy,twins,1968 type,rubber mt.	EA
97-2288	USE 97-3659	ea
97-2290	bolt,3/8x24,chrome	EA
97-2291	eyebolt,handlebar clamp*	EA
97-2291/SS	eyebolt,handlebar clamp,stainless	ST
97-2293	forkyoke,top,3cyl,pre71	EA
97-2294	USE 97-4170	ea
97-2295	USE 97-4220	ea
97-2297	housing,instr,3cyl,pre71	EA
97-2300	bracket,hdlt,pre71 3cylLH*	EA
97-2300/2301	brackets,hdlt,pre71 3cy	PR
97-2301	bracket,hdlt,pre71 3cylRH	EA
97-2362	spacer,plastic,sm.hdlight	EA
97-2365	USE 97-4262	ea
97-2503	USE 97-2549	ea
97-2504	forkleg,RH	EA
97-2510	bracket,hdlt,69/70 A65,LH	EA
97-2510/2512/CHR	brackets,hdlt,68/70A50/65,chrome	PR
97-2512	bracket,hdlt,69/70 A65,RH *	EA
97-2513	USE 531-27 (pair)	ea
97-2514	forkseal holder,pre69 BSA,w/ring	EA
97-2525	forkyoke,top,pre71 1cyl	EA
97-2543	USE 68-5177	ea
97-2544	USE 68-5176	ea
97-2549	forkcap,lower leg	EA
97-2557	oilseal,forks,BantamD14/4	EA
97-2558	bracket,hdlt,pre71 B25 RH	EA
97-2559	bracket,hdlt,pre71 B25 LH *	EA
97-2621	forkyoke,bot,pre71 A75	EA
97-2622	dustcover,steering hd,A75	EA
97-2628	USE 40-4960	ea
97-2630	washer,5/16,headlight mt.	EA
97-2631	spacer,headlight mt.	EA
97-2632	washer	EA
97-2633	washer,sealing,forks	EA
97-2634	screw,forkdrain,BSA	EA
97-2634/SS	screw,forkdrain,BSA,stainless	EA
97-2635	USE 97-3893	ea
97-2636	forktube,pre'69 BSA	EA
97-2636/12	forktubes,pre69BSA,+12	PR
97-2636/4	forktubes,pre69 BSA +4"	PR

97-2636/6	forktubes,pre69 BSA +6"	PR
97-2636/8	forktubes,pre69 BSA,+8"	PR
97-2637	bush, forktube, top	EA
97-2637/2638	bush&seal set, forks, pre 69 BSA *	ST
97-2637/2638/ER	bush set, forks, pre 69 BSA, econo	ST
97-2638	bush, forktube, bottom	EA
97-2639	USE 97-2709	ea
97-2640	washer	EA
97-2641	oilseal, pre 69 BSA forks, 70 B44VS	EA
97-2641/ER	oilseal, pre69BSA forks, 70 B44VS, econo	PR
97-2643	spacer, forktube	EA
97-2644	USE 97-3678	ea
97-2645	bolt, special, fork crown	EA
97-2646	nut, 3/8x26, extended*	EA
97-2647	cone, steering hd, top, 1cyl.	EA
97-2648	cone, steering hd, bot, 1cyl	EA
97-2650	dustcover, strg. head, 1cyl. *	EA
97-2651	nut, steering stem	EA
97-2652	nut, forktube top, 20TPI *	EA
97-2653	washer, forktube nut, top	EA
97-2653/SS	washer, forktube nut, top, stainless	EA
97-2654	guide, cable	EA
97-2655	clip, handlebar clamping	EA
97-2656	bolt, 5/16CEI, chrome, domed	EA
97-2658	guide, cables	EA
97-2659	grommet, cable guide	EA
97-2661	bush, damper valve, forks	EA
97-2662	circlip, forks	EA
97-2663	USE 06-7745	ea
97-2664	circlip, forks, BSA	EA
97-2665	damper valve, forks	EA
97-2666	damper valve, forks	EA
97-2667	damper valve seat, forks	EA
97-2668	sealing washer, forks	EA
97-2669	rod, fork damper	EA
97-2670	washer, rubber, forks	EA
97-2671	retainer, fork damper rod	EA
97-2673	bolt, 5/16X26, chrome	EA
97-2682	oring, forkseal holder	EA
97-2688	USE 06-7745	ea
97-2689	USE 97-3875	ea
97-2702	nut, steering stem, compl.	EA
97-2704	USE 422-14	ea
97-2708	nut, forktube bottom, BSA	EA
97-2709	nut, forktube bottom, BSA	EA
97-2710	nut, forktube bottom, BSA	EA
97-3200	USE 97-4325	ea
97-3602	steering damper rod & knob	EA
97-3604	USE 83-4776 *	ea
97-3605	USE 97-3904 & 2245 & 2091	ea
97-3623	USE 97-3688	ea
97-3633	forkseal holder, chrome*	EA
97-3633/A	forkseal holder, alloy	PR
97-3633/ER	forkseal holder, chrome, econo. repl.	EA
97-3633/SS	forkseal holders, stainless	PR
97-3635	USE 531-28	ea
97-3637	USE 97-3906	ea
97-3638	washer, forkspring support	EA
97-3639	forkseal holder, short type	* EA
97-3641	USE 97-4170	ea
97-3643	USE 97-1844	ea
97-3645	USE 97-4220	ea
97-3647	USE 97-1844	ea
97-3648	USE 40-4960	ea
97-3650	bracket, fenderstay, BSA	EA
97-3651	USE 97-1892 *	ea
97-3659	forkyoke, bot, wide	EA
97-3662	forkyoke, top, wide, solidMt	EA
97-3663	brack, fender stay, forward	EA
97-3664	bracket, fenderstay, centre	EA
97-3667	forkyoke, top, wide, rub.mt.	EA

97-3668	USE 97-3688	ea
97-3672	sleeve,damping,forks,BSA*	EA
97-3677	mudguard,F,unpainted	EA
97-3677/A	mudguard,F,alloy,beaded	EA
97-3678	spring,forks,34lb.rating	EA
97-3682	cable guide assy.*	EA
97-3683	bracket,mudguard,bot,1hole,blk.	EA
97-3685	USE 97-3683	EA
97-3688	bracket,mudgrd,bot,1 hole,chrome	EA
97-3689	bracket,instr,pre71 Tribsa 1cyl.	EA
97-3693	brack,hdlgt,pre71 1cyl,LH	EA
97-3694	brack,hdlgt,pre71 1cyl,RH	EA
97-3740	forkyoke,bot,69 D14/4	EA
97-3765	USE 70-9711	ea
97-3766	oilseal,forks,D175 Bantam	EA
97-3767	sleeve,damping,forks	EA
97-3770	plug,front forks,Bantam	EA
97-3850	bracket,fenderstay,USA65L	EA
97-3862	forkyoke,bot,pre71 BSA2	EA
97-3870	USE 97-1140 *	ea
97-3875	steering damper rod &knob	EA
97-3878	USE 97-3904	ea
97-3879	USE 97-3906	ea
97-3882	USE 97-3677	ea
97-3884	USE 97-4439/SS	ea
97-3885	USE 97-4044	ea
97-3886	USE 97-4046	ea
97-3893	washer,sealing,forkdrain	EA
97-3894	screw,2BA,Philip	EA
97-3896	mudguard,F,A65F,A75	EA
97-3897	bracket,fender stay,2Hole	EA
97-3904	forktube,UNF,shuttlevalve,22"*	EA
97-3904/10	forktubes,UNF shuttle,+10	PR
97-3904/12	forktubes,UNF shuttle,+12"	PR
97-3904/14	forktubes,UNF shuttle,+14	PR
97-3904/2	forktubes,UNF shuttle,+2"	PR
97-3904/4	forktubes,UNF shuttle,+4"	PR
97-3904/6	forktubes,UNF shuttle,+6"	PR
97-3904/8	forktubes,UNF shuttle,+8"	PR
97-3904/A	forktube,UNF,hardchrome,22"*	EA
97-3904/ER	forktubes,UNF,shuttlevalve,econo	PR
97-3905	USE 97-2636	ea
97-3906	forktube,UNF,1969 &70 BSA,22.5"	EA
97-3906/10	forktubes,UNF,69&70BSA +10	PR
97-3906/12	forktubes,UNF,69/70 BSA,+12"	PR
97-3906/4	forktubes,UNF,69&70 BSA,+4"	PR
97-3906/6	forktubes,UNF,69&70BSA+6"	PR
97-3906/8	forktubes,UNF,69&70 BSA,+8"	PR
97-3906/ER	forktubes,UNF,69/70 BSA,econo	PR
97-3907	fork assy,twins,1970,rub.mt.bars	EA
97-3908	fork assy,twins,1970,solid mt.bars	EA
97-3910	USE 97-3908*	ea
97-3921	USE 97-4170	ea
97-3922	USE 97-4220	ea
97-3926	nut,square,lower forkleg	EA
97-3933	USE 97-4170	ea
97-3934	USE 97-4220	ea
97-3947	forkcap,conical wheels	EA
97-3947/A	forkcaps,conical wheel,billet	PR
97-3947/ER	forkcap,conical wheels,econo.repl.	PR
97-3952	USE 97-4342	ea
97-3954	USE 97-4343	ea
97-3985	USE 97-4115	ea
97-3987	USE 97-4313	ea
97-3996	USE 97-4325	ea
97-4001	oilseal,forks,71on TriBSA,orig.style	EA
97-4001/A	oilseal,forks,LEAKPROOF	PR
97-4001/B	oilseal,forks,LEAKPROOF,moly	PR
97-4001/ER	oilseal,forks,economy*	EA
97-4002	boot,fork tube	EA
97-4002/ER	boots,fork tube,econo	PR

97-4003	oring,damper valve,forks	EA
97-4003/A	seal kit,damper, Hi-Perf.	ST
97-4004	washer,sealing,bonded	EA
97-4005	bracket,steering damper	EA
97-4007	forktube,conical hubType,22"	EA
97-4007/10	forktubes,conical hub,+10"	PR
97-4007/12	forktubes,conical hub +12	PR
97-4007/2	forktubes,conical hub,+2"	PR
97-4007/4	forktubes,conical hub,+4" *	PR
97-4007/6	forktubes,conical hub,+6"	PR
97-4007/8	forktubes,conical hub,+8"	PR
97-4007/ER	forktubes,conical hubType,econo	PR
97-4008	USE 97-4258	ea
97-4009	spring,rebound,forkdamper	EA
97-4010	washer,fork damper valve	EA
97-4011	forkspring,7lon 1&2 cyl	EA
97-4011/A	forksprings,HiPerf,PROG.SUSP.	PR
97-4011/B	forksprings,multi-rate	PR
97-4012	nut,fork dampervalve,7lon	EA
97-4020	damper valve piston,forks,7lon	EA
97-4021	rubber grommet*	EA
97-4022	bracket,mudguard,conical*	EA
97-4023	bracket,instr,chrome,sm.	EA
97-4026	bracket,instrument,chrome,lg.*	EA
97-4026/SS	bracket,instr,lg,stainless	EA
97-4028	dustcover,steering hd.brg*	EA
97-4029	nut,steering head,3/4x16	EA
97-4031	bearing,taper w/seal,strg	EA
97-4033	USE 97-4342	ea
97-4034	USE 422-14 (20 of)	ea
97-4035	forkyoke,top,7lon drum br	EA
97-4044	bracket,fenderstay,bot,blk,2 hole	EA
97-4046	bracket,fender stay,bot,chrome	EA
97-4048	bracket,hdlt,7lon 1cyl,LH	EA
97-4050	bracket,hdlt,7lon 1cyl,RH	EA
97-4052	USE 97-4271	ea
97-4058	bracket,headlight,LH*	EA
97-4058/4060	brackets,7"headlight,71/72 650	PR
97-4060	bracket,headlight,RH*	EA
97-4065	USE 97-4271	ea
97-4075	USE 97-4359	ea
97-4076	nut,forktube bot,7lon*	EA
97-4080	fork assy,twins,1971/72	EA
97-4082	forkyoke,bottom,1971 650 *	EA
97-4084	USE 97-4035	ea
97-4085	USE 97-4343	ea
97-4087	USE 97-4011	ea
97-4088	bracket,5-3/4" hdlt,LH	EA
97-4090	bracket,5-3/4"hdlt,RH	EA
97-4092	nut,3/4x16,forkstemW/hole	EA
97-4102	nut,steering damper,7lon	EA
97-4112	clip,wiring,chrome	EA
97-4115	forkyoke,top,1971on 1cyl	EA
97-4116	USE 97-4319	ea
97-4121	bracket,hdlt,LH,w/sw.hole	EA
97-4123	USE 97-4203	ea
97-4125	spacer,headlight mount	EA
97-4127	USE 97-4271	ea
97-4138	forkyoke,bot,T150 drum,1971*	EA
97-4145	spacer,fork bearings,top	EA
97-4145/A	spacer,fork bearings,bottom	EA
97-4157	USE 97-1018	ea
97-4159	nut,3/4x16 forkstem,w/hole,3cyl.	EA
97-4160	bracket,zener diode,3cyl	EA
97-4162	bracket,hdlt,7lon 3cyl,LH	EA
97-4163	bracket,hdlt,7lon 3cyl,RH	EA
97-4166	washer,flat,top forktube	EA
97-4167	USE 97-3633	ea
97-4170	fork leg,left hand*	EA
97-4171	forkleg,pre69 unit Tri,RH *	EA
97-4173	USE 97-7041	ea

97-4193	USE 97-4007/2	ea
97-4195	bracket,hdlt,Hurricane	EA
97-4200	USE 97-4325	ea
97-4203	bracket,headlight,RH	EA
97-4215	spring,forks,71-74,3cyl.	EA
97-4220	fork leg,wide type RH*	EA
97-4244	nut,fork dampervalve,71on	EA
97-4252	bars,USA,Tri/BSA,1971	EA
97-4258	nut,forktube top,conical hub type,zinc	EA
97-4258/CHR	nut,forktube top,chr,stock type*	EA
97-4258/SS	nut,forktube top,stainless,smooth	PR
97-4259	decals,190cc,forktube nut	EA
97-4260	USE 97-4271	ea
97-4262	bracket,heat sink mt.	EA
97-4270	mudguard,wirestay,chr,USA	EA
97-4270/A	mudguard,wirestay,primer,USA	EA
97-4271	mudguard,wirestay,chr,UK*	EA
97-4271/A	mudguard,wirestay,primer,Uk	EA
97-4272	USE 97-4271 *	ea
97-4273	USE 97-4270	ea
97-4300	USE 97-7041	ea
97-4309	USE 97-4258	ea
97-4310	decals,230cc,forktube nut	EA
97-4313	forkyoke,bare,bot,71on B25/50,T25/TR5	EA
97-4315	forkyoke,bottom,1972 650 *	EA
97-4317	nut,3/4x24,forkstem,72on	EA
97-4317/SS	nut,3/4x24,forkstem,stainless	EA
97-4318	nut,3/4x24,forkstemW/hole	EA
97-4319	forkstem,71onB25/50,T25/TR5*	EA
97-4321	forkyoke,bot,3cyl.drum,72/73*	EA
97-4323	nut,3/4x24 forkstem,w/hole,3cyl.	EA
97-4325	dampner tube,forks*	EA
97-4326	bearing cone,forks,X75	EA
97-4341	USE 97-4321	ea
97-4342	forkleg,71on drum,LH	EA
97-4343	forkleg,71on drum,RH	EA
97-4359	bracket,fenderstay,offroad,late	EA
97-4376	USE 97-7089	ea
97-4377	USE 97-7088	ea
97-4380	forktube,dischrk.Tri.fork,22"	EA
97-4380/10	forktubes,Tri.disc,+10in.	PR
97-4380/2	forktubes,Tri.disc.,+2"	PR
97-4380/4	forktubes,Tri.disc.,+4"	PR
97-4380/6	forktubes,Tri.disc,+6inch	PR
97-4380/8	forktubes,Tri.disc,+8inch	PR
97-4380/ER	forktubes,dischrk.Tri.fork,econo	PR
97-4381	forkyoke,top,pre79 disc*	EA
97-4385	forkyoke,lower,early disc	EA
97-4387	nut,forktube top,allen hd*	EA
97-4391	USE 60-4206	ea
97-4394	USE 97-4395	ea
97-4395	nut,forktube top,upper,zinc*	EA
97-4395/CHR	nut,forktube top,upper,chrome	EA
97-4395/SS	nut,forktube top,upper,stainless	PR
97-4396	fork assy,T140pre79*	EA
97-4397	USE 97-4381	ea
97-4399	USE 97-7088	ea
97-4404	USE 97-4395	ea
97-4406	USE 97-4481	ea
97-4409	USE 97-4481	ea
97-4411	USE 97-7205	ea
97-4416	bracket,instr.mount,TR5T	EA
97-4417	USE 97-4121	ea
97-4439	mudguard,F,6hole,chrome	EA
97-4439/SS	mudguard,F,3 bracket,s.s*	EA
97-4440	USE 97-4439	ea
97-4442	USE 97-4550	ea
97-4444	USE 97-4547	ea
97-4446	USE 83-5151	ea
97-4447	USE 97-4552	ea
97-4456	fork cap,disc,LH	EA

97-4456/4457/A	fork caps,disc,steel	PR
97-4456/4457/B	forkcaps,disc,billet alloy	PR
97-4456/4457/ER	forkcaps,disc,economy repl.	PR
97-4457	fork cap,disc,RH	EA
97-4461	rubber,forktube	EA
97-4463	forkyoke,lower,T150 disc	EA
97-4468	fork assy,T150 disc	EA
97-4476	bolt,forkyoke pinch	EA
97-4477	USE 83-5150	ea
97-4480	cover,fork,top LH,T140,chrome*	EA
97-4480/4481/SS	covers,fork,top,T140,stainless	PR
97-4481	cover,fork,top RH,T140,chrome*	EA
97-4482	cover,fork,top LH,T150,chrome	EA
97-4483	cover,fork,top RH,T150,chrome	EA
97-4502	cover,fork,top LH,T100,chrome	EA
97-4503	cover,fork,top RH,T100,chrome	EA
97-4514	USE 97-7088	ea
97-4515	USE 97-7089	ea
97-4529	USE 97-4416	ea
97-4532	USE 97-4439	ea
97-4533	USE 97-4547	ea
97-4534	USE 97-4550	ea
97-4535	USE 97-4552	ea
97-4541	USE 97-7081	ea
97-4547	bracket,fr.mudguard,forw.	EA
97-4550	bracket,fenderstay,centre,chrome	EA
97-4552	bracket,rear,fr.fender	EA
97-4554	dampner tube,forks*	EA
97-4556	spring,forks,T160	EA
97-4557	cover,fork,top LH,T160	EA
97-4558	cover,fork,top RH,T160	EA
97-4563	USE 97-7205 *	ea
97-4564	bracket,headlight,LH	EA
97-4566	forkyoke,bot,T160	EA
97-4573	rubber cup,instr.mt,late	EA
97-4574	bracket,tach,T160&79on(LH)	EA
97-4575	bracket,speedo,T160&79on(RH)	EA
97-4577	console body,dash,T160&79	EA
97-4579	USE 97-7089	ea
97-4583	USE 97-7041	ea
97-4588	rubber bush,console dash	EA
97-4589	nut,ign.sw.	EA
97-4596	spacer,ign.sw.	EA
97-4600	USE 97-7034 & 97-5078	ea
97-4616	USE 97-4396 *	ea
97-4651	bars,T160	EA
97-5000	cover,dash console	EA
97-5053	USE 97-7138	ea
97-5055	USE 83-7064	ea
97-5056	bracket,headlight,T160,LH	EA
97-5057	bracket,headlight,T160 RH	EA
97-5058	USE 97-7004	ea
97-5061	rubber plug	EA
97-5074	lever,brake,alloy,disc	EA
97-5078	decal,210cc,forktube nut	EA
97-7001	USE 97-7205	ea
97-7002	USE 97-7041	ea
97-7003	USE 97-7039	ea
97-7004	bracket,bridge,fr.fender	EA
97-7004/CHR	bracket,bridge,fr.fender,chrome	EA
97-7006	spacer,axle, LH rear disc	EA
97-7010	USE 97-4001/A (set)	ea
97-7012	USE 97-7138	ea
97-7013	USE 97-7138	ea
97-7014	USE 97-7138	ea
97-7015	USE 97-7138	ea
97-7016	washer,oilseal retaining	EA
97-7031	USE 97-7095	ea
97-7032	USE 97-7095	ea
97-7034	forktube cap,plastic *	EA
97-7034/A	forktube cap,hex type,alloy *	PR

97-7035	lever,clutch,alloy,late	EA
97-7037	rubber plug,mirror hole	EA
97-7039	mudguard,fr,2bracket,chr.	EA
97-7039/SS	mudguard,fr,2bracket,s.s.	EA
97-7040	bars,USA,T140	EA
97-7041	bars,T140,UK	EA
97-7053	bush,clutch lever pivot	EA
97-7057	guide,cable	EA
97-7062	fork cap,lower,T140D	EA
97-7062/A	forkcaps,T140D,billet	PR
97-7065	mudguard,front,T140D type	EA
97-7070	nut,3/4X24,forkstem,1979 on	EA
97-7071	cap,plastic,forkstem nut	EA
97-7073	support,Fr.mudguard,T140D	EA
97-7079	USE 97-4001/A (set)	ea
97-7081	forkyoke,top	EA
97-7082	USE 97-7062	ea
97-7083	USE 97-7070 & 97-7071	ea
97-7088	forkleg,discbrake type,LH	EA
97-7089	forkleg,discbrake type,RH *	EA
97-7093	washer,forkseal upper	EA
97-7095	forkyoke,bottom,1979-1983	EA
97-7096	USE 97-7095	ea
97-7114	bracket,hdlt,82on,LH,blk	EA
97-7115	bracket,hdlt,82on,RH,blk	EA
97-7118	spacer,headlight mount*	EA
97-7119	rubber sleeve,hdlt.brack.	EA
97-7120	nut,ign.sw,1981on style	EA
97-7123	rubber cover,ignition key	EA
97-7126	USE 97-7138	ea
97-7138	USE 97-7039/SS	ea
97-7146	USE 97-7088	ea
97-7147	USE 97-7089	ea
97-7158	forkleg,dual disc type,RH	EA
97-7159	USE 97-7158	ea
97-7191	lever,clutch,alloy dogleg	EA
97-7193	lever,brake,alloy dogleg	EA
97-7198	bracket,hdlt,82on,LH,chrome	EA
97-7199	bracket,hdlt,82on,RH,chrome	EA
97-7204	USE 97-7138	ea
97-7205	bars,T140 US,8" rise	EA
97-7205/ER	bars,T140 US,8" rise,econo repl*	EA
97-7257	USE 98-0008	ea
98-	TRIUMPH PARTS	*
98-	-----	---
98-0008	mudguard,F,84type,S.steel	EA
99-	NORTON AND TRIUMPH PARTS	*
99-	-----	---
99-0001	USE 551-2031	ea
99-0002	USE 551-2031	ea
99-0003	USE 551-951 (set)	ea
99-0004	USE 551-997	ea
99-0023	USE 432-812	ea
99-0027	USE 433-04	ea
99-0028	USE 433-04	ea
99-0031	USE 432-335	ea
99-0041	USE GS36/005	ea
99-0045	USE 14-6101	ea
99-0046	USE 60-4251	ea
99-0047	nut,3/8x26,plain *	EA
99-0048	USE 60-4262	ea
99-0055	bolt,1/4x24,muffler clamp	EA
99-0057	USE 37-1021	ea
99-0059	USE 551-10581 (set)	ea
99-0062	USE 71-3748	ea
99-0063	USE 71-3748	ea
99-0107	USE 543-64546048	ea
99-0122	USE 543-64533645	ea
99-0137	USE 572-05	EA
99-0166	USE 572-RSM300301	ea
99-0168	nut,2BA,instrument mount	EA

99-0173	USE 572-01	ea
99-0224	USE 691-5077	ea
99-0225	USE 523-11013	ea
99-0226	USE 523-11014	ea
99-0230	USE 523-12595	ea
99-0238	USE 523-16008	ea
99-0239	USE 523-16009	ea
99-0240	USE 523-16010	ea
99-0241	USE 523-16011	ea
99-0246	USE 523-16329	ea
99-0250	USE 523-18053	ea
99-0251	USE 523-18084	ea
99-0252	USE 523-18087	ea
99-0337	523-210007	ea
99-0338	USE 523-210008	ea
99-0339	USE 691-5077	ea
99-0347	USE 523-31313	ea
99-0418	USE 691-376072/106	ea
99-0425	USE 691-376076/20	ea
99-0426	USE 691-376076/25	ea
99-0438	USE 691-376093	ea
99-0441	USE 691-376100/230	ea
99-0443	USE 691-376100/140	ea
99-0444	USE 691-376100/160	ea
99-0445	USE 691-376100/180	ea
99-0446	USE 691-376100/190	ea
99-0447	USE 691-376100/200	ea
99-0448	USE 691-376100/210	ea
99-0449	USE 691-376100/220	ea
99-0450	USE 691-376100/230	ea
99-0451	USE 691-376100/240	ea
99-0452	USE 691-376100/250	ea
99-0453	USE 691-376100/260	ea
99-0454	USE 691-376100/270	ea
99-0455	USE 691-376100/280	ea
99-0456	USE 691-376100/290	ea
99-0457	USE 691-376100/300	ea
99-0458	USE 691-376100/320	ea
99-0502	USE 691-622101	ea
99-0506	USE 691-622055	ea
99-0509	USE 691-622129	ea
99-0510	USE 691-622067	ea
99-0511	USE 691-622197	ea
99-0512	USE 691-622069	ea
99-0513	USE 691-622071	ea
99-0514	USE 691-622073	ea
99-0515	USE 691-622076	ea
99-0516	USE 691-622077	ea
99-0517	USE 691-622078	ea
99-0520	USE 691-622082	ea
99-0521	USE 691-622086	ea
99-0522	USE 691-622101	ea
99-0527	USE 691-928060/3.5	ea
99-0528	USE 691-928062	ea
99-0537	USE 392-281	ea
99-0542	USE 392-380	ea
99-0545	USE 392-446	ea
99-0548	USE 392-989	ea
99-0552	USE 691-622101	ea
99-0555	USE 391-31563	ea
99-0558	USE 391-30608	ea
99-0563	USE 391-31788	ea
99-0564	USE 391-35835	ea
99-0568	USE 391-38189	ea
99-0569	USE 391-38191	ea
99-0576	USE 391-45275	ea
99-0588	USE separate components*	EA
99-0589	USE 391-49072	ea
99-0590	USE 391-49345	ea
99-0597	USE 391-53973	ea
99-0612	USE 391-70276	ea

99-0630	USE 391-380459	ea
99-0683	USE 391-504665	ea
99-0686	USE 391-516798	ea
99-0690	USE 391-534296	ea
99-0691	USE 391-534343	ea
99-0692	USE 391-553248	ea
99-0694	USE 391-554602	ea
99-0704	USE 391-575219	ea
99-0719	USE 335-02	ea
99-0725	USE 391-54033234	ea
99-0737	USE 391-54170009	ea
99-0739	USE 391-60600684	ea
99-0757	USE 391-54415642	ea
99-0767	USE 391-54418528	ea
99-0769	USE 391-54419220	ea
99-0771	USE 391-54425657	ea
99-0772	USE 391-54419827	ea
99-0778	USE 391-54483156	ea
99-0803	USE 391-54364380	ea
99-1000	USE 391-54130041	ea
99-1001	USE 345-1457	ea
99-1004	USE 391-112201	ea
99-1005	USE 391-137498	ea
99-1006	USE 391-47205	ea
99-1009	USE 323-69/A	ea
99-1013	USE 391-54419327	ea
99-1014	USE 391-54419828	ea
99-1015	USE 391-54419867	ea
99-1016	USE 391-47209	ea
99-1023	USE 691-622126	ea
99-1024	USE 691-5077	ea
99-1026	USE 391-54524048	ea
99-1027	USE 391-33188	ea
99-1028	USE 391-34815	ea
99-1030	USE 391-57111	ea
99-1031	USE 523-18838/839	ea
99-1032	USE 691-928098	ea
99-1033	USE 691-622131	ea
99-1034	USE 691-622128	ea
99-1035	USE 691-622122/106	ea
99-1036	USE 691-622124	ea
99-1037	USE 691-928103	ea
99-1038	USE 691-622129	ea
99-1041	USE 391-54525272	ea
99-1043	USE 391-54420128	ea
99-1044	USE 391-36403	ea
99-1045	USE 345-1061	ea
99-1046	USE 391-54577109	ea
99-1051	USE 691-622129	ea
99-1053	USE 345-1498	ea
99-1102	USE 523-364018 *	ea
99-1109	USE 391-56605	ea
99-1119	USE 391-57160	ea
99-1129	USE 433-04	ea
99-1151	USE 391-54419974	ea
99-1152	USE 691-622155	ea
99-1153	USE 691-622151	ea
99-1156	USE 391-516798	ea
99-1157	USE 06-2321	ea
99-1158	USE 345-1007	ea
99-1160	USE 391-54418526	ea
99-1161	USE 391-57183	ea
99-1162	USE 391-575189	ea
99-1164	USE 391-36421	ea
99-1166	USE 432-835	ea
99-1179	element,oilfilter,small	EA
99-1181	washer,rubber,oilfilter	EA
99-1182	oring	EA
99-1186	USE 543-54533645	ea
99-1188	USE 391-54115246	ea
99-1189	USE 391-144921	ea

99-1190	USE 391-56605	ea
99-1191	USE 391-60600621	ea
99-1192	USE 392-382	ea
99-1193	USE 391-54123401	ea
99-1200	USE 391-30552	ea
99-1201	USE 391-35048	ea
99-1204	USE 391-54385091	ea
99-1207	USE 391-54363453	ea
99-1208	USE 391-54363522	ea
99-1209	USE 391-54363455	ea
99-1210	USE 391-54140331	ea
99-1211	USE 391-31356	ea
99-1212	USE 391-54525272	ea
99-1213	USE 391-54573590	ea
99-1214	USE 392-446	ea
99-1215	USE 391-54343791	ea
99-1216	USE 391-70276	ea
99-1219	USE 323-66	ea
99-1221	USE 323-69	ea
99-1222	USE 345-1014 & 345-1015	ea
99-1223	USE 391-54115106	ea
99-1224	USE 391-143086	ea
99-1228	USE 345-1013	ea
99-1233	USE 391-54419327	ea
99-1234	USE 391-54417992	ea
99-1249	USE 391-516798	ea
99-1251	USE 391-34419	ea
99-1252	USE 391-56513	ea
99-1253	USE 323-66	ea
99-1256	USE 83-2216	ea
99-1257	USE 391-54584930	ea
99-1259	USE 345-1142	ea
99-1260	USE 345-1144	ea
99-1263	USE 391-54425657	ea
99-1264	USE 391-54415642	ea
99-1265	USE 391-54425160	ea
99-1266	USE 391-60600271	ea
99-1268	USE 391-54033751	ea
99-2751	USE 60-4365	ea
99-2752	USE 60-4366	ea
99-2753	housing, master cyl.	EA
99-2754	mastercylinder trap valve	EA
99-2755	spring, mastercylinder piston	EA
99-2756	retainer, spring, mastercyl	EA
99-2757	mastercyl.primary cup	EA
99-2758	washer, curved, mastercyl.	EA
99-2759	piston, mastercylinder*	EA
99-2759/SS	piston, mastercylinder, stainless	EA
99-2760	mastercyl.secondary cup	EA
99-2761	circlip, mastercylinder	EA
99-2762	rubber boot, mastercyl, fr.*	EA
99-2763	screw, set, allen, mastercyl	EA
99-2764	nipple, bleed, caliper	EA
99-2765	piston, caliper, chrome	EA
99-2765/A	piston, caliper, alloy	EA
99-2765/SS	pistons, caliper, stainless	PR
99-2766	USE 99-7006 (kit)	ea
99-2767	USE 99-7006 (kit)	ea
99-2768	seal kit, master cyl, F	EA
99-2769	brakepads, Lockheed, fr. & r. *	PR
99-2769/A	brakepads, Hi-Perf SBS, F&R	PR
99-2769/B	brakepads, DUNLOP, ironDisc	PR
99-2769/ER	brakepads, Tri. disc, econo*	PR
99-2770	mastercyl.barrel assembly	EA
99-2770/SS	mastercyl.barrel assy, stainless	EA
99-3023	USE 433-05/B	ea
99-3501	USE 60-1816	ea
99-3502	USE 60-1816	ea
99-3504	USE 60-0052	ea
99-3506	USE 60-0056	ea
99-3507	decal, BONNEVILLE 120, script, gold	EA

99-3508	decal,BONNEVILLE 120,script,black	EA
99-3509	USE 60-0061	ea
99-3512	USE 222-180	ea
99-3514	bracket,chronometric mounting	EA
99-3516	bolt,5/16x26	EA
99-3517	USE 04-0137	ea
99-3518	bolt,5/16x26	EA
99-3524	USE GS36	ea
99-3525	USE 70-2254	ea
99-3526	USE 57-3673	ea
99-3527	plunger,oilpump,.375"diam	EA
99-3540	USE 40-0239	ea
99-3541	nut,holder,F.fenderstay	EA
99-3542	USE 57-2009	ea
99-3544	cap,pri.chainInsp,preunit	EA
99-3545	washer,sealing,insp.cap*	EA
99-3557	nut,1/2x20	EA
99-3600	USE 222-613768	ea
99-3602	USE 221-82/7075	ea
99-3604	USE 222-296 or 222-296/A	ea
99-3605	USE 222-296 or 222-296/A	ea
99-3620	USE 221-82/6065	ea
99-3621	USE 221-82/6570	ea
99-3633	USE 222-617017	ea
99-3700	USE 451-279	ea
99-3701	USE separate components	ea
99-3702	USE 442-3850	ea
99-3703	USE 442-3850/010	ea
99-3704	USE 442-3850/020	ea
99-3706	USE 442-3850/040	ea
99-3707	USE separate components	ea
99-3708	brg.cup&cone set,strg.hd,rigid type*	ST
99-3715	USE 441-19119	ea
99-3716	USE 441-19119/020	ea
99-3717	USE 441-19119/040	ea
99-3718	USE 451-510	ea
99-3721	brg.cup&cone set,strg.hd,Cub*	ST
99-3722	USE 441-12581	ea
99-3725	USE 441-12581	ea
99-3733	brg.cup&cone set,strg.hd,swingarm*	ST
99-3733/A	brg.set,taper conv,strgHd	EA
99-3733/ER	brg.cup&cone set,strg.hd,econo	ST
99-3736	USE 442-10280	ea
99-3737	USE 442-10280/010	ea
99-3738	USE 442-10280/020	ea
99-3739	USE 442-10280/040	ea
99-3741	bearing set, strng, 3TA/5TA, pre67*	EA
99-3741/A	brg.set,taper conv,strgHd	EA
99-3741/ER	bearing set, strng, 3TA/5TA, econo*	EA
99-3745	USE 441-12581	ea
99-3750	USE 442-13570	ea
99-3751	USE 442-13570/010	ea
99-3752	USE 442-13570/020	ea
99-3754	USE 451-615	ea
99-3760	USE 551-10581	ea
99-3763	USE 451-574	ea
99-3769	USE 551-1095	ea
99-3772	USE 442-11050/010	ea
99-3773	USE 442-11050/020	ea
99-3777	USE 442-23010	ea
99-3778	USE 442-23010/020	ea
99-3779	USE 442-23010/040	ea
99-3780	USE 442-23020	ea
99-3781	USE 442-23020/010	ea
99-3782	USE 442-23020/020	ea
99-3783	USE 442-23020/040	ea
99-3784	USE 442-11050	ea
99-3788	USE 442-17350	ea
99-3789	USE 442-26490	ea
99-3790	USE 442-26490/010	ea
99-3791	USE 442-26490/020	ea

99-3792	USE 442-26490/040	ea
99-7001	USE 432-836/D	ea
99-7002	USE 433-05/B	ea
99-7005	USE 543-70520135	ea
99-7006	rebuild kit,caliper,fr.&r*	EA
99-7012	USE 391-54115106	ea
99-7013	screw,10-32,tailense*	EA
99-7018	rubber boot,rearMasterCyl	EA
99-7021	connector,inlet,mastercyl	EA
99-7022	sealkit,master cyl,rear	EA
99-7027	mastercyl.barrel only,bare	EA
99-7027/SS	mastercyl.barrel,bare,stainless	EA
99-7037	USE 451-646	ea
99-7039	USE 323-700/B	ea
99-7043	USE 391-54400905	ea
99-7044	USE 391-54400766	ea
99-7045	USE 391-56513	ea
99-7046	USE 391-54584930	ea
99-7047	USE 391-35316	ea
99-7048	USE 391-35318	ea
99-7051	USE 391-83539	ea
99-7052	USE 323-700	ea
99-7053	USE 323-700	ea
99-7054	USE 391-54361250	ea
99-7055	USE 391-30552	ea
99-7056	USE 345-1186	ea
99-7058	USE 391-60600684	ea
99-7065	USE 391-54584931	ea
99-7073	USE 691-2622067	ea
99-7074	USE 691-2928030	ea
99-7079	USE 691-2928062	ea
99-7083	USE 691-376100/200	ea
99-7087	USE 691-2622070	ea
99-7092	USE 691-2622145	ea
99-7098	USE 323-700/A	ea
99-7125	USE 451-02 (4 of)	ea
99-7550	USE 391-54400766	ea
99-7562	USE 421-5400/010 (set)	ea
99-7563	USE 421-5400/020 (set)	ea
99-7570	USE 421-5400 (set)	ea
99-7575	lens,turnsignal,sq,1982on	EA
99-7583	jet,main,Bing#140	EA
99-9059	USE 691-622134	ea
99-9923	USE 99-7018	ea
99-9924	washer,tab,masterycl,rear	EA
99-9925	nut,connector,inlet,m.cyl,rear	EA
99-9927	nut,slotted,masterycl,rear	EA
99-9928	nut,barrel,masterycl,rear	EA
99-9947	USE 99-7013	ea
99-9980	USE 391-862217	ea
99-9982	cyl.barrel conv.kit,alloy,TR7/140	ST
-	-	---
100-	BRITISH CYCLE SUPPLY PUBLICATIONS	*
100-----	-----	---
101-	BCS EXTERNAL FORMS	*
101-----	-----	---
101-001	company info brochure	EA
101-002	BSA Owners Club sample & appl.	EA
101-003	Norman Hyde brochure	EA
101-004	BCS dealer application forms	EA
101-005	BCS best seller list	EA
101-006	speedo & tach policy sheet	EA
101-007	Price Guide,Cdn.Retail,Sept. 2001	EA
101-007/A	priceguide,Cdn.dlr,5.25"diskette	EA
101-007/B	priceguide,Cdn.dlr,3.5"diskette	EA
101-007/C	priceguide,USdlr,5.25"diskette	EA
101-007/D	priceguide,USdlr,3.5"diskette	EA
101-007/E	priceguide,Cdn.retail,5.25"diskette	EA
101-007/F	priceguide,Cdn.retail,3.5"diskette	EA
101-007/G	priceguide,USretail,5.25"diskette	EA
101-007/H	priceguide,USretail,3.5"diskette	EA

101-007USA	Price Guide,USARetail,Sept 2003	EA
101-008	SEE APPROPRIATE PRICEGUIDE	ea
101-009	catalogue,BRITISH CYCLE SUPPLY,#12,JAN02	EA
101-101	info pack	PK
101-102	dlr.approval pack*	PK
101-103	quote reply pack	PK
101-104	BCS Feb/93 Sale Flyer	EA
101-105	race program info pack	EA
101-106	instructions,"BRITAX"for345-1009harness*	EA
101-107	decal,BCS,"Parts Supplied"	EA
101-AMAL/01	booklet,AMAL concentric tuning	EA
101-AMAL/02	booklet,AMAL monobloc tuning	EA
101-AMAL/03	booklet,AMAL pre-monobloc tuning	EA
101-AMAL/04	booklet,AMAL MKII tuning booklet	EA
101-BSAOC	BSA Owners Canada Membership	EA
102-	BCS INTERNAL FORMS	*
102-----	-----	--
150-	COMPACT DISKS	--
150-----	-----	---
150-01	CD,LUCAS Electrics	EA
150-11	CD,BSA pts. books & shopmanuals*3rd Ed.	EA
150-12	CD,BSA 1914-30,parts catalogues	EA
150-13	CD,BSA 1940,1947-52,parts catalogues	EA
150-14	CD,BSA 1930-39, parts catalogues	EA
150-15	CD,BSA Service Sheets 1946-1963	EA
150-21	CD,Norton pts. books & shopmanuals*3rdEd	EA
150-31	CD,Triumph pts. books & shopman* Cen.Ed.	EA
150-41	CD,Ariel Parts Books & Owners Guides	EA
150-51	CD,Enf.single pts.books&manuals,30s-60s	EA
211-	HAYNES & FOULIS BOOKS	*
211-----	-----	--
211-01	book rack,Haynes	EA
211-1083	Motorcycle Basics Manual	EA
211-117	BSA Bantam manual	EA
211-121	BSA A7 & A10 manual	EA
211-122	Triumph Unit 6&750 manual	EA
211-125	Commando 750/850 manual	EA
211-127	TriBSA unit single manual	EA
211-136	750 3 cyl,T150/A75 manual*	EA
211-137	Tri 500 unit twin manual*	EA
211-1454	MC Workshop Practice Man.	EA
211-155	BSA unit twins manual	EA
211-186	Velocette singles manual,OUTOF PRINT	EA
211-187	Nor.Twin manual(pre Comm)	EA
211-251	Tri Preunit Twin manual	EA
211-326	BSA Preunit Single manual*	EA
211-3471	Motorcycle Electrics man.	EA
211-3514	motorcycle fuel system manual	EA
211-414	Triumph TigerCub manual	EA
211-446	USE 211-3471	ea
211-603	USE 211-3514	ea
211-F182	"It's A Triumph",history	EA
211-F185	USE 211-F853	EA
211-F255	OUT OF PRINT Giants of SH	EA
211-F257	USE 211-F957	ea
211-F266	"Always in Picture",Velo	EA
211-F283	VELOCETTE DEVELOPMENT HISTORY	EA
211-F313	"A Million Miles Ago"hist	EA
211-F333	"Bantam Super Profile"	EA
211-F335	"Commando Super Profile"	EA
211-F352	Trident Super Profile	EA
211-F353	"Thunderbird SuperProfile	EA
211-F363	Sunbeam S7&8 SuperProfile	EA
211-F364	BroughSuperior SuperProf.	EA
211-F365	Nort.Intern. SuperProfile	EA
211-F388	"Square 4 Super Profile"	EA
211-F444	"Velo KSS Super Profile"	EA
211-F446	BSA A7& A10 SuperProfile	EA
211-F452	"Manx Super Profile"	EA
211-F453	"Bonneville SuperProfile"	EA
211-F455	Match.G3L&G80SuperProfile	EA

211-F458	JAP,The Vintage Years	EA
211-F459	"Whatever Happened?"hist.	EA
211-F460	"Vincent Super Profile"	EA
211-F472	Vintage Cyclist's Workshp	EA
211-F479	BSA Competition History	EA
211-F483	BSA Goldstar Superprofile	EA
211-F485	"BSA M20&M21 SuperProfile	EA
211-F489	T-100/Daytona,dev.history	EA
211-F611	JAP - The End of an Era	EA
211-F662	"Full Circle"by English	EA
211-F688	"Sunbeam,Illus. History"	EA
211-F709	Practical 2-Stroke M/C's	EA
211-F722	Triumph Speed Twin	EA
211-F786	It's Easy on a Triumph	EA
211-F799	Douglas M/C,illus. History	EA
211-F853	Resto of Vintage MC,2nd Ed	EA
211-F901	British 4-Stroke M/C	EA
211-F957	"Bonnie Book" 2nd Ed.	EA
212-	CLYMER MANUALS	*
212-----	-----	--
212-302	BSA,Clymer,USE M330	EA
212-361	Norton,Clymer,USE M330	EA
212-382	Triumph,Clymer,USE M330	EA
212-M330	Vintage British,Clymer	EA
213-	OSPREY BOOKS	*
213-----	-----	--
213-1181	Classic M/C,BSA	EA
213-1246	Classic M/C,Triumph	EA
213-1408	Classic M/C,Norton	EA
213-1815	Norton Rotaries	EA
213-2021	"Norton" by M. Woollett	EA
213-3303	Classic M/C,Vincent	EA
213-3682	"BSA Twins&Triples" hist.	EA
213-3982	Classic M/C,Bonneville	EA
213-4034	USE 213-7009	ea
213-4055	Road Racing 50's,McKinnon	EA
213-4239	"Norton Twins" history	EA
213-4288	Classic M/C,Tri,Triples	EA
213-4352	"Vincent Vee Twins" hist.	EA
213-4476	"BSA GStar&Other Singles"	EA
213-459	"Royal Enfield Postwar"	EA
213-4859	"Norton Singles" history	EA
213-4867	"Villiers Singles &Twins"	EA
213-5367	"AJS/Matchless Postwar"	EA
213-5375	"Ariel Postwar Models"	EA
213-5456	"ClassicBrit.TrialsBikes"	EA
213-560X	"M/Cycle Chassis Design"	EA
213-5669	"Triumph Singles" history	EA
213-5898	Classic M/C Racer Tests	EA
213-6185	"Military M/C WW2" OP	EA
213-6320	"Velocette Flat Twins"	EA
213-6355	"TriumphTwin Restoration"	EA
213-6495	Classic Brit. Scramblers	EA
213-6576	"British M/C's of 1930's"	EA
213-669	"BSA Twin Restoration"	EA
213-6770	"Cafe Racers" by Clay	EA
213-7009	"Triumph Twins & Triples"	EA
213-7084	"Norton Twin Restoration	EA
213-7092	"BSA Singles Restoration"	EA
213-7173	Velocette, by Rhodes	EA
213-7459	Brit 2 Str Trials Bikes	EA
213-7556	"Matchless & AJS Resto."	EA
213-7858	"British M/C's of 1960's"	EA
213-7874	"Restoring 4-Stroke Eng."	EA
213-7882	"Restoring M/C Electrics"	EA
213-8072	Road Bike Racing Prep.	EA
213-8560	"British M/C's 40's&50's"	EA
213-8587	"Restoring M/C Carbs"	EA
213-8595	"Restoring M/C Tran."	EA
213-8609	"Restoring 2-Stroke Eng."	EA
213-8617	"Resto. M/C Frames/Forks"	EA

213-8803	Classic Brit. Racing M/C	EA
213-882X	"Greeves"	EA
213-9192	A-Z Guide to British M/C	EA
214-	BOOKS, MISCELLANEOUS	*
214-----	-----	---
214-0007	"MC Milestones"-Renstrom	EA
214-0050	M/C Legends, Triumph	EA
214-005753	Norton Part# Conversions	EA
214-01	ModernMotorcycleMechanics	EA
214-0180	Tri/BSA Triples-Duckworth	EA
214-02	"Mcycle Riding in Canada"	EA
214-0217	Brit. M/C Since 1950, #5	EA
214-026	T100/Daytona pts. specs.	EA
214-03	"Triumph Speed Tuning"man	EA
214-0312	Handbook of Classic British Bikes	EA
214-0330	Best of British Bikes	EA
214-04	"Mcycle Elect.W/Out Pain"	EA
214-0415	Triumph Motorcycles by Tipler* Hinckley	EA
214-05	Dunstall's"Norton Tuning"	EA
214-0573	Great MC Legends-Renstrom	EA
214-06	Triumph "Tuning Sheet"set	ST
214-07	Hurricane Named Vetter	EA
214-08	NORVIL Conversion sheets	EA
214-0837	Classic Brit. M/C + 500cc	EA
214-09	"What Year Is It??" Book	EA
214-10	Triumph Chopper Guide*	EA
214-11	Triumph Buyer's Guide	EA
214-12	BSA Buyer's Guide	EA
214-1260	BSA, Illus. Legend, Bacon *	EA
214-13	Rockers!	EA
214-14	Classic M/C Engines	EA
214-15	The Gold Star Book	EA
214-16	Norton Buyer's Guide	EA
214-17	Matchless Buyer's Guide	EA
214-1743	Tri Racing MC in USA	EA
214-18	Vincent Buyer's Guide	EA
214-1832	Tri M/C Resto Guide, Gaylin	EA
214-20	Tuning for Speed by Irving*	EA
214-2021	USE 213-2021	EA
214-2194	Norton, Illus. Legend	EA
214-2620	Velocette Saga book	EA
214-2664	Triumph Motorcycles by Tipler	EA
214-2671	Royal Enfield, Bradford	EA
214-2800	Great British M/C the 60's by Currie	EA
214-3092	Triumph:Return of the Legend	EA
214-3106	Norton:Racing Legend	EA
214-3126	Triumph Twins & Triples, Remus	EA
214-3925	Brit. M/C Since 1950, #6	EA
214-3933	M/C Restorer's Workshop	EA
214-4137	TRIUMPH STORY, RACING&PRODUCTION, MINTON	EA
214-4199	"Cafe Racers"by Walker	EA
214-4269	BRITISH CLASSIC BIKE GUIDE, WESTWORTH	EA
214-4564	Triumph MC's, A Century of Passion	EA
214-458X	Triumph by Ivor Davies	EA
214-4901	BRITISH M/C SINCE 1900, COLLINS	EA
214-4972	Classic Hints & Tips	EA
214-5071	CLASSIC M/C, TRIUMPH (HUGO WILSON)	EA
214-5169	Brit. M/C Since 1950, #1	EA
214-5395	BSA Bantam	EA
214-5443	Tiger Cub Bible, Estall	EA
214-5454	Norton, The Complete Story	EA
214-5464	M/Cing in 50's, by Clew	EA
214-557X	Tri MC:Tales of Meriden	EA
214-5638	Royal Enfield, The Complete Story	EA
214-5665	Brit. M/C Since 1950, #2	EA
214-5715	Triumph M/C 1950-88, Wilson	EA
214-5723	BSA M/C Since 1950, Wilson	EA
214-5731	Norton M/C 1950-86, Wilson	EA
214-5877	Turner's Triumphs by Clew	EA
214-6122	Triumph Trophy & Tiger Bible, H. Woolridge	EA
214-6262	Brit. M/C Since 1950, #3	EA

214-6656	TRIUMPH BONNEVILLE & TR6,REMUS	EA
214-6792	TRIUMPH T120/T140 BONNEVILLE,WILSON	EA
214-7023	BSA,The Complete Story	EA
214-7363	MANX NORTON, WALKER	EA
214-7371	Road Racing 50's,Jenkinson	EA
214-7467	Triumph M/C in America	EA
214-7768	ORIGINAL TRIUMPH BONNEVILLE,KANE	EA
214-782X	Classic M/C,Resto/Collect	EA
214-7853	The Winged Wheel Patch	EA
214-7919	"Norton Story"	EA
214-8303	Brit. M/C Since 1950, #4	EA
214-8505	Jupiter's Travels-Ted Simon	EA
214-8684	Know Thy Beast (Vincent)	EA
214-8689	"M/C Encyclo." Tragatsch	EA
214-880X	Classic Competition M/C	EA
214-9001	Norton from 1946	EA
214-901X	Vincent From 1938	EA
214-9055	Norton,Pict.Hist.,Reynolds	EA
214-9063	Triumph,Pict.Hist.,Davies	EA
214-9176	Triumph Twins from 1937	EA
214-9200	H.R.D. M/C,Preece	EA
214-980X	The Panther Story by Barry M Jones	EA
214-9818	Rupert Ratio BSA Unit Singles Eng Manual	EA
214-9834	Original Vincent M/C - Bickerstaff	EA
214-9842	"When Rosie Met Anneka" by Steve Wilson	EA
214-BSA/01	BSA Road Tests 1962-1971	EA
214-GOLD/01	G.Portfolio,BSA A50/65	EA
214-GOLD/02	G.Portfolio,BSA A7/A10	EA
214-GOLD/03	G.Portfolio,AJS/Matchless	EA
214-GOLD/04	G.Portfolio,Commando	EA
214-GOLD/05	G.Portfolio,Bonneville	EA
214-GOLD/06	G.Portfolio,Vincent	EA
214-GOLD/07	G.Portfolio,BSA/Triumph Triples	EA
214-GOLD/08	G.Portfolio,BSA Singles 45-63	EA
214-GOLD/09	G.Portfolio,BSA Singles 64-74	EA
214-MIKUNI	man,Mikuni Carb Tuning	EA
214-MONO/01	monograph,Bacon,Bantam	EA
214-MONO/02	monograph,Bacon,Commando	EA
214-MONO/03	monogph,Bonnie T120,59-74	EA
214-MONO/04	monograph,Bacon,BSA A7/10	EA
214-MONO/05	mono,Tiger 100/110,39-61	EA
214-MONO/06	mono,AJS/Matchless twins	EA
214-MONO/07	mono,BSA unit singles58-73	EA
214-MONO/08	monograph,Bacon,Tri. T140	EA
214-MONO/09	monograph,Norton Dominator	EA
214-MONO/10	monograph,Bacon,BSA A50/65	EA
214-MONO/11	mono,AJS/Matchless singles	EA
214-MONO/12	mono,Tri 3/5/6T & 3TA/5TA	EA
214-MONO/13	mono,Ariel Leader/Arrow	EA
214-MONO/14	mono,Velo,Viper,Ven,Thrx.	EA
214-MONO/15	mono,Tri T90/100,1960-74	EA
214-MONO/16	mono,BSA pre-unit singles	EA
214-MONO/17	monograph,Norton singles	EA
214-MONO/18	mono,Tri/BSA triples	EA
214-NOR/01	Norton Road Tests 1962-71	EA
214-TRI/01	Triumph Road Tests 62-67	EA
214-TRI/02	Triumph Road Tests 67-72	EA
214-TRI/03	Triumph Road Tests 72-87	EA
215-	"FACTORY" MANUALS	*
215-----	-----	---
215-004020	servicesheets,BSA D group	EA
215-004036	ownerman,Bantam D1/3/5	EA
215-004047	service sheets,BSA A7&A10	EA
215-004048	servicesheets,BSA B group	EA
215-004050	service sheets,BSA C11&12	EA
215-004082	service sheets,BSAC15&B40	EA
215-004113	shopmanual,pre66BSA A50/65	EA
215-004115	ownerman,CycloneLightning	EA
215-004116	ownermanual,67BSA A50&A65	EA
215-004117	owner man.A50/A65,1965	EA
215-004123	shopmanual,1966-68 BSAtwin	EA

215-004124	ownermanual, 67 Bantam D10	EA
215-004128	shopmanual, B44VS, GP, Enduro, all*	EA
215-004132	owner man, B44V End, Roadster, C25Barracuda	EA
215-004136	shopmanual, 66-68 B25& B44SS	EA
215-004138	owner manual, B44, C25	EA
215-004139	owner man, B44 VS, SS & B25 Starfire 1968	EA
215-004142	owner man, A50/A65, 1968	EA
215-004144	ownerman, 69 BSA B44/B25	EA
215-004147	ownermanual 1969 BSA A75	EA
215-004162	owner man, BSARocket3, 1970	EA
215-004169	servicesheets, Bantam B175	EA
215-004176	shopmanual, 69-70 B25 &B44SS	EA
215-004177	shopmanual, 69-70 A50 &A65	EA
215-004180	shopmanual, BSA A75R, pre71	EA
215-004182	shopmanual, Ariel 3	EA
215-004183	ownermanual, 1971 B25 &B50	EA
215-004184	ownermanual, 1971 BSA A65	EA
215-004188	shop manual, BSA 250/500, 71on	EA
215-004189	shopmanual, 1971on BSA A65	EA
215-004191	shopmanual, BSA A75 Rocket	EA
215-004218	ownerman, 72 BSA 650/750	EA
215-004220	ownerman, BSA 1973 T65	EA
215-004222	ownermanual, Triumph T160	EA
215-004223	shopmanual suppl, discT150	EA
215-004224	shopmanual, Nort. 850Mk3 ES	EA
215-004225	shopmanual, Triumph T160V	EA
215-004226	ownermanual, 1977 Tri. 750	EA
215-063061	ownerman, 69/70 Fastbk etc	EA
215-063062	shopmanual, pre70 Commando	EA
215-063063	ownermanual, 1971 Commando	EA
215-063852	ownermanual, Norton 750/850	EA
215-064135	ownermanual, 1973 Comm 750	EA
215-064585	ownermanual, 73 Comm 850	EA
215-064866	ownerman, Nor Mk1A supp.	EA
215-065146	shopmanual, 1970-74 Norton	EA
215-065321	ownermanual, 74 Nor 850	EA
215-066144	ownermanual, suppl, 850 JPN	EA
215-066240	ownermanual, Nor850 Mk3 ES	EA
215-068201	shopmanual, featherbed1&2cyl.	EA
215-068201/A	shopmanual, 250-750twins, 1960-68	EA
215-607191	owner manual, 1979 T140E	EA
215-607192	ownermanual, 79 TR7 UK	EA
215-607234	ownermanual, Bonne. Special	EA
215-607284	ownermanual, 1980 Bonnie	EA
215-607285	ownermanual, 1980 Tiger	EA
215-607396	ownermanual, 81 Tri. 750	EA
215-607539	ownerman, Tri 750 82/83	EA
215-607656	ownermanual, Triumph, TSS	EA
215-607700	ownermanual, Triumph, TSX	EA
215-630075	ownermanual, 87on MatchG80	EA
215-990833	shopmanual, Terrier & Cub*	EA
215-990834	ownermanual, 63-65 Cub	EA
215-990835	ownermanual, 66-68 Cub	EA
215-990836	shopmanual, 45-56 Tri. Twin	EA
215-990837	shopmanual, 57-preunit Tri*	EA
215-990839	ownermanual, 1967 Tri. 650	EA
215-990840	ownermanual, 67 T120 US	EA
215-990842	shopmanual, pre63uc350/500(#4) *	EA
215-990842/A	shopmanual, pre59uc350/500(#2)	EA
215-990843/0948	shopmanual, 63onTri350/500	EA
215-990867	ownermanual, 69 T150	EA
215-990868	ownermanual, 68 TR25W UK	EA
215-990869	ownerman, 69 Tri TR25W USA	EA
215-990873A	ownermanual, 67 T100 US	EA
215-990873B	ownermanual, 67 T100 UK	EA
215-990874	ownermanual, 69 T100 UK	EA
215-990875	ownermanual, 1968 Tri. 500	EA
215-990876	ownermanual, 69 T120 US	EA
215-990877	ownermanual, 69 T120 UK	EA
215-990879	ownermanual, 1968 Tri. 650	EA
215-990883/0889	shopmanual, 1963-70 Tri650	EA

215-990883/0889/A	shopmanual,1963-70 Tri650,softbound	EA
215-990884	ownermanual,1963 Tri. 650	EA
215-990886	ownermanual,64/65 T100	EA
215-990887/0963	shopmanual,Triumph T150	EA
215-990890	ownermanual,1970 Trident	EA
215-990891	ownermanual,70 Tri 650 US	EA
215-990892	ownermanual,70 T120 UK	EA
215-990894	ownermanual,1970 Tri. 500	EA
215-990895	ownerman,70 Tri 250 USA	EA
215-990896	ownermanual,70 TR25W UK	EA
215-990921	shopmanual,pre'71 Tri.250	EA
215-990925	ownermanual,1971 Tri.500	EA
215-990926	ownermanual,71 T100 UK	EA
215-990927	ownermanual,1971 Tri. 250 USA	EA
215-990928	ownerman,71 T25SS UK	EA
215-990930	ownermanual,71 T120 US	EA
215-990931	ownermanual,71 T120 UK	EA
215-990937	ownermanual,71 Trident UK	EA
215-990938	ownermanual,1971 T150	EA
215-990945	shopmanual,1971 Tri.250	EA
215-990947	shopmanual,1971on Tri.650	EA
215-990951	ownermanual,72 T120 US	EA
215-990952	ownermanual,72 T120 UK	EA
215-990956	ownermanual,72 T100 US	EA
215-990957	ownermanual,72 T150 US	EA
215-990958	ownermanual,73 Tri TR5T	EA
215-990960	ownermanual,72 T100 UK	EA
215-990961	ownermanual,72 T150 UK	EA
215-990966	ownermanual,X75 Hurricane	EA
215-990969	ownerman,73 Tri 650 UK	EA
215-990970	ownermanual,73 T150V-drum	EA
215-990974	ownerman,73Tri 750 TwinUSA	EA
215-990976	ownermanual,73 T150V-disc	EA
215-990977	ownermanual,73 T150 UK (2)	EA
215-990978	ownermanual,'73 T100R USA	EA
215-990979	ownermanual,'73 T100R UK	EA
215-990983	shopmanual,T140/TR7,pre79*	EA
215-990983/A	shopmanual,T140/TR7,pre76	EA
215-990984	shopmanual,Triumph TR5T	EA
215-990989	ownerman,73Tri 750 TwinUK	EA
215-990991	ownermanual,74 Tri TR5T	EA
215-990992	ownerman,74 Tri 750 twin,US	EA
215-990993	ownerman,74Tri 750 TwinUK	EA
215-990994	ownerman,74 Tri T100R USA	EA
215-990995	ownerman,74 Tri T100R UK	EA
215-990997	ownermanual,1974Tri.T150V,UK	EA
215-990998	ownermanual,1974 Tri. 650	EA
215-992256	ownermanual,late'74 T150V *	EA
215-997007	ownermanual,1978 T140E	EA
215-997014	ownermanual,1978 TR7/140V	EA
215-997015	ownermanual,78 T140 UK	EA
215-997059	shopmanual,1979-88Triumph	EA
215-997089	shopmanual suppl,TSS 8v1v	EA
215-9990001	shopmanual,87on,Match.G80	EA
215-AJS 1955/1965	shopmanual,AJS/Match twin	EA
215-AJS/01	shopmanual,AJS/Match 1cyl	EA
215-BSA/DATA/1969	model data book,1969 BSA	EA
215-BSA1	USE 215-004048	EA
215-BSA2	servicesheets,BSA M20&M21	EA
215-BSA3	servicesheets,BSA C10L	EA
215-BSA4	serv. sheets,A7/A10Plunger	EA
215-BSA5	servicesheets,BSA C10&C11	EA
215-BSA6	servicesheets,BSA M33	EA
215-ENF1	shopmanual,Enfield,Interceptor Series II	EA
215-ENF2	shopmanual,Enfield,Meteor 700 & 500 Twin	EA
215-ENF3	shopmanual,RE,350&500 Bullet,Clipper,etc	EA
215-LUCAS	Lucas Electrical Manual	EA
215-NOR/06	manual,G80/85,P11	EA
215-NOR/07	service notes,Comm,NOC	EA
215-NOR1	shopmanual,1928-1955Nort.	EA
215-NOR1960	USE 215-068201	ea

215-NOR2	shopmanual,1955Nort.Twins	EA
215-NOR3	shopmanual,'39Nort.Single	EA
215-NOR4	shopmanual,1937-45 Norton S.V.	EA
215-NOR5	USE 215-068201	ea
215-TRI1	shopmanual,TRW,SV500 army	EA
215-TRI2	ownermanual,TRW,SV500army	EA
215-VELO1	man.,Velo,Viper,Venom,etc	EA
215-VELO2	man.,Velo,MOV,MAC,MSS	EA
215-VIL1	manual,Villiers Mk8E &12D	EA
215-VIL2	serv&ptsbk,Viliers148-246	EA
215-VIN1	shopmanual,Vincent,B,C,D	EA
216-	"FACTORY" PARTS BOOKS	*
216-----	-----	---
216-000080	parts book,1985-87 Triumph	EA
216-005051	pts.bk,'54-56 BantamD1&D3	EA
216-005067	pts.book,1958 Bantam D-1	EA
216-005071	pts.bk,'58Bantam D5 Super	EA
216-005074	pts.book,1959 BSA C15	EA
216-005076	pts.book,'58onBSA GoldStar	EA
216-005079	pts.bk,59-64BantamD7Super	EA
216-005086	pts.bk,1960-63 BSA A7&A10	EA
216-005093	pts.book,1961-64 BSA B40	EA
216-005103	pts.bk,BSASunbeam Scooter	EA
216-005105	pts.book,1960-64 C15 Star	EA
216-005113	pts.book,Beagle K1	EA
216-005115	pts.bk,64&65 BantD7 Trail	EA
216-005116	pts.book,1962-64 A50 &A65	EA
216-005118	pts.book,1965BSA A50 &A65	EA
216-005119	pts.book,1965 C15 & SS80	EA
216-005120	pts.bk,'65 C15T & C15S	EA
216-005121	pts.bk,1965BSA B40 & SS90	EA
216-005122	pts.bk,65 B40 Enduro Star	EA
216-005124	pts.bk,'65&66D7& D7deluxe	EA
216-005126	pts.book,'66BSA A50 & A65	EA
216-005127	pts.bk,66BSA VictorEnduro	EA
216-005129	pts book,1967BSA A50 &A65	EA
216-005130	pts.bk,'67Bantam D10 3spd	EA
216-005131	pts.bk,'67 D10 Sport,4spd	EA
216-005132	pts.book,67B44 VictorSpec	EA
216-005133	pts.bk,1967 BSA C25 & B25	EA
216-005134	pts.bk,67 B44SS &Roadster	EA
216-005135	pts.book,1967 Bushman D10	EA
216-005136	pts.bk,67Bantam D7GPO 3sp	EA
216-005137	pts book,1968 BSA A50&A65	EA
216-005138	pts.book,1968 BSA B25	EA
216-005139	pts.book,1968 BSA B44 SS	EA
216-005140	pts,bk,68BantSupremeD14/4	EA
216-005141	pts.book,1968&69 BSA A75R	EA
216-005142	pts.book,68B44 VictorSpec	EA
216-005143	pts.bk,1968 Bantam D14/4S	EA
216-005144	pts.bk,1968 Bantam D14/4B	EA
216-005145	pts.book,1969 BSA A50&A65	EA
216-005146	pts.bk,'69 B44Victor Spec	EA
216-005197	pts.book,1969 BSA B25	EA
216-005701	pts.book,1969 Bantam 175	EA
216-005702	pts.book,1969 Bushman 175	EA
216-005706	pts.book,1969 BSA B44SS	EA
216-005707	pts.book,1970 BSA A50&A65	EA
216-005708	pts.bk,'70B44 VictorSpec.	EA
216-005709	pts.book,1970 BSA B25	EA
216-005710	pts.book,1970 BSA A75R,genuine	EA
216-005711	pts.book,B40 Rough Rider	EA
216-005712	pts.book,1970 BSA B44 SS	EA
216-005717	pts.book,Ariel 3 Scooter	EA
216-005720	pts.book,1971 BSA 250	EA
216-005721	pts.book,1971 BSA B50	EA
216-005722	parts book,1971 BSA A65	EA
216-005723	parts book,1971 BSA A75R	EA
216-005726	BSA Tool Catalogue	EA
216-005731	parts book,1972 BSA A75R	EA
216-005732	parts book,1972 BSA B50	EA

216-005733	parts book,1972 BSA A65	EA
216-005735	pts.list,1973 BSA T65	EA
216-005736	pts.bk,1973 B50MX(&TR5MX)	EA
216-005738	pts.book,1974 Tri.T150V	EA
216-005754	pts.book,Triumph T160V	EA
216-005756	pts.book,Nort.850Mk3 E.S.	EA
216-01	partsbook microfiche set	ST
216-011	microfiche viewer,USED	EA
216-063065	pts.book,1968-70 Commando	EA
216-063402	pts.book,1972 NorCommando	EA
216-064621	Norton Tool Catalogue	EA
216-065034	pts.bk,1973 Norton750&850	EA
216-065988	pts.bk.suppl,1974 Nor.850	EA
216-068200	pts.book,1971 Norton 750	EA
216-068202	pts.bk,'66-68Nor(pre.Com)	EA
216-990811	pts.book,1962&63 Tri.Cubs	EA
216-990812	pts.book,1964 Triumph Cub	EA
216-990813	pts.book,1965 Triumph Cub	EA
216-990814	pts.book,1966 Triumph Cub	EA
216-990815	pts.bk,67- Super&Bant.Cub	EA
216-990819	pts.bk,1960-TriPreunit650(#16)	EA
216-990820	pts.book,1963 Triumph 650*	EA
216-990821	pts.book,1964 Triumph 650	EA
216-990822	pts.book,1965 Triumph 650(#3)	EA
216-990823	pts.book,1966 Triumph 650	EA
216-990824	pts.book,1967 Triumph 650(#5)	EA
216-990827	pts.bk,1961-63 Tri350/500	EA
216-990828	pts.book,1964 Tri.350/500	EA
216-990829	pts.book,1965 Tri.350/500	EA
216-990830	pts.book,1966 Tri.350/500(#7)	EA
216-990831	pts.book,1967 Tri.350/500	EA
216-990832	pts.book,1968 Tri.350/500	EA
216-990866	pts.book,1969Triumph T150	EA
216-990870	pts.book,1968 Tri.TR25W	EA
216-990871	pts.book,1969 Tri.TR25W	EA
216-990880	pts.book,1968 Triumph 650(#6)	EA
216-990882	pts.book,1969 Triumph 650(#7)	EA
216-990885	pts.book,1969 Tri.350/500	EA
216-990901	pts.book,70 Tri 650,UK	EA
216-990902	pts.book,70 Tri.T100T&S,UK,#11*	EA
216-990902/A	pts.book,1970 T100C&R,USA*	EA
216-990903	pts.book,70 Tri 650,USA	EA
216-990904	pts.book,1970Triumph T150	EA
216-990906	pts.book,1970TriumphTR25W	EA
216-990929	pts.book,1971 Triumph 250	EA
216-990932	pts.book,1971 Triumph 650	EA
216-990934	pts.book,1971 Triumph 500	EA
216-990943	pts.book,1971Triumph T150	EA
216-990953	pts.book,1972 Triumph 650	EA
216-990954	pts.book,1972 Triumph 500	EA
216-990955	pts.bk,1972Tri.T150/T150V	EA
216-990967	pts.bk,1973 X75 Hurricane	EA
216-990972	pts.bk,73 T150V w/fr.drum	EA
216-990973	pts.book,1973Triumph TR5T	EA
216-990980	pts.bk,1973 Tri.750 Twins	EA
216-990981	pts.book,'73Triumph T100R	EA
216-990982	pts.bk,73 T150V w/fr.disc	EA
216-992251	pts.bk,1974&75 Tri750Twin	EA
216-992253	pts.book,1974Triumph TR5T	EA
216-992254	pts.book,1974 Tri. T100R	EA
216-992257	pts.bk,1976&77 Tri750Twin	EA
216-992257/A	supplement,Silver Jubilee	EA
216-997003	pts.book,1978 Triumph	EA
216-997003/A	pts.suppl,1978 Tri. T140E	EA
216-997102	pts.bk,1979 Tri.T140E&TR7	EA
216-997113	pts.suppl,1979 Tri. T140D	EA
216-997139	pts.book,1980 Triumph	EA
216-997502	pts.book,1981 Triumph	EA
216-997507	pts.book,1982/3 Triumph	EA
216-997507/A	USE 216-997507	ea
216-997516	pts.book,Triumph T140ESAV	EA

216-997576	pts.book, Tri. TSS, 8 valve	EA
216-997581	pts.book, Tri. TSX (custom)	EA
216-9990002	pts.bk, 87on, Match. G80, eng	EA
216-AJS 1956/1958	pts.book, AJS&Match, 56/58	EA
216-ARI1	pts.book, Ariel 650 Twins	EA
216-ARI2	pts.book, Ariel SQ4, all models*	EA
216-ARI3	pts.book, Ariel 500 Twins	EA
216-BSA1914/1924	pts book, 1914-1924BSA, all	EA
216-BSA1925/1926	parts book, 1925&26BSA, all	EA
216-BSA1930	parts book, 1930 BSA, all	EA
216-BSA1940	parts book, 1940 BSA, all	EA
216-BSA1946	pts.book, 1946 BSA, all	EA
216-BSA1949	parts book, 1949 BSA, all	EA
216-BSA1949/1952	USE 216-BSA1949/1953	ea
216-BSA1949/1953	pts.bk, 1949-53 BSA"B"mod.	EA
216-BSA1949/1953A	pts.bk, 1949-53BSA C10&C11	EA
216-BSA1949/1953B	pts.book, 1949-53BSA A7/10	EA
216-BSA1949/1954	pts.book, 1949-54 Bantam	EA
216-BSA1949/1958	pts.book, 1949-58BSA"M"mod	EA
216-BSA1954	pts.book, 1954 BSA C10&C11	EA
216-BSA1954/1956	USE 216-005051	ea
216-BSA1954/1957	pts.book, 1954-57BSA"B"mod	EA
216-BSA1954/1957A	pts.book, 1954-57BSA A7/10	EA
216-BSA1954/1957B	pts.book, 1954-57BSA"C"mod	EA
216-BSA1954/1959	USE 216-BSA1954/1957	ea
216-BSA1954/A	pts.book, 1954 BSA Bantam	EA
216-BSA1958	pts.book, 1958on BSA B mod	EA
216-BSA1958/1959	pts.bk, 1958&59 BSA A7&A10	EA
216-ENF67	pts.bk, Enf. Interceptor, 1967 (STG.1)	EA
216-ENF69/70	pts.bk, Enf. Inter. II, 69/70	EA
216-NOR1	pts.book suppl, JohnPlayer	EA
216-NOR1936/1938	pts.book, 1936-38Nor (road)	EA
216-NOR1947	pts.book, 1947 Nort. Single	EA
216-NOR1948/1950	pts.bk, 1948-49 Nor. Single*	EA
216-NOR1949/1950	pts.bk, 1949&50 Nort. Twins	EA
216-NOR1950/1953	pts.bk., 1950-1954 Norton Singles *	EA
216-NOR1955	pts.book, 1955 NortonTwins	EA
216-NOR1956	pts.book, 1956 Nort. Twins	EA
216-NOR1957	pts.bk, '57 Nor, ES2, 19S, 50	EA
216-NOR1957/1958	pts.bk, 1957 Nort. Twins	EA
216-NOR1959	pts.book, 1959 Norton, all	EA
216-NOR1961/1962	pts.bk, 1961&62 Norton, all	EA
216-NOR1963/1965	pts.bk, 1963-65 Nort. bigTwins	EA
216-NOR2	pts.bk, wdl6H#W26001-43000	EA
216-NOR4	pts.bk, wdl6H#W90001-96000	EA
216-TRI/TOOL	Triumph Tool Catalogue	EA
216-TRI1	pts.book, Tri. TR65S"Third"	EA
216-TRI1938	pts.book, 1938 Triumph, all	EA
216-TRI1939	pts.book, 1939 Triumph, all*	EA
216-TRI1946	pts.book, 1946TriumphTwins	EA
216-TRI1947/1948	pts.book, 1947&1948Triumph	EA
216-TRI1949	pts.book, 1949 Triumph	EA
216-TRI1949/A	pts.book, 1949&50TriTrophy	EA
216-TRI1950	pts.book, 1950 Triumph	EA
216-TRI1951	pts.book, 1951 Triumph twins	EA
216-TRI1952	pts.book, 1952Triumph Twin	EA
216-TRI1953	pts.book, 1953 TriumphTwin	EA
216-TRI1953/A	pts.book, 1953 Cub&Terrier	EA
216-TRI1954	pts.book, 1954 TriumphTwins	EA
216-TRI1954/A	pts.book, 1954 Cub&Terrier	EA
216-TRI1955	pts.book, 1955 TriumphTwin	EA
216-TRI1955/A	pts.book, 1955 Cub&Terrier	EA
216-TRI1956	pts.bk, 1956 Tri. OHV Twins	EA
216-TRI1956/A	pts.book, 1956 Cub&Terrier	EA
216-TRI1956/B	pts.bk, Tri. TRW, SV500 army	EA
216-TRI1957	pts.book, 1957 Tri. 500&650	EA
216-TRI1957/1958	pts.book, 1957&58 unit 350	EA
216-TRI1957/1958A	parts book, 1957&1958 Cub	EA
216-TRI1958	pts.book, 1958 Tri. 500&650	EA
216-TRI1959	pts.book, 1959 Triumph 650 (#15)	EA
216-TRI1959/A	pts.bk, 1959TriUnit350/500	EA

216-TRI1959/B	parts book,1959 Tri. Cub	EA
216-TRI1960	pts.bk,1960TriUnit350/500	EA
216-TRI1960/1961	pts.book,1960&61 Tri.Cubs(#7)	EA
216-VELO1	pts.book,Velo,Viper,Venom	EA
216-VELO2	pts.book,Velo,MOV,MAC	EA
216-VILL1	pts.bk,Villiers 148-246cc	EA
216-VIN1	pts.book,Vincent B&C Mod.	EA
216-VIN2	pts.book,Vincent D Model	EA
217-	WALL POSTERS	*
217-----	-----	--
217-005629	wallchart,T160 engine	EA
217-005630	wallchart,T160 gearbox	EA
217-005631	wallchart,T160 front forks	EA
217-005632	wallchart,Amal concentric	EA
217-005633	wallchart,T160 brakes	EA
217-005634	wallchart,T160 starter	EA
217-005635	wallchart,T160 lubrication	EA
217-005636	wallchart,Comm MKIII,gearbox	EA
217-005637	wallchart,Comm MKIII,engine	EA
217-005638	wallchart,Comm MKIII,f wheel	EA
217-005639	wallchart,Comm MKIII,r wheel	EA
217-005640	wallchart,Comm MKIII,isolastics	EA
217-005641	wallchart,Comm MKIII,elec start	EA
217-005642	wallchart,Comm MKIII,f forks	EA
217-005643	wallchart,Comm MKIII,lubrication	EA
217-005782	wallposter,Norton Manx	EA
217-005783	wallposter,73 Nort.Interstate	EA
217-01	wallchart set,Norton Mk3	ST
217-011	wallchart,T140 eng section	EA
217-02	wallchart set,TriumphT160*	ST
217-024	wallchart,Tri pre-unit,engine	EA
217-025	wallchart,Cub eng/gbx,sidepoints type	EA
217-03	wallchart set,Nor. Rotary	EA
217-035	wallchart,Cub,eng/gbx,distr.type	EA
217-04	wall poster,Tri. Coventry	EA
217-05	wall poster,BSA Motorbike	EA
217-06	wall poster,'63 Norton SS	EA
217-201	wall poster,BSA 1958	EA
217-202	wall poster,Ariel 1932	EA
217-203	wall poster,BSA 1953	EA
217-210	wall poster,Velocette '38	EA
217-211	wall poster,Triumph 1953	EA
217-990911	wallchart,Tri 650,expl eng	EA
217-990912	wallchart,Tri 350/500 eng/gbx	EA
217-990920	wallchart,T150 12V wiring	EA
217-990922	wallchart,Tri 650,4/S gbx	EA
217-990924	wallchart,Tri forks,69/70	EA
217-990964	wallchart,T120 wiring	EA
217-BONNIE/01	mural,42"x90"Bonneville65	EA
217-GOLDIE/01	mural,42"x90"Gold Star 61	EA
217-MANX/01	mural,42"x90",1961 Manx	EA
217-VINCENT/01	mural,42"x90"Black Shadow	EA
218-	CALENDARS	*
218-----	-----	--
218-01	calendar,Classic Triumph,2005	EA
218-02	calendar,Norton Owners Club,2005*	EA
218-03	calendar,British Motorcycles,2004	EA
221-	TOOLS,GENERAL	*
221-----	-----	--
221-01	battery charger,mini	EA
221-02	tool,chain breaker	EA
221-02/A	tool,chain breaker,heavy duty	EA
221-03	file,points,Flexstone	EA
221-04	degree wheel,timing,plastic*	EA
221-04/A	degree wheel,timing,metal*	EA
221-05	tool,valve lapping	EA
221-062551	screwdriver,reversable	EA
221-07	greasegun,small,Brit.type	EA
221-08	hydrometer,battery	EA
221-09	socket,tubular,spark plug	EA
221-0903	truign stand,wheels	EA

221-09041	balance kit,truing stand	EA
221-10	stand,engine,universal	EA
221-102	tool,TDC indicator	EA
221-11	gear puller,univ.BSA type	EA
221-12	wrench,spoke nipple,universal	EA
221-13	tool,impact driver	EA
221-14	tyre iron,12"flat type	EA
221-15	tyre iron,7 in.spoon type	EA
221-16/BSA	toolbag,w/BSA logo	EA
221-16/NOR	toolbag,w/NORTON logo	EA
221-16/TRI	toolbag,w/TRIUMPH logo	EA
221-17	toolroll	EA
221-17/BSA	toolroll,w/BSA logo	EA
221-17/NOR	toolroll,w/NORTON logo	EA
221-17/TRI	toolroll,w/TRIUMPH logo	EA
221-175	tool set,valve guides *	ST
221-18/TRI	toolkit,universal Triumph	EA
221-188	tool,strap wrench	EA
221-20	spanners,Whit,openend 6 pc. *	ST
221-21	spanners,Whit,box end 5pc.	ST
221-210	tool,cableOiler,hydraulic	EA
221-211	tool,valvespring compressor,tubular	EA
221-215/A	tool,thread file,UNF/UNC	EA
221-215/B	tool,thread file,British	EA
221-22	spanners,Whit,comb.7pc	ST
221-235	tool,dimpling,cable ferrule	EA
221-24	spanner,box,3/8x5/16 Whit	EA
221-25	socket set,BSW,6pc,12pt,3/8",UK	ST
221-25/A	socket set,BSW,6PC,12pt,KOKEN	ST
221-25/B	socket set,BSW,8pc,12pt,KOKEN	ST
221-25/C	socket set,deepBSW,8pc,6pt,KOKEN	ST
221-25/D	socket set,BSW,8pc,6pt,KOKEN	ST
221-25/E	socket set,BA,9pc,6pt,KOKEN	ST
221-26	valveseat cutter kit,NEWAY *	ST
221-27	valve refacer kit,NEWAY *	ST
221-28	tool,ferrule crimping,sm.	EA
221-29	tool,ferrule crimping,med*	EA
221-29/A	tool,ferrule crimping,lg*	EA
221-30	thread gauge tool	EA
221-301	tool,valve guide drift	EA
221-302	tool,valveguide drift3cyl	EA
221-31	toolkit,Mikuni carb,8pc.	EA
221-32	spoke threading machine,w/9G head	ST
221-33	spoke rolling head,8G	EA
221-34	spoke rolling head,9G	EA
221-35	spoke rolling head,10G	EA
221-36	tool,shockspring instal,wall mt*	EA
221-37	tool,bullet connector crimping	EA
221-38	synchroniser,twin carbs	EA
221-38/A	case,carb synchronizer	EA
221-400935	screwdriver&feeler guage	EA
221-500	colortune kit	EA
221-600296	pump,tyre,12" compressed	EA
221-602251	wrench,flat,1-1/8X1-5/16	EA
221-64947081	tool,shock spring adjust.	EA
221-689467	tool,valve stem	EA
221-82/5560	tool,ring compr,55-60mm	EA
221-82/6065	tool,ring compr,60-65mm	EA
221-82/6570	tool,ring compr,65-70mm	EA
221-82/7075	tool,ring compr,70-75mm	EA
221-82/7580	tool,ring compr,75-80mm	EA
221-82/8085	tool,ring compr,80-85mm	EA
221-82/L	USE 221-82 OF CORRECT SIZE	ea
221-82/M	USE 221-82 OF CORRECT SIZE	ea
221-91	workbench,hydraulic lift*	EA
222-	"FACTORY" SERVICE TOOLS	*
222-----	-----	--
222-01	wrench,x collar,T140D	EA
222-060934	puller,auto advance,Commando*	EA
222-060942	spanner,pre71Nor strg.brg	EA
222-060949	tool,auto advance locking	EA

222-061015	tool,clutch locking,Comm.*	EA
222-061359	tool,points seal guideCEI	EA
222-063965	spanner,Nor.caliper&wheel*	EA
222-063970	puller,bearing,hydraulic	EA
222-063971	tool,insertion,isolastics	ST
222-064292	drift set,t/cov.seals,Nor	ST
222-064297	puller,eng,cam spr&cl,Comm	EA
222-066473	tool,timing,Nort 850 Mk3	EA
222-066532	tool,adj,isolastics,Mk3	EA
222-067185	tool,rockershaft align,Nort	EA
222-106	tool,cl.compressor,Bantam	EA
222-108	puller,magneto pinion	EA
222-109	tool,cl.puller,Cub	EA
222-110	puller,cl,20tpiTriBSAtwin *	EA
222-117	puller,clutch,BSA internal threaded	EA
222-118	puller,flywheel,Bantam	EA
222-121	puller,cl,TriBSA 1cyl,Cub pinion*	EA
222-127	puller,cl,26tpiTriBSAtwin*	EA
222-1320	puller,eng.spr,T120/T140,etc*	EA
222-1330	puller,eng.sprocket,3 cyl	EA
222-155	puller,camgear,Tri.2&3cyl,early	ST
222-156	puller,eng.spr,Nor,preCommando	EA
222-158	puller,crankpinion,NorTri*	EA
222-158/BOLT	bolt,centre,222-158 puller	EA
222-158/JAWS	jaw,to repair 222-158tool	EA
222-162	puller,cl,Nor.preCommando	EA
222-167	USE 222-117	EA
222-168	tool,cl.compressor,Comman	EA
222-170	puller,eng.sprock&cl,Comm	EA
222-171	USE 222-198	ea
222-179	tool,pushrod comb,A7& A10	EA
222-180	tool,cl.spring adjuster,small	EA
222-180/A	tool,cl.spring adj,heavyduty	EA
222-181	extractor,gudgeon pin	EA
222-183	wrench,Xcollar,NortonTwin	EA
222-186	tool,Nort.cl.rel.ret.ring	EA
222-188	USE 221-188	EA
222-189	puller,rocker spindle,Nor*	EA
222-190	puller,auto advance unit*	EA
222-191	puller,fr.fork tube,w/adaptors	ST
222-192	puller,cl.hub,Tri/BSA triples	EA
222-198	puller,crank bearing*	EA
222-200B	tool,forkseal inst&rem,BSA	EA
222-231	socket,1"BSW,gbox.nut,Tri.4sp	EA
222-234	socket,7/8"BSW,Norton/BSA gbx.nut*	EA
222-236	tool,forkseal holder,PU Tri	EA
222-260	socket,fr.brk.plt,1x1-1/8"	EA
222-290	adaptor assy,degree wheel,UNF crank	EA
222-291	adaptor assy,degree wheel,CEI crank	EA
222-296	cambush sizing kit,T120/140	EA
222-296/A	cambush sizing kit,unit350/500	EA
222-305	drift,for bar bush97-1527	EA
222-307	tool,indexing,5speed gbx.	EA
222-308	tool,slotted insp.cap,TRI/BSA	EA
222-311	drift,for forkseal97-4001	EA
222-319	drift,for brg57-1606&1614	EA
222-600496	tool,pri.adj,Tri.UnitTwin,early	EA
222-600571/0572	tool,timing,pre69 TriTwin*	EA
222-600605	timing disc kit,points,26TPI	ST
222-600605/A	timing disc kit,points,28TPI	ST
222-601825	timing plate,68 T100/120 style	EA
222-601858	tool,timing,TriBSA triple	EA
222-601859	tool,timing,69-TriBSA 1&2 cyl.	EA
222-601862	puller,chainwheel,Triples	EA
222-601865	tool,thr.rod assy,Triples	EA
222-602020	tool,valve adjusting,Tri	EA
222-602020/A	tool,valve adj.TriBSA CEI,STUBBLEFIELD	EA
222-602020/B	tool,valve adj.TriBSA UNF,STUBBLEFIELD	EA
222-602108	tool,pri.adj,Tri.UnitTwin *	EA
222-602135	spanner,rel.valve,Triples	EA
222-602211/2212	tool,baffle plate,Triples	ST

222-602218	tool,drift,lwr.strg.brg.	EA
222-607041	tommy bar,rear wheel	EA
222-613005	tool,forkseal holder,BSA	EA
222-613006	drift,BSAforkseal removal	EA
222-613007	drift,BSA forkseal instal	EA
222-613008	tool,adj,strg.brg,BSAto68	EA
222-613063	puller,strg.brg,BSApre71	EA
222-613256	pullers,BSA master set	EA
222-613503	tool,shockspring instal,BSA type	EA
222-613585	jaws,oilpump gear puller,C15/B40	EA
222-613606/A	tool,bot.nut,forks,pre71type*	EA
222-613760	tool,cl.lock,62-65,A50/65	EA
222-613768	tool,cl.lock,Tri&BSA Twin,late	EA
222-613768/A	tool,cl.lock,BSA,6spring	EA
222-613769	jaws,oilpump gear puller,C/B25/44	EA
222-613774	tool,cl.lock,Tri/BSA 1cyl	EA
222-616002	tool,eng.lifting,Triples	EA
222-616008	tool,drift,tappet blocks	EA
222-616010	reamer,highgear,Tri 4spd.	EA
222-616017	spanner,fork seal holders	EA
222-616020	drift,RH crank brg,Triple	EA
222-616021	drift,LH crank brg,Triple	EA
222-616024	tool,crank pinion rep,3cy	ST
222-616025	tool,fork guage plate	EA
222-616026	drift,highgear,4spdTriBSA	EA
222-616042	tool,cl.alignment,Triples	EA
222-616046	USE 222-1320	ea
222-616050	drift,for s.a.bush82-6042	EA
222-616051	tool,guide,pullrod seal	EA
222-616059	tool,tap.block drill,3cyl	ST
222-616060	puller,outer race,LHcrank,T100R type*	EA
222-616061	socket,4thgear,4sp.Triple	EA
222-616070	tool,cl.locking,Triples	EA
222-616103	tool,pri align support3cy	EA
222-616105	guage,pri.align,Triples	EA
222-616113	tool,late fork damp.assy.*	EA
222-616117	tool,for s.a.bush#83-2521	EA
222-616121	drift,strg.head brgs,OIF*	EA
222-616125	socket,sprocket nut,5spd.	EA
222-616132	puller,camwheel,2BoltType	EA
222-617010	tool,cyl.head nut,T140	EA
222-617013	tool,points seal guideUNF	EA
222-617017	puller,outer race,LHcrank*	EA
222-617019	tool,rocker shaft oring *	EA
222-617019/A	tool,rocker shaft oring,unit500*	EA
222-617024	spanner,wheelbrg.retainer*	EA
222-622104	tool,Amal mainjet socket	EA
222-680710	tool,timing,pre'69 A50/65	EA
223-	TAPS & DIES	*
223-----	-----	---
223-01	tap&die set,BA,35pc.	ST
223-02	tap&die set,CEI,17pc.*	ST
223-03	tap&die set,BSF,21pc.	ST
223-04	tap&die set,BSW,24pc.	ST
223-1220	die,1/2x20CEI	EA
223-1226/S	tap,1/2x26CEI,second cut	EA
223-1419/S	tap,1/4x19BSP,second cut	EA
223-1426	die,1/4x26CEI	EA
223-1426/B	tap,1/4Xx26CEI,bottoming	EA
223-1426/T	tap,1/4Xx26CEI,taper	EA
223-1828/S	tap,1/8x28BSP,second cut	EA
223-1840/B	tap,1/8x40BSW,bottoming	EA
223-1840/T	tap,1/8x40BSW,taper	EA
223-31624/B	tap,3/16x24BSW,bottoming	EA
223-31624/T	tap,3/16x24BSW,taper	EA
223-3420	die,3/4x20UNEF	EA
223-3426/S	tap,3/4x26CEI,second cut	EA
223-3819/S	tap,3/8x19BSP,second cut	EA
223-3820	die,3/8x20BSF	EA
223-3820/B	tap,3/8x20BSF,bottoming	EA
223-3820/T	tap,3/8x20BSF,taper	EA

223-3826	die, 3/8x26CEI	EA
223-3826/B	tap, 3/8x26CEI, bottoming	EA
223-3826/T	tap, 3/8x26CEI, taper	EA
223-51622	die, 5/16x22BSF	EA
223-51622/B	tap, 5/16x22BSF, bottoming	EA
223-51622/T	tap, 5/16x22BSF, taper	EA
223-51626	die, 5/16x26CEI	EA
223-51626/B	tap, 5/16x26CEI, bottoming	EA
223-51626/T	tap, 5/16x26CEI, taper	EA
223-53232/B	tap, 5/32x32BSW, bottoming	EA
223-53232/T	tap, 5/32x32BSW, taper	EA
223-5826/S	tap, 5/8x26CEI, second cut	EA
223-71626	die, 7/16x26CEI	EA
223-71626/B	tap, 7/16x26CEI, bottoming	EA
223-71626/T	tap, 7/16x26CEI, taper	EA
223-91620	die, 9/16x20CEI	EA
223-91620/LH	die, 9/16x20CEI, LH thread	EA
223-91626/S	tap, 9/16x26CEI, second cut	EA
223-BA2/B	tap, 2BA, bottoming	EA
223-BA2/T	tap, 2BA, taper	EA
223-BA4/B	tap, 4BA, bottoming	EA
223-BA4/T	tap, 4BA, taper	EA
223-BA5/B	tap, 5BA, bottoming	EA
223-BA5/T	tap, 5BA, taper	EA
224-	HELICOIL KITS	*
224-----	-----	--
224-1426	thread kit, 1/4x26	EA
224-30060	thread kit, 3/8x20 BSF	EA
231-	OIL, BRAKE FLUID, & GREASE	*
231-----	-----	--
231-01/10-40	motoroil, Cast. 10-40, litre	EA
231-01/20-50	motoroil, Cast. 20-50, litre	EA
231-02/20	motoroil, Cast. 20 GP, litre	EA
231-02/40	motoroil, Cast. 40 GP, litre	EA
231-02/50	motoroil, Cast. 50 GP, litre	EA
231-03	gearoil, Castrol 80/90, ltr	EA
231-03/A	gearoil, Cast. 80/90, 4litre	EA
231-04	oil, 140, Com. swingarm, bag	EA
231-05	forkoil	EA
231-06	grease, universal	EA
231-07	chainlube 250 gram can	EA
231-08	filteroil, K&N, 8 oz. bottle	EA
231-09	filteroil, UNI, 16oz. bottle	EA
231-10	brakefluid, Lockheed, litre	EA
232-	CLEANERS, POLISH, & WAX	*
232-----	-----	--
232-01	engine degreaser, spray on	EA
232-11	polish, Solvol Autosol, 75g	EA
233-	LOCTITE, & GASKET SEALERS	*
233-----	-----	--
233-01	Loctite med. threadlocker, blue, 6ml.	EA
233-02	Loctite "Wick N Lock", green, 6ml.	EA
233-03	Loctite strong threadlocker, red, 6ml.	EA
233-07	silicone seal, hitemp, 80ml	EA
233-08	Loctite "Gask. Elimin.", 6 g	EA
234-	PAINT	*
234-----	-----	--
234-01/BLK	paint, hitemp gloss black	EA
234-01/SIL	paint, hitemp aluminium	EA
234-01/WHT	paint, hitemp white	EA
234-02	paint, Trophy red, pint	EA
234-03	paint, Astral red, pint	EA
234-04	paint, Lincoln Green, pint	EA
234-05	paint, Flamboyant Aircraft Blue, pint	EA
234-06	paint kit, Tiger gold/blk	ST
234-07	paint kit, Tiger gold/wht	ST
234-08	paint, Aquamarine, pint	EA
234-09	paint, Dove Grey, pint	EA
234-10	paint, Jacaranda purple, pint	EA
234-11	paint, silver gloss	EA
234-12	paint kit, Silver Jubilee	ST

235-	CHEMICALS, MISCELLANEOUS	*
235-----	-----	---
235-01	hand cleaner, waterless	EA
235-02	sealant & prep kit, gastank, KREEM	ST
235-03	fuel conditioner, Duralt, 8oz.	EA
235-04	tyreseal & inflate in a can	EA
235-07	grinding compound, valves	EA
235-08	chrome guard, x pipe liner	EA
241-	GOGGLES	*
241-----	-----	---
241-01	goggles, Mark 4, Brit. made SILVERCROSS	EA
241-02	goggle straps, Stadium Type	EA
241-03	goggle lenses, clear glass	PR
241-03/A	goggle lenses, tinted glass	PR
241-04	goggles, over-glasses, Emgo	EA
241-05	goggles, Mark 49, Brit. made, blk.	EA
241-06	goggles, Mark 49, Brit. made, brown	EA
242-	HELMETS & FACE SHIELDS	*
242-----	-----	---
243-	GLOVES AND GAUNTLETS	*
243-----	-----	---
244-	SHIRTS	*
244-----	-----	---
244-01/BSA	baseball hat, BSA, coloured*	EA
244-01/NOR	baseball hat, NORTON, coloured*	EA
244-01/TRI	baseball hat, TRIUMPH, coloured*	EA
244-34/BSA/CUSTOM	sweatshirt, BSA, custom	EA
244-34/BSA/L	sweatshirt, BSA, lrg	EA
244-34/BSA/M	sweatshirt, BSA, med	EA
244-34/BSA/S	sweatshirt, BSA, sm	EA
244-34/BSA/XL	sweatshirt, BSA, xlg	EA
244-34/BSA/XXL	sweatshirt, bsa, xxl	EA
244-34/NOR/CUSTOM	sweatshirt, nor, custom	EA
244-34/NOR/L	sweatshirt, nor, lrg	EA
244-34/NOR/M	sweatshirt, nor, med	EA
244-34/NOR/S	sweatshirt, nor, sm	EA
244-34/NOR/XL	sweatshirt, nor, xlg	EA
244-34/NOR/XXL	sweatshirt, norton, xxlrg	EA
244-34/TRI/CUSTOM	sweatshirt, tri, custom	EA
244-34/TRI/L	sweatshirt, tri, lrg	EA
244-34/TRI/M	sweatshirt, tri, med	EA
244-34/TRI/S	sweatshirt, tri, sm	EA
244-34/TRI/XL	sweatshirt, tri, xlg	EA
244-34/TRI/XXL	sweatshirt, tri, xxlrg	EA
244-36/BSA/CUSTOM	kangaroosweat, BSA, custom	EA
244-36/BSA/L	kangaroosweat, BSA, lrg	EA
244-36/BSA/M	kangaroosweat, BSA, med	EA
244-36/BSA/S	kangaroosweat, BSA, sm	EA
244-36/BSA/XL	kangaroosweat, BSA, xlg	EA
244-36/BSA/XXL	kangaroosweat, BSA, xxlrg	EA
244-36/NOR/CUSTOM	kangaroosweat, nor, custom	EA
244-36/NOR/L	kangaroosweat, nor, lrg	EA
244-36/NOR/M	kangaroosweat, nor, med	EA
244-36/NOR/S	kangaroosweat, nor, sm	EA
244-36/NOR/XL	kangaroosweat, nor, xlg	EA
244-36/NOR/XXL	kangaroosweat, nor, xxlrg	EA
244-36/TRI/CUSTOM	kangaroosweat, tri, custom	EA
244-36/TRI/L	kangaroosweat, tri, lrg	EA
244-36/TRI/M	kangaroosweat, tri, med	EA
244-36/TRI/S	kangaroosweat, tri, sm	EA
244-36/TRI/XL	kangaroosweat, tri, xlg	EA
244-36/TRI/XXL	kangaroosweat, tri, xxl	EA
244-67/BSA/CUSTOM	DISCONTINUED	EA
244-67/BSA/L	DISCONTINUED	EA
244-67/BSA/M	DISCONTINUED	EA
244-67/BSA/S	DISCONTINUED	EA
244-67/BSA/XL	DISCONTINUED	EA
244-67/NOR/CUSTOM	DISCONTINUED	EA
244-67/NOR/L	DISCONTINUED	EA
244-67/NOR/M	DISCONTINUED	EA
244-67/NOR/S	DISCONTINUED	EA

244-67/NOR/XL	DISCONTINUED	EA
244-67/TRI/CUSTOM	DISCONTINUED	EA
244-67/TRI/L	DISCONTINUED	EA
244-67/TRI/M	DISCONTINUED	EA
244-67/TRI/S	DISCONTINUED	EA
244-67/TRI/XL	DISCONTINUED	EA
244-68/BSA/CUSTOM	DISCONTINUED	EA
244-68/BSA/L	DISCONTINUED	EA
244-68/BSA/M	DISCONTINUED	EA
244-68/BSA/S	DISCONTINUED	EA
244-68/BSA/XL	DISCONTINUED	EA
244-68/NOR/CUSTOM	DISCONTINUED	EA
244-68/NOR/L	DISCONTINUED	EA
244-68/NOR/M	DISCONTINUED	EA
244-68/NOR/S	DISCONTINUED	EA
244-68/NOR/XL	DISCONTINUED	EA
244-68/TRI/CUSTOM	DISCONTINUED	EA
244-68/TRI/L	DISCONTINUED	EA
244-68/TRI/M	DISCONTINUED	EA
244-68/TRI/S	DISCONTINUED	EA
244-68/TRI/XL	DISCONTINUED	EA
244-69/BSA/CUSTOM	t shirt,BSA,custom	EA
244-69/BSA/L	t shirt,BSA,lrg	EA
244-69/BSA/M	t shirt,BSA,med	EA
244-69/BSA/S	t shirt,BSA,sm	EA
244-69/BSA/XL	t shirt,BSA,xlrg	EA
244-69/BSA/XXL	t shirt,BSA,xxlrg	EA
244-69/NOR/CUSTOM	t shirt,nor,custom	EA
244-69/NOR/L	t shirt,nor,lrg	EA
244-69/NOR/M	t shirt,nor,med	EA
244-69/NOR/S	t shirt,nor,sm	EA
244-69/NOR/XL	t shirt,nor,xlrg	EA
244-69/NOR/XXL	t shirt,nor,xxlrg	EA
244-69/RACE/L	t shirt,RACING/lrg*	EA
244-69/RACE/XL	t shirt,RACING/xlrg*	EA
244-69/TRI/CUSTOM	t shirt,tri,custom	EA
244-69/TRI/L	t shirt,tri,lrg	EA
244-69/TRI/M	t shirt,tri,med	EA
244-69/TRI/S	t shirt,tri,sm	EA
244-69/TRI/XL	t shirt,tri,xlrg	EA
244-69/TRI/XXL	t shirt,tri,xxlrg	EA
244-69/VINTT/L	t shirt,VintageTT,large	EA
244-69/VINTT/M	t shirt,VintageTT,medium	EA
244-69/VINTT/S	t shirt,VintageTT,small	EA
244-69/VINTT/XL	t shirt,VintageTT,xlarge	EA
244-69/VINTT/XXL	t shirt,VintageTT,xxl	EA
245-	LEATHERS	*
245-----	-----	---
246-	RAIN SUITS	*
246-----	-----	---
247-	LOADING RAMPS	*
247-----	-----	---
247-01	loading ramp,950lb.capacity	EA
249-	MOTORCYCLE COVERS	*
249-----	-----	---
251-	DECALS	*
251-----	-----	---
251-01	decal,Union Jack,3x2 inch	EA
251-02	decal,Union Jack,1.5"x 2"	EA
251-03	decal kit,POIF Daytona/Bonnie	EA
251-04	decal,Union Jack,1-3/4"x1-1/4"	EA
251-05	decal,Union Jack,3-7/8"x5-7/8"	EA
251-06	decal,Union Jack,9-1/2"x6"	EA
251-067108	decal,AUTH.NORTON DLR. *	EA
251-07	decal,speedo"DO NOT PULL TRIPSHAFT"	EA
251-08	decal,gastank,TRITON	EA
251-09	decal,speedo dr,GREASE EVERY	EA
251-10	decal,airfilter,WASH IN PETROL	EA
251-11	decal,airfilter,70 TriBSA Twins,etc	EA
251-12	decal,US safety stds,69 BSA	EA
251-13	decal,tank,STARFIRE	EA

251-14	decal, tanktop, SUPERROCKET	EA
251-15/B	decal, tank, BSA, black, 3.5"	EA
251-15/B/A	decal, tank, BSA, black, 7"	EA
251-15/BL	decal, tank, BSA, blue, 3.5"	EA
251-15/R	decal, tank, BSA, red, silv. line, 5"	EA
251-15/R/A	decal, tank, BSA, red, 7"	EA
251-15/W	decal, tank, BSA, white, 3.5"	EA
251-15/W/A	decal, tank, BSA, white, 7"	EA
251-15/Y	decal, tank, BSA, yellow, 7"	EA
251-17	decal, gastank, BSA, gold, 7"	EA
251-1760	decal, STARFIRE 250, flames*	EA
251-18	decal, gastank, BSA rifles	EA
251-19	decal, BSA Cycles piled arms	EA
251-1939	decal, BSA rifles, 250cc	EA
251-1941	decal, BSA rifles, 500cc	EA
251-1942	decal, BSA rifles, 650cc	EA
251-1978	decal, Thunderbird emblem	EA
251-20/B	decal, gastank, TRIUMPH, blk	EA
251-20/BL	decal, gastank, TRI, blue	EA
251-20/R	decal, gastank, TRIUMPH, red	EA
251-20/S	decal, gastank, TRIUMPH, silver	EA
251-20/W	decal, gastank, TRI, white	EA
251-21	decal, gastank, TRI, gold	EA
251-22	decal, data, underseat, TR7/140V	EA
251-2205	decal, THUNDERBOLT, w/cloud	EA
251-2207	decal, Victor Roadster tanktop	EA
251-23	decal, Union Jack, 3x5	EA
251-24	decal, gastank, GOLDSTAR	EA
251-25	decal, Crossed Flags	EA
251-2591	decal, tanktop, SPITFIRE MK4	EA
251-26	decal, oval airfilter, twins	EA
251-BSA/01	decal, BSA, red, 10"	EA
251-BSA/02	decal, BSA, red, 6"	EA
251-BSA/03	decal, BSA, star, 3", mflake	EA
251-BSA/04	decal, BSA, flags, 3", mflake	EA
251-BSA/05	decal, BSA, oval, 4", mflake	EA
251-BSA/06	decal, BSA, 19x5, orange	EA
251-BSA/07	decal, BSA, 9x2, defractive	EA
251-NOR/01	decal, NORTON, black, 10"	EA
251-TRI/01	decal, TRIUMPH, red, 6"	EA
251-TRI/02	decal, TRI, oval, 4", mflake	EA
251-TRI/03	decal, TRI, 19x5, orange	EA
251-TRI/04	decal, TRI, 9x2, defractive	EA
252-	PATCHES, IRON AND SEW ON	*
252-----	-----	--
252-0011	patch, nor, eagle, lrg, 9	EA
252-0012	patch, tri, eagle, lrg, 9	EA
252-0016	patch, nor, commando, round3	EA
252-0017	patch, nor, comm, flag, 4x3	EA
252-0018	patch, BSA, with flag, 4x3	EA
252-01	patch, "Happiness is riding BSA"	EA
252-0110	patch, tri, tiger, 4x3	EA
252-0111	patch, tri, with flag, 4x3	EA
252-066983	patch, Nor, white letters, genuine	EA
252-1005	patch, tri, fastest m/c, 5x6	EA
252-1006	patch, flag, british, 2x3	EA
252-1018	patch, BSA, circle, red, 3.5	EA
252-1018/A	patch, BSA, circle, blue, 3.5	EA
252-1018/B	patch, BSA, circle, black3.5	EA
252-1027	patch, nor, circle, black3.5	EA
252-1037	patch, tri, circle, blue, 3.5	EA
252-1116	patch, nor, flame, 2x4	EA
252-1139	patch, tri, wings, grey, 2x7	EA
252-1188	patch, tri, #1 US, 4x3	EA
252-1399	patch, tri wing 2x7	EA
252-1400	patch, tri, wings, grey, 3x11	EA
252-1401	patch, tri, wings, grey, 2x4	EA
252-1420	patch, tri, wingspurple4x12	EA
252-1528	patch, BSA, wings, blue, 1x3	EA
252-1533	patch, tri, wings, purple1x3	EA
252-1738	patch, tri, wings, purple2x5	EA

252-1742	patch,nor,name,yellow,1x4	EA
252-1743	patch,tri,name,yellow,1x4	EA
252-1744	patch,BSA,name,yellow,1x4	EA
252-1745	patch,tri,tri nut,3x4	EA
252-1757	patch,tri,eagle,brown,4x5	EA
252-1763	patch,tri,eagle,brn,8x10"	EA
252-1820	patch,tri,flag,2x3	EA
252-1821	patch,tri,oval,blue,2x4	EA
252-1827	patch,tri,eagle,brown,3x3	EA
252-1832	patch,tri,"leather",2x3	EA
252-2023	patch,BSA,letters as flag	EA
252-2023/A	patch,BSA,logo,outline2x4	EA
252-2024	patch,BSA,#1,as flag,2x4	EA
252-2118	patch,NORTON,blk&wht,4x9"	EA
252-2119	patch,TRI,logo,blue,4.5X9"	EA
252-2285	patch,BSA,letters,large,3x8"	EA
253-	PINS,BADGES,AND JEWELRY	*
253-----	-----	--
253-01	DISCONTINUED	EA
253-02	DISCONTINUED	EA
253-03	DISCONTINUED	EA
253-033	label,brass,LYCETT seat	EA
253-034	label,brass,TERRY seat	EA
253-04	DISCONTINUED	EA
253-05	DISCONTINUED	EA
253-06	DISCONTINUED	EA
253-6001	pin,LUCAS,"Prince of Darkness"	EA
253-6013	DISCONTINUED	EA
253-6014	pin,TRIUMPH,script,blue&white	EA
253-6015	pin,TRIUMPH,script,black&gold	EA
253-6016-BG	pin,BSA,oval,black&gold	EA
253-6016-RW	pin,BSA,oval,red&white	EA
253-6017-BW	pin,TRI,oval,white let. on blue	EA
253-6017-WB	pin,TRI,oval,blue let. on white	EA
253-6020	pin,BSA,"Gold Star"	EA
253-6023	pin,TRIUMPH,patent numbers	EA
253-6025	pin,MATCHLESS,"London"(wreath)	EA
253-6026	pin,BSA,logo,red&gold	EA
253-6027	pin,MATCHLESS,"In Name & Reputation"	EA
253-6028	pin,AJS,"London"	EA
253-6034	pin,NORTON,green moon	EA
253-6036	pin,BSA,coloured X-rifles	EA
253-6037	pin,VELOCETTE,headstock logo,post war	EA
253-6038	pin,AJS,A.J.Stevens,Wolverhampton	EA
253-6039	pin,AJS,oval,blue&gold	EA
253-6040	pin,ARIEL,horseshoe logo	EA
253-6043	pin,ROYAL ENFIELD,"Built Like a Gun"	EA
253-6044-P	earring,TRI,script,post	PR
253-7002	pin,UNION JACK,British Flag	EA
253-7003	pin,BSA,BSA&Union Jack	EA
253-7006	pin,VINCENT,Mercury Crest	EA
253-7008	pin,NORTON,"Unapproachable"	EA
253-7013	pin,NORTON,script,black&gold	EA
253-7014	pin,NORTON,P-11 Tank Badge	EA
253-7025	pin,TRIUMPH,Triumph & Union Jack	EA
253-7033	pin,JPS,John Player Special logo	EA
253-7037	pin,HRD,black & gold logo	EA
253-7038	pin,JAMES,logo	EA
253-7040	pin,ARIEL,round tank badge logo	EA
253-7052	pin,VINCENT,tank scroll logo	EA
253-7072	pin,min.bike,NORTON,Commando	EA
253-7073	pin,NORTON,patent #'s logo	EA
253-7101	pin,min.bike,BSA,67 A65 Lightning	EA
253-7102	pin,min.bike,TRIUMPH,70 Bonneville	EA
253-7113	pin,NORTON/TRIUMPH,NVT logo	EA
253-7138-L	earring,TRI,pat.nos.,loop	PR
253-7138-P	earring,TRI,pat.nos.,post	PR
253-7141	pin,ROYAL ENFIELD,p/t badge logo	EA
253-7142	pin,TRIUMPH,"Bonneville" logo	EA
253-7143	pin,BSA,"Super Rocket" logo	EA
253-7146	pin,TRIUMPH,World M/C Spd.Rcd.Hldr.	EA

253-7160	pin,NORTON,"Roadholder" logo	EA
253-7161	pin,NORTON,"Oil Bath" logo	EA
253-7163-P	earring,NORTON,script,post	PR
253-7166	pin,min.bike,VINCENT,Black Shadow	EA
253-7179	pin,"Trident" logo	EA
253-7201	pin,TRIUMPH,"T"crank & pistons logo	EA
253-7262	pin,TRIUMPH,Coventry,1903 logo	EA
253-7265	pin,min.bike,NORTON,John Player Special	EA
253-7354	pin,NORTON,"750 Commando" logo	EA
253-7355	pin,NORTON,"850 Commando" logo	EA
253-7386	pin,min.bike,BSA,DBD Gold Star	EA
253-7387	pin,min.bike,NORTON,Manx	EA
253-7443	pin,min.bike,AJS,7-R	EA
253-7444	pin,min.bike,TRIUMPH,Hurricane	EA
253-7627	pin,BSA,"75th Anniversary"	EA
253-8008	pin,BSA,"Most Popular M/C" logo	EA
253-8011	pin,BSA,"Genuine Spares" logo	EA
253-8035	pin,VINCENT,"STOP"Vincent tail light	EA
253-8052	pin,BSA,X-rifles & garter	EA
253-8074	pin,NORTON,"Genuine Factory Parts"	EA
253-8117-BG	pin,TRIUMPH,"Living Legend"blk/gold	EA
253-8117-BW	pin,TRIUMPH,"Living Legend"blue/white	EA
253-8118	DISCONTINUED	EA
253-8119	DISCONTINUED	EA
253-8120	DISCONTINUED	EA
253-8121	DISCONTINUED	EA
253-8135	DISCONTINUED	EA
253-8605	pin,min.bike,NORTON,yellow sub, racer	EA
253-8622	pin,AMAL,DISCONTINUED	EA
253-8648	pin,min.bike,VELOCETTE,Thruxton	EA
253-8668	DISCONTINUED	EA
253-8680	pin,MATCHLESS,Devon	EA
253-8828-L	earring,BSA,star,loop	PR
253-8828-P	earring,BSA,star,post	PR
253-8829	pin,BSA,star,red & gold	EA
253-8848	pin,TRIUMPH,patent #'s/Union Jack	EA
253-8850	pin,TRIUMPH,tiger's head	EA
253-8859	pin,NORTON,"N"	EA
253-8860-L	earring,NORTON,"N",loop	PR
253-8860-P	earring,NORTON,"N",post	PR
253-8872	pin,TRIUMPH,6T engine	EA
253-8881	pin,TRIUMPH,Thunderbird logo	EA
253-8882	pin,NORMAN HYDE,logo	EA
253-8883	DISCONTINUED	EA
253-8884	DISCONTINUED	EA
253-8886-A	pin,min.bike,TRIUMPH,'58 T110,blk&white	EA
253-8886-B	pin,min.bike,TRIUMPH,'58 T110,blue&white	EA
253-8887	pin,min.bike,TRIUMPH,'59 T120 Bonneville	EA
253-8890	pin,TRIUMPH,leaping tiger	EA
253-8891	pin,TRIUMPH,"Triumph Twins"&"T"	EA
253-AJS	DISCONTINUED	EA
253-AJS/01	pin,AJS,silver on blue	EA
253-AJS/02	pin,AJS,silver logo,black,yellow outline	EA
253-ARIEL/01	pin,ARIEL,horseshoe logo	EA
253-ARIEL/02	pin,ARIEL,triangle "A"	EA
253-ARIEL/03	pin,ARIEL,logo on black	EA
253-ARIEL/04	emblem w/stud,ARIEL	EA
253-BA	DISCONTINUED	EA
253-BB	DISCONTINUED	EA
253-BC	DISCONTINUED	EA
253-BD	DISCONTINUED	EA
253-BE	DISCONTINUED	EA
253-BRIT/01	pin,British Flag	EA
253-BSA/01	pin,BSA,piled arms,round	EA
253-BSA/02	pin,BSA,round,wings,arms	EA
253-BSA/03	pin,BSA,piled arms,wings	EA
253-BSA/04	pin,BSA,logo as letters	EA
253-BSA/05	pin,BSA,silver star,coloured	EA
253-BSA/06	pin,BSA,logo,arms,on red	EA
253-BSA/07	pin,BSA,logo,oval	EA
253-BSA/08	pin,BSA,jumbo,red,yellow	EA

253-BSA/09	pin, TriBSA, as logo, blue	EA
253-BSA/10	pin, BSA, jumbo, silver star	EA
253-BSA/11	pin, BSA, silver star, blue	EA
253-BSA/12	pin, BSA, logo, star, round	EA
253-BSA/13	pin, BSA, rect., arms, green	EA
253-BSA/14	pin, BSA, eagle	EA
253-BSA/15	pin, TriBSA, as logo, red	EA
253-BSA/16	pin, BSA, arms, red	EA
253-BSA/17	pin, BSA, bantam	EA
253-BSA/18	pin, BSA, super rocket	EA
253-BSA/19	pin, BSA, golden flash	EA
253-BSA/20	pin, BSA, goldstar bike	EA
253-BSA/21	emblem w/stud, BSA	EA
253-BSA/22	pin, GOLD STAR emblem, star	EA
253-BSA/23	pin, BSA logo, wings	EA
253-COTTON/01	pin, COTTON, silver logo, red on black	EA
253-DOUGLAS/01	pin, DOUGLAS, logo on blue	EA
253-DUNSTALL/01	pin, DUNSTALL, round, blue	EA
253-ENF/01	pin, ROYAL ENFIELD, cannon	EA
253-ENF/02	pin, ROYAL ENFIELD, wings	EA
253-EXCELSIOR/01	pin, EXCELSIOR, emblem	EA
253-JAMES/01	pin, JAMES, silver name, oval, red&orange	EA
253-JAP/01	pin, JAP, emblem	EA
253-LEVIS/01	pin, LEVIS, emblem	EA
253-M	DISCONTINUED	EA
253-MATCH/01	pin, flying "M", rect., red	EA
253-MATCH/02	pin, flying "M", round, bl.	EA
253-MATCH/03	pin, MATCHLESS, wings, flying "M"	EA
253-MECHANIC/01	pin, MASTER MECHANIC, man w/hammer&spanner	EA
253-NA	DISCONTINUED	EA
253-NB	DISCONTINUED	EA
253-NC	DISCONTINUED	EA
253-NE	DISCONTINUED	EA
253-NOR/01	pin, NORTON, logo, coloured	EA
253-NOR/02	pin, NORTON, logo, letters	EA
253-NOR/03	pin, NORTON, logo, wings	EA
253-NOR/04	pin, NORTON COMMANDO, round	EA
253-NOR/05	pin, NORTON, rectangle, blue	EA
253-NOR/06	pin, NORTON, jumbo, flag, rd.	EA
253-NOR/07	pin, NORTON TRIUMPH, jumbo	EA
253-NOR/08	pin, NORTON TRIUMPH, small	EA
253-NOR/09	pin, NORTON, eagle	EA
253-NOR/10	pin, NORTON, jumbo, on red	EA
253-NOR/11	pin, NORTON F1	EA
253-NOR/12	pin, NOR COMM, round, large	EA
253-NOR/13	emblem w/stud, NORTON	EA
253-NOR/14	pin, NORTON, emblem, oblong	EA
253-NOR/15	pin, NORTON, sliver logo, blue on red	EA
253-NOR/16	pin, NORTON, Commando&"N", red on black	EA
253-PANTHER/01	pin, PANTHER, oval w/ cat	EA
253-PANTHER/02	pin, BLACK PANTHER, black head	EA
253-RE	DISCONTINUED	EA
253-RUDGE/01	pin, RUDGE, hand logo	EA
253-SCOTT/01	pin, SCOTT, logo	EA
253-SEELEY/01	pin, SEELEY, emblem	EA
253-SUNBEAM/01	pin, SUNBEAM, round, logo	EA
253-SUNBEAM/02	pin, SUNBEAM, rectangle	EA
253-TA	DISCONTINUED	EA
253-TB	DISCONTINUED	EA
253-TC	DISCONTINUED	EA
253-TRI/01	pin, TRIUMPH, logo on blue	EA
253-TRI/02	pin, TRIUMPH, wings	EA
253-TRI/03	pin, TRIUMPH, sq. w/ globe	EA
253-TRI/04	pin, TRIUMPH, rectangular	EA
253-TRI/05	pin, TRIUMPH, oval, checker	EA
253-TRI/06	pin, TRIUMPH, jumbo, checker	EA
253-TRI/07	pin, TRIUMPH, jumbo, black	EA
253-TRI/08	pin, TRIUMPH BONNEVILLE	EA
253-TRI/09	pin, TRIUMPH, logo, rd, black	EA
253-TRI/10	pin, TRIUMPH, eagle	EA
253-TRI/11	pin, TRIUMPH, logo	EA

253-TRI/12	pin,1990 DAYTONA	EA
253-TRI/13	pin,TRIUMPH,patent plate	EA
253-TRI/14	pin,TRIUMPH,tiger	EA
253-TRI/15	emblem w/stud,TRI	EA
253-TRI/16	pin,TRIUMPH HYDRAULIC,emblem	EA
253-TRI/17	pin,TRIUMPH,double wing,various colours	EA
253-TRITON/01	pin,TRITON,round,blue	EA
253-TT	DISCONTINUED	EA
253-VEL	DISCONTINUED	EA
253-VELO/01	pin,VELOCETTE,gold logo	EA
253-VIN/01	pin,VINCENT HRD,oval	EA
253-VIN/02	pin,VINCENT,black,gold	EA
253-WESTLAKE/01	pin,WESTLAKE,emblem	EA
254-	KEYCHAINS	*
254-----	-----	---
254-01	keytag,NORTON,metal logo	EA
254-02	keytag,BSA,w/arms,metal	EA
254-03	keytag,TRIUMPH,blue,metal	EA
254-04	keytag,BSA,arms	EA
254-05	keytag,BSA,logo,plastic	EA
254-06	keytag,TRI,logo	EA
254-07	keytag,NOR,blk/wht plastic	EA
254-08	keytag,NORTON,red & blue	EA
254-09	keytag,BSA,star on red	EA
254-10	keytag,TRIUMPH,on black	EA
254-11	keytag,BSA Spitfire Mk4	EA
254-12	keytag,Triumph"T",plastic	EA
254-13	keytag,TR6 blue/white on black	EA
254-14	keytag,TR7 checker/green	EA
254-15	keytag,TRIUMPH logo on globe	EA
254-16	keytag,UNION JACK	EA
254-17	keytag,VELOCETTE	EA
254-18	keytag,VINCENT	EA
254-19	keytag,NORTON,gold logo,black leather	EA
255-	RUBBER STAMPS	*
255-----	-----	---
255-103	stamp,Norton Fastback 750	EA
255-106	stamp,Triumph Bonnie T120	EA
255-107	stamp,BSA Spitfire Mk11	EA
255-134	stamp,Norton Manx	EA
255-135	stamp,John Player Norton	EA
255-136	stamp,Norton Mk111 ES	EA
255-137	stamp,Triumph T120R	EA
255-138	stamp,Triumph Tiger T100C	EA
255-139	stamp,Triumph Trident	EA
255-140	stamp,BSA Goldstar	EA
255-141	stamp,BSA Lightning 650	EA
255-142	stamp,BSA Rocket 111 750	EA
255-151	stamp,Vincent BlackShadow	EA
255-152	stamp,Matchless G80 CS	EA
255-168	stamp,Ariel Square Four	EA
255-180	stamp,BSA B44 Victor	EA
256-	BELT BUCKLES & WALLETS	*
256-----	-----	---
256-11	buckle,BIRM,BSA,SM ARMS	EA
256-21	buckle,TRI,750,BONNEVILLE	EA
256-23	buckle,TRI,650,BONNEVILLE	EA
256-25	buckle,TRI,500,TIGER	EA
256-26	buckle,TRI,500,DAYTONA	EA
256-31	buckle,NORTON COMMANDO	EA
256-32	buckle,NOR COMMANDO	EA
256-33	buckle,NOR,750,COMMANDO	EA
256-34	buckle,NORTON,ATLAS,750	EA
256-4111	buckle,NORTON,brass*	EA
256-4445	buckle,TRIUMPH,brass	EA
256-BSA	buckle,BSA,plain silver	EA
256-BSA/E	buckle,BSA,enamel,bk & rd	EA
256-T38	buckle,TRI,plain silver	EA
256-T38/E	buckle,TRI,enamel,maroon	EA
257-	WALL CLOCKS	*
257-----	-----	---

257-04	wall clock,TRI SpeedTwin	EA
257-1313	wall clock,Union Jack	EA
257-632	wall clock,Vincent eng.	EA
257-634	wall clock,Triumph eng.	EA
257-635	wall clock,Velo eng.	EA
257-636	wall clock,Gold Star eng.	EA
257-BSA	wall clock,BSA	EA
257-NOR	wall clock,NORTON	EA
257-TRI	wall clock,TRIUMPH	EA
258-	SIGNS	*
258-----	-----	---
258-01	wall plaque,Norton 850 ES	EA
258-02	wall plaque,Tri. Trident	EA
258-03	wall plaque,Slippery Sam	EA
258-04	wall plaque,Bonnie 750	EA
258-05	wall plaque,BSA Gold Star	EA
258-06	wall plaque,1934 Manx	EA
258-07	wall plaque,67 Velo ThruX	EA
258-08	wall plaque,1967 Bonnie	EA
258-09	wall plaque,Manx Norton	EA
258-10	wall plaque,Matchless G50	EA
258-1000	rug,TRIUMPH logo	EA
258-101	sign,BSA DEALER	EA
258-102	sign,TRIUMPH DEALER	EA
258-103	sign,NORTON DEALER	EA
258-1046	rug,BSA logo	EA
258-1047	rug,NORTON logo	EA
258-11	wall plaque,1922 AJS	EA
258-12	licence plate,NORTON *	EA
258-13	licence plate,TRIUMPH*	EA
258-14	licence plate,BSA	EA
258-201	sign,NORTON DOMINATOR,1951	EA
258-202	sign,TRIUMPH THUNDERBIRD,1950	EA
258-203	sign,BSA GOLDSTAR,1959	EA
258-204	sign,BSA BANTAM	EA
258-205	sign,VINCENT BLACK SHADOW	EA
258-206	sign,ARIEL SQUARE 4	EA
258-207	sign,MATCHLESS	EA
258-208	sign,VELOCETTE	EA
258-209	sign,NORTON MANX	EA
258-442	sign,TRIUMPH 3T DELUXE	EA
258-5008	sign,TRIUMPH PARKING ONLY	EA
258-5008/A	sign,TRIUMPH PARKING,embossed*	EA
258-5009	sign,NORTON PARKING ONLY	EA
258-5010	sign,BSA PARKING ONLY	EA
258-506	sign,TRIUMPH 650 RIGID	EA
258-5067	sign,BRITISH PARKING ONLY	EA
258-507	sign,TRIUMPH 650 TROPHY,S.A.	EA
258-511	sign,TRIUMPH THUNDERBIRD,S.A.	EA
258-515	sign,TRIUMPH SPEED TWIN RIGID	EA
258-517	sign,COMMANDO FASTBACK	EA
258-6113	sign,NORTON PARKWAY	EA
258-658	sign,AJS TWIN	EA
258-659	sign,COMMANDO INTERSTATE 750	EA
258-660	sign,BSA GOLDSTAR 500	EA
258-T11	sign,BROUGH SUPERIOR	EA
258-T3	sign,TRIUMPH BONNEVILLE,1960	EA
258-T32	sign,TRIUMPH SPEED TWIN,prewar	EA
258-T4	sign,COMMANDO ROADSTER 750	EA
259-	MUGS	*
259-----	-----	---
259-01/AJS	coffee mug,AJS,white	EA
259-01/ARIEL	coffee mug,ARIEL,white	EA
259-01/BSA	coffee mug,BSA,red letters on white	EA
259-01/BSA/A	coffee mug,BSA,red/silv on wht.	EA
259-01/BSA/B	coffee mug,GOLDSTAR on grey	EA
259-01/BSA/C	coffee mug,BSA guns on wht.	EA
259-01/BSA/D	coffee mug,BSA,gold letters on black	EA
259-01/BSA/E	coffee mug,BSA,red letters on black	EA
259-01/BSA/F	coffee mug,BSA,GOLDEN FLASH,logo on yell	EA
259-01/BSA/G	coffee mug,BSA,GOLDSTAR photo on white	EA

259-01/ENF	coffee mug,ROYAL ENFIELD	EA
259-01/JACK	coffee mug,UNION JACK	EA
259-01/MATCH	coffee mug,MATCHLESS,wh.	EA
259-01/NOR	coffee mug,NORTON,gold on white	EA
259-01/NOR/A	coffee mug,NORT bl/sil on grey	EA
259-01/NOR/B	coffee mug,NORTON,gold on black	EA
259-01/OIL	coffee mug,MIN.OIL LEVEL,blk/wht	EA
259-01/OIL/A	coffee mug,MIN.OIL LEVEL,gold/blk	EA
259-01/OIL/B	coffee mug,MIN OIL LEVEL,wht on blk.	EA
259-01/RUDGE	coffee mug,RUDGE-WHIT,wh.	EA
259-01/SCOTT	coffee mug,SCOTT,white	EA
259-01/TRI	coffee mug,TRIUMPH,blue/white	EA
259-01/TRI/A	coffee mug,TRIUMPH,red/white	EA
259-01/TRI/B	coffee mug,TRIUMPH,white/blue	EA
259-01/TRI/C	coffee mug,TRIUMPH,gold/blk	EA
259-01/TRI/D	coffee mug,TRIUMPH gold on wht.	EA
259-01/TRI/E	coffee mug,BONNIE on blk.	EA
259-01/TRI/F	coffee mug,TRIUMPH,gold/wt on black	EA
259-01/TRI/G	coffee mug,TRIUMPH,bl/sil on blue	EA
259-01/TRI/H	coffee mug,TRI Meriden,black on cream	EA
259-01/TRI/J	coffee mug,TRI Meriden,silver on blue	EA
259-01/TRI/K	coffee mug,TRI Meriden,red on sand	EA
259-01/TRI/L	coffee mug,TRI Daytona,logos on black	EA
259-01/TRI/M	coffee mug,TRI logo,bl w/gold trim,white	EA
259-01/TRI/N	coffee mug,TRI HURRICANE	EA
259-01/VELO	coffee mug,VELOCETTE,wh.	EA
259-01/VIN	coffee mug,VINCENT,white	EA
260-	FLAGS	*
260-	-----	--
260-02	flag,British,4x6",w/base	EA
260-03	flag,British,18x36 inches	EA
260-04	flag,British,27x54 inches	EA
260-05	flag,British,36x72 inches	EA
260-06	flag,British,45x90 inches	EA
260-07	flag,British,54x108 inch	EA
261-	PUZZLES	*
261-	-----	--
261-03	puzzle,TRI Bonneville preunit	EA
262-	MODELS	*
262-	-----	--
262-109	model,Norton Manx,Protar	EA
262-137	model,Norvil Commando,Protar	EA
262-360	model,AJS 7R,Protar	EA
263-	STOOLS	*
263-	-----	--
263-BSA	barstool,BSA logo	EA
263-NOR	barstool,NORTON logo	EA
263-TRI	barstool,TRIUMPH logo	EA
321-	HEADLIGHT BRACKETS	--
321-	-----	--
321-01	hdlight bracket,bot.mt,single	EA
321-02	hdlt.bracks,sd.mt,w/holes	PR
321-03	hdlight bracket,bot.mt,dual	EA
321-04	hdlt.bracks,sd.mt,rubber mounted	PR
323-	HEADLIGHTS AND COMPONENTS	*
323-	-----	--
323-01	headlight assy,Miller 8"repl.	EA
323-30	visor,7inch headlight	EA
323-31	visor,5-3/4inch headlight	EA
323-41	"Bates"hdlght,12V.bot.mt.	EA
323-41/A	"Bates"hdlght,12V.bot.mt,halogen	EA
323-41/SHELL	shell&rim,5-3/4"bot.mt Bates hdlt.	EA
323-42	"Bates"hdlght,12V,side mt	EA
323-42/A	"Bates"hdlt,12V,side mt,halogen	EA
323-42/SHELL	shell&rim,5-3/4"sidemt.Bates hdlt.	EA
323-43/ER	hdlght,5-3/4"6V,side mt,econo	EA
323-66	hdlt.assy,5-3/4inch,Lucas	EA
323-66/A	hdlt.shell,5-3/4,blank,w/rim	EA
323-66/B	hdlt.shell,5-3/4",blk,w/rim,blank	EA
323-66/C	hdlt.shell,5-3/4,3warn,1sw.hole,w/rim	EA
323-66/D	hdlt.shell,5-3/4,1warn,lg&sm sw,w/rim	EA

323-66/E	hdlt.shell,5-3/4,3warn,1lg.sw.hole,w/rim	EA
323-69	hdlt.assy,flatback,no holes	EA
323-69/A	hdlt.shell,fltbk,no holes,w/rim	EA
323-69/B	shell,flatback,3warn.lt&1sw.hole,w/rim*	EA
323-700	hdlt.assy,7" Lucas type,blank top*	EA
323-700/A	shell,blank top,3 bot holes,7"headlight*	EA
323-700/A/ER	shell,blank,3bot.hole,7",w/rim.econo*	EA
323-700/B	shell,3warn.lt&1sw.hole,3bot.hole,7"hdlt	EA
323-700/C	shell for2warn lt,toggle sw.&amm,7"hdlt*	EA
323-700/C/ER	shell,2warnLt,toggleSw&amm,7"w/rim,econ*	EA
323-700/D	shell,w/amm.hole,7" headlight*	EA
323-700/D/ER	shell,w/amm.hole,7" hdlt.w/rim,econo*	EA
323-700/E	shell,3warn.lt&1sw.hole,1bot.hole,7"hdlt	EA
323-700/E/ER	shell,3warnLt&1sw&1bot.hole,7"w/rim,econ	EA
323-700/F	shell for2warn lt,rotary sw.&amm,7"hdlt*	EA
323-700/G	shell for2warn lt,&ammeter,7"headlight*	EA
323-700/H	shell for1warn lt,rotary sw.&,7"hdlt	EA
323-700/I	shell,1warn lt,toggle sw.&ammeter,7"hdlt	EA
323-700/J	shell,1warn.lt,rotary sw.&,7"hdlt*	EA
323-700/K	shell for2warn lt,&ammeter,7"headlight*	EA
323-700/L	shell,blank top,1 bot.hole,7"headlight*	EA
323-700/L/BLK/ER	shell,blank,1bot.hole,7",w/rim.econo*	EA
323-700/L/ER	shell,blank,1bot.hole,7",w/rim.econo*	EA
323-700/M	shell,1toggle sw.hole,3bot.hole,7"hdlt	EA
323-700/N	shell for2warn lt,rotary sw,7"hdlt*	EA
323-MU42	hdlt.assy,6",blk,compl.w/sw.panel	EA
323-SSU700P	hdlt.assy,7",blk,compl,w/sw.panel	EA
324-	TAILLIGHTS, PARTS, & BRACKETS	*
324-----	-----	---
324-01	taillight,tombstone style	EA
324-01/A	lense,red,tombstone light	EA
324-02	taillight assy,Sparto type,LED	EA
324-03	taillight,Maltese cross	EA
324-04	taillight assy,catseye	EA
324-11	reflector,tail,chrome rim,univ.	EA
324-82	sidemount taillight assy.	EA
324-83	bracket,taillight&lic.,ss	EA
324-84	bracket,taillight&lic,classic univ.	EA
324-85	bracket,taillight&lic,alloy	EA
324-86	bracket,taillight&lic,w/lite,chrome	EA
324-91	licence backing plate,ss.	EA
324-92	number plate,front,UKtype	EA
324-93	holder,tax disc,UK	EA
324-93/SS	holder,tax disc,UK, stainless	EA
325-	TURN SIGNALS AND MARKER LIGHTS	*
325-----	-----	---
325-01	bullet light,amber	EA
325-02	signals,bar end	EA
331-	BOYER ELECTRONIC IGNITION	*
331-----	-----	---
331-01	Boyer elec.ign,Norton	EA
331-01/A	Boyer elec.ign,Nor,Microdigital	EA
331-01/B	Boyer MicroPower kit,Norton	EA
331-02	Boyer ign,TriBSA unitTwin*	EA
331-02/A	Boyer,TriBSA unitTwin,microdigital	EA
331-02/B	Boyer MicroPower kit,TriBSA unitTwin*	EA
331-02/C	Boyer raceIgn/reg kit,Com&TriBSAunitTwin	EA
331-03	Boyer ign,TriBSA Triples	EA
331-03/A	Boyer,TriBSA Triples,microdigital	EA
331-03/B	Boyer MicroPowerkit,TriBSA 3	EA
331-03/C	Boyer raceIgn/reg.kit,TriBSA 3cyl.	EA
331-04	amplifier,Boyer,Commando	EA
331-04/A	amplifier,Boyer,CommandoMicrodigital	EA
331-04/B	amp,Boyer,CommandoMicroPower	EA
331-04/U	amplifier,Boyer,Commando,pretested	EA
331-05	amp,Boyer,2cyl.TriBSA*	EA
331-05/A	amp,Boyer,2cyl.TriBSA,Microdigital	EA
331-05/B	amp,Boyer,2cyl.TriBSA,MicroPower	EA
331-05/U	amplifier,Boyer,1&2cyl,pretested	EA
331-06	pickup plate,Boyer,1&2 cyl*	EA
331-06/U	pickup plate,Boyer,1&2cyl.,USED*	EA

331-07	rotor,Boyer,2 cyl,latelcyl.	EA
331-08	pickup plate,Boyer,3 cyl.	EA
331-09	amplifier,Boyer,3cylinder	EA
331-09/A	amplifier,Boyer,3cylMicrodigital	EA
331-09/B	amp,Boyer,3cylMicroPower	EA
331-10	rotor,Boyer,3 cylinder	EA
331-12	Boyer kit,TriBsa single,64on *	EA
331-12/A	Boyer,TriBsa single,microdigital	EA
331-12/B	Boyer Micropowerkit,unit 1cyl,sidepoints	EA
331-12/C	Boyer race ign/reg,unit1cyl,sidepoints	EA
331-13/B	Boyer MicroPowerkit,unitDist.1cyl	EA
331-13/C	Boyer race ign/reg,unit1cyl,distr.	EA
331-13E	Boyer kit,TriBsa single,distr.	EA
331-14	Boyer elec.ign,Bullet	EA
331-14/A	Boyer elec.ign,Bullet,microdigital	EA
331-14/B	Boyer MicroPowerkit,EnfieldBullet	EA
331-15	Boyer ign,TriBSA unitTwin,6V*	EA
331-16	amplifier,Boyer,1&2 cyl,6V	EA
331-17	coil,single output,for Micropower kit	EA
331-18	coil,dual output,for Micropower kit*	EA
331-19	amp,Boyer,TriBSAunit1cyl.MicroPower*	EA
331-19/A	amp,Boyer,TriBSAunit1cyl*	EA
332-	POWER UNITS	*
332-----	-----	--
332-01	regulator,12Vdynamo conv,positive	EA
332-01/A	regulator,12Vdynamo conv,negative	EA
332-02	regulator,6Vdynamo,solid state,pos.	EA
332-02/A	regulator,6Vdynamo,elect,negative*	EA
332-03	battery eliminator,dynamo	EA
332-101	rectifier,solid state,1phase	EA
332-101/A	rectifier,solid state,3phase	EA
332-104	MityMax PowerControl unit,1phase	EA
332-104/A	TympaniumPowerControl unit,1phase	EA
332-104/B	PowerBox,Boyer,1phase	EA
332-104/C	PowerControl unit,1phase,econo	EA
332-104/D	PowerBox,Boyer,1ph.w/lite delay	EA
332-104/E	PowerBox,Boyer,1ph,w/chg.ind*	EA
332-105	Mity Max,for 3 phase alt.	EA
332-105/A	PowerControl unit,3phase,econo	EA
332-105/B	TympaniumPowerControl unit,3phase*	EA
332-105/C	PowerBox,Boyer,3phase3Wire*	EA
332-105/D	PowerBox,Boyer,3ph,w/chg.ind*	EA
332-12/A	coil,12V dual lead,3.6 OHM*	EA
332-12/CH	coil,12V.dual lead,chrome	EA
332-21	engine rpm control unit	EA
333-	RITA IGN,&POWERBASE ALTS.	*
333-----	-----	--
333-01	diode,Rita ign*	EA
333-02	pickup assy,comp,Rita twin ign.*	EA
333-03	amplifier,Rita AB11,for 12V coils	EA
333-04	cover,Rita,Tri1&2cyl,smooth	EA
333-05	cover,Rita,3cyl.	EA
333-06	cover,Rita,Commando,RHign.	EA
333-07	cover,Rita,rear ign.	EA
333-08	pickup plate,Rita triple ign.	EA
333-09	pickup plate,Rita twin ign.	EA
333-100	Rita ign,Commando,RH side*	EA
333-100/A	Rita ign,Nort.Twin,rear mount	EA
333-101	Rita ign,oilframe Tri.twin*	EA
333-102	Rita ign,Triumph T160V ES	EA
333-112	USE 333-121	ea
333-113	Rita ign,Triumph T150	EA
333-119	Rita ign,BSA A50 and A65*	EA
333-120	Rita ign,BSA Rocket Three	EA
333-121	Rita ign,1963on POIF TRI twin*	EA
333-131	PowerbaseHi-OutputAlt.kit	EA
333-131/A	Hi-OutputAlt.kit,solid state, repl.	ST
333-134	Rita elec.magneto replkit	EA
333-135	Rita ign,Tri/BSA unit1cyl	EA
334-	MAGNETOS AND COMPONENTS	*
334-----	-----	--

334-01	magneto,ARDw/lock,TriTwin	EA
334-02	magneto,ARD CDI,unitTRI twin,M-4*	EA
334-03	magneto,ARD CDI,unitTRIBSAsingle,M-4*	EA
334-04	magneto,ARD CDI,rear mt.twin	EA
334-05	magneto,ARD CDI,BSA A65	EA
334-06	magneto,ARD CDI,Commando*	EA
334-07	magneto,ARD CDI,Gold Star	EA
334-08	magneto,ARD CDI,VINCENT	EA
334-10	belt,ARD BSA magneto	EA
334-11	belt,ARD Triumph magneto	EA
334-1131	screw set,magneto cap,HUNT	ST
334-1133	condensor,Hunt & ARD mags	EA
334-1137	points,Hunt clockwise mag	EA
334-1138	points,Hunt&ARD ccw mags	EA
334-1177	coil,magneto,twin output	EA
334-1198	gasket,mag.cap,ARD & Hunt	EA
334-12	cap,ARD Triumph magneto	EA
334-1278	Hunt mag,rear mount,twins*	EA
334-1278/A	Hunt mag,rear mt.twins,w/lock	EA
334-1279	Hunt mag,`63onTriumphTwin*	EA
334-1279/A	Huntmag,63-TriTwin,w/lock*	EA
334-1280	Hunt mag,Commando,RHmount	EA
334-1281	Hunt mag,A50/A65,w/cover*	EA
334-149	bearing,ball,mag,drive end	EA
334-149P	bearing,roller,mag,pointsplate	EA
334-15	rotor,ARD mag,CCWrotation*	EA
334-16	rotor,ARD mag,clockwise	EA
334-17	pulley,top,ARD mag	EA
334-18	pulley,bot,ARD mag	EA
334-19	driveshaft,tapered,ARD mag	EA
334-20	contact kit,ARD mag	ST
334-21	screw set,magneto cap,ARD	ST
334-3001	adaptor plate,1279 mag to t/cov.	EA
334-3003/3004	driveshaft,tapered,w/hex,Huntmag*	ST
334-3005	hdwe.kit,334-1279&1280 mags	ST
334-463	pointsplate,FM magneto,CW	EA
334-4631	points plate,FM magneto,CCW	EA
334-5005	hdwe.kit,334-1281 mag	ST
334-6001	adaptor plate,1278 mag to case,3hole	EA
334-6005	hdwe.kit,334-1278 mag	ST
334-61	cap,Joe Hunt magneto,genuine	EA
334-61/A	cap,Joe Hunt magneto,clear	EA
334-61/ER	cap,JoeHunt mag,econo	EA
334-64	keylock assy,ARD&Hunt mag	EA
334-65	spring,coil to cap,HUNT magneto	EA
334-71	coil,twin cyl.ARD CDI mag	EA
334-72	coil,single cyl. ARD CDI mag	EA
334-73	amplifier,ARD CDI magneto	EA
335-	BATTERIES	*
335-	-----	---
335-02	bat,12N94B-1,stdKickstart	EA
335-02/A	bat,12N94B-1 type,sealed	EA
335-03	bat,12N74B,std.kickstart	EA
335-04	bat,12C16B-3B,forT160V ES	EA
335-05	bat,12N14-3AforMk3&T140ES	EA
335-06	bat,6N113A,late style 6v.	EA
335-07	bat,6V w/hard rubber case,std.	EA
335-07/A	bat,6V,B386A,plastic case	EA
335-07/B	bat,6V,black plastic case	EA
335-07/C	cover,bakelite,6V bat.	EA
335-08	bat,12V w/hard rubber case	EA
335-09	bat,6V w/hard rubber case,small	EA
335-10	shell,battery,blk.6vtype	EA
335-11	shell,battery,blk.Tshape	EA
336-	SPARK PLUGS	*
336-	-----	---
336-C55R	spark plug,Champion C55R,racing type	EA
336-C57R	spark plug,Champion C57R,racing type	EA
336-D16	spark plug,Champion D16	EA
336-G63	spark plug,Champion G63	EA
336-H10	spark plug,Champion H10	EA

336-L10	USE 336-L86	ea
336-L10S	USE 336-L86	ea
336-L11S	USE 336-L82C	ea
336-L5	USE 336-L82C	ea
336-L7	USE 336-L86	ea
336-L78C	spark plug,Champion L78C	EA
336-L82C	spark plug,Champion L82C	EA
336-L85	USE 336-L86	ea
336-L86	spark plug,Champion L86C	EA
336-N2C	spark plug,Champion N2C	EA
336-N3	USE 336-N3C	ea
336-N3C	spark plug,Champion N3C	EA
336-N4	USE 336-N4C	ea
336-N4C	spark plug,Champion N4C	EA
336-N5	spark plug,Champion N5C	EA
336-N54R	USE 336-C55R	ea
336-N57G	spark plug,Champion N57G	EA
336-N57R	spark plug,Champion N57R*	EA
336-N6Y	USE 336-N6YC	ea
336-N6YC	spark plug,Champion N6YC	EA
336-N74C	USE 336-N5C	ea
336-N7Y	USE 336-N7YC	ea
336-N7YC	spark plug,Champion N7YC	EA
336-N8	USE 336-N5C	ea
336-Z10	USE 336-Z9Y	ea
336-Z9Y	spark plug,Champion Z9Y	EA
341-	HANDLEBAR SWITCHES	*
341-----	-----	--
341-04	horn button,universal	EA
341-04/A	horn button,universal,1"	EA
341-05	turnsignal switch,univer.	EA
341-06	handlebar sw,univ.multipurpose	EA
341-07	handlebar switch,univ.hi/lo	EA
341-08	handlebar sw,univ.hi/lo/horn,Miller type	EA
341-3857	"Ducon" handlebar switch,repl*	EA
341-3857/ER	"Ducon" handlebar switch,econo*	EA
341-3858	"Tricon" handlebar sw,repl.*	EA
341-3858/ER	"Tricon" handlebar sw,econo repl.	EA
341-3859	"Triconsul" handlebar sw,repl.	EA
342-	BRAKE SWITCHES	*
342-----	-----	--
342-02	brake light switch,univ.	EA
343-	IGNITION SWITCHES&BRACKET	*
343-----	-----	--
343-01	ignition sw. bracket,chr.	EA
343-11	switch,key,universal,3position	EA
344-	HORNS	*
344-----	-----	--
344-01	horn,universal 12 volt	EA
344-01/A	horn,universal 6 volt	EA
344-620051	horn&bracket,late Triumph	EA
345-	WIRING HARNESSSES & PIECES	*
345-----	-----	--
345-01	plug wire kit,universal,black,7MM	ST
345-02	plugwire kit,performance,yellow,7MM	ST
345-03	plug wire&cap,black resistor,24",7MM	EA
345-03/A	plug wire&cap,copper,24",7MM	EA
345-04	plug wire&cap,black resistor,10",7MM	EA
345-04/A	plug wire&cap,blk.copper,10",7mm	EA
345-05	plugwire,coppercore,7mm,100ft.roll	EA
345-06	plug wire kit,universal,red resistor,8MM	EA
345-10	plug cap,universal	EA
345-10/A	plug cap,Champion soft,Tri&Nort type	EA
345-10/B	plug cap,Champion bakelite,resistor type	EA
345-10/C	plug cap,Champion soft,BSA type	EA
345-10/D	plug cap,Champion bakelite,non-resistor*	EA
345-1002	harness,1958-62 A7 & A10	EA
345-1002/A	harness,1958-62 A7/A10,cloth	EA
345-1007	harness,main,71-72 T100*	EA
345-1007/A	harness,main,71-72 T100,cloth*	EA
345-1008	harness,hdlt,71-73 T100*	EA

345-1008/A	harness,hdlt,71-73 T100,cloth*	EA
345-1009	harness,main,71-74 Norton*	EA
345-1009/A	harness,main,71-74Nort,cloth	EA
345-1010	harness,hdlt,71-74 Norton	EA
345-1010/A	harness,hdlt,71-74Nort,cloth	EA
345-1011	harn,hdlt,71-2 3cyl	EA
345-1012	harness,main,72 A75	EA
345-1013	harn,main,71/72T150,71A75	EA
345-1013/A	harn,main,71-72T150,71A75,cloth	EA
345-1014	harness,hdlt,71-TriBSA650	EA
345-1014/A	harness,hdlt,71-TriBSA650,cloth	EA
345-1015	harness,main,71-TriBSA650	EA
345-1015/A	harness,main,71-TriBSA650,cloth	EA
345-1016	harn,hdlt,71-TriBSA 1cyl.	EA
345-1017	harn,main,71-TriBSA 1cyl.	EA
345-1018	harn,el.box,71-TriBSA1cyl	EA
345-1020	harness,B33,1958	EA
345-1020/A	harness,B33,1958,cloth	EA
345-1023/B	harness,pre1966 A50 & A65,cloth	EA
345-1023A	harness,pre1966 A50 & A65	EA
345-1025	harness,1956-59 T100&T110	EA
345-1025/A	harness,1956-59 T100/110,cloth	EA
345-1027	harness,63 Tri.TR6,T120,T90,T100	EA
345-1027/A	harness,63 Tri.TR6,T120,T90,T100	EA
345-1036	harness,63-64 T120;TR6;T100;T90	EA
345-1036/A	harness,63-64 T90/100/120&TR6,cloth	EA
345-1055	harn,68 Tri Twins,exc."C"*	EA
345-1055/A	harn,68TriTwins,exc"C",cloth	EA
345-1061	harn,69&70 TriTwin,exc"C"	EA
345-1061/A	harn,69&70 TriTwin,exc"C",cloth	EA
345-1066	harness,1976-78 Tri Twins	EA
345-1066/A	harness,76-78TR7/140,cloth	EA
345-1129	harness,B32/34,Goldstar,1954-63	EA
345-1129/A	harness,B32/34,Goldstar,1954-63,cloth	EA
345-1140	plugwires,twins,long type,Champion	PR
345-1142	harness,TR7/T140,1973-75	EA
345-1142/A	harness,TR7/140,73-75,cloth	EA
345-1143	harness,main,1973 T100R *	EA
345-1143/A	harness,main,1973 T100R,cloth*	EA
345-1144	harn,main,T150,73on	EA
345-1144/A	harn,main,T150,73on,cloth	EA
345-1145	harness,69&70,T100C& TR6C	EA
345-1145/A	harness,69/70T100C&TR6C	EA
345-1146	harness,pre 1971 T150	EA
345-1146/A	harness,pre71 T150,cloth	EA
345-1147	harness,67 TR6,T120,T100	EA
345-1147/A	harness,67 TR6/100/120,cloth	EA
345-1149	harness,'66 TR6,T120&T100	EA
345-1149/A	harness,66TR6,120,100	EA
345-1151	harness,main,T20SH	EA
345-1151/A	harness,main,T20SH,cloth	EA
345-1153/B	harness,65 T90/100/120/6,cloth	EA
345-1153A	harness,65TRI Twin ex.6T	EA
345-1157	harn,pre71 Comm.w/RH points	EA
345-1157/A	harn,pre71Comm.w/RHpoints,cloth	EA
345-1158	harness,Comm.w/rearpoints	EA
345-1158/A	harness,Comm.w/rearpoints,cloth	EA
345-1159	harn,Atlas &650 w/magneto	EA
345-1159/A	harn,Atlas &650 w/mag,cloth	EA
345-1160	harn,Atlas;G15;650bat.ign	EA
345-1160/A	harn,Atlas,G15,650bat.ign,cloth	EA
345-1171	harness,Triumph T160 ES	EA
345-1171/A	harness,T160,cloth *	EA
345-1172	harn,69&70 A50/65except F	EA
345-1172/A	harn,69&70 A50/65except F,cloth*	EA
345-1173	harness,pre71 A65Firebird	EA
345-1173/A	harness,pre71 A65Firebird,cloth	EA
345-1174	harness,67 B25/B44	EA
345-1174/A	harness,67 B25/44,cloth	EA
345-1177	subharn,rear,78on TriTwin	EA
345-1180	harness,hdlt,HurricaneX75	EA

345-1180/A	harness,hdlt,HurricaneX75,cloth	EA
345-1181	harness,main,HurricaneX75	EA
345-1181/A	harness,main,HurricaneX75,cloth	EA
345-1186	harness,1979&80 T140D & E	EA
345-1186/A	harness,1979&80 T140D & E,braided	EA
345-1192	subharness,points,Triples	EA
345-1192/A	subharness,points,3cyl,extra quality	EA
345-1195	harness,main,Nort850MK3es	EA
345-1195/A	harness,main,Nort850MK3es,orig.quality	EA
345-1196	harness,hdlght,Nort.Mk3ES	EA
345-1196/A	harness,hdlght,Nort.Mk3ES,orig.quality	EA
345-1197	subharness,ign,Nort850Mk3	EA
345-1202	plugwires,twins,shortype,Champion	PR
345-1217	harness,AMC 1cyl,pre58	EA
345-1218	harn,1968&69 TriBSA 250/441SS	EA
345-1218/A	harness,68/69 TriBSA 441SS,cloth	EA
345-1233	subharn,tail,pre71A50/65/75	EA
345-1250	subharn,points,Twins,68on	EA
345-1250/A	subharn,points,twin,68on,extra quality	EA
345-1254/B	harness,57-63 T21,3TA/5TA,6T,cloth	EA
345-1254A	harness,1957-63 T21,3TA/5TA,6T	EA
345-1280	harness,6T,1966	EA
345-1280/A	harness,6T,1966,cloth	EA
345-1283	subharn,tail,73-78TriTwin	EA
345-1284	harness,main,A75,pre71	EA
345-1284/A	harness,main,A75,pre71,cloth	EA
345-1285	harness,1966 BSA Twins	EA
345-1285/A	harness,1966 BSA Twins,cloth	EA
345-1291	harness,1967 BSA Twins	EA
345-1291/A	harness,1967 BSA Twins,cloth	EA
345-1292	harness,1968 BSA Twins	EA
345-1292/A	harness,1968 BSA Twins,cloth	EA
345-1293	harness,ign,64-67 A65F&S	EA
345-1293/A	harness,ign,64-67 A65F&S	EA
345-1336	harness,1968 T100C &TR6C	EA
345-1336/A	harness,1968 T100C&TR6C,cloth	EA
345-1366	subharn,tail,63-68TriTwin	EA
345-1375	harn,main,81-82 T140ES	EA
345-1384	subharn,tail,71-TriBSA650	EA
345-1394	harness,1960-62 TR6/120 *	EA
345-1394/A	harness,1960-62 TR6/120,cloth	EA
345-1396	plugwire set,T160,resistor*	ST
345-1442	subharness,hornpush,pre61	EA
345-1443	subharness,dipswitchPre61	EA
345-1444	subharn,63-70horn/dip,Tri	EA
345-1444/A	subharn,63-70horn/dip,Tr,grey	EA
345-1446	harness,C10/C11	EA
345-1446/A	harness,C10/11,cloth	EA
345-1449	harn,dynamo/nacelle,rigid	EA
345-1449/A	harness,dynamo/nacelle,rigid,cloth	EA
345-1457	harness,68 TR25W&B44VS	EA
345-1457/A	harness,68 TR25W&B44VS,cloth	EA
345-1490	harness,5T/6T,pre59w/alt.	EA
345-1490/A	harness,5T/6T,pre59w/alt,cloth	EA
345-1498	harness,1969 TR25&B44VS	EA
345-1498/A	harness,1969 TR25&B44VS,cloth	EA
345-1499	harness,70 B44VS	EA
345-1499/A	harness,1970 B44VS,cloth	EA
345-1500	harness,1970 B25 & B44SS	EA
345-1500/A	harness,1970 B25 & B44SS,cloth	EA
345-1504	harness,Vincent "D" series	EA
345-1518	harn,main,81-83 TR7/T140	EA
345-1525	harness,main,NortSingle,1959-62	EA
345-1526	harness,1958-59 Nor88/89	EA
345-1528	harness,1962-64 Nor.SS	EA
345-1542	subharn,Ducon horn/dipsw.*	EA
345-1543	subharn,points,unitSingle	EA
345-1571	harness,pre1958 BSA A7/10	EA
345-1571/A	harness,pre58 BSA A7/10,cloth	EA
345-1597	subharn,fr.brk,Nor.850Mk3	EA
345-1598	subharness,horn,Commando	EA

345-1684	subharness, stator, 3wire	EA
345-1696	harness, TR5	EA
345-1743	subharness, dip/horn/flash	EA
345-1744	subharness, turn/kill/strt	EA
345-1751	harness, 1966 G15CSR w/magneto*	EA
345-1751/A	harness, 66 G15CSR w/mag, cloth	EA
345-1815	harness, 1962-63 BSA RGS	EA
345-1916	subharness, Tricon	EA
345-21	cable tie, nylon	EA
345-2238	harn, main, 82-83 T140	EA
345-2934	subharness, warning lites, MK3 Norton	EA
345-54937097	harness, TriTwin w/ET ign, cloth	EA
345-54952937	harness, P11&P11A	EA
345-54953440	harness, 68TriTwin w/capac	EA
345-54953455	subharness, for capacitor	EA
345-5500	wire, 16GA red, 100ft.	EA
345-5501	wire, 16GA, brown, 100ft.3	EA
345-5502	wire, 16GA blue, 100ft.	EA
345-5503	wire, 16GA, white, 100ft.	EA
345-5510	wire, 16GA, brown/green, 100ft.	EA
345-5511	wire, 16GA, brown/blue, 100ft.	EA
345-5512	wire, 16GA, black/white, 100ft.	EA
345-5513	wire, 16GA, black/yellow, 100ft.	EA
345-5514	wire, 16GA, green/white, 100ft.	EA
345-5515	wire, 165GA, green/yellow, 100ft.	EA
345-5516	wire, 16GA, brown/white, 100ft.	EA
345-5517	wire, 16GA, brown/black, 100ft.	EA
345-5518	wire, 16GA, blue/red, 100ft.	EA
345-5519	wire, 16GA, blue/white, 100ft.	EA
345-5520	wire, 16GA, black, 100ft.	EA
345-5521	wire, 16GA, red/black, 100ft.	EA
345-5522	wire, 16GA, green/black, 100ft.	EA
345-607199	lead, amp. box earth, T140E	EA
345-838591	harness, TRW w/Lucas alt, cloth	EA
391-	LUCAS ELECTRICAL PARTS	*
391-----	-----	---
391-01	tag, magneto, K2F, blk, CCW (BSA/NORTON/TRI)	EA
391-02	tag, magneto, K2FC, red CCW (Triumph)	EA
391-03	tag, magneto, K2F, black, CW (Vincent/RE)	EA
391-04	lever, console switch, red	EA
391-05	lever, console sw, black 3 pos.	EA
391-06	lever, console sw, black 2 pos.	EA
391-069225	USE 391-54068034	ea
391-069239	USE 391-54068034	ea
391-069380	USE 391-54068034	ea
391-069424	USE 391-54068034	ea
391-069428	USE 391-54068034	ea
391-069442	USE 391-54068034	ea
391-069446	USE 391-54068034	ea
391-069468	USE 391-54068034	ea
391-069469	USE 391-54068034	ea
391-069482	USE 391-54068034	ea
391-069483	USE 391-54068034	ea
391-069498	USE 391-54068034	ea
391-069508	USE 391-54068034	ea
391-07	tag, magneto, K2FC, red CW	EA
391-08	rivet, mag gear	EA
391-111704	bolt, dynamo gear	EA
391-112201	bolt, 5/16cei, early hdlght*	EA
391-112201/CHR	bolt&washer set, chrome	ST
391-112201/SS	bolt&washer set, stainless	ST
391-122160	bolt, magneto points plate	EA
391-132466	USE 82-1915	ea
391-137498	washer, plain, for 5/16bolt	EA
391-143086	washer, flat, 7/16 id	EA
391-144921	screw, 2BA, chrome, hd&taillight	EA
391-145074	USE 391-145079	ea
391-145079	screw, magneto pickup	EA
391-154660	clip, retaining, mag points	EA
391-1572289	USE 391-144921	ea
391-169194	nut, slotted, pointsplate	EA

391-170109	nut,3/8X20,dynamo gear,E3L	EA
391-173974	nut,3/8x20,drive gear,mag	EA
391-180316	nut,headlight switch	EA
391-185015	washer,brass,pickup	EA
391-188218	fuse,35amp	EA
391-188614	oilseal,dynamo	EA
391-188618	oilseal,dynamo	EA
391-188818	terminal	EA
391-189210	bearing,generator	EA
391-189244	bearing,magneto	EA
391-189284	bearing,magdyno	EA
391-189289	bearing,magdyno	EA
391-189291	bearing,magneto	EA
391-189294	bearing,magneto	EA
391-189296	USE 04-0099	ea
391-189298	USE 37-1041	ea
391-189299	USE 89-3022	ea
391-189307	bearing,ball	EA
391-189308	USE 04-0100	ea
391-189309	USE 37-0653	ea
391-189314	USE 57-0665	ea
391-1981721	USE 14-0404	ea
391-199001	grommet,wiring	EA
391-199002	grommet	EA
391-20010	USE 391-GENERATOR/1	ea
391-200188	field coil,dynamo,48watt	EA
391-200229	terminal pin,dynamo	EA
391-200290	brush set,dynamo,early	PR
391-200303	USE 391-200304	ea
391-200304	armature,dynamo,Ariel&BSA,outright	EA
391-200354	cover,dynamo end,bakelite,48W.	EA
391-20036	USE 391-GENERATOR/2	ea
391-200370	armature,gen,pre50AMCsing,outright	EA
391-200380	gasket,cork,BSA dynamo	EA
391-200431	plate,dynamo brush	EA
391-200435	band,dynamo	EA
391-200609	band,dynamo cover	EA
391-200609/A	cork,dynamo cover band	EA
391-200712	armature,dynamo,Triumph,outright	EA
391-200718	USE 391-200826	ea
391-200731	field coil,dynamo,60watt	EA
391-200737	brush set,dynamo,large	ST
391-200738	plate,dynamo brush,60Watt	EA
391-200752	armature,dynamo,lateA7/10,outright	EA
391-200754	armature,dynamo,magdyno,outright	EA
391-200802	armature,dynamo,AMC,outright	EA
391-200826	cover,dynamo end,bakelite,60W.	EA
391-200895	grommet,dynamo end cover	EA
391-200911	plate,dynamo brush	EA
391-200918	cover,dynamo end,metal	EA
391-200924	cover,dynamo end,metal	EA
391-20488	fieldcoils,Prestolite starter	PR
391-24257	switch,brakelite	EA
391-2479	bush,starter,Mk3,LH,Prestolite	EA
391-26518	starter motor,T160	EA
391-26521	starter motor,T140ES	EA
391-30447	USE 391-30707	ea
391-30552	sw,ign,4pos,4contact,bare,149SA*	EA
391-30608	switch,ignition,2pos,bare*	EA
391-30608/ER	sw,ign,2pos,bare,econo repl*	EA
391-30663	USE 391-35317	EA
391-30664	USE 391-35316	EA
391-30702	switch,neutral	EA
391-30707	switch console,LH,75-78Tr,repl*	EA
391-30707/A	switch console,bottom half only	EA
391-30709	USE 391-30781	ea
391-30723	switch console,RH T160V,169SA	EA
391-30781	sw.console,RH,76-78 style,repl*	EA
391-30825	switch body,ign,Mk3 lights on	EA
391-31071	switch,cutout,bare,SS5	EA
391-31220	USE 391-31482	ea

391-31276	USE 391-31356	ea
391-31281	USE 391-34755	ea
391-31315	switch,lighting	EA
391-31315/ER	switch,lighting,econo repl*	EA
391-31340	USE 391-31315	ea
391-31356	switch,headlight,rotary	EA
391-31371	switch,lighting,3 pos.	EA
391-31383	switch,brake*	EA
391-31405	switch,dip,1954-55	EA
391-31437	USE 391-54033234	ea
391-31443	switch,ign.&lighting,PRS8*	EA
391-31443/ER	switch,ign.&lighting,PRS8,repl.	EA
391-31445	USE 391-54033234	ea
391-31482	switch,dip,repl.	EA
391-31549	USE 391-31563	ea
391-31563	switch,horn/dip,repl,w/wires	EA
391-31563/ER	switch,horn/dip,econo rep *	EA
391-31563/ER/A	switch,horn/dip,clamp on,econo	EA
391-315738	spring,brake switch	EA
391-31620	switch,dip,hdlt.mounted *	EA
391-31684	switch,headlight	EA
391-31743	switch,toggle	EA
391-31754	USE 391-31763	ea
391-31763	switch,lighting	EA
391-31780	switch,hdlt,toggle,2 pos.	EA
391-31784	switch,hdlt,60-62,alt/mag,SA41,repl.	EA
391-31788	switch,hdlt,toggle,3 pos,5terminal	EA
391-31788/ER	switch,hdlt,toggle,3pos,econo repl.	EA
391-31827	switch,brake,lever type	EA
391-31828	light switch,toggle,2 pos	EA
391-318323	grommet,key	EA
391-318341	key,early ignition switch	EA
391-318343	bezel,switch,for 31443sw.	EA
391-318346	knob,switch,PRS8	EA
391-31886	USE 391-30608	ea
391-31889	USE 391-30552	ea
391-318942	USE 391-318343	ea
391-31899	USE 391-30608	ea
391-33018	USE 391-37144	ea
391-33053	USE 391-37144	ea
391-33188	relay,dual horns*	EA
391-33213	relay,dual horns,6RA*	EA
391-332529	washer,concave,switch knob*	EA
391-33302	USE 391-33213	ea
391-33336	USE 391-33356	ea
391-33356	relay,starter,Tri.T160V	EA
391-33708	USE 391-35316	EA
391-33709	USE 391-35318	EA
391-33906	USE 391-30702	ea
391-34055	switch,light,rotary,PLC6,repl.	EA
391-34057	switch,light,rotary,PLC6,repl.	EA
391-34080	switch,ignition & lights	EA
391-34093	switch,ignition	EA
391-34257	switch,brake	EA
391-34287	USE 391-34427	ea
391-34289	switch,lighting,88SA,repl.*	EA
391-34419	switch,hdlt,toggle,3 pos,8terminal	EA
391-34427	switch,ignition,88SA,w.key,repl.	EA
391-34448	switch,brake,pre71 A50/65	EA
391-344715	key,ignition switch	EA
391-34619	switch,brake,hydraulic	EA
391-34619/ER	switch,hydraulic brake,econo repl.	EA
391-34660	light switch,toggle,2 pos*	EA
391-34755	switch,brake	EA
391-34815	switch,brake,Lucas*	EA
391-34815/ER	switch,brake,economy repl	EA
391-35048	flasher unit,12Volt,LUCAS*	EA
391-35048/ER	flasher unit,signals,econo repl	EA
391-351551	USE 391-31315	ea
391-351567	knob,lever type,light sw.	EA
391-351803	bezel,switch,for PRS8 sw.	EA

391-351815	knob	EA
391-35316	switch console,LHlate,w/lever, repl,187SA	EA
391-35317	switch,console,RH elec.st	EA
391-35318	switch,console,RHlatekick	EA
391-35318/A	switch,bot,RHlatekick	EA
391-35351	sw,ign,4pos,4contact,late *	EA
391-35601	switch,cutout,bare,SS-5	EA
391-35710	USE 391-31788	ea
391-35835	switch,cutout,bare, repl.151SA	EA
391-35835/A	sw.assy,cutout,compl, repl.	EA
391-35953	USE 391-39595	ea
391-36000	USE 391-36129 *	ea
391-36047	ammeter,small,black face	EA
391-36082	USE 391-36184	ea
391-36084	ammeter,small, Lucas,8amp,black	EA
391-36084/A	ammeter, rep.8amp,blk.	EA
391-36084/ER	ammeter,econ.rep.8amp,blk.	EA
391-36084/ER/A	ammeter,econ.rep.8amp,wht.	EA
391-36085	USE 391-36184	ea
391-36129	ammeter,large,black face,BM4	EA
391-36129/ER	ammeter,lg,blackface,8amp, repl.	EA
391-36129/ER/A	ammeter,lg,whiteface,8amp, repl.	EA
391-36129/ER/B	ammeter,lg,blackface,12amp, repl.	EA
391-36129/ER/C	ammeter,lg,whiteface,12amp, repl.	EA
391-36184	ammeter,sm,w/warn.bulb,8A	EA
391-36189	USE 391-36129	ea
391-36204	USE 391-36184	ea
391-36220	USE 391-36184	ea
391-36296	USE 391-36403	ea
391-364027	USE 391-36184	ea
391-36403	ammeter,small, Lucas 12amp,blk,2AR*	EA
391-36403/A	ammeter, rep.12amp,blk, shielded needle	EA
391-36403/ER	ammeter,econ.rep.12amp,blk.	EA
391-36403/ER/A	ammeter,econ.rep.12amp,wht.	EA
391-364045	USE 391-36184	ea
391-364061	USE 391-36184	ea
391-36421	USE 391-36403	ea
391-364306	USE 391-36184	ea
391-364310	USE 391-36184	ea
391-364455	USE 391-36403	ea
391-364456	USE 391-36184	ea
391-369075	USE 391-36129 *	ea
391-369076	USE 391-36129 *	ea
391-36956	oilseal,starter,Mk3 Norton	EA
391-37097	USE 391-37144	ea
391-37127	regulator, RB107, tab mount	EA
391-37144	regulator, MCR2, 6V dynamo	EA
391-37144/ER	regulator, 6V,econo repl.	EA
391-37151	USE 391-37144	ea
391-37221	regulator, RB108, rubber mt	EA
391-37223	USE 391-37144	ea
391-37224	USE 391-37144	ea
391-37225	regulator, RB108, tab mount	EA
391-37228	USE 391-37221	ea
391-37232	USE 391-37221	ea
391-37252	USE 391-37225	ea
391-37288	USE 391-37221	ea
391-380056	USE 391-31405	ea
391-380459	pad,rubber, for 31563 sw.	EA
391-380521	USE 391-31482	ea
391-380660	cover,bare, for 31563 sw.	EA
391-38189	lense,warning, red, jewel, repl	EA
391-38189/A	light assy,warning, red,econo	EA
391-38189/ER	lense,warning, red, repl,econo	EA
391-38191	lense,warning, green jewel, repl	EA
391-38191/ER	lense,warning, green,econo repl.	EA
391-38192	lense,warning, amber jewel, repl	EA
391-38706	relay,warning light,Nort.	EA
391-38706/A	relay,warning light,Nort,solid state	EA
391-38717	USE 391-38706	ea
391-390398	USE 391-37144	ea

391-390409	USE 391-37144	ea
391-390704	USE 391-37144	ea
391-390706	USE 391-37144	ea
391-39184	USE 391-30702	ea
391-39565	USE 391-30552	ea
391-39593	USE 391-39595	ea
391-39595	switch console assy,compl,horn/dip*	EA
391-39596	switch console assy,comp,turn/kill*	EA
391-39756	USE 391-39596	ea
391-39757	USE 391-54033666,bracket,& screws*	ea
391-39784	USE 391-30552	ea
391-39949	USE 391-39595	ea
391-39951	switch,console,turnsignal	EA
391-400001	base,distributor	EA
391-400051	rotor,distr,Tri.TRW SV500	EA
391-400052	rotor,distributor,early	EA
391-400135	distributor cap,Ariel Sq4	EA
391-400136	distributor cap,earlyTwin,DKX2A	EA
391-400308	USE 391-60410173	ea
391-400415	points,distr,early,UK repl.	EA
391-400415/ER	points,distr,early,econo.	EA
391-402101	cover,distributor,DKX1	EA
391-404435	brush,distributor cap	EA
391-405588	collar,distr.shaft	EA
391-407050	points,BSA C11 &late Bantam	EA
391-410600	nut,plugwire,plastic	EA
391-418114	condensor	EA
391-4188511	battery carrier,univ.6 V.	EA
391-420196	points	EA
391-420301	USE 391-423871	ea
391-420302	USE 391-423871	ea
391-421106	points,C15 distr,etc.	EA
391-421106/ER	points,distr,econo.repl.	EA
391-421327	USE 391-425377	ea
391-421748	USE 391-54410823	ea
391-421863	terminal,plugwire to coil,univ	EA
391-423113	baseplate,distributor	EA
391-423153	points,3CA type	EA
391-423486	rotor,distributor,late	EA
391-423871	condensor	EA
391-424151	cover,distributor,18D1	EA
391-424158	clip,distributor cap	EA
391-425049	distributor cap,late,tall(18D2)	EA
391-425049/ER	distributor cap,late,econo	EA
391-425219	points,distributor,late	EA
391-425370	pointplate,4CA type,bare	EA
391-425377	condensor	EA
391-425377/ER	condensor,econo repl*	EA
391-425379	pointplate assy,4CA,compl,econo.repl.	EA
391-43027	USE 391-54400766	ea
391-43029	USE 391-54400766	ea
391-45036	USE 391-45275	ea
391-45077	USE 391-45152	ea
391-45110	coil,ign,12V LUCAS,lg.dia.MA12	EA
391-45112	coil,ET ignition,early type,2ET*	EA
391-45124	USE 391-45152	ea
391-451260	brush,magneto pickup	EA
391-451323	brush,ground,magdyno	EA
391-451378	insul cup,magneto	EA
391-451379	insul cup,magneto,small	EA
391-45149	coil,ET ignition	EA
391-45149/ER	coil,ET ignition,econo repl. *	EA
391-45150	USE 391-45149	ea
391-45152	coil,ign,6V LUCAS,lg.dia.MA6	EA
391-45164	USE 391-45110	ea
391-45220	USE 391-45275	ea
391-45222	USE 391-45275	ea
391-45223	USE 391-45276	ea
391-45275	coil,ignition,6 voltLucas	EA
391-45275/A	coil,ign,6Volt German PVL	EA
391-45275/B	coil,ign,6Volt,replacement	EA

391-45275/ER	coil,ign,6Volt,econo repl*	EA
391-45276	coil,ignition,12VoltLucas	EA
391-45276/A	coil,ign,12Volt GermanPVL	EA
391-45276/B	coil,ign,12Volt,replacement	EA
391-45276/ER	coil,ign,12Volt econo rep*	EA
391-452907	shim,mag end cover,.005	EA
391-454475	grommet,magneto cable	EA
391-454495	gear,dynamo,22T*	EA
391-454496	slip ring,K1F magneto&magdyno	EA
391-455190	brush,ground,magneto	EA
391-455191	brush&holder,magneto grnd	ST
391-455361	slip ring,K2F magneto	EA
391-455622	gasket,mag pickup	EA
391-456794	pickup,N1 magneto	EA
391-456817	condensor	EA
391-457810	cover,rubber,mag.pickup,K1FC	EA
391-458053	points,SR mag,ccw,Match.	EA
391-458339	condensor,magneto*	EA
391-458346	gasket,clip on mag pickup	EA
391-458356	shim,mag end cover,.005	EA
391-458361	armature,K1F mag,exchange *	EA
391-458367	pickup,K2F mag,clipon,RH *	EA
391-458368	pickup,K2F mag,clipon,LH *	EA
391-458375	oilseal,magneto,1.250" OD	EA
391-458389	USE 391-458389/A	ea
391-458389/A	camring,auto&manual adv,K2F*	EA
391-458613	clip&pin,mag cap	EA
391-458619	cover,clipon bakelite,K2F mag*	EA
391-458658	grommet,magneto pickup*	EA
391-458725	USE 391-458389/A	ea
391-458865	USE 391-459190	ea
391-458866	USE 391-459190	ea
391-458876	pickup,K2FCmag,screwinL&R	EA
391-459002	oilseal,K2F magneto,1.445" OD	EA
391-459004	armature,K2F mag,exchange *	EA
391-459005	insul cup,K2F magneto,lg.	EA
391-459031	oilseal,K1F magneto,1.250"OD	EA
391-459033	oilseal,magneto,1.250" OD	EA
391-459190	pickup,K2F mag,clipon L&R	EA
391-459199	cover assy,mag,screwon,vented	EA
391-459269	cover assy,screwon,K2F mag.	EA
391-459271	cover,end,K2F>manual adv.	EA
391-459376	USE 391-459004	ea
391-460051	pointsplate assy,magdyno,repl.	EA
391-460055	bush,magdyno retaining strap	EA
391-460056	strap,magdyno	EA
391-460061	cover,points,magdyno	EA
391-460380	brush & holder assy,grnd,magdyno	EA
391-463066	pickup assy,Magdyno	EA
391-463109	gear,dynamo,fibre,58tooth	EA
391-463932	insul cup,K2F magneto,med	EA
391-464092	tappet,magneto,N14,ETC.	EA
391-464140	condensor,magdyno,early	EA
391-464205	armature,M01 magdyno,exch *	EA
391-465817	condensor	EA
391-465909	nut,rotor	EA
391-465915	USE 391-47105	ea
391-465969	rotor,RM14 alt,3.250"od	EA
391-465998	stator,RM14	EA
391-466125	rotor,alternator,2.75"od	EA
391-466168	USE 391-465998	ea
391-468678	USE 391-47105	ea
391-469427	USE 391-47127	ea
391-470534	pointplate assy,K2F,early*	EA
391-470537	brush & spring,magneto	EA
391-470608	points,magneto,cw *	EA
391-470608/9	points,magneto,cw/ccw *	EA
391-470609	points,K2F magneto,early,ccw*	EA
391-47078	USE 391-49072	ea
391-470877	USE 391-470609	ea
391-47097	USE 391-49072	ea

391-47103	USE 391-49072 *	ea
391-47105	stator, RM13 alt, 3 wire	EA
391-47111	USE 391-49072	ea
391-47122	USE 391-47127	ea
391-47124	USE 391-47105	ea
391-47127	stator, RM15 alt, 3 wire	EA
391-47128	USE 391-49072	ea
391-47132	USE 391-49072	ea
391-47134	USE 391-47105	ea
391-47135	USE 391-47127	ea
391-47142	USE 391-49072	ea
391-47153	USE 391-47105	ea
391-47154	USE 391-47127	ea
391-47161	USE 391-47204	ea
391-47162	USE 391-47204	ea
391-47164	USE 391-47204	ea
391-47168	USE 391-47105	ea
391-47171	USE 391-47105	ea
391-47173	USE 391-47197	ea
391-47178	USE 391-47105	ea
391-47181	USE 391-47204	ea
391-47183	USE 391-47204	ea
391-47188	USE 391-47197	ea
391-47190	ballast resistor, Tri. T160	EA
391-47194	stator, sing. phase, 180Watt, 3wire*	EA
391-47197	stator, 5 wire, RM19, for ET ign.	EA
391-47204	stator, 3 wire, RM19, 120 Watt*	EA
391-47204/ER	stator, 3 wire, RM19, 120Watt, econo. repl.	EA
391-47205	stator, 2 wire, RM21, std. 120Watt	EA
391-47205/ER	stator, 2 wire, upgraded econo repl.	EA
391-47209	stator, RM20, early Triples	EA
391-47225	ballast resistor, 7lon Nor	EA
391-47230	USE 391-47205 ?	ea
391-47239	stator, sing. phase, 180Watt, 2 wire*	EA
391-47239/ER	stator, sing. phase, 180Watt, econo. repl.	EA
391-47244	stator, 3Phase, 180 Watt	EA
391-47244/ER	stator, 3Phase, 215 Watt, repl.	EA
391-47252	stator, 3ph, '79&80 Tri ks	EA
391-47266	zener diode pack, 1981 on*	EA
391-47270	amplifier, Rita ign, AB11, for 6V coils	EA
391-47502	auto advance, magneto, Tri.	EA
391-47502/A	gear, fibre, advance, Tri.*	EA
391-47502/B	gear, alloy, advance, Tri.*	EA
391-47503	autoadvance, mag, BSA twin	EA
391-47503/A	gear, alloy, advance, BSA*	EA
391-47503/B	gear, fibre, advance, BSA	EA
391-47508	autoadvance, magneto, Nort.	EA
391-47638	USE separate components	ea
391-48016	amplifier, Rita ign, AB5	EA
391-48022	USE 391-47270	ea
391-484098	points, magdyno	EA
391-484098/ER	points, magdyno, econo repl.	EA
391-49072	rectifier, Lucas, pos. grnd, UK	EA
391-49072/ER	rectifier, economy replace	EA
391-49181	rectifier, Norton 850 Mk3	EA
391-492854	pointplate assy, K1/2F, late, CCW	EA
391-492856	bolt, pointsplate, K1/2F mag, late	EA
391-492979	rotor arm, mag, SR2, cw	EA
391-49345	zener diode, pos. grnd, genuine*	EA
391-49345/ER	zener diode, economy repl.	EA
391-49589	zener diode, -grnd79&80Tri	EA
391-498131	washer, U, mag auto advance	EA
391-498157	springs, advance unit, mag.	EA
391-498339	washer, cupped, autoadvance	EA
391-504665	wire clip, headlight rim	EA
391-504665/ER	wire clip, headlight rim, econo, 10PK	PK
391-507079	USE 391-575189	ea
391-507586	USE 391-515140/A (assy)	ea
391-508247	reflector, hdlt	EA
391-509482	rim, headlight, 6", repl.	EA
391-509484	rim w/lense, 6", MU42*	EA

391-509484/A	light unit,6",repl.	EA
391-509487	USE 391-509484	ea
391-51211859	USE 345-1375	ea
391-51271406	bulbholder,instr,latetype,plastic	EA
391-515140	USE 391-515140/A	ea
391-515140/A	light unit,7-1/2",replacement	EA
391-515172	USE 391-516242	ea
391-516173	USE 391-515140/A (assy)	ea
391-516242	rim,headlight,7-1/2",repl.	EA
391-516386	lens,pilot lamp	EA
391-516524/ER	panel assy,w/sw&ammeter,hdlt,econo	EA
391-516723	rim,headlight,5-3/4",Cub	EA
391-516798	light unit,7 inch,w/Lucas name,BPF	EA
391-516798/A	light unit for halogen bulb,7",pilot	EA
391-516798/B	light unit w/halogen bulb,7",econo	EA
391-516798/C	light unit w/halogen bulb,for pilot,econo	EA
391-516798/D	light unit for halogen bulb,7",econo	EA
391-516798/ER	light unit,7" econo repl,BPF	EA
391-516801	USE 391-516798	ea
391-516812	USE 391-516798	ea
391-516828	USE 391-54525272	ea
391-52184	lamp assy,pilot,nacelle,repl.	EA
391-52184/ER	light assy,parking,nacelle,repl.	EA
391-523986	oring,ammeter,small	EA
391-526001	USE 391-53140/ER *	ea
391-526082	USE 391-53140/ER *	ea
391-526404	lens,tailamp,type L529	EA
391-53009	USE 391-53140/ER *	ea
391-53056	USE 391-53140/ER	ea
391-53065	USE 391-53140/ER *	ea
391-53090	USE 391-53140/ER	ea
391-53122	USE 391-53140/ER *	ea
391-53140/ER	tailite assy,early rnd,#480	EA
391-53182	USE 391-53140/ER *	ea
391-53216	USE 391-53140/ER *	ea
391-53394	USE 391-53454	ea
391-534296	retaining plate,hdlt.rim*	EA
391-534296/A	retaining plate,hdlt.rim,w/screw	ST
391-534296/A/ER	retaining plate,hdlt.rim,w/screw,econo	ST
391-53432	USE 391-53454	ea
391-534343	rim,headlight,5-3/4 inch,British	EA
391-534343/ER	rim,headlight,5-3/4",repl. *	EA
391-53454	taillight assy,rectangular,L564	EA
391-53454/ER	taillight assy,rect,econo*	EA
391-53973	taillight assy,bullet,Luc.,L679*	EA
391-53973/ER	taillight assy,bullet,econo	EA
391-54027029	USE 335-02	ea
391-54029292	USE 335-04	ea
391-54033056	USE 391-34427	ea
391-54033190	USE 391-34289	ea
391-54033234	switch,brake	EA
391-54033234/ER	switch,brake,econo *	EA
391-54033666	switch,console,horn/dip,169SA*	EA
391-54033667	switch,console,turnsignal,169SA*	EA
391-54033722	USE 391-54033751	ea
391-54033751	switch,console,RH73&74Tr,169SA,2POS*	EA
391-54047722	USE 391-56605	ea
391-54048008	USE 391-49072	ea
391-54048017	USE 391-49181	ea
391-54048288	USE 391-49345	ea
391-54048370	USE 391-83589 (pair)	ea
391-54048381	USE 391-83539	ea
391-54051498	USE 345-1186	ea
391-54057552	USE 391-56605	ea
391-54057553	USE 391-56605	ea
391-54057566	USE 391-56605	ea
391-54057567	USE 391-56605/A	ea
391-54057722	USE 391-56605	ea
391-54068034	horn,Altette,6V,HF1234,repl.	EA
391-54068034/ER	horn,Altette,econo repl.	EA
391-54068036	USE 391-540368034	ea

391-54068152	USE 391-69219	ea
391-54068189	USE 391-69219	ea
391-54094162	USE 345-1254A	ea
391-54094328	USE 345-1254A	ea
391-54094333	USE 345-1254A	ea
391-54094407	USE 345-1254A	ea
391-54094431	USE 345-1254A	ea
391-54115106	bolt,headlight,7/16x20UNF	EA
391-54115106/CHR	bolt,7/16x20UNF,hdlt,chrome,domed	EA
391-54115106/SS	bolts & washers,7/16x20UNF,hdlt,stainles	ST
391-54115246	screw	EA
391-54120019	screw,self tapping	EA
391-54123401	screw	EA
391-54130041	nut,switch	EA
391-54140331	washer,rubber,warninglite	EA
391-54170009	capacitor,bat.eliminator	EA
391-54170009/ER	capacitor,bat.elim,econo*	EA
391-54190042	terminal sleeve,1/4,Lucar	EA
391-54190043	terminal sleeve,3/8 Lucar*	EA
391-54190096	connector,1/4"Lucar,male,single	EA
391-54190387	USE 391-54938986	ea
391-54201143	USE 391-60600684	ea
391-54201147	USE 391-60600684	ea
391-54202275	USE 391-60600684	ea
391-54202298	USE 391-60600684	ea
391-54202299	USE 391-60600684	ea
391-54210937	USE 391-60600684	ea
391-54212006	USE 391-60600684	ea
391-54213901	USE 391-60600684	ea
391-54213902	USE 391-60600684 &71-4435	EA
391-54213903	USE 391-60600684	ea
391-54215824	USE 391-60600684	ea
391-54315070	USE 39154335169	ea
391-54316731	USE 391-54335169	ea
391-5431899	USE 391-35351	ea
391-54330485	USE 391-54330934	ea
391-54330576	bezel,switch	EA
391-54330934	knob,switch,for Lucas sw.only	EA
391-54330934/A	screw,switch knob	EA
391-54330934/ER	knob,sw,for repl.sw.only	EA
391-54331482	USE 391-54330934 *	ea
391-54335169	lock & keys,ignition sw.	EA
391-54335169/A	keyblank,ignition,FS type	EA
391-54335169/ER	lock & keys,ignition sw,econo.repl*	EA
391-54335172	USE 391-54335169	ea
391-54335174	USE 391-54335169	ea
391-54336176	key,ignition,old type	EA
391-54336178	knob,switch	EA
391-54340881	USE 391-54343791 *	ea
391-54340882	USE 391-54343791	ea
391-54340883	USE 391-54343791	ea
391-54343791	bracket,control lever,cl*	EA
391-54343792	bracket,control lever,brake*	EA
391-54361250	lense,warning,blue jewel	EA
391-54361250/A	light assy,warning,blue,econo	EA
391-54361250/ER	lense,warning,blue,econo	EA
391-54362071	USE 523-18053	ea
391-54363453	lense,warning,amber flat,repl	EA
391-54363453/A	light assy,warning,amber,econo	EA
391-54363453/ER	lense,warning,amber,econo	EA
391-54363454	lense,warning,red,flat,repl	EA
391-54363455	lense,warning,green,flat,repl	EA
391-54363455/ER	lense,warning,green,econo	EA
391-54363522	USE 391-38189	ea
391-54363522/A	USE 391-38189	ea
391-54363522/ER	USE 391-38189	ea
391-54364380	bulbholder,warning light	EA
391-54364382	USE 391-54959626	ea
391-54384768	USE 391-54385091	ea
391-54385091	clip,flasher unit	EA
391-54385768	USE 391-54385091	ea

Aug 01 02

391-54386637	spring, flasher unit	EA
391-54400766	pickup assy, Rita ignition *	EA
391-54400905	reluctor, Rita ignition *	EA
391-54410823	condensor, distributor, replacement	EA
391-54411664	bracket, coil, 1-7/8"	EA
391-54411736	clip, spring	EA
391-54411737	distributor cover, Cub, etc.	EA
391-54412018	USE 391-54417992	ea
391-54412229	USE 391-54415642	ea
391-54412731	USE 391-54417992	ea
391-54412732	USE 391-54417992	ea
391-54413020	USE 391-54417992	ea
391-54415296	USE 391-425379 *	ea
391-54415638	USE 391-54417992	ea
391-54415640	USE 391-54417992	ea
391-54415641	USE 391-54417992	ea
391-54415642	springs, advance unit	PR
391-54415746	advance unit, c.wise, 5deg.	EA
391-54415750	USE 391-54425657	ea
391-54415803	points, 4CA, Lucas	EA
391-54415803/ER	points, 4CA, economy repl.	EA
391-54415803/ER/A	points, pr, incl. plate, econ	ST
391-54416150	advance unit, ccw, 5 degree	EA
391-54416405	advance unit, ccw, 10degree	EA
391-54417989	USE 391-54418404	ea
391-54417992	springs, adv. unit, strong	PR
391-54418404	advance unit, ccw, 5 degree	EA
391-54418526	bracket, condensor pack	EA
391-54418527	USE 391-54420128	ea
391-54418528	cover, rubber, condensor pk, repl.	EA
391-54419097	USE 391-54425160	ea
391-54419220	adjuster, eccentric, points	EA
391-54419254	advance unit, clockwise	EA
391-54419327	pointplate assy, 7CA, 3cyl.	EA
391-54419338	USE 391-54425657	ea
391-54419340	USE 391-54425657	ea
391-54419344	USE 391-54426429	ea
391-54419645	USE 391-54424425	ea
391-54419653	USE 391-54427182	ea
391-54419827	points, 6CA, Lucas	EA
391-54419827/A	points, 6CA, UK repl.	EA
391-54419827/ER	points, 6CA, economy repl.	EA
391-54419828	points, 7CA, 3 cyl, Lucas UK	EA
391-54419828/ER	points, 7CA, 3cyl, econo rep	EA
391-54419867	advance unit, cw, 3 cyl.	EA
391-54419899	USE 391-54415642	ea
391-54419974	clamp, ignition coil, small, repl *	EA
391-54419974/SS	clamp, ign. coil, small, stainless	EA
391-54420128	condensor, British	EA
391-54420128/ER	condensor, economy repl*	EA
391-54420472	USE 391-54419254	ea
391-54424425	points plate, 6CA, 68on1cyl	EA
391-54425160	pointplate, 10CA, 2 cyl, repl.*	EA
391-54425656	USE 391-54426429	ea
391-54425657	advance unit, cw, Tri.type*	EA
391-54426429	advance unit, ccw, Nort&BSA*	EA
391-54427182	advance unit, ccw12dg, 1cyl	EA
391-54440029	cam, advance unit, ccw	EA
391-54440887	points, mag, K2F, late, cw, UK repl.	EA
391-54440888	points, K2Fmag, late, ccw *	EA
391-54440888/ER	points, K2F mag, late, CCW, repl*	EA
391-54441582	USE 391-60410181	ea
391-54483155	spring, capacitor mounting *	EA
391-54483156	spring, capacitor mounting	EA
391-54520452	USE 391-54525272	ea
391-54520540	USE 391-554602	ea
391-54524048	rubber, rear, flatback hdlt	EA
391-54524099	USE 323-69/A	ea
391-54524526	USE 391-54525272	ea
391-54525212	shield, rubber, warn. light	EA
391-54525272	light unit, 5-3/4", Lucas	EA

391-54525272/A	light unit for halogen bulb,5-3/4"	EA
391-54525272/B	sealed beam,5-3/4",12Volt	EA
391-54525272/C	sealed beam,5-3/4",6 Volt	EA
391-54525272/ER	light unit,5-3/4"econo.repl,BPF*	EA
391-54525286	USE 391-54578213	ea
391-54525403	USE 83-2216	ea
391-54525927	USE 391-516798	ea
391-54531899	USE 391-30552 *	ea
391-54570242	rubber backing,57162 reflector,w/hole	EA
391-54571677	base,rub,bullet taillight	EA
391-54572932	USE 391-54577109	ea
391-54573590	bulbholder,pilot,bare	EA
391-54576001	lens,tailite,early,L564*	EA
391-54576001/ER	lense,rect.taillight,econo	EA
391-54577109	lens,bullet tailite,Luc.L679	EA
391-54577109/ER	lense,bullet tailite,econ	EA
391-54578212	base,tailite	EA
391-54578213	bulbholder,taillight	EA
391-54580322	bulbholder,signals	EA
391-54581638	USE 391-60600621	ea
391-54584930	lense,sq.tailite,late,LucL917,w.refl.	EA
391-54584930/ER	lens,sq.tailite,late,econ,L917	EA
391-54584931	USE 391-56513 (assy)	ea
391-54585200	lens,signal,red	EA
391-54585314	lense,sq.tailite,late,LucL917,no.refl.	EA
391-54683762	bracket,horn,6H	EA
391-54930000	USE 345-1027	ea
391-54930007	socket,light switch,9wire	EA
391-54930007/ER	socket,light switch,9wire,rubber	EA
391-54930008	socket,ign.switch,7 wire	EA
391-54930008/ER	socket,ign.switch,7 wire,rubber	EA
391-54931221	USE 345-1394	ea
391-54932248	USE 345-1528	ea
391-54933228	USE 345-1250	ea
391-54934657	USE 345-1023A	ea
391-54934952	USE 345-1293	ea
391-54935175	USE 345-1159	ea
391-54936415	USE 345-1153A	ea
391-54938941	USE 345-1149	ea
391-54938942	USE 345-1280	ea
391-54938986	fuseholder assy,complete	EA
391-54938986/ER	fuseholder assy,econo rep	EA
391-54939169	USE 345-1192	ea
391-54939347	USE 345-1285	ea
391-54939968	USE 345-1159	ea
391-54941009	USE 345-1444	ea
391-54942078	USE 391-54960661	ea
391-54942079	terminal,3/8"Lucar,female	EA
391-54944995	USE 345-1027	ea
391-54945043	USE 391-54364380	ea
391-54949011	boot,rubber,straight,coil end,univ.repl.	EA
391-54949773	USE 345-1002	ea
391-54950449	USE 345-1147	ea
391-54950625	USE 345-1291	ea
391-54952711	USE 345-1160	ea
391-54952732	USE 345-1174	ea
391-54952857	USE 345-1250	ea
391-54953385	USE 345-1292	ea
391-54953386	USE 345-1233	ea
391-54953387	bulbholder assy,dual*	EA
391-54953389	bulb holder w/single wire	EA
391-54953442	USE 345-1173	ea
391-54953443	USE 345-1055	ea
391-54953444	USE 345-1233	EA
391-54953459	USE 345-1218	ea
391-54953550	USE 345-1457	ea
391-54953628	boot,rubber	EA
391-54954246	USE 345-1146	ea
391-54954277	USE 345-1158	ea
391-54954279	terminal,3/16"Lucar,female	EA
391-54955256	USE 345-1061	ea

391-54955257	USE 345-1061	ea
391-54955258	USE 345-1172	ea
391-54955270	USE 345-1218	ea
391-54955718	USE 345-1498*	ea
391-54955719	USE 345-1145	ea
391-54955720	USE 345-1173	ea
391-54955732	USE 345-1146	ea
391-54955800	USE 345-1284	ea
391-54956250	USE 345-1157	ea
391-54956251	USE 345-1250	ea
391-54957095	USE 345-1061	ea
391-54957096	USE 345-1145	ea
391-54957239	USE 345-1500	ea
391-54957308	USE 345-1499	ea
391-54959401	USE 391-54190042	ea
391-54959480	USE 345-1017	ea
391-54959531	USE 345-1008	ea
391-54959532	USE 345-1016	ea
391-54959535	USE 345-1014	ea
391-54959625	USE 391-54364380	ea
391-54959626	bulbholder,instr/pilot,metal**	EA
391-54959628	USE 345-1007	ea
391-54959629	USE 345-1015	ea
391-54959633	USE 345-1010	ea
391-54959638	USE 345-1013	ea
391-54959643	USE 345-1009	ea
391-54959646	USE 345-1013	ea
391-54960661	terminal,1/4"Lucar,female	EA
391-54960707	USE 345-1180	ea
391-54960708	USE 345-1181	ea
391-54960710	USE 345-1015	ea
391-54960711	USE 345-1014	ea
391-54960712	USE 345-1011	ea
391-54960714	USE 345-1007	ea
391-54960715	USE 345-1013	ea
391-54960717	USE 345-1012	ea
391-54960723	USE 345-1009	ea
391-54960724	USE 345-1010	ea
391-54961586	USE 345-1009	ea
391-54961593	USE 345-1142	ea
391-54961594	USE 345-1143	ea
391-54961595	USE 345-1144	ea
391-54961681	USE 391-54364380	ea
391-54962252	USE 345-1171	ea
391-54962258	USE 345-1066	ea
391-54962265	USE 345-1010	ea
391-54965505	USE 345-1518	ea
391-551371	USE 391-516242	ea
391-551674	USE 391-515140/A (assy)	ea
391-552928	screw,tailamp	EA
391-553248	rim,hdlt,7",British made	EA
391-553248/ER	headlight rim,7" econo repl.	EA
391-553267	hdlt rim,inner nacelle	EA
391-553267/ER	hdlt rim,inner nacelle,econo	EA
391-553738	adaptor,hdlt.bulb,late	EA
391-553738/ER	adaptor,hdlt.bulb,lt,econ	EA
391-553925	light unit,7",no pilot lamp	EA
391-554354	washer,rubber	EA
391-554602	bulbholder,hdlt,early	EA
391-554602/ER	bulbholder,headlight,econ	EA
391-554710	bulbholder,pilot light,repl.	EA
391-554710/ER	bulbholder,pilot & instr,econo*	EA
391-554734	USE 391-54959626	ea
391-554983	screw,chrome	EA
391-555275	USE 391-516798	ea
391-555309	USE 391-516798	ea
391-555910	terminal	EA
391-56147	turn signal,no stem,LucasL874	EA
391-562303	bulbholder,hdlt,early	EA
391-56513	taillight,square,late,Luc.L917,w/reflect.	EA
391-56513/ER	taillight,square,late,econ,L917	EA

391-56515	taillight, square, late, Luc.L917, no/reflect	EA
391-56605	turn sig.assy, short, LucasL874	EA
391-56605/A	turnsignal assy, long, LucasL874	EA
391-56605/ER	turnsignal assy, short, econo	EA
391-56605/ER/A	turnsignal assy, long, econo	EA
391-57079	USE 391-575189	ea
391-57110	USE 391-57124	ea
391-57111	reflector, teardrop, LUCAS, RER24	EA
391-57111/ER	reflector, teardrop, repl.	EA
391-57124	reflector, round, red, bolton type, RER25*	EA
391-57160	reflector assy, rect, repl*	EA
391-57161	reflector, round, amber, pushin, RER25*	EA
391-57161/RUBBER	rubber cup, orig.type, 57161reflector	EA
391-57162	reflector, round, amber, bolton type, RER25*	EA
391-57173	USE 391-57162 & 82-8271	ea
391-57183	reflector, round, amber	EA
391-57183/ER	reflector, round, amber, econo	EA
391-572289	USE 391-144921	ea
391-573819	lense, rect.tailite#L525	EA
391-573839	USE 391-54576001	ea
391-575189	reflector, round, red, RER14	EA
391-575189/ER	reflector, round, red, econo	EA
391-575200	USE 391-54576001	ea
391-575219	nut, sleeve, early tailite	EA
391-575219/A	kit, mtng, gen.L564 lense to/ER light	ST
391-57610	USE 391-57160	ea
391-59882	USE 323-66	ea
391-59892	USE 323-69	ea
391-60260	USE 323-69	ea
391-60280	USE 323-66	ea
391-60410173	condensor, distributor	EA
391-60410181	condensor, Lucas	EA
391-60410181/ER	condensor, economy repl.	EA
391-60600091	stanchion, signal, 5-1/2", no flats	EA
391-60600092	stanchion, signal, 4", no flats*	EA
391-60600269	stanchion, signal, 2-1/2", no flats	EA
391-60600271	points, 10CA, Lucas*	EA
391-60600271/ER	points, 10CA, economy repl*	EA
391-60600312	USE 391-60600320	ea
391-60600320	stanchion, signal, 3-3/4", flats	EA
391-60600443	stanchion, signal, 5-3/4", flats	EA
391-60600444	USE 391-60600684	ea
391-60600459	USE 391-54417992	ea
391-60600536	USE 391-60600684	ea
391-60600621	lens, signal, amber*	EA
391-60600621/ER	lens, turnsignal, econo.rep	EA
391-60600684	rotor, alternator, late, welded, 2.915"OD	EA
391-60600684/ER	rotor, alternator, late, 2.915", econ rep	EA
391-60600752	USE 391-35318/A	ea
391-60867	USE 323-700	ea
391-61386	USE 323-700	ea
391-61387	USE 323-700	ea
391-69158	USE 391-69219	ea
391-69219	horn, 9H, Commando*	EA
391-700168	bracket, Altette horn, flat	EA
391-70039	USE 391-54068034	ea
391-70059	USE 391-54068034	ea
391-70091	USE 391-54068034	ea
391-70106	USE 391-54068034	ea
391-70183	USE 391-70276	ea
391-70197	USE 391-70276	ea
391-70216	USE 391-70276	ea
391-70228	USE 391-70276	ea
391-70248	USE 391-70276	ea
391-70276	horn, 6H Lucas, Triumph&BSA*	EA
391-703349	bracket, Altette horn, cranked	EA
391-76200	horn push, threaded	EA
391-76204	switch, horn push/kill, replacement*	EA
391-76206	USE 391-76204	ea
391-76210	switch, horn push/kill, 1", repl.	EA
391-76944	solenoid, starter, T160	EA

391-77099	USE 06-5508	ea
391-83137	diode,clipper,6v	EA
391-83205	USE 391-83225	ea
391-83225	diode,lighting,78on Tri,etc*	EA
391-83536	rectifier,3phase,pos.grnd	EA
391-83539	rectifier,3phase,neg.grnd,repl	EA
391-83589	zener diodes,matched+grnd	PR
391-83614	USE 391-83225	ea
391-838604	USE 345-1366	ea
391-850641	connector,female,double	EA
391-850832	connector,female,5 way,isolated	EA
391-850844	connector,female,3 way*	EA
391-862217	grommet,wiring,lg.	EA
391-862217/ER	grommet,wiring,lg,econo.repl.	EA
391-863511	USE 391-54959626	ea
391-900269	terminal,bullet type	EA
391-900288	connector,female,single	EA
391-CORE	core chg, Lucas dynamo armature	EA
391-CORE/A	core chg, Lucas magneto armature	EA
391-CORE/C	core chg, Lucas gen&mag	EA
391-DKX/A	rebuild kit, DKX distributor	ST
391-GENERATOR/1	gen, E3L, TRI, twin, exchange	EA
391-GENERATOR/2	generator, E3L, A7/10, exchange	EA
391-GENERATOR/3	generator, magdyno, exchange	EA
391-K2F	magneto, K2F, auto adv, CCW, exchange	EA
391-K2F/MANUAL	magneto, K2F, manual adv, CCW, exchange	EA
391-K2FC	magneto, K2FC, manual adv, CCW, exchange*	EA
391-MCZ98	USE 335-04	ea
391-MLZ9E	USE 335-06	ea
391-PUZ5A	USE 335-03	ea
391-PUZ7E1	USE 335-07	ea
391-SR102	starter reb.kit, 2br.Prest	ST
391-SR104	starter reb. kit, 4brPrest*	EA
392-	LIGHT BULBS	*
392-----	-----	--
392-01	bulb,hdlt,H4,55/60W,6V	EA
392-02	bulb,mini speedo/tach	EA
392-166	USE 392-312 *	ea
392-233	bulb,inst,12 Volt bayonet	EA
392-233/ER	bulb,instrument,econo repl.	EA
392-281	bulb,warning lights	EA
392-281/ER	bulb,warning lights,econo.repl.	EA
392-282	bulb,warning lights,6volt	EA
392-312	bulb,headlight,6 volt,repl.	EA
392-370	bulb,headlight,45/40 watt	EA
392-380	bulb,stop/tail,12 volt	EA
392-380/A	bulb,stop/tail,12 volt,halogen	EA
392-380/ER	bulb,stop/tail,12volt,econ.rep	EA
392-382	bulb,turn signal,12 volt	EA
392-382/ER	bulb,turn signal,econ.rep	EA
392-384	bulb,stop/tail,6 volt,repl	EA
392-384/ER	bulb,stop/tail,6 volt,econo.repl.	EA
392-410	bulb,hdlt,45/40 watt,late	EA
392-410/ER	bulb,headlight,12V,econo	EA
392-414	USE 392-446	ea
392-417	bulb,hdlt,60/40watt,late	EA
392-417/A	bulb,hdlt,100/80watt,late	EA
392-446	bulb,hdlt,50/40watt,repl*	EA
392-446/A	bulb,headlight,halogen,BPF	EA
392-446/ER	bulb,hdlt,12v economy rep*	EA
392-472	bulb,hdlt,QuartzH4,60/55w	EA
392-484	bulb,hdlt,quartz,H4,100/80W	EA
392-501	bulb,inst,"flashbulb"type,5 Watt	EA
392-504	bulb,inst,"flashbulb"type	EA
392-504/ER	bulb,instrument,econo repl.	EA
392-643	USE 392-233	ea
392-951	bulb,inst&pilot,6Vbayonet	EA
392-987	bulb,inst,12V.screw type	EA
392-987/ER	bulb,inst,12V.screw type,econo	EA
392-988	USE 392-951	ea
392-989	bulb,pilot,12Volt bayonet	EA

392-989/A	bulb,pilot,12VHalogen,bayonet	EA
392-989/ER	bulb,pilot,econo	EA
392-990	bulb,inst,6V,screw type,3Watt	EA
393-	WIPAC ELECTRICAL PARTS	*
393-----	-----	---
393-13391	USE 341-3858*	ea
393-14832	USE 393-S3611	ea
393-S0089	lens,tailight,Wipac 143 type	EA
393-S0781	switch,light,rotary	EA
393-S0782	switch,ignition,rotary	EA
393-S1233	points,Bantam & RE125	EA
393-S1243	cam,autoadvance	EA
393-S3611	tailight assy,Wipac 143 type	EA
396-	ELECTRIC START CONVERSIONS	*
396-----	-----	---
396-01	conversion,elect.start,unit6/750	EA
396-02	conversion,electric start,Commando	EA
397-470878	USE 391-470608	ea
411-	ALLEN BOLT SETS	*
411-----	-----	---
411-01	allenkit,TriTRW,SV500army	ST
411-02	allenkit,in.t/c,pre69,1cy	ST
411-03	allenkit,swingarm.A7&A10	ST
411-03/SS	allenkit,swingarm.A7&A10,stainless	ST
411-04	allenkit,rigid&plunger A7&A10	ST
411-05	allenkit,B31/32/33/34&M33	ST
411-104	USE 411-140	ea
411-112104	allenkit,Nor.pts&gbx.caps	ST
411-112104/SS	allenkit,Nor.pts&gbx.caps,stainless	ST
411-112110	allen kit,cyl.hd,Commando	ST
411-112408	allen kit,pri,P11,G15&N15	ST
411-112408/SS	allen kit,pri,P11,G15&N15,stainless	ST
411-12/16	allen kit,preCommandoTwin	ST
411-12/16/SS	allen kit,Nort,stainless	ST
411-121804	allen kit,points cov,TriBSA	ST
411-121804/SS	allen kit,points cov,TriBSA,stainless	ST
411-122102	allen kit,rocker insp.cov,T140*	ST
411-122102/SS	allenkit,rocker insp,T140,stainless*	ST
411-122201/SS	allen kit,T140ES,stainless	ST
411-124	allen kit,Norton Mk3 ES	ST
411-124/SS	allen kit,Nort,stainless	ST
411-126204	allen kit,points cov,3cyl	ST
411-126204/SS	allen kit,points cov,3cyl,stainless	ST
411-133	allen kit,Triumph T150	ST
411-133/SS	allen kit,Tri,stainless	ST
411-134	allen kit,1963-68 Tri.650	ST
411-134/SS	allen kit,Tri,stainless	ST
411-135	allen kit,69onTri.650/750	ST
411-135/SS	allen kit,Tri,stainless	ST
411-136	allen kit,69onTri.350/500	ST
411-136/SS	allen kit,Tri,stainless	ST
411-137	allen kit,pre69TriUnit350/500	ST
411-137/SS	allen kit,Tri,stainless	ST
411-138	allen kit,pre69BSA A50/65	ST
411-138/SS	allen kit,BSA,stainless	ST
411-139	allen kit,1969 BSA A50/65	ST
411-139/SS	USE 411-140/SS	ea
411-140	allen kit,70on BSA A50/65	ST
411-140/SS	allen kit,BSA,stainless	ST
411-141	allen kit,BSA Rocket 3	ST
411-141/SS	allen kit,BSA,stainless	ST
411-143	allenkit,innerT/C,pre50A10,pre51A7	ST
411-144	allenkit,inner t/c,50onA10,51onA7	ST
411-148	allen kit,Triumph T160V	ST
411-148/SS	allen kit,Tri,stainless	ST
411-153	allen kit,pre'75 Commando	ST
411-153/SS	allen kit,Nort,stainless	ST
411-168	a.k,5&6Tto51,T100/110to59	ST
411-169	allen kit,60-62,T110&T120	ST
411-170	all.kit,55-58 5T&55-62 6T	ST
411-170/SS	allenKit,55-58 5T&55-62 6T,stainless	ST

411-171	allen kit,1951-54,5T & 6T	ST
411-176	allen kit,1960-1963 Cub	ST
411-177	allen kit,1964-1969 Cub	ST
411-181909	allenkit,in.t/c,69on 1cyl	ST
411-183409	allen kit,inner t/c,69A65	ST
411-183509	allen kit,inner/tc,70-A65	ST
411-184009	allenkit,in.t/c,pre69 A65	ST
411-2034	allen kit,licence plate	ST
411-21	allen kit,Amal Concentric	ST
411-22/23	allen kit,pre64BSAC15/B40	ST
411-23/24	allen kit,pre69TriBSAlcyl *	ST
411-23/24/SS	allen kit,pre69TriBSAlcyl, stainless*	ST
411-237	USE 411-12/16	ea
411-29/30	allen kit,69onTriBSA 1cyl	ST
411-29/30/SS	allen kit,69onTriBSA 1cyl, stainless	ST
411-33	allen kit,gbx,69onTri.500	ST
411-44	USE 411-141	ea
411-47/48	allen kit,BSAB50&TriTR5MX	ST
411-47/48/SS	allen kit,BSAB50&TriTR5MX, stainless	ST
412-	ACORN NUTS, INDIVIDUAL	*
412-----	-----	---
412-1220	acorn nut,1/2x20,UNF	EA
412-1226	acorn nut,1/2x26,CEI	EA
412-1420	acorn nut,1/4x20,UNC	EA
412-1420/A	acorn nut,1/4x20with stud	EA
412-1426	acorn nut,1/4x26,CEI	EA
412-1428	acorn nut,1/4x28,UNF	EA
412-3420	acorn nut,3/4x20,UNF	EA
412-3816	acorn nut,3/8x16,UNC	EA
412-3824	acorn nut,3/8x24,UNF	EA
412-3826	acorn nut,3/8x26,CEI	EA
412-51618	acorn nut,5/16x18,UNC	EA
412-51624	acorn nut,5/16x24,UNF	EA
412-51626	acorn nut,5/16x26,CEI	EA
412-5818	acorn nut,5/8x18,UNF	EA
412-71620	acorn nut,7/16x20,UNF	EA
412-71626	acorn nut,7/16x26,CEI	EA
412-91618	acorn nut,9/16x18,UNF	EA
413-	ACORN NUT SETS	*
413-----	-----	---
413-10270	acornkit,mtr.mt,early Tri	EA
413-10271	acornkit,mtr.mt,later Tri	EA
413-10273	acornkit,rockerbox,Tri650	ST
413-10274	acornkit,mtr.mt,A50&A65	ST
413-10275	acornkit,cyl,pre69Tri.650	ST
413-10276	acornkit,cyl,69on Tri.650	ST
413-10277	acornkit,hd&rockercov,BSA	ST
413-10278	acornkit,gbx,69onTri6/750	ST
413-10279	acornkit,t/c,69onTri6/750	ST
413-10280	acornkit,pri,69onTri6/750	ST
413-10281	acornkit,rockers,NortTwin	ST
413-10282	acornkit,gbx,63-68 Tri650	ST
413-10283	acornkit,t/c,63-68 Tri650	ST
413-10284	acornkit,pri,63-68 Tri650	ST
413-122120	acornkit,cyl,Tri.750 Twin	ST
414-	NUT AND BOLT SETS,MISC.	*
414-----	-----	---
414-000088	mtg.set,tank,63-66 Tri650*	ST
414-000089	mtg.set,tank,54-59 TriPU	ST
414-000091	mtg.set,tank,68-70 TriTwins*	ST
414-000105	mtg.set,tank,TR7/140	ST
414-00160	fastener kit,cases,TR6/120,63-68	ST
414-00187	boltkit,hd,BSA M20/21,1949on*	ST
414-00187/A	boltkit,hd,BSA M20/21,pre1949	ST
414-00800	mtg.set,tank,57-63 3/5TA	ST
414-00801	mtng.kit,pegs,TR6/120,64-68	ST
414-00802	mtng.kit,pegs,TR6/120,69/70	ST
414-00803	mtng.kit,rubber mt.bars	ST
414-01	T160type"hd.fix kit",Hyde	ST
414-02	nut kit,cyl,Nort.850,ss	ST
414-03	nutkit,cyl,pre72Nor750,ss	ST

414-04	nutkit,cyl,72onNort750,ss	ST
414-05	boltkit,alloy headBSA A10	ST
414-06	boltkit,iron head BSA A10	ST
414-067094	stud & nut kit,preMk3 crank	ST
414-067095	stud & nut kit,Mk3 crank	ST
414-067097	fastener kit,cyl.hd,Nort*	ST
414-067120	stud & nut kit,650SS crank	ST
414-07	boltkit,hd,BSA A50/65,late	ST
414-07/A	boltkit,hd,BSA A50/65,early	ST
414-08	mtg.set,oiltank top,A50/65	ST
414-09	stud set,oilpump,A7/10	ST
414-10	bolt set,allenBSF,MORGORotary pump mtg.	ST
414-11	mtg.set,c.stand,A7/10,etc.	ST
414-110/A	tappet retaining kit,A10,late	ST
414-110/B	tappet retaining kit,A7 &earlyA10	ST
414-113/A	mounting kit,oiltank bot,A75/X75	ST
414-12	boltkit,hd,preunit Tri,iron hd.	ST
414-12/A	boltkit,hd,preunit Tri,alloy hd.	ST
414-13	mounting kit,rearsets,DBD34	ST
414-14	mtg.kit,tank,duplex frame	ST
414-15	boltkit,hd,unit350/500 Tri	ST
414-999948	boltkit,hd,TR6/120,63-70*	ST
414-999949	mtg.set,c.stand,66on500Tri	ST
414-999950	mtg.set,c.stand,60-62 TriPU	ST
414-999951	mtg.set,c.stand,1980on	ST
414-999952	mtg.set,c.stand,54-59 TriPU	ST
414-999953	mtg.set,c.stand,71-79 oilframe	ST
414-999955	mtg.set,c.stand,69/70 650Tri	ST
414-EBS1	eng.mt.hdwe,A7/10,pre1957	ST
414-EBS11	eng.mt.hdwe,C15/B25/B40/B44,pre71	ST
414-EBS14	eng.mt.hdwe,unit350/500,pre1965	ST
414-EBS15	eng.mt.hdwe,unit350/500,1965-68	ST
414-EBS16	eng.mt.hdwe,unit350/500,1969	ST
414-EBS17	eng.mt.hdwe,unit350/500,1970	ST
414-EBS18	eng.mt.hdwe,T100C/T100R,71on	ST
414-EBS19	eng.mt.hdwe,TR6/120,1963/64	ST
414-EBS20	eng.mt.hdwe,TRI650,1965/66	ST
414-EBS21	eng.mt.hdwe,TR6/120,1967/68	ST
414-EBS22	eng.mt.hdwe,TR6/120,1969	ST
414-EBS23	eng.mt.hdwe,TR6/120,1970	ST
414-EBS24	eng.mt.hdwe,TR6/120,1971-72	ST
414-EBS27	eng.mt.hdwe,TRIPreunitSA,1954-59	ST
414-EBS28	eng.mt.hdwe,TRI650,1960-62	ST
414-EBS29	eng.mt.hdwe,Commando,pre75	ST
414-EBS3	eng.mt.hdwe,B31/32/33/34,1954on	ST
414-EBS30	eng.mt.hdwe,Commando,MK3	ST
414-EBS31	eng.mt.hdwe,Featherbed	ST
414-EBS4	eng.mt.hdwe,A7/10,rigid&plunger	ST
414-EBS5	eng.mt.hdwe,A50/65,pre1969	ST
414-EBS6	eng.mt.hdwe,A50/65,1969/70	ST
414-EBS7	eng.mt.hdwe,A50/65,oilframe	ST
414-EBS8	eng.mt.hdwe,B25/50,oilframe	ST
415-	BOLTS,MISC.	*
415-----	-----	---
415-1220/114	bolt,1/2x20x1-1/4"	EA
415-1220/134	bolt,1/2x20x1-3/4"	EA
415-1420/1	bolt,1/4x20x1"	EA
415-1420/112	bolt,1/4x20x1-1/2"	EA
415-1420/114	bolt,1/4x20x1-1/4"	EA
415-1420/134	bolt,1/4x20x1-3/4"	EA
415-1420/2	bolt,1/4x20x2"	EA
415-1420/212	bolt,1/4x20x2-1/2"	EA
415-1420/34	bolt,1/4x20x3/4"	EA
415-1426/1	bolt,1/4x26x1"	EA
415-1426/112	bolt,1/4x26x1-1/2"	EA
415-1426/112/A	bolt,1/4x26x1-1/2", allen	EA
415-1426/114/A	bolt,1/4x26x1-1/4", allen	EA
415-1426/2	bolt,1/4x26x2"	EA
415-1426/3/A	bolt,1/4x26x3", allen*	EA
415-1426/34	bolt,1/4x26x3/4"	EA
415-1426/38	bolt,1/4x26x3/8"	EA

415-1428/112	bolt,1/4x28x1-1/2"	EA
415-1428/114/A	bolt,1/4x28x1-1/4", allen	EA
415-1428/134	bolt,1/4x28x1-3/4"	EA
415-1428/2	bolt,1/4x28x2"	EA
415-1428/212	bolt,1/4x28x2-1/2"	EA
415-1428/214	bolt,1/4x28x2-1/4"	EA
415-3816/1	bolt,3/8x16x1"	EA
415-3816/112	bolt,3/8x16x1-1/2"	EA
415-3816/114	bolt,3/8x16x1-1/4"	EA
415-3816/134	bolt,3/8x16x1-3/4"	EA
415-3816/2	bolt,3/8x16x2"	EA
415-3816/212	bolt,3/8x16x2-1/2"	EA
415-3816/34	bolt,3/8x16x3/4"	EA
415-3824/1	bolt,3/8x24x1"	EA
415-3824/112	bolt,3/8x24x1-1/2"	EA
415-3824/114	bolt,3/8x24x1-1/4"	EA
415-3824/2	bolt,3/8x24x2"	EA
415-3824/34	bolt,3/8x24x3/4"	EA
415-3826/1	bolt,3/8x26x1"	EA
415-3826/112	bolt,3/8x26x1-1/2"	EA
415-3826/12	bolt,3/8x26x1/2"	EA
415-3826/2	bolt,3/8x26x2"	EA
415-3826/3	bolt,3/8x26x3"	EA
415-3826/34	bolt,3/8x26x3/4"	EA
415-51618/112	bolt,5/16x18x1-1/2"	EA
415-51618/114	bolt,5/16x18x1-1/4"	EA
415-51618/12	bolt,5/16x18x1/2"	EA
415-51618/134	bolt,5/16x18x1-3/4"	EA
415-51618/212	bolt,5/16x18x2-1/2"	EA
415-51618/3	bolt,5/16x18x3"	EA
415-51622/112	bolt,5/16x22x1-1/2"	EA
415-51624/112	bolt,5/16x24x1-1/2"	EA
415-51624/134	bolt,5/16x24x1-3/4"	EA
415-51624/2	bolt,5/16x24x2"	EA
415-51624/212	bolt,5/16x24x2-1/2"	EA
415-51626/1	bolt,5/16x26x1"	EA
415-51626/112	bolt,5/16x26x1-1/2"	EA
415-51626/12	bolt,5/16x26x1/2"	EA
415-51626/2	bolt,5/16x26x2"	EA
415-51626/3	bolt,5/16x26x3"	EA
415-51626/34	bolt,5/16x26x3/4"	EA
415-71620/1	bolt,7/16x20x1"	EA
415-71620/134	bolt,7/16x20x1-3/4"	EA
415-71620/2	bolt,7/16x20x2"	EA
415-71620/212	bolt,7/16x20x2-1/2"	EA
415-91618/1	bolt,9/16x18x1"	EA
415-91618/112	bolt,9/16x18x1-1/2"	EA
416-	NUTS,MISC.	*
416-----	-----	--
416-1220	nut,1/2x20	EA
416-1226	nut,1/2x26,CEI	EA
416-1420	nut,1/4x20 UNC	EA
416-1426	nut,1/4x26 CEI	EA
416-1428	nut,1/4x28 UNF	EA
416-1428/L	nut,1/4x28 UNF,lock	EA
416-3816	nut,3/8x16,UNC	EA
416-3820/L	nut,3/8x20 BSF,lock	EA
416-3824	nut,3/8x24,UNF	EA
416-3824/L	nut,3/8x24 UNF,lock	EA
416-3826	nut,3/8x26 CEI	EA
416-51618	nut,5/16x18 UNC	EA
416-51618/L	nut,5/16x18 UNC,lock	EA
416-51622/L	nut,5/16x22 BSF,nylock	EA
416-51624/L	nut,5/16x24 UNF,lock	EA
416-51626	nut,5/16x26 CEI	EA
416-71614	nut,7/16x14,UNC	EA
416-71618	nut,7/16x18,BSF	EA
416-71620	nut,7/16x20,CEI	EA
416-71620/L	nut,7/16x20,lock	EA
416-71626	nut,7/16x26 CEI	EA
417-	SHIMS & WASHERS	*

417-----	-----	---
417-01	shim kit,BSA twin crank,preunit	ST
417-02	shim kit,BSA forks	ST
417-03	shim kit,unit single crank	ST
417-04	shim kit,BSA twin crank,unit,early	ST
417-05	shim kit,BSA twin crank,unit,late	ST
418-	TAB WASHER SETS	*
418-----	-----	---
418-01	tabwasher set,Tri.6/750 V	ST
418-02	tabwasher set,3 cylinder	ST
418-03	tabwasher set,TriBSA 1cyl.	ST
418-04	tabwasher set,A7/10	ST
418-05	tabwasher set,Tri.650 4spd.	ST
418-06	tabwasher set,BSA A50/65	ST
418-07	tabwasher set,Bantam	ST
418-08	tabwasher set,B31/B33,etc*	ST
419-	HARDWARE,MISCELLANEOUS	*
419-----	-----	---
421-	SHELL BEARINGS,CRANK& ROD	*
421-----	-----	---
421-53	brgs,rod,std,Nor.6/7/850	ST
421-53/010	brgs,rod,-.010,Nor6/7/850	ST
421-53/020	brgs,rod,-.020,Nor6/7/850	ST
421-53/030	brgs,rod,-.030,Nor6/7/850	ST
421-53/040	brgs,rod,-.040,Nor6/7/850	ST
421-5400	brgs,rod,std,Tri TSS 8vlv	ST
421-5400/010	brgs,rod,-.010,Tri TSS	ST
421-5400/020	brgs,rod,-.020,Tri TSS	ST
421-56	brgs,rod,std,Tri6&750twin	ST
421-56/010	brgs,rod,-.010,Tri 6&750	ST
421-56/020	brgs,rod,-.020,Tri 6&750	ST
421-56/030	brgs,rod,-.030,Tri 6&750	ST
421-56/040	brgs,rod,-.040,Tri 6&750	ST
421-57	brgs,rod,std,Nor250-600cc	ST
421-57/010	brgs,rod,-010Nor250-600cc	ST
421-57/020	brgs,rod,-020Nor250-600cc	ST
421-57/030	brgs,rod,-030Nor250-600cc	ST
421-57/040	brgs,rod,-040Nor250-600cc	ST
421-60	brgs,rod,std,A7&A10,early	ST
421-60/010	brgs,rod,-.010,A7/10early	ST
421-60/020	brgs,rod,-.020,A7/10early	ST
421-60/030	brgs,rod,-.030,A7/10early	ST
421-60/040	brgs,rod,-.040,A7/10early	ST
421-68	brgs,rod,std,Tri350/500uc*	ST
421-68/010	brgs,rod,-.010,Tri350/500*	ST
421-68/020	brgs,rod,-.020,Tri350/500*	ST
421-68/030	brgs,rod,-.030,Tri350/500*	ST
421-68/040	brgs,rod,-.040,Tri350/500*	ST
421-783	brgs,rod,std,A50&'56on650*	ST
421-783/010	brgs,rod,-.010,A50/65&A10	ST
421-783/020	brgs,rod,-.020,A50/65&A10	ST
421-783/030	brgs,rod,-.030,A50/65&A10	ST
421-783/040	brgs,rod,-.040,A50/65&A10	ST
421-91484	brgs,rod,std,TriBSATriple	ST
421-91484/010	brgs,rod,-.010,Triples	ST
421-91484/020	brgs,rod,-.020,Triples	ST
421-91484/030	brgs,rod,-.030.Triples	ST
421-91484/040	brgs,rod,-.040,Triples	ST
421-91495	brgs,main,std,Triples	ST
421-91495/010	brgs,main,-.010,Triples	ST
421-91495/020	brgs,main,-.020,Triples	ST
421-91495/030	brgs,main,-.030,Triples	ST
421-91495/040	brgs,main,-.040,Triples	ST
422-	BEARING BALLS AND ROLLERS	*
422-----	-----	---
422-12	bearing ball,steel,1/2"	EA
422-14	bearing ball,steel,1/4"	EA
422-1414	bearing roller,1/4x1/4"	EA
422-316	bearing ball,steel,3/16"	EA
422-38	bearing ball,steel,3/8"	EA
422-516	bearing ball,steel,5/16"	EA

422-532	bearing ball,steel,5/32"	EA
422-6MM	bearing ball,steel,6mm	EA
422-716	bearing ball,steel,7/16"	EA
422-732	bearing ball,steel,7/32"	EA
423-	BEARINGS,AND BEARING SETS	*
423-----	-----	--
423-000090	bush set,cams,70onTri6/750	ST
423-000092	bush set,cams,pre70Tri650	ST
423-000116	bush&pin set,s.arm,PU Tri*	ST
423-000117	bush&pin set,s.arm,63-70T120	ST
423-000118	bush&pin set,s.arm,oilframe twins	ST
423-000119	bush&pin set,s.arm,350/500-66	ST
423-000120	bush&pin set,s.arm,350/500,67on	ST
423-01	brg.cups,cones&balls, strg.hd,BSA A&B*	ST
423-01/A	brg.set,taper convBSAstrg	ST
423-01/ER	brg.cup&cone set, strg.brg,BSA A&B*	ST
423-02	brg.set, strg.hd,unit 1cyl TriBSA	ST
423-02/A	brg.set,taper,unit1cyl.TriBSAstrg,pre71	EA
423-03	plunger bush/shaft kit,BSA	ST
423-067092	bush & seal kit,Roadholder	ST
423-68	bush only,A50/65 crank RH,std	EA
423-999935	bush&seal set,forks,ext.spr.	ST
423-999936	bush&seal set,forks,int.spr.	ST
423-AMC6	crankpin assy,AJS/MATCHLESS single	EA
423-B14	crankpin assy,PU 1cyl,exc.GS	EA
423-B14/GS	crankpin assy,Goldstar	EA
423-B24	crankpin assy,1961-63C15,1962-63B40	EA
423-B25	crankpin assy,1964onC15,65onB40	EA
423-B26	crankpin assy,BSA VICTOR	ST
423-B28	crankpin assy,BSA B50,steel caged	EA
423-N3	crankpin assy,NORTON	ST
423-RE13	crankpin assy,ROYAL ENFIELD	ST
423-T11	crankpin assy,CUB,1964on	ST
423-T7	crankpin assy,CUB/TERRIER,PRE56	ST
423-T8	crankpin assy,CUB,1956-61	ST
423-T9	crankpin assy,CUB,1962-63	ST
431-	LOOSE GASKETS	*
431-----	-----	--
431-01	gask,out.gbx.cov,Tri500uc	EA
431-02	gask,gbx.cov,in,Tri 500uc	EA
431-03	gask,tim.cov,Tri 500 unit	EA
431-04	fibre washer assortment pack	ST
431-05	gask,gbx.cov,outer,TriPreunit	EA
431-06	gasket,gbx.cov,inner,TriPreunit	EA
431-07	gask,tim.cov,TriPreunit	EA
432-	GASKET SETS,STD.REPL.TYPE	*
432-----	-----	--
432-208	gask.set,Ariel Sq4,1949-53	EA
432-209	gask.set,Ariel Sq4,1954on	EA
432-252/D	gask.set,top end,16H,48on	EA
432-254	USE 432-258	ea
432-255	gask.set,Nor# 7,77,88& 99	EA
432-256	USE 432-258	ea
432-258	gask.set,Norton OHVsingle(ES2,19)	EA
432-258/D	gask.set,top end,Nor.OHVsingle	EA
432-260	gask.set,Jubilee,1959-66	EA
432-260/D	gask.set,top end,Jubilee	EA
432-261	gask.set,Norton 650 twins,early*	EA
432-261/D	gask.set,top end,Nor.650,early	EA
432-264	USE 432-267	ea
432-265	USE 432-268	ea
432-267	gask.set,Nor750w/spig.cyl	EA
432-267/D	gask.set,top end,early750	EA
432-268	gask.set,Nor750Atlas,late	EA
432-268/D	gask.set,top end,Nor.Atlas,late*	EA
432-269	gask.set,Nor.750 Commando	EA
432-269/D	gask.set,top end,Nor.750,later	EA
432-270	gask.set,Nor.850 pre 1975	EA
432-270/D	gask.set,top end,Nort.850	EA
432-271	gask.set,Nor850 MK3(75on)	EA
432-271/D	USE 432-270/D	ea

432-300	gasket set,Bantam D1,1948-53	EA
432-301	gasket set,Bantam D1,1955-63	EA
432-302	gask.set,BSA Bantam D3	EA
432-303	gask.set,BSA C10,1939-53	EA
432-304	gask.set,BSA C10L,1954-57	EA
432-305	gask.set,BSA C11,1939-53*	EA
432-306	gask.set,BSA C11G & C12	EA
432-306/D	gask.set,top,BSA C11G&C12	EA
432-307	gask.set,B31/32 Comp,1946-48	EA
432-308	gask.set,B31/32 Comp,1949-60	EA
432-309	gask.set,B31/32 alloy hd,50-61	EA
432-310	gask.set,B32 Goldstar,1949-52	EA
432-311	gask.set,B32 Goldstar,1953-57	EA
432-312	gask.set,B33/34 & M33,1948-60*	EA
432-313	gask.set,BSA B33&34 alloy	EA
432-314	gask.set,A7,1947-50*	EA
432-315	gask.set,BSA A7,1951 on*	EA
432-316	gask.set,Goldstar B34,1949-52	EA
432-317	gask.set,B34 Goldstar,1953-55	EA
432-318	gask.set,M20/21,1939-49	EA
432-319	gask.set,M20/21,1950-61	EA
432-320	USE 432-325	ea
432-321	gask.set,B34Gold Star,1956 on	EA
432-324	gasket set,Bantam D1,1954	EA
432-325	gask.set,BSA A10&ARIEL650	EA
432-325/D	gask.set,top,BSA A10&ARIEL 650	EA
432-326	gasket set,Bantam D5/D7,1958-66	EA
432-327	gask.set,BSA C15 & SS80	EA
432-327/D	gask.set,top end,C15/SS80	EA
432-328	gask.set,B40,SS90	EA
432-328/D	gask.set,top end,B40/SS90	EA
432-330	USE 432-334	ea
432-332	gask.set,BSA B44,441 1cyl	EA
432-332/D	gask.set,top end,BSA B44	EA
432-333	gask.set,BSA Bantam D10	EA
432-334	USE 432-338	ea
432-334/D	gask.set,top,BSA A65pre70	EA
432-335	gask.set,TriBSA 250,67-70	EA
432-335/D	gask.set.top end,B25,to71*	EA
432-336	gasket set,Bantam D14/D175,1968-71	EA
432-337	gask.set,BSA A50,500 unit,all*	EA
432-337/D	gask.set,top end, BSA A50*	EA
432-338	gask.set,BSA A65,all years	EA
432-338/D	gask.set,top end,A65,70on	EA
432-339	gask.set,BSA B50,500 1cyl	EA
432-340	gask.set,DB32 Goldstar,1953-57	EA
432-419	gask.set,Royal Enfield 750	EA
432-800	gasket set,Terrier T15	EA
432-801	gask.set,Cub,pre 60	EA
432-802	gask.set,Tri 5T,500,p.u.	EA
432-803	gask.set,Tri T100,1946-50	EA
432-804	gask.set,Tri500,alloy cyl	EA
432-805	gask.set,Tri650iron hd-55	EA
432-806	gask.set,Tri500iron,51-58	EA
432-809	gask.set,Tri.3T,1945-46	EA
432-810	gask.set,Tri 3T,1947-51*	EA
432-811	USE 432-806	ea
432-812	gask.set,T110&TR6,1956-62	EA
432-812/D	gask.set,top endT110&TR6,1956-62*	EA
432-814	gask.set,Tri 500 uc,58-65	EA
432-814/D	gask.set,top end,Tri.500,58-65*	EA
432-815	gask.set,Tri T120,preunit	EA
432-815/D	gask.set,top end,TriT120,preunit*	EA
432-816	gask.set,Tri Cub,1960 on	EA
432-818	gask.set,Tri650 uc,'63-66	EA
432-818/D	gask.set,top end,Tri650,63-66*	EA
432-820	gask.set,Tri500 uc,'66-69	EA
432-820/D	gask.set,top,Tri500 uc,'66-69*	EA
432-822	gask.set,Tri650,1967&1968	EA
432-822/D	gask.set,top,Tri650,67&68 *	EA
432-825	gask.set,Triples,exc.T160	EA

432-825/D	USE 432-839/D	ea
432-826	gask.set, Tri650, 1969&1970	EA
432-826/D	gask.set, top, 650Tri, 69/70	EA
432-828	gask.set, Tri 500, 1970 on*	EA
432-828/D	gask.set, top, Tri 500, 1970 on*	EA
432-832	gask.set, Tri650, '71-mid72	EA
432-832/D	gask.set, top end, Tri650, 71-mid72*	EA
432-833	gask.set, Tri650, mid'72 on	EA
432-833/D	gask.set, top end, Tri650, mid72on	EA
432-834	gask.set, Tri6T, iron, 56-62	EA
432-835	gask.set, TriBSA 250, 71on	EA
432-835/D	gask.set, top end, TriBSA250, 71on	EA
432-836	gask.set, Tri 750 twins	EA
432-836/D	gask.set, top, Tri 750 twins*	EA
432-837	USE 432-825	ea
432-838	gask.set, TriTRW, SV500army	EA
432-839	gask.set, Tri. T160, Triple	EA
432-839/D	gask.set, top end, triples *	EA
432-842	gask.set, Tri TSS 8 valve	EA
432-842/D	gask.set, top, Tri 750 TSS	EA
432-850	gasket set, 200ccLE, 51on	EA
432-851	gasket set, MOV/MAC, pre51	EA
432-852	gasket set, MAC, 52-60	EA
432-853	gasket set, 149ccLE, 49-50	EA
432-854	gask.set, 500ccMSS Venom, 54on	EA
432-855	gask.set, 350ccViper, 54-69	EA
432-856	gask.set, 500 Venom Thruxton, 65on	EA
432-857	gasket set, 200ccLE Mk3, 58on	EA
432-858	gask.set, 350ccKSSmk2, 1936-48	EA
432-859	gask.set, 500 Venom Thruxton	EA
432-870/D	gask.set, top end, 500ccThruxtonMk2	EA
432-997572	USE 432-842	ea
433-	HEAVY DUTY GASKET SETS	*
433-----	-----	--
433-01	gask/oring set, BSA A75&X75, Hyde	EA
433-02	gask/oring set, Tri. T150, Hyde	EA
433-02/A	gask.set, Tri T150, Ibco	EA
433-03	gask/oring set, Tri T160, Hyde	EA
433-03/A	gask.set, Tri T160, Ibco	EA
433-04	gask/oring set, Tri650unit, Hyde	EA
433-04/A	gask.set, Tri650 uc, Ibco	EA
433-04/B	gask.set, Tri 650 unit twin, all	EA
433-04/B/D	gask.set, topend, unit650TRI, all	EA
433-05	gask/oring set, TR7/140, Hyde	EA
433-05/A	gask.set, TR7/140, Ibco	EA
433-05/B	gask.set, TR7/140, complete, all	EA
433-05/B/D	gask.set, topend, TR7/140, all*	EA
433-06	gask.set, Tri 500 uc, Ibco	EA
433-07	gask/oring set, Nor. Com. 750, Hyde*	EA
433-07/A	gask.set, Nor Com. 750, Ibco	EA
433-07/B	gask&seal set, gen. Nor 750*	EA
433-08	gask/oring set, Nor. 850, Hyde	EA
433-08/A	gask.set, Nor. 850, Ibco	EA
433-08/B	gask&seal set, gen. Nor. 850	EA
433-09	gask/oring set, Nor. 850 Mk3, Hyde	EA
433-09/A	gask.set, Nor 850 Mk3, Ibco	EA
433-09/B	gask&seal set, gen. Nor. Mk3	EA
434-	OIL SEAL KITS	*
434-----	-----	--
434-01	sealkit, 3 cyl, 4 speed	ST
434-02	sealkit, 5spd. A75V & T150V	ST
434-03	sealkit, Triumph T160V	ST
434-04	sealkit, 68on TriBSA 1cyl.	ST
434-05	sealkit, 1963-67 Tri. 650	ST
434-06	sealkit, 1968&69 Tri. 650	ST
434-07	sealkit, 70on Tri. 650 4spd	ST
434-08	sealkit, Triumph 5spd. Twin	ST
434-09	sealkit, 1959-63Tri350/500	ST
434-10	sealkit, 63-67 Tri. 350/500	ST
434-11	sealkit, 68-69 Tri. 350/500	ST
434-12	sealkit, 70on Tri. 500 Twin	ST

434-13	sealkit,pre'69 A50 & A65	ST
434-14	sealkit,1969 on BSA Twins	ST
434-15	sealkit,pre75 Norton Twin eng.	ST
434-16	sealkit,75 Norton 850 Mk3	ST
434-17	gbx.rebuild kit,pre75Nort	ST
441-	PISTONS	*
441-----	-----	---
441-10030	piston assy,std,A7 pre51,7:1	PR
441-10064	piston assy,std,TriPU 350,8:1	PR
441-10226	piston assy,std,ES2,48on,6.45:1	EA
441-10334	piston assy,std,TriPU 500,7:1	PR
441-10334/020	piston assy,+.020,TriPU 500,7:1	PR
441-10334/040	piston assy,+.040,TriPU 500,7:1	PR
441-10334/060	piston assy,+.060,TriPU 500,7:1	PR
441-10338	piston set,l&r,std,Nor500,8:1	ST
441-10338/020	piston set,l&r,020,Nor500,8:1	ST
441-10338/040	piston set,l&r,.040,Nor500,8:1	ST
441-10399	piston assy,std,D1 Bantam,1947-63	EA
441-10399/020	piston assy,020,D1 Bantam,1947-63	EA
441-10499	piston assy,std,TriPU 350,7:1	PR
441-10500	piston assy,std,TriPU 350,6.3:1	PR
441-10533	piston set,l&r,std,Nor500,6.75:1	ST
441-10652	piston assy,std,TriPU 500,12:1	PR
441-10739	piston assy,std,A7 pre51,7.5:1	PR
441-10739/020	piston assy,.020,A7 pre51,7.5:1	PR
441-10739/040	piston assy,.020,A7 pre51,7.5:1	PR
441-11016	piston assy,std,BSA A10,6.5-1	PR
441-11062	piston assy,std,BSA A10,7.25:1	PR
441-11062/020	piston assy,+.020,A10,7.25:1	PR
441-11062/030	piston assy,+.030,A10,7.25:1	PR
441-11062/030/A	USE 441-11412/030 Jun 14 93	PR
441-11062/040	piston assy,+.040,A10,7.25:1	PR
441-11062/040/A	USE 441-11412/040 Jun 14 93	PR
441-11062/060	piston assy,+.060,A10,7.25:1	PR
441-11062/060/ER	piston assy,+.060,economy	PR
441-11094	piston assy,std,A7 late,6.66-1	PR
441-11134	piston assy,std,Tri650,8.5-1,ironhd.	PR
441-11134/010	piston assy,010,Tri650,8.5-1,ironhd.	PR
441-11151	piston assy,std,A7 pre51,6.6-1	PR
441-11288	piston assy,std,A7 late,7.25-1	PR
441-11288/020	piston assy,+.020,A7 late,7.25-1	PR
441-11288/040	piston assy,+.040,A7 late,7.25-1	PR
441-11288/060	piston assy,+.060,A7 late,7.25-1	PR
441-11341	piston assy,std,B33,1947-52,6.8:1	EA
441-11341/020	piston assy,.020,B33,1947-52,6.8:1	EA
441-11342	piston assy,std,B33,1947-52,7.5:1	EA
441-11342/020	piston assy,020,B33,1947-52,7.5:1	EA
441-11412	piston assy,std,BSA A10,9-1	PR
441-11412/020/ER	piston assy,+.020,9-1,econo	PR
441-11412/030	piston assy,+.030,9-1	PR
441-11412/040	piston assy,+.040,9-1	PR
441-11412/040/ER	piston assy,+.040,9-1,econo	PR
441-11412/060	piston assy,+.060,9-1	PR
441-11412/ER	piston assy,std,BSA A10,9-1,econo	PR
441-11431	piston assy,std,BSA A10,8-1	PR
441-11563	piston assy,std,TriPU 500,7.8:1	PR
441-11563/060	piston assy,060,TriPU 500,7.8:1	PR
441-11564	piston assy,std,Tri 650,7-1,ironhd.	PR
441-11564/010	piston assy,+.010,Tri650,7-1,ironhd.	PR
441-11564/020	piston assy,+.020,Tri650,7-1,ironhd.	PR
441-11564/020/ER	piston assy,020,6T,7-1,econo	PR
441-11564/030	piston assy,+.030,Tri650,7-1,ironhd.	PR
441-11564/040	piston assy,+.040,Tri650,7-1,ironhd.	PR
441-11564/040/ER	piston assy,040,6T,7-1,econo	PR
441-11564/ER	piston assy,std,6T,7-1,econo	PR
441-11603	piston assy,std,A7 late,8-1	PR
441-11603/020	piston assy,+.020,A7	PR
441-11744	piston assy,std,B33,1953-60,7.5:1	EA
441-11744/020	piston assy,020,B33,1953-60,7.5:1	EA
441-11787	piston assy,std,BSA A10,8.5-1	PR
441-11813	piston assy,std,B31,9-1	EA

441-11917	piston set,l&r,std,Nor500,9.45:1	ST
441-11952	piston assy,std,Terrier,7-1	EA
441-11957	piston assy,std,M20,4.9-1	EA
441-11957/020	piston assy,020,M20,4.9-1	EA
441-11957/040	piston assy,040,M20,4.9-1	EA
441-11957/060	piston assy,060,M20,4.9-1	EA
441-11960	piston assy,std,ES2,48on,7.9:1	EA
441-11982	piston assy,std,Terrier,9-1	EA
441-12010	piston assy,std,B33,1947-52,8.5:1	EA
441-12010/020	piston assy,020,B33,1947-52,8.5:1	EA
441-12010/040/ER	piston assy,040,B33,1947-52,8.5:1,econo	EA
441-12010/080/ER	piston assy,080,B33,1947-52,8.5:1,econo	EA
441-12058	piston assy,std,A7 late,9.5-1	PR
441-12279	piston assy,std,B33,1953-60,8.5:1	EA
441-12420	piston assy,std,TriPU 500,8:1	PR
441-12543	piston assy,std,D3 Bantam,1954	EA
441-12543/020	piston assy,020,D3 Bantam,1954	EA
441-12543/040	piston assy,040,D3 Bantam,1954	EA
441-12543/050	piston assy,050,D3 Bantam,1954	EA
441-12581	piston assy,std,Cub,7-1,bare	EA
441-12581/010	piston assy,+.010,Cub	EA
441-12581/020	piston assy,+.020,Cub	EA
441-12581/030	piston assy,+.030,Cub	EA
441-12581/040	piston assy,+.040,Cub	EA
441-12600	piston assy,std,Cub,9-1	EA
441-12600/020/ER	piston assy,020,Cub,9-1,econo	EA
441-12600/040/ER	piston assy,040,Cub,9-1,econo	EA
441-12600/060/ER	piston assy,060,Cub,9-1,econo	EA
441-12600/ER	piston assy,std,Cub,9-1,econo	EA
441-12659	piston assy,std,M21,1939on	EA
441-12659/020	piston assy,020,M21,1939on	EA
441-12659/040	piston assy,040,M21,1939on	EA
441-12659/060	piston assy,060,M21,1939on	EA
441-12713	piston assy,std,Tri650,8.5-1,ironhd.	PR
441-12804	piston assy,std,B34GS,54on,7.25:1	EA
441-12923	piston assy,std,D3 Bantam,1955-57	EA
441-12923/020	piston assy,020,D3 Bantam,1955-57	EA
441-12923/040	piston assy,040,D3 Bantam,1955-57	EA
441-13012	piston assy,std,B34GS,54on,8.5:1	EA
441-13052	USE 441-18527	EA
441-13325	piston set,l&r,std,Nor600,7.4:1	ST
441-13346	piston assy,std,ES2,48on,7.1:1	EA
441-13346/020	piston assy,020,ES2,48on,7.1:1	EA
441-13408	USE 441-18553	ea
441-13414	piston assy,std,Tri650,9-1,ironhd.	PR
441-13423	USE 441-18524	ea
441-13469	piston assy,std,Cub,10.5-1	EA
441-13469/020	piston assy,020,Cub,10.5-1	EA
441-13469/020/ER	piston assy,020,Cub,10.5-1,econo	EA
441-13469/040/ER	piston assy,040,Cub,10.5-1,econo	EA
441-13469/060/ER	piston assy,060,Cub,10.5-1,econo	EA
441-13469/ER	piston assy,std,Cub,10.5-1,econo	EA
441-13528	piston assy,std,Tri 650,8.5-1	PR
441-13529	piston assy,std,Tri 650,8-1	PR
441-13529/020	piston assy,020,Tri 650,8-1	PR
441-13529/040	piston assy,040,Tri 650,8-1	PR
441-13952	piston assy,std,Tri uc350,7.5-1	PR
441-13980	piston assy,std,Tri 650,9-1	PR
441-14087	piston assy,std,Tri 650,9-1	PR
441-14178	piston assy,std,D5/D7 Bantam,1958-63	EA
441-14180	USE 441-16986	ea
441-14629	piston set,l&r,std,Nor600,8:1	ST
441-15034	piston assy,std,Tri uc500,7-1,pre67	PR
441-15034/020	piston assy,+020,Tri uc500,7-1,pre67	PR
441-15034/040	piston assy,+040,Tri uc500,7-1,pre67	PR
441-15123	piston assy,std,Tri uc500,9-1,pre67	PR
441-15123/010	piston assy,+.010,Tri 500	PR
441-15123/020	piston assy,+.020,Tri.500*	PR
441-15123/020/ER	piston assy,+.020,economy	PR
441-15123/030	piston assy,+.030,Tri.500	PR
441-15123/040	piston assy,+.040,Tri.500	PR

441-15123/040/ER	piston assy,+ .040,economy	PR
441-15123/060	piston assy,+ .060,Tri.500	PR
441-15123/060/ER	piston assy,+ .060,economy	PR
441-15123/070	piston,+ .070,bare,Mondial	PR
441-15123/080	piston,+ .080,Mondial	PR
441-15123/080/ER	piston assy,+ .080,economy	PR
441-15123/ER	piston assy,std,Tri uc500,9-1,pre67,econ	PR
441-15137	piston assy,std,BSA 250C15,7.5-1	EA
441-15137/020	piston assy,020,BSA 250C15,7.5-1	EA
441-15137/040	piston assy,040,BSA 250C15,7.5-1	EA
441-15219	piston assy,std,Tri 650,8.5-1	PR
441-15219/020	piston assy,020,Tri 650,8.5-1	PR
441-15219/030	piston assy,030,Tri 650,8.5-1	PR
441-15219/040	piston assy,040,Tri 650,8.5-1	PR
441-15219/060	piston assy,060,Tri 650,8.5-1	PR
441-15305	piston assy,std,BSA 250C15,10-1	EA
441-15305/020	piston assy,020,BSA 250C15,10-1	EA
441-15305/040	piston assy,040,BSA 250C15,10-1	EA
441-15417	piston assy,std,BSA 250C15,6.5-1	EA
441-15504	piston assy,std,B31,6.5-1	EA
441-15504/020	piston assy,020,B31,6.5-1	EA
441-15504/040	piston assy,040,B31,6.5-1	EA
441-15504/060	piston assy,060,B31,6.5-1	EA
441-15544	piston assy,std,BSA B40,7-1	EA
441-15593	USE 441-17839	ea
441-15638	piston assy,std,BSA A10,10.5-1	PR
441-15638/020/ER	piston assy,+020 A10,10.5-1,econo	PR
441-15638/ER	piston assy,std,BSA A10,10.5-1,econo	PR
441-15639	piston assy,std,Tri 650,10.5-1	PR
441-15695	piston assy,std,Tri650,7.5-1,ironhd.	PR
441-15695/020	piston assy,020,Tri650,7.5-1,ironhd.	PR
441-15695/040	piston assy,040,Tri650,7.5-1,ironhd.	PR
441-15897	piston assy,std,Tri 650,7.5-1,repl.	PR
441-15897/020	piston assy,+020,Tri650,7.5-1,repl.	ST
441-15897/040	piston assy,+040,TRI650,7.5-1,repl.	ST
441-15933	piston assy,std,BSA A65,7.5-1	PR
441-15933/020	piston assy,+ .020,BSA A65,7.5-1	PR
441-15933/040	piston assy,+ .040,BSA A65,7.5-1	PR
441-15933/060	piston assy,+ .060,BSA A65,7.5-1	PR
441-15934	piston assy,std,BSA A50,9-1 *	PR
441-15934/020	piston assy,+ .020,A50	PR
441-15934/020/ER	piston assy,+020,economy *	PR
441-15934/040/ER	piston assy,+ .040,economy *	PR
441-15934/060/ER	piston assy,+ .060,economy *	PR
441-15934/ER	piston assy,std,BSA A50,econo *	PR
441-15988	USE 441-19488	ea
441-16001	pistons,l&r,std,Nor750,8.7-1,early	ST
441-16001/010	pistons,l&r,+ .010,Nor750,8.7-1,early	ST
441-16001/040	pistons,l&r,+ .040,Nor750,8.7-1,early	ST
441-16114	piston assy,std,BSA 250C15,9-1	EA
441-16114/020	piston assy,020,BSA 250C15,9-1	EA
441-16114/040	piston assy,040,BSA 250C15,9-1	EA
441-16687	piston assy,std,BSA B40,8.75-1	EA
441-16687/020	piston assy,020,BSA B40,8.75-1	EA
441-16687/040	piston assy,040,BSA B40,8.75-1	EA
441-16940	USE 441-19233	ea
441-16945	piston assy,std,Tribsa250,10-1*	EA
441-16945/020	piston assy,+ .020,uc 250	EA
441-16945/040	piston assy,+ .040,250 uc	EA
441-16945/060	piston assy,+ .060,uc 250	EA
441-16986	piston assy,std,Tri uc350,9:1	PR
441-16986/020	piston assy,020,Tri uc350,9:1	PR
441-17050	USE 441-18786	ea
441-17063	USE 441-15933	ea
441-17284	piston assy,std,C25,10.5	EA
441-17284/020	piston assy,020,C25,10.5***	EA
441-17284/040	piston assy,040,C25,10.5	EA
441-17293	piston,std,D7 Bantam,1964-66,7.5:1	EA
441-17293/020	piston,020,D7 Bantam,1964-66,7.5:1	EA
441-17380	USE 441-15123	ea
441-17555	USE 441-16945	ea

441-17791	piston assy, std, BSA B44, 9.5-1	EA
441-17791/010	piston assy, +.010, B44	EA
441-17791/020	piston assy, +.020, B44	EA
441-17791/040	piston assy, +.040, B44	EA
441-17791/060	piston assy, +.060, B44	EA
441-17797	USE 441-17844	ea
441-17839	piston set, l&r, std, Nor650, 8.9-1	ST
441-17839/020	piston set, l&r, .020, Nor650, 8.9-1	ST
441-17839/040	piston set, l&r, .040, Nor650, 8.9-1	ST
441-17839/060	piston set, l&r, .060, Nor650, 8.9-1	ST
441-17844	piston assy, std, Tri 650, 9-1	PR
441-17844/010	piston assy, +.010, Tri 650	EA
441-17844/010/A	USE 441-18514/010 Jun 14 93	ea
441-17844/010/ER	piston assy, +.010, economy	PR
441-17844/020	piston assy, +.020, Tri 650	PR
441-17844/020/ER	piston assy, +.020, economy	PR
441-17844/030	piston assy, +.030, Tri 650	PR
441-17844/040	piston assy, +.040, Tri 650	PR
441-17844/040/A	USE 441-18514/040 Jun 14 93	PR
441-17844/040/ER	piston assy, +.040, economy	PR
441-17844/060	piston assy, +.060, Tri 650	PR
441-17844/060/ER	piston assy, +.060, economy	PR
441-17844/080	piston assy, +.080, Tri 650 *	PR
441-17844/080/ER	piston assy, +.080, economy	PR
441-17844/100/ER	piston assy, +.100, economy	ST
441-17844/A	USE 441-18514 Jun 14 93	PR
441-17844/ER	piston assy, std, economy	PR
441-17897	USE 441-19916	ea
441-17911	USE 441-19916	ea
441-17952	piston assy, std, D10/D14 Bantam, 1967-69	EA
441-18289	USE 441-18782	ea
441-18290	USE 441-15123	ea
441-18514	piston assy, std, Tri650, 11-1	PR
441-18514/010	piston assy, +.010, 10.5tol	PR
441-18514/020	piston assy, +.020, 11 to 1	PR
441-18514/040	piston assy, +.040, 11 to 1	PR
441-18523	USE 441-18786	ea
441-18524	piston assy, std, TriPU 500, 9:1, repl.	PR
441-18524/020	piston assy, 020, TriPU 500, 9:1, repl.	PR
441-18524/040	piston assy, 040, TriPU 500, 9:1, repl.	PR
441-18524/060	piston assy, 060, TriPU 500, 9:1	PR
441-18526	USE 441-19233	ea
441-18527	piston assy, std, B34GS, 54on, 9-1	EA
441-18527/020	piston assy, 020, B34GS, 54on, 9-1	EA
441-18527/040	piston assy, 040, B34GS, 54on, 9-1	EA
441-18527/060	piston assy, 060, B34GS, 54on, 9-1	EA
441-18548	piston set, l&r, std, Nor500, 9.2:1	ST
441-18549	piston set, l&r, std, Nor600, 8.5:1	ST
441-18553	piston set, l&r, std, Nor600, 9:1	ST
441-18553/020	piston set, l&r, 020, Nor600, 9:1	ST
441-18553/040	piston set, l&r, 040, Nor600, 9:1	ST
441-18553/060	piston set, l&r, 060, Nor600, 9:1	ST
441-18554	piston set, l&r, std, Nor750, 10.5-1	ST
441-18554/020	piston set, l&r, +020, Nor750, 10.5-1	ST
441-18554/040	piston set, l&r, +040, Nor750, 10.5-1	ST
441-18732	piston assy, std, BSA A65, 10.5-1	PR
441-18732/020	piston assy, .020, BSA A65, 10.5-1	PR
441-18732/040	piston assy, .040, BSA A65, 10.5-1	PR
441-18782	piston assy, std, Tri uc500, 9.75-1	PR
441-18782/020	piston assy, +.020, Tri uc500, 9.75-1	PR
441-18783	USE 441-19917	ea
441-18786	piston assy, std, Tri uc500, 9-1*	PR
441-18786/010	piston assy, +.010, Tri 500	PR
441-18786/020	piston assy, +.020, Tri 500	PR
441-18786/020/A	USE 441-18782/020 Jun 14 93	PR
441-18786/020/ER	piston assy, +.020, econo	PR
441-18786/030	piston assy, +.030, Tri 500	PR
441-18786/040	piston assy, +.040, Tri 500	PR
441-18786/040/ER	piston assy, +.040, econo	PR
441-18786/060	piston assy, +.060, Tri 500	PR
441-18786/060/ER	piston assy, +.060, econo	PR

441-18786/080/ER	piston assy,+080,econo,no rings	PR
441-18786/A	USE 441-18782 Jun 14 93	PR
441-18786/ER	piston assy,std,Tri uc500,econo	PR
441-18964	USE 441-19145	ea
441-18998	piston assy,std,Tri 725	PR
441-19074	piston assy,std,Morgo 750,2.976"	PR
441-19074/020	piston assy,+020Morgo750,2.996"	PR
441-19074/040	piston assy,+040Morgo750,3.016"	PR
441-19074/060	piston assy,+060Morgo750,3.036"	PR
441-19119	piston assy,std,Tri SV500 *	PR
441-19119/020	piston assy,+020,SV500	PR
441-19119/040	piston assy,+040,SV500	PR
441-19145	piston set,l&r,std,Nor750,9-1	ST
441-19145/020	piston set,l&r,+020	PR
441-19145/020/ER	piston set,l&r,+020econo,no rings	PR
441-19145/030	piston set,l&r,+030,Nor	ST
441-19145/030/ER	piston set,l&r,+030econo	ST
441-19145/040	piston set,l&r,.040,Nor*	ST
441-19145/040/ER	piston set,l&r,+040econo,no rings	ST
441-19145/060	piston set,l&r,+060 Nor	ST
441-19145/060/ER	piston set,l&r,+060,econo,no rings	PR
441-19145/A	USE 441-18554 Jun 14 93	ST
441-19145/ER	piston set,l&r,std,econo,no rings	PR
441-19162	USE 441-19255	ea
441-19206	USE 441-19255	ea
441-19233	piston assy,std,BSA A65,9-1	PR
441-19233/010/ER	piston assy,A65+.010,econo	PR
441-19233/020	piston assy,+020,A65	PR
441-19233/020/ER	piston assy,+020,economy	PR
441-19233/030	piston assy,+030,A65	PR
441-19233/040	piston assy,+040,A65	PR
441-19233/040/ER	piston assy,+040,economy	PR
441-19233/060	piston assy,+060,A65*	PR
441-19233/060/ER	piston assy,+060,economy	PR
441-19233/080/ER	piston assy,+080,economy	PR
441-19233/A	USE 441-18732 Jun 14 93	PR
441-19233/ER	piston assy,std,economy	PR
441-19255	piston assy,std,Tri 750,8.5-1	PR
441-19255/010	piston assy,+010,Tri 750	PR
441-19255/020	piston assy,+020,Tri 750	PR
441-19255/020/ER	piston assy,Tri750,+020,econo	PR
441-19255/040	piston assy,+040,Tri 750	PR
441-19255/040/ER	piston assy,Tri750,+040,econo *	PR
441-19255/060	piston assy,+060,Tri 750	PR
441-19255/060/ER	piston assy,Tri750,+060,econo	PR
441-19255/080/ER	piston assy,+080,econo,no rings	PR
441-19255/A	USE 441-19378 Jun 14 93	PR
441-19255/ER	piston assy,Tri750,std,econo	PR
441-19257	piston assy,std,BSA B50,10-1	EA
441-19257/020	piston assy,+020,B50	EA
441-19257/040	piston assy,+040,B50	EA
441-19257/060	piston assy,+060,B50	EA
441-19285	USE 441-19074	ea
441-19342	piston assy,std,Nor 850,8.5-1	PR
441-19342/020	piston assy,+020,Nor 850	PR
441-19342/020/ER	pistons,+020,Nor850,econo,no rings	PR
441-19342/040	piston assy,+040,Nor 850	PR
441-19342/040/ER	pistons,+040,Nor850,econo,no rings	PR
441-19342/060	piston assy,+060,Nor 850	PR
441-19342/060/ER	pistons,+060,Nor850,econo,no rings	PR
441-19342/ER	pistons,std,Nor850,econo,no rings	PR
441-19378	piston assy,std,Tri 750,11-1	PR
441-19378/020	piston assy,+020,Tri 750,11-1	PR
441-19378/040	piston assy,+040,Tri 750,11-1	PR
441-19378/060	piston assy,060,Tri 750,11-1	PR
441-19488	pistons,l&r,std,Nor750,7.5-1	ST
441-19916	piston assy,std,Triples,9.5-1	ST
441-19916/010	piston assy,+010,Triples	EA
441-19916/020	piston assy,+020,Triples	ST
441-19916/020/ER	pistons,+020,triples,econo,no rings	ST
441-19916/040	piston assy,+040,Triples	ST

441-19916/040/ER	pistons,+040,triples,econo,no rings	ST
441-19916/060	piston assy,+060, Triples	ST
441-19916/060/ER	pistons,+060,triple,econo,no rings	ST
441-19916/080/ER	pistons,+080,triple,econo,no rings	ST
441-19916/ER	pistons,std,triple,econo,no rings	ST
441-19917	piston assy,std, Triple,11-1	ST
441-20432	piston assy,std,TR7/140,7.9-1	PR
441-20432/020/ER	piston assy,020,7.4-1,econo	PR
441-20432/040/ER	piston assy,040,7.4-1,econo	PR
441-20432/ER	piston assy,std,7.4-1,econo	PR
441-20895	piston assy,std, Tri TR65	PR
441-7150	piston assy,std,BSA 250SV,B2/B18 OHV	EA
441-717374	piston assy,std,TSS,9.5:1	PR
441-717651	piston assy,010,Tri TSS	PR
441-717652	piston assy,020,Tri TSS	PR
441-7504	piston assy,Aerco/Routt750(2.9916")	PR
441-7504/010	piston assy,AERCO/Routt750(3.01")	PR
441-7504/020	piston assy,AERCO/Routt750(3.02")	PR
441-7504/030	piston assy,AERCO/Routt750(3.03")	PR
441-7504/040	piston assy,AERCO/Routt750(3.04")	PR
441-7504/050	piston assy,AERCO/Routt750(3.051")	PR
441-8267	piston assy,std,BSA250 C11/12,7-1	EA
441-8267/020	piston assy,020,BSA250 C11/12,7-1	EA
441-8267/040	piston assy,040,BSA250 C11/12,7-1	EA
441-8421	piston assy,std, TriPU 500,8.5:1	PR
441-8901	pistonsetL&R,Dunstall 810	ST
441-9939	piston assy,std,B31,7.75-1	EA
442-	PISTON RINGS	*
442-----	-----	--
442-10280	ringset,std,Tri.Unit 350,2.2933"	ST
442-10280/010	ringset,010,Tri.Unit 350	ST
442-10280/020	ringset,020,Tri.Unit 350	ST
442-10280/040	ringset,040,Tri.Unit 350	ST
442-10872	ringset,std,Cub hi compr.	ST
442-10872/020	ringset,+020,Cub hi comp	ST
442-10872/040	ringset,+040,Cub hi comp	ST
442-10872/060	ringset,+060,Cub hicompr*	ST
442-10940	ringset,std,Bantaml75cc,D5/D7,2.421"	EA
442-10940/020	ringset+020,Bantaml75cc,D5/D7	EA
442-10940/030	ringset+030,Bantaml75cc,D5/D7	EA
442-10940/040	ringset+040,Bantaml75cc,D5/D7	EA
442-10940/060	ringset+060,Bantaml75cc,D5/D7	EA
442-11050	ringset,std,Tri 650	ST
442-11050/010	ringset,+010,Tri 650	ST
442-11050/010/ER	ringset,+010,economy	ST
442-11050/020	ringset,+020,Tri 650	ST
442-11050/020/ER	ringset,+020,economy rep	ST
442-11050/030	ringset,+030,Tri 650	ST
442-11050/030/ER	ringset,+030,economy rep	ST
442-11050/040	ringset,+040,Tri 650	ST
442-11050/040/ER	ringset,+040,economy rep	ST
442-11050/050	ringset,+050,Tri 650	ST
442-11050/050/ER	ringset,+050,economy rep	ST
442-11050/060	ringset,+060,Tri 650	ST
442-11050/060/ER	ringset,+060,economy repl	ST
442-11050/080	ringset,+080,Tri 650	ST
442-11050/080/ER	ringset,+080,economy rep	ST
442-11050/100/ER	ringset,+100,economy rep	ST
442-11050/ER	ringset,std,economy repl.	ST
442-11640	USE 442-23010	ea
442-11650	ringset,std,250 Jubilee,2.3622"	ST
442-11650/020	ringset,020,250 Jubilee	ST
442-11650/040	ringset,040,250 Jubilee	ST
442-13570	ringset,std,Tri unit 500	ST
442-13570/010	ringset,+010,Tri unit500	ST
442-13570/020	ringset,+020,Tri unit500	ST
442-13570/020/ER	ringset,+020,economy	ST
442-13570/030	ringset,+030,Tri.unit500	ST
442-13570/040	ringset,+040,Tri unit500	ST
442-13570/040/ER	ringset,+040,economy	ST
442-13570/060	ringset,+060,Tri unit500	ST

442-13570/060/ER	ringset,+060,economy rep	ST
442-13570/080/ER	ringset,+080,economy rep	ST
442-13570/ER	ringset,std.Tri unit 500,econo	ST
442-15110	ringset,std,350 Navigator,2.4803"	ST
442-15110/020	ringset,020,350 Navigator	ST
442-15110/040	ringset,040,350 Navigator	ST
442-15490	ringset,std,BSA B40& B44	ST
442-15490/010	ringset,+010,BSA B40&B44	ST
442-15490/020	ringset,+020,BSA B40&B44	ST
442-15490/020/ER	ringset,+020,economy rep	ST
442-15490/040	ringset,+040,BSA B40&B44	ST
442-15490/040/ER	ringset,+040,economy rep	ST
442-15490/060/ER	ringset,+060,economy rep	ST
442-17293	ringset,std,Bantam175cc,D7 3ring,2.421"	EA
442-17350	ringset,std,BSA A65[2.953	ST
442-17350/010	ringset,+010,A65[2.963in	ST
442-17350/010/ER	ringset,+010,economy rep	ST
442-17350/020	ringset,+020,A65[2.973in	ST
442-17350/020/ER	ringset,+020,economy	ST
442-17350/030	ringset,+030,A65[2.983in	ST
442-17350/030/ER	ringset,+030,economy rep	ST
442-17350/040	ringset,+040,A65[2.993in*	ST
442-17350/040/ER	ringset,+040,economy*	ST
442-17350/060	ringset,+060,A65[3.013in*	ST
442-17350/060/ER	ringset,.060,economy repl*	ST
442-17350/ER	ringset,std,economy repl.	ST
442-17360	ringset,std,BSA A50	ST
442-17360/010	ringset,+010,BSA A50	ST
442-17360/020	ringset,+020,BSA A50	ST
442-17360/040	ringset,+040,BSA A50	ST
442-17360/040/ER	ringset,+040,BSA A50,econo	EA
442-17360/060	ringset,+060,BSA A50	ST
442-18020	ringset,std,Nor 750 early*	ST
442-18020/010	ringset,+010,Nor750 early	ST
442-18020/010/ER	ringset,+010,Nor750 early,econo	ST
442-18020/020	ringset,+020,Nor750,early	ST
442-18020/020/ER	ringset,+020,Nor750 early,econo	ST
442-18020/030	ringset,+030,Nor750,early	ST
442-18020/040	ringset,+040,Nor750,early	ST
442-18020/040/ER	ringset,+040,Nor750 early,econo	ST
442-18020/060	ringset,+060,Nor750,early	ST
442-18150	ringset,std,400 Electra,2.5984"	ST
442-18150/020	ringset,.020,400 Electra	ST
442-18150/040	ringset,040,400 Electra	ST
442-2.975	ringset,std.Morgo*	ST
442-2.992	ringset,std810Dunstallkit	ST
442-2.995	ringset,+020,Morgo*	ea
442-21710	USE 442-17350	ea
442-22610	USE 442-15490	ea
442-23010	ringset,std,Tri/BSA 250	ST
442-23010/010	ringset,+010,Tri/BSA 250	ST
442-23010/020	ringset,+020,Tri/BSA 250	ST
442-23010/040	ringset,+040,Tri/BSA 250	ST
442-23010/060	ringset,+060,Tri/BSA 250	ST
442-23020	ringset,std,Tribsa Triple	ST
442-23020/010	ringset,+010,Triples	ST
442-23020/020	ringset,+020,Triples	ST
442-23020/020/ER	ringset,std,triple,econo repl.	ST
442-23020/040	ringset,+040,Triples	ST
442-23020/040/ER	ringset,+040,triples,econo	ST
442-23020/060	ringset,+060,Triples	ST
442-23020/060/ER	ringset,+060,triples,econo	ST
442-23020/ER	ringset,std,economy repl.	ST
442-23080	ringset,std,Bantam175cc,D10/D14,2.244"	EA
442-23080/030	ringset,+030,Bantam175cc,D10/D14	EA
442-26260	ringset,std,Nor 750,late	ST
442-26260/020	ringset,+020,Nor 750,late	ST
442-26260/020/ER	ringset,+020,Nor 750,late,repl*	ST
442-26260/030	ringset,+030,Nor750,late	ST
442-26260/040	ringset,+040,Nor750,late	ST
442-26260/040/ER	ringset,+040,Nor750,late,repl*	ST

442-26260/060	ringset,+0.060,Nor750,late	ST
442-26260/060/ER	ringset,+0.060,Nor750,late,repl*	ST
442-26260/ER	ringset,std,Nor 750,late,repl*	ST
442-26490	ringset,std,Tri 750 twin	ST
442-26490/010	ringset,+0.010,Tri750 Twin	ST
442-26490/020	ringset,+0.020,Tri750 twin	ST
442-26490/020/ER	ringset,+0.020,economy repl.	ST
442-26490/040	ringset,+0.040,Tri750 twin	ST
442-26490/040/ER	ringset,+0.040,economy repl.	ST
442-26490/060	ringset,+0.060,Tri750 twin	ST
442-26490/060/ER	ringset,+0.060,economy repl.	ST
442-26490/ER	ringset,std,economy repl.	ST
442-26510	ringset,std,BSA B50	ST
442-26510/020	ringset,+0.020,BSA B50	ST
442-26510/040	ringset,+0.040,BSA B50	ST
442-26730	ringset,std,Nor 850	ST
442-26730/020	ringset,+0.020,Nor 850	ST
442-26730/020/ER	ringset,+0.020,Nor850,econo	ST
442-26730/040	ringset,+0.040,Nor 850	ST
442-26730/040/ER	ringset,+0.040,Nor850,econo	ST
442-26730/060	ringset,+0.060,Nor 850	ST
442-26730/060/ER	ringset,+0.060,Nor850,econo	ST
442-26730/ER	ringset,std,Nor850,econo	ST
442-3.002	ringset,+010,Dunstall 810	ST
442-3.015	ringset,+040,Morgo	ST
442-3.035	ringset,+060,Morgo	ST
442-3.504	ringset,std,560bigboreB50	ST
442-3620	ringset,std,Bantam 125cc,2.047"	ST
442-3620/010	ringset,+0.010,Bantam125cc	ST
442-3620/020	ringset,+0.020,Bantam125cc	ST
442-3620/040	ringset,+0.040,Bantam125cc	ST
442-3630	ringset,std,BSA A7,pre51,2.4405"	ST
442-3640	ringset,std,250BSApre59	ST
442-3640/020	ringset,+0.020,pre59BSA250	ST
442-3640/040	ringset,+0.040,250BSApre59	ST
442-3640/060	ringset,+0.060,250BSApre59	EA
442-3650	ringset,std,BSA A10	ST
442-3650/010	ringset,+0.010,A10	ST
442-3650/010/ER	ringset,+0.010,A10,econo	ST
442-3650/020	ringset,+0.020,A10	ST
442-3650/040	ringset,+0.040,A10	ST
442-3650/060	ringset,+0.060,A10	ST
442-3650/070/ER	ringset,+0.070,A10,econo	ST
442-3660	USE 442-4530	ea
442-3670	ringset,std,M20,3.2283"	EA
442-3670/020	ringset,020,M20,3.2283"	EA
442-3680	ringset,std,B33,3.3464"	EA
442-3680/020	ringset,020,B33,3.3464"	ST
442-3680/040	ringset,040,B33,3.3464"	ST
442-3680/060	ringset,060,B33,3.3464"	ST
442-3730	ringset,std,Nor.500twin	ST
442-3730/010	ringset,+0.010,Nor.500twin	ST
442-3730/020	ringset,+0.020,Nor.500twin	ST
442-3730/030	ringset,+0.030,Nor.500twin	ST
442-3730/040	ringset,+0.040,Nor.500twin	ST
442-3730/060	ringset,+0.060,Nor.500twin	ST
442-3750	ringset,std,Nor500,1cyl,3.1102"	EA
442-3772/050	ringset,050,Nor500 single	ST
442-3840	ringset,std,Tri350preunit,2.1653"	ST
442-3850	ringset,std,Tri500preunit	ST
442-3850/010	ringset,+0.010,Tri 500 pu,repl.	ST
442-3850/020	ringset,+0.020,Tri 500 pu	ST
442-3850/020/ER	ringset,+0.020,Tri 500 pu,econo	ST
442-3850/040	ringset,+0.040,Tri 500 pu	ST
442-3870	USE 442-11050	ea
442-3920	ringset,std,M21,3.2283"	EA
442-39550	USE 442-26490	ea
442-39610	USE 442-17350	ea
442-4530	ringset,std,B31,2.7953"	ST
442-4540	ringset,Norton early Manx type	ST
442-4550	ringset,std,BSA A7,late	ST

442-4550/020	rings,+020,A7,late	ST
442-4550/040	rings,+040,A7,late	ST
442-4550/060	rings,+060,A7,late	ST
442-5560	ringset,std,Bantam 150cc,2.244"	EA
442-5560/020	ringset,+020,Bantam150cc	ST
442-5560/040	ringset,+040,Bantam150cc	ST
442-5560/060	ringset,+060,Bantam150cc	ST
442-5570	ringset,std,Tri T15,2.2441"	ST
442-5810	ringset,std,Tri Cub T20	ST
442-5810/020	ringset,+020,Cub	ST
442-5810/030	ringset,+030,Cub	ST
442-5810/040	ringset,+040,Cub	ST
442-5810/060	ringset,+060,Cub	EA
442-7502	ringset,3.00"Routt 750kit*	ST
442-7502/020	ringset,3.020"Routt 750kit	ST
442-7700	ringset,std,Goldstar,85mm	EA
442-7700/010/ER	ringset,+010,Goldstar,85mm,econo	EA
442-7700/020/ER	ringset,+020,Goldstar,85mm,econo	EA
442-7700/030/ER	ringset,+030,Goldstar,85mm,econo	EA
442-7700/040	ringset,+040,Goldstar,85mm	EA
442-7700/ER	ringset,std,Goldstar,85mm,econo	EA
442-7970	ringset,std,Nor 600 & 650	ST
442-7970/020	ringset,+020,Nor 600&650	ST
442-7970/040	ringset,+040,Nor 600&650	ST
442-7970/060	ringset,+060,Nor 600&650	ST
442-9252	ringset,stdRoutt825(3.12"	ST
442-997567	ringset,std,TSS 8valveTri*	ST
442-997568	ringset,+010,TSS 8 valve	ST
442-997569	ringset,+020,8valve TSS	ST
443-	CYLINDER SLEEVES	*
443-----	-----	---
443-134	sleeve,cyl,ARIEL 500 single,82mm	EA
443-142	sleeve,cyl,Norton 600/650	EA
443-143	sleeve,cyl,Nor 850	EA
443-161	sleeve,cyl,RE 750,71mm	EA
443-162	sleeve,cyl,VELO 500,86mm	EA
443-165	sleeve,cyl,BSA B33	EA
443-173	sleeve,cyl,B44,sq. barrel	EA
443-174	sleeve,cyl,BSA A50	EA
443-175	sleeve,cyl,BSA A65	EA
443-176	sleeve,cyl,Tri/BSA triple	EA
443-177	sleeve,cyl,BSA A10*	EA
443-180	sleeve,cyl,TriBSA 250,pre69	EA
443-182	sleeve,cyl,Goldstar 500,shortrod	EA
443-184	sleeve,cyl,Ariel SQ4	EA
443-185	sleeve,cyl,Tri500 alloyPU*	EA
443-186	sleeve,cyl,B44 roundbarrel	EA
443-187	sleeve,cyl,TriBSA 250,69on	EA
443-188	sleeve,cyl,VINCENT,3.312"	EA
443-199	sleeve,cyl,T150 type bigbore kit	EA
443-206	sleeve,A7,pre1951	EA
443-214	sleeve,cyl,Nor 750	EA
443-227	sleeve,cyl,Dunstall 810	EA
443-234	sleeve,cyl,B50/TR5MX,84mm	EA
443-248	sleeve,cyl,Goldstar 500,longrod	EA
443-290	sleeve,cyl,Tri 500 unit	EA
443-291	sleeve,cyl,Tri 650	EA
443-328	sleeve,cyl,B50/TR5MX bigbore,89mm	EA
443-480/A	sleeve,cyl,Cub&Tri500 iron,PU	EA
443-482	sleeve,cyl,A7,51on&NOR 500	EA
443-483	sleeve,cyl,Tri 750 twin	EA
443-5486	sleeve,cyl,G80,late,86mm	EA
443-5522	sleeve,cyl,G80,late,82.5mm	EA
443-5529	sleeve,cyl,Manx,late,86mm	EA
443-56	sleeve,cyl,AJS/Match 650	EA
443-750	sleeve,cyl,T120 bigbore kit	EA
443-791	sleeve,cyl,Nor 500 iron 1cyl	EA
443-821	sleeve,cyl,BSA M20/21	EA
443-925	sleeve,cyl,TriTSS 8valve	EA
451-	VALVE SPRING SETS,STOCK	*
451-----	-----	---

451-279	spring set, valve, tri twin	ST
451-343	spring set, valve, Nor CS1	ST
451-421	spring set, valve, 48-58 NorOHVsingle	EA
451-454	spring set, valve, BSA A10	ST
451-463	spring set, valve, BSA A10R	ST
451-466	spring set, valve, Cub & Terrier	ST
451-488	spring set, valve, BSA 441/500ohv	ST
451-501	spring set, valve, 1949-61 Nor.Twin	ST
451-510	spring set, valve, tri twin	ST
451-514	spring set, valve, tri 350	ST
451-531	spring set, valve, C15/B40	ST
451-531/A	spring set, valve, A50/65, pre67*	ST
451-537	spring set, valve, tri 500	ST
451-574	spring set, valve, Tri twin	ST
451-615	spring set, valve, Tri.unit500	ST
451-641	spring set, valve, A50/A65, 67on	ST
451-646	spring set, valve, tri6/750	ST
451-647	spring set, valve, 1 cyl250	ST
451-720	spring set, valve, 62on Nor.twin	ST
451-720/A	springset, valves, genuine Norton*	ST
451-724	spring set, valve, 3 cyl750	ST
451-997570	spring set, valve, TSS 8v1v	ST
452-	VALVE GUIDES	*
452-----	-----	--
452-01	guide, nickel/brz, 6/750Tri	EA
452-01/002	guide, oversize, .002	EA
452-01/004	guide, oversize, .004	EA
452-01/006	guide, oversize, .006	EA
452-01/010	guide, oversize, .010	EA
452-01/015	guide, oversize, .015	EA
452-01/050	guide, oversize, .050	EA
452-01/A	guide, nickel/brz, 6/750 Tri, seal type*	EA
452-02	guide, bronze, T140E	EA
452-02/001	guide, bronze, +.001, T140E	EA
452-02/002	guide, bronze, +.002, T140E	EA
452-02/004	guide, bronze, +.004, T140E	EA
452-02/006	guide, bronze, +.006, T140E	EA
452-02/015	guide, bronze, +.015, T140E	EA
452-269	guide, cast, in&x, ES2&Mod18	EA
452-355	guide, C11, C11G, C12, 1939-58, I&X	EA
452-420	guide, cast, in, Tri 650	EA
452-420/PB	guide, bronze, in, Tri. 650	EA
452-424	guide, cast, x, Tri 650	EA
452-424/PB	guide, bronze, x, Tri. 650	EA
452-432	guide, cast, BSA M20/21	EA
452-454	guide, cast, I&X, Nort.twin, early	EA
452-457	guide, cast, B31/32, inlet	EA
452-458	guide, cast, B31/32, exhaust	EA
452-460	guide, cast, B33, B34, M33, 1946-58	EA
452-461	guide, cast, TriCub, 350/500, C15	EA
452-461/002	guide, oversize, .002	EA
452-461/004	guide, oversize, .004	EA
452-461/006	guide, oversize, .006	EA
452-461/008	guide, oversize, .008	EA
452-461/015	guide, oversize, .015	EA
452-461/035	guide, oversize, .035	EA
452-461/PB	guide, brz, Tri Cub, 350/500, C15	EA
452-477/PB	guide, brz, x, Velo	EA
452-478	guide, cast, BSA A7/A10	EA
452-478/002	guide, oversize, .002	EA
452-478/004	guide, oversize, .004	EA
452-478/PB	guide, bronze, BSA A7/A10	EA
452-510	guide, cast, BSA unit sing.	EA
452-510/002	guide, brz, BSA unit 1cyl, 002	EA
452-510/PB	guide, brz, BSA unit single*	EA
452-516	guide, cast, BSA A50/65	EA
452-516/002	guide, oversize, .002	EA
452-516/004	guide, oversize, .004	EA
452-516/006	guide, oversize, .006	EA
452-516/050	guide, oversize, .050	EA
452-516/PB	guide, brz., BSA A50/65	EA

452-537/002	guide,oversize,.002	EA
452-537/PB	guide,brz,in,BSA Goldstar	EA
452-538/002	guide,oversize,.002	EA
452-538/PB	guide,brz,x,BSA goldstar	EA
452-539/002	guide,oversize,.002	EA
452-539/004	guide,oversiz,.004	EA
452-539/010	guide,oversize,.010	EA
452-539/015	guide,oversize,.015	EA
452-539/PB	guide,brz,1 cyl.250 uc	EA
452-540/002	guide,oversize,.002	EA
452-540/004	guide,oversize,.004	EA
452-540/006	guide,oversize,.006	EA
452-540/015	guide,oversize,.015	EA
452-540/PB	guide,brz,3 cyl.x	EA
452-540/PB/A	guide,brz,for seal	EA
452-542/002	guide,oversize,.002	EA
452-542/004	guide,oversize,.004	EA
452-542/PB	guide,brz,BSA A65,71 up	EA
452-543	guide,cast,Nor 750,in.	EA
452-543/002	guide,oversize,.002	EA
452-543/004	guide,oversize,.004	EA
452-543/005	guide,oversize,.005	EA
452-543/006	guide,oversize,.006	EA
452-543/010	guide,oversize,.010	EA
452-543/015	guide,oversize,.015	EA
452-543/PB	guide,brz,Nor 750 inlet	EA
452-544	guide,cast,x,Nort 750*	EA
452-544/002	guide,oversize,.002	EA
452-544/004	guide,oversize,.004	EA
452-544/006	guide,oversize,.006	EA
452-544/010	guide,oversize,.010	EA
452-544/015	guide,oversize,.015	EA
452-544/PB	guide,brz,x,Norton 750	EA
452-545/PB	guide,brz,in,Tri 650/750	EA
452-546/PB	guide,brz,x,Tri 650/750	EA
452-547	guide,cast,in,Norton 850	EA
452-547/002	guide,oversize,.002	EA
452-547/004	guide,oversize,.004	EA
452-547/006	guide,oversize,.006	EA
452-547/015	guide,oversize,.015	EA
452-547/PB	guide,brz,in,Norton 850	EA
452-548	guide,cast,x,Nort 850	EA
452-548/002	guide,oversize,.002	EA
452-548/004	guide,oversize,.004	EA
452-548/006	guide,oversize,.006	EA
452-548/015	guide,oversize,.015	EA
452-548/PB	guide,brz,x,Nort 850	EA
452-604/PB	guide,bronze,T140E	EA
452-605/PB	USE 452-02	ea
452-606/002	guide,oversize,.002	EA
452-606/004	guide,oversize,.004	EA
452-606/006	guide,oversize,.006	EA
452-606/010	guide,oversize,.010	EA
452-606/PB	guide,brz,late 250 1 cyl.intake	EA
452-607/002	guide,oversize,.002	EA
452-607/004	guide,oversize,.004	EA
452-607/006	guide,oversize,.006	EA
452-607/010	guide,oversize,.010	EA
452-607/PB	guide,brz,late 250 1 cyl.X	EA
452-703062	guide,cast,Tri 500 TRW	EA
452-712231	USE 452-607/PB	ea
452-717346	guide,brz,Tri TSS 8vlv,seal type	EA
452-717346/002	guide,oversize,.002	EA
452-717346/004	guide,oversize,.004	EA
452-717346/006	guide,oversize,.006	EA
452-717346/015	guide,oversize,.015	EA
452-717347	guide,brz,x,Tri TSS 8valv	EA
453-	VALVES	*
453-----	-----	--
453-12	valve,in &x,C11,C11G,C12	EA
453-127	valve,in,1956-59 A10 SR	EA

453-128	valve,x,A10 Super Rocket	EA
453-128/A	valve,x,A10SuperRocket,performance	EA
453-135	valve,in,3TA & T21 only	EA
453-136	valve,x,350cc T21,3TA,T90	EA
453-137	valve,in,Tri 650 early	EA
453-138	valve,x,Tri 650,early*	EA
453-14	valve,in&x,5T/T100preunit	EA
453-15	valve,in,1957on BSA A7	EA
453-16	valve,exh,1952 on BSA A7	EA
453-169	valve,in,BSA C15,early	EA
453-17	valve,in,A10,early	EA
453-170	valve,x,BSA C15	EA
453-18	valve,x,A10,early	EA
453-183	valve,in,Norton unit twin	EA
453-184	valve,x,Norton unit twins	EA
453-186	valve,x,Enfield 500 & 700	EA
453-187	valve,in,Tri uc 500,early	EA
453-188	valve,x,Tri uc 500,early	EA
453-191	valve,in,Cub,1959 onward	EA
453-195	valve,in,Nor500-650,60on	EA
453-195/A	valve,in,Nor500-650,60on,performance	EA
453-20	valve,x,M20/21	EA
453-211	valve,in,BSA B40,early	EA
453-212	valve,x,BSA B40&early B44	EA
453-215	valve,in,1960 on A10 SR*	EA
453-215/A	valve,in,60onA10SR,performance	EA
453-215/OS	valve,inlet,+060,A10 SR	EA
453-223	valve,in,SS90&early B44	EA
453-224	USE 453-255	ea
453-225	valve,x,BSA A50,early	EA
453-226	valve,in,BSA A65 early	EA
453-23	valve,in,Tri 650,early	EA
453-232	valve,in,350cc Tiger 90	EA
453-24	valve,x,Tri 650/750	EA
453-24/A	valve,x,Tri650/750,performance	EA
453-24/ER	valve,x,Tri 650/750,econo.repl.	EA
453-24/N	valve,x,nimonic steel	EA
453-24/OS/SS	valve,x,+060,stainless	EA
453-24/SS	valve,x,stainless steel	EA
453-240	valve,in,Norton 750,early	EA
453-240/A	valve,in,hardchromed stem	EA
453-240/OS	valve,in,+060,Nor,early	EA
453-243	valve,in,BSA DBD34,all	EA
453-244	valve,x,BSA DBD34,all	EA
453-244/A	valve,x,BSA DBD34,all,performance	EA
453-245	valve,in,Tri 650/750	EA
453-245/A	valve,in,Tri650/750,performance	EA
453-245/ER	valve,in,Tri 650/750,econo.repl.	EA
453-245/OS	valve,in,+060 oversize	EA
453-245/OS/SS	valve,in,+060,stainless	EA
453-245/SS	valve,in,stainless steel	EA
453-253	valve,in,BSA A65 late	EA
453-253/A	valve,in,performance	EA
453-253/SS	valve,in,stainless steel	EA
453-254	valve,x,BSA A65,late	EA
453-254/A	valve,x,performance	EA
453-254/SS	valve,x,stainless steel	EA
453-255	valve,in,A50& Tribsa 250	EA
453-256	valve,x,A50& Tribsa 250	EA
453-26	valve,in,1948-59Nort Twin	EA
453-263	valve,in,Nort 750/850	EA
453-263/A	valve,in,Nort750/850,performance	EA
453-263/OS/SS	valve,in,+60,stainless	EA
453-263/SS	valve,in,stainless steel	EA
453-264	valve,x,Nor 750/850	EA
453-264/A	valve,x,Nor 750/850,performance	EA
453-264/OS/SS	valve,x,oversize,stainless	EA
453-264/SS	valve,x,stainless steel	EA
453-265	valve,in,Tri uc 500,late	EA
453-265/A	valve,in,TriUnit500,late,performance	EA
453-265/OS/SS	valve,in,+060,stainless	EA

453-265/SS	valve,in,stainless steel	EA
453-266	valve,x,TriUnit500,late	EA
453-266/A	valve,x,TriUnit500,late,performance	EA
453-266/OS/SS	valve,x,+.050,stainless	EA
453-266/SS	valve,x,stainless steel	EA
453-267	USE 453-256	ea
453-268	valve,in,B44,late	EA
453-269	valve,x,B44,late	EA
453-27	valve,x,Norton twin,early	EA
453-27/A	valve,x,NortonTwin,early,performance	EA
453-270	valve,in,Triple,earlylong	EA
453-270/A	valve,in,hardchromed stem	EA
453-270/OS/SS	valve,in,+.060,stainless	EA
453-270/SS	valve,in,stainless steel	EA
453-271	valve,x,Triple,early,long	EA
453-271/A	valve,x,hardchromed stem	EA
453-271/OS/SS	valve,x,+.090,stainless *	EA
453-271/SS	valve,x,stainless steel	EA
453-272	valve,in,B50	EA
453-273	valve,x,B50	EA
453-282	valve,in,triple,lateshort	EA
453-282/A	valve,in,performance	EA
453-282/OS/A	valve,in,+.110,hardchrome	EA
453-282/OS/SS	valve,in,+.060,stainless	EA
453-282/SS	valve,in,stainless steel	EA
453-283	valve,x,triple,late,short	EA
453-283/A	valve,x,performance	EA
453-283/OS/A	valve,x,+.090,hardchromed	EA
453-283/OS/SS	valve,x,+.090,stainless	EA
453-283/SS	valve,x,stainless steel	EA
453-37	valve,in&x,Nort.OHV 1 cyl	EA
453-42	valve,in,BSA350ccB31/32	EA
453-43	valve,x,BSA350ccB31/32	EA
453-48	valve,in,Cub,pre.1959	EA
453-49	valve,x,Cub & Terrier,all	EA
453-660235	valve,in,M20/21	EA
453-702382	valve,in,Tri 500 TRW	EA
453-702383	valve,x,Tri 500 TRW	EA
453-717288	valve,in,Tri TSS 8 valve	EA
453-717295	valve,x,Tri TSS 8 valve	EA
461-	BIG BORE KITS	*
461-----	-----	--
461-01	750 bigbore kit,Tri.650,MORGO*	ST
461-01/A	750bigbore kit,Tri650,AERCO*	ST
461-01/B	750 bigore kit,Tri.650,alloy	EA
461-02	825 kit,Triumph 750 Twin	ST
461-021	pin,piston,Morgo	EA
461-022	gasket,cylinderhead,Morgo,037"	EA
461-022/A	gask,cyl.hd,Morgo low comp,068"	EA
461-022/B	gask,cyl.hd,Morgo hicompr,025"	EA
461-023	gasket,cylinderhead,Routt/Aerco	EA
461-024	gasket,cyl.hd,Dunstall 810	EA
461-03	530 bigbore kit,Tri500,late style*	EA
461-04	bigbore kit,BSA B50,570cc	ST
461-05	867 kit,3 cylinder *	ST
461-07	750 kit,BSA A65	ST
461-08	850kit,A65,inc.crankshaft	ST
461-09	920 kit,Norton 850,components	ST
462-	VALVE COMPONENTS,HI-PERF.	*
462-----	-----	---
462-01	valve lash caps,hardened	EA
462-02	rock.spacer kit,Tri.6/750&Norton	ST
462-03	rocker spacer kit,3 cyl.	ST
462-04	rockerSpacerKitTri500unit	ST
462-05	rocker spacer kit,A50&A65	ST
462-12	shim,vlv.spr,BSA A50 &A65pre71	EA
462-13	shim,valve spring,.685"ID	EA
462-14	shim,valve spring,BSA A10	EA
462-15	shim,valve spring,.510"ID	EA
462-16	shim,valve spring,Nort850	EA
462-20	valve,guide&spr.set,7mmT120/140	ST

462-21	valve,guide&spr.set,7mmT100R	ST
463-	CAMSHAFTS,HI-PERFORMANCE	*
463-----	-----	---
463-01	cams,Tri6/750,Hydel/2race	PR
463-02	USE 463-51060	ea
463-11	adaptor kit,needlebrg,Nort cam	EA
463-12	gear,cam,B25/50,alloy	EA
463-51000	cams,Tri6/750,Mega 51005,outright	ST
463-51005	USE 463-51000	ea
463-51015	cams,Tri.6/750,KH15,outright	ST
463-51060	cams,Tri6/750,Mega1065,outright	ST
463-51060/A	USE 463-51060	ST
463-51065	USE 463-51060	ea
463-51070	cams,Tri650/750,Mega1070,outright	ST
463-51075	USE 463-51070	ea
463-51080	cams,Tri6/750,Mega1080,outright *	PR
463-51085	USE 463-51080	ea
463-510N480	cams,Tri6/750,Norris 580,outright	PR
463-51100	cams,TriBSA 3cyl,Mega1105,outright	ST
463-51105	USE 463-51000	ea
463-51135	cams,TriBSA 3cyl,Mega1135,outright	ST
463-51175	cams,TriBSA 3cyl,Mega1175,outright	ST
463-511X5	cams,TriBSA 3cyl,Mega11X5,outright	ST
463-51230	USE 463-51260	ea
463-51230/A	USE 463-51260	ea
463-51260	cams,unitTri500,Mega1260,billet	ST
463-51265	USE 463-51260	ea
463-541X1	cam,TriBSA unit single,lg.journal*	EA
463-541X1/A	cam,TriBSA unit single,sm.journal*	EA
463-541X8	cam,TriBSA unit single,lg.journal*	EA
463-541X8/A	cam,TriBSA unit single,sm.journal*	EA
463-54200	cam,BSA A50/65,Mega542-00,outright	EA
463-542X1	cam,BSA A50/65,Mega542x1,outright	EA
463-542X2	cam,BSA A50/65,Mega 542X2,outright	EA
463-542X2/A	cam,BSA A10,Mega 542X2,exchange	EA
463-543X1	cams,Gold Star Clubman,regrind	PR
463-56000	cam,70onCommando,Mega6000,outright*	EA
463-56000/A	cam,pre70 Norton,Mega6000,exchange	EA
463-560N480	cam,70onNort,Norris480,SPECIAL ORDER*	EA
463-560NR	cam,Nort,70on Norris R,outright*	EA
463-560NSS	cam,70onNort,Norris SS,outright*	EA
463-560NSS/A	cam,pre70Nort,Norris SS,exchange*	EA
463-560SS	cam,70onNort,Megacycle SS,outright*	EA
463-CORE	core chg,camshaft	EA
463-KH54	cams,unit Tri.T100R,KH#54,billet	ST
464-	VALVE SPRINGKITS,HI-PERF.	*
464-----	-----	---
464-01	spr.kit,compl,Tri6/750,PM	ST
464-01/A	spring kit,Tri6/750,titanium,RD	ST
464-02	spr.kit,compl,Nor7/850,PM	ST
464-02/A	spring kit,Nor.7/850,TRI6/750/HYDE*	ST
464-02/B	spr.kit,Nor7/850,titanium,RD,compl.	ST
464-021	spr.kit,bare,Nor7/850,PM	ST
464-03	springkit,comp,750 3,Hyde	ST
464-03/B	springkit,compl,750 3,RD	ST
464-04	spr.kit,compl,Tri.unit500,early,RD	ST
464-05	springkit,A65BSA,titanium,RD	ST
464-05/A	springkit,bare,A65BSA,etc.RD*	ST
464-06	spring kit,B50,titanium,RD*	ST
464-07	spring kit,B44,titanium,RD	ST
464-08	spr.kit,lateT100R,compl	ST
464-08/A	spr.kit,lateT100R,titanium,RD	ST
464-08/B	spr.kit,lateT100R,titanium,PM	ST
464-09	springkit,Goldstar,titanium,RD	ST
464-10	spring kit,B25/T25,titanium,RD	ST
464-11	spring kit,A10R,titanium,RD	ST
465-	BELT DRIVE KITS & PARTS,FRONT	*
465-----	-----	---
465-01	beltdrive,unit Tri6/750twin,29MM	ST
465-01/A	beltdrive,unit Tri6/750,alloy,29MM,14plt	ST
465-01/C	beltdrive,unit Tri6/750twin,25MM	ST

465-01/D	beltdrive,unit750,alloy,32mm,14 plate	EA
465-011	belt,replacement,6/750 Tri unit,29MM	EA
465-012	belt,replacement,6/750 Tri unit,25MM	EA
465-02	beltdrive,preunit Triumph,short*	ST
465-02/A	beltdrive,preunit Tri,alloy,short,12 plt	ST
465-021	belt,replacement,TriPreunit,short	EA
465-03	beltdrive,Tri.unit 500,alloy,12 plate	ST
465-031	belt,replacement,TriUnit500	EA
465-04	beltdrive,preunit Triumph,long*	ST
465-04/A	beltdrive,preunit Tri,alloy,long,12plate	ST
465-041	belt,replacement,TriPreunit,long	EA
465-07	beltdrive,BSA A50/65,alloy,30MM,14 plate	ST
465-071	belt,replacement,A50/65	EA
465-08	beltdrive,C15,B25,B44 etc*	EA
465-081	belt,replacement,unit single	EA
465-09	beltdrive,Norton Commando,pre75,alloy*	ST
465-091	belt,replacement,CommandoPre75	EA
465-10	beltdrive,Nor.Mk3 kick only,alloy*	EA
465-101	belt,replacement,CommandoMk3	EA
465-11	beltdrive,TRIBSAtriple,alloy*	EA
465-11/A	beltdrive,TRIBSA3cyl,iron	EA
465-111	belt,repl,TRIBSAtriple	EA
465-12	beltdrive,preCommando*	EA
465-121	belt,repl,preCommando	EA
465-13	beltdrive,B50.TR5MX	EA
465-500-11	beltdrive,B50.TR5MX	EA
465-650-11	beltdrive,QPD,A50/65	EA
465-650-12	beltdrive,A7/10 swingarm	EA
465-650-13	beltdrive,A7/10 dynamo drive	EA
465-650-2	belt,repl,preCommando,QPD	EA
465-650-22	beltdrive,QPD,preCommando	EA
465-750-1	belt,repl.unit 6/750 Tri,QPD	EA
465-750-11	beltdrive,QPD,T120/140	ST
465-750-2	belt,repl,pre75Comm&PunitTriS.A,QPD	EA
465-750-22	beltdrive,pre75Commando,QPD,compl.	EA
465-750-3	belt,repl,A50/65&T100R,QPD	EA
465-750-3/A	belt,repl,A50/65&T100R,QPD,RACE ONLY	EA
465-750-33	beltdrive,QPD,T100R	EA
465-750-33/A	beltdrive,QPD,T100R,race only	EA
465-750-44	beltdrive,QPD,preunit,short	EA
465-750-5	belt,repl,rigid PU Tri	EA
465-750-55	beltdrive,QPD,rigid p.unitTRI	EA
465-850-3	belt,repl,QPD,MK3 ES	EA
465-850-33	beltdrive,QPD,850MK3 ES	EA
465-PINS	pins,beltdrive,hardened	ST
465-PLATE/01	clutchplate,plain,beltdrive	EA
465-PLATE/02	clutchplates,friction,beltdrive,7	ST
465-PLATE/03	clutchplates,friction,beltdrive,6	ST
466-	BELTDRIVE KITS AND PARTS,REAR	*
466-----	-----	---
466-01	beltdrive,rear,76onTR7/140	EA
466-02	beltdrive,rear,Commando,pre75	EA
471-	TRANSMISSIONS	*
471-----	-----	---
471-01	gearset,650Tri.4spd,CR	ST
471-02	gearset,650Tri.4spd,STD	ST
471-03	gearset,650Tri.4spd,WIDE	ST
471-04	gearset,3cyl.4spd,STD	ST
471-05	gearset,unit500Tri4spd,STD.	ST
471-06	gearset,3cyl.5spd	ST
471-07	gearset,Tri.5spd,twins	ST
471-08	gearset,AMC,5speed	ST
471-09	gears,Tri.5spd,CR conversion	ST
472-	BURMAN GEARBOX PTS	*
472-----	-----	---
473-	QUAIFE GEARBOX PTS.	*
473-----	-----	---
481-		*
481-----	-----	---
511-	SEATS,STOCK	*
511-----	-----	---

511-01	seat,T140V with UK tank	EA
511-02	seat,Fastback Long Range	EA
511-02/A	seat,Fastback LR,Leighton	EA
511-029449	seat,G15/N15	EA
511-03	seat,P11A Ranger,1968	EA
511-032134	seat,single,67 P11 Cheetah	EA
511-032271	seat,N15CS	EA
511-034021	seat,P11A,67/8	EA
511-061168	seat,1969/70 Comm.R,S&Roadster *	EA
511-061770	seat,Nort.Interpol	EA
511-100	seat,Atlas with hump *	EA
511-100/A	seat,Atlas w/hump,Leighton	EA
511-101	seat,Nort.Comm.Fastback	EA
511-101/A	seat,Nort.Fastback,Leighton	EA
511-102	seat,1971/72 Comm.Roadster *	EA
511-102/A	strap,seatcover,Commando	EA
511-103	seat,1972 Comm.Interstate	EA
511-104	seat,Nor slimline,62-66*	EA
511-104/A	seat,Nor slimline,62-66,Leigton	EA
511-105	seat,Nort.wideline featherbed	EA
511-106	seat,Commando Hi-Rider *	EA
511-107	seat,73 Commando Roadster	EA
511-108	seat,73 Comm. Interstate	EA
511-130	seat,Nor.pre featherbed s.arm	EA
511-154	seat,74 Commando Roadster	EA
511-154/ER	seat,74 Commando Roadster,econo.repl.	EA
511-155	seat,75 Comm.Roadster Mk3	EA
511-155/ER	seat,75 Comm.Roadster Mk3,econo.repl.	EA
511-156	seat,1974 Comm.Interstate	EA
511-156/ER	seat,1974 Comm.Interstate,econo.repl.	EA
511-162	seat,Comm.Interstate Mk3	EA
511-162/ER	seat,Comm.Interstate Mk3,econo.repl.	EA
511-200	seat,preunit Tri,swingarm,short	EA
511-201	seat,preunit Tri,swingarm,long	EA
511-201/A	seat,preunit Tri,SA,long,Leighton	EA
511-202	seat,blkw/greytop,TriTwins,smooth	EA
511-202/A	seat,blkw/greytop,Twins,64-66Leighton	EA
511-202/B	seat,blkw/greytop,Twins,Leighton	EA
511-202/C	seat,blk,TriTwins,wht.piping,Leighton	EA
511-202/D	seat,blk,TriTwins,blk.piping,Leighton	EA
511-203	seat,1978-80 T140V/E USA *	EA
511-204	seat,T140US,1978,brown	EA
511-208	seat,Triumph250,pre'71	EA
511-209	seat,60onT120/TR6preunit,greystop	EA
511-210	seat,Tri250,1971	EA
511-211	seat,greystop,67 T120	EA
511-257	seat,69/70 Tri.twin,long	EA
511-257/A	seat,Trident&Twins,short *	EA
511-257/A/ER	seat,Trident&Twins,short,econo.repl.	EA
511-257/B	seat,69/70 Tri.twin,short,Leighton*	EA
511-257/C	seat,66/68 Tri.twin,short,Leighton	EA
511-257/D	seat,67 Tri.twin,short,black trim strip	EA
511-257/D/ER	seat,67 Tri.twin,short,blk,econo.repl.	EA
511-259	seat,73-77 Tri.750 Twin	EA
511-259/ER	seat,73-77 Tri.750 Twin,econo.repl.	EA
511-260	seat,71/72 Tri650,US,clip type,RH hinge*	EA
511-260/A	seat,71/72Tri650,UK*	EA
511-261	seat,Triumph T160V	EA
511-300	seat,earlyA7/10,Gold Star(narrow)	EA
511-300/A	seat,earlyA7/10,GS,Leighton(narrow)	EA
511-300/ER	seat,earlyA7/10,Gold Star,econo.repl.	EA
511-301	seat,pre66A50/65,flat	EA
511-301/A	seat,pre66A50/65,flat,Leighton	EA
511-302	seat,71BSA twin,USA,smooth *	EA
511-305	seat,B25/50T&SS,71on*	EA
511-306	seat,BSA B25/B44 w/hump *	EA
511-306/A	seat,BSA B25/B44 w/hump,Leighton*	EA
511-307	seat,late A10SR&RGS,wide	EA
511-307/A	seat,late A10SR&RGS,wide,Leighton	EA
511-364	seat,pre71BSA twin,w/hump*	EA
511-364/A	seat,pre71BSA twin,w/hump,Leighton	EA

511-364/B	trim,chrome,seat,hump style A50/65	PR
511-364/ER	seat,pre71BSA twin,w/hump,econo.repl.	EA
511-365	seat,BSA twin,USA,72,quilted *	EA
511-401	seat,Ariel 650,etc.	EA
511-501	seat,Vincent "C" model	EA
511-601	seat,Enfield Interceptor MK1A	EA
511-602	seat,Enfield Interceptor MK2	EA
511-760	seat,Velo,flat	EA
511-763	seat,Velo Thruxton	EA
511-823119	seat,solo,rigid,w/springs,econo*	ST
511-824272	seat,Cub,1963on,greypop	EA
511-828942	seat,A75,pre71,for UKtank*	EA
511-832746	seat,B50MX,short	EA
511-833438	seat,A75 UK,71on,flat top	EA
511-833853	seat,A75,71onUS,with hump	EA
511-834599	seat,T120V,plunger type,widenose	EA
511-834732	seat,TR5T Trophy Trail (Adventurer)	EA
511-837391	seat,T140D&81-83TriUSw/ks	EA
511-837598	seat,T140D&81-83TriUKw/ks	EA
511-838377	seat,TSX style,T140	EA
512-	SEAT COVER KITS	*
512-----	-----	--
512-01	seatcover,Norton HiRider	EA
512-02	seatcover,Rocket3,pre71	EA
512-04	seatcover71onT120widenose	EA
512-05	USE 512-2044	ea
512-06	seatcov,preoilfr.Tri,long*	EA
512-061168/COV	seatcover,69/70 Comm.R,S&Roadster	EA
512-07	seatcov,POIF Tri,short*	EA
512-08	seatcover,Atlas,with hump	EA
512-09	seatcover,slim featherbed	EA
512-10	seatcover,Norton Jubilee	EA
512-1001	seatcover,1974 Roadster *	EA
512-1002	seatcover,850Mk3 Roadster	EA
512-1003	seatcover,1974 Interstate*	EA
512-1004	seatcover850Mk3Interstate	EA
512-1006	seatcover,1973 Interstate	EA
512-1007	seatcover,71-72 Roadster	EA
512-1008	seatcover,1972 Interstate	EA
512-1009	seatcover,Nort.Fastback	EA
512-1009/A	seatcover,Nort.FastbackLR	EA
512-1010	seatcover,1973 Roadster	EA
512-1061	seatcover,wide featherbed	EA
512-196050	seatcov,A75US,71on,w/hump	EA
512-2001	seatcover,Silver Jubilee T140SJ*	EA
512-2005	USE 512-2044	ea
512-2044	seatcov,71-77 US 6/750 tw	EA
512-2075	seatcover,X75 Hurricane	EA
512-2093	seatcover,Triumph T160V	EA
512-2107	seatcover,78-80TR7V&T140V&E,US	EA
512-2107/A	seatcov,78-80TR7V&T140V US,brown	EA
512-3001	seatcover,BSA Twin w/hump,pre71*	EA
512-3003	seatcov,A75 UK,71on,flat	EA
512-3004	seatcover,1971BSAtwin	EA
512-3004/A	seatcover,1972BSAtwin	EA
512-3009	seatcover,B25&B44,w/hump	EA
512-3009/A	seatcover,B25&B44,w/hump,grey	EA
512-3010	seatcover,B25/50T&SS,71on	EA
512-3072	seatcover,BSA A50/65,flat,pre67*	EA
512-6001	seatcover,Enfield Interceptor	EA
512-823153/COV	seatcover,50-54 SpeedTwin	EA
512-823234	seatcover,solo saddle	EA
512-823234/ER	seatcover,solo saddle,econo repl.*	EA
512-823654	seatcover,1954-59 TriT110	EA
512-824104	seatcover,1963-68 T20 Cub	EA
512-824244	seatcov,greypop,smooth,pre67	EA
512-827489	seatcov,blk,ribbed,67TR6C,T120TT	EA
512-827777	seatcov,greypop,ribbed 67 T120	EA
512-829504	seatcover,pre71Triumph250	EA
512-832746/COV	seatcover,B50MX,short	EA
512-833349	seatcover,71 Triumph 250	EA

512-834737	seatcover,TR5T Trophy Trail (Adventurer)	EA
512-837086	seatcover,Silver Jubilee UK	EA
512-837132	seatcover,78-80TR7&T140uk	EA
512-837392	seatcover,T140D SpecialUS	EA
512-837595	seatcover,81-83TR7&T140uk	EA
512-838379	seatcover,1982-83Tri.TSX	EA
513-	SEATS,BOLTON,CUSTOM&TOUR.	*
513-----	-----	---
513-01	seat,custom,Tri.750 Twin *	EA
513-011	seat,custom,850Mk3 Roadster	EA
513-02	seat,cust, POIF Tri2&3cyl	EA
513-03	USE 513-02	EA
513-04	seat,custom,pre'71 A65	EA
513-05	seat,custom,71 on T120,clip type	EA
513-05/A	seat,custom,72 T120V,LH plunger	EA
513-06	seat,custom,pre75Roadster	EA
513-07	seat,custom,850Mk3 Inter*	EA
513-08	seat,custom,71onA65	EA
513-09	seat,custom,pre75Interstate	EA
513-11	seat,racing,A65 Clubman *	EA
513-12	seat,racing,Roadster,kick,solo	EA
513-12/A	seat,racing,Roadster,kick,dual	EA
513-13	seat,racing,TR7/T140,solo	EA
513-13/A	seat,racing,TR7/T140,dual	EA
513-14	seat,racing,PreOilFr.Tri,solo	EA
513-14/A	seat,racing,PreOilFr.Tri,dual	EA
513-15	seat,racing,71on T120R,solo	EA
513-15/A	seat,racing,71on T120R,dual	EA
513-16	seat,racing,Inter,kick,solo	EA
513-16/A	seat,racing,Inter,kick,dual	EA
513-17	seat,racing,Slimline Norton	EA
513-170	tourseat,pre`75 Roadster	EA
513-171	tourseat,850Mk3 Roadster	EA
513-172	tourseat,pre75 Interstate	EA
513-173	tourseat,850Mk3Interstate	EA
513-175	tourseat,POIF Tri2&3 cyl.	EA
513-176	tourseat,oilframe Tri.650,for clip	EA
513-177	tourseat,72 T120V,for plunger	EA
513-18	seat,racing,Wideline Norton	EA
513-187	tourseat,Tri.750 Twin	EA
513-201	seat,Scorpion,Tri750 Twin	EA
514-	SEATS,UNIVERSAL,CUSTOM	*
514-----	-----	---
514-01	seat,KQ,lowback rigid fr.	EA
514-11	seat,"Wassell Banana"univ	EA
514-14	seat,"Wassell Competition"univ	EA
514-273	soloseat,black,w/bracket	EA
514-273/A	soloseat,black,custom,US made	EA
514-274	pillion pad,custom	EA
514-274/A	pillion pad,classic univ.	EA
514-274/B	pillion pad,custom,US made	EA
514-274/C	pillion pad,sprung	EA
514-275	springs,solo seat,3",chr,barrell	PR
514-275/A	springs,solo seat,6",chr,straight	PR
514-275/B	springs,solo seat,5",chr.,barrel	PR
514-275/C	springs,solo seat,7"overall,chr.	PR
514-276	seat,solo,rigid,med,w/springs	ST
514-280	seat hinge mount,soloseat	EA
515-	BACKRESTS AND PADS	*
515-----	-----	---
515-01	USE 515-03	ea
515-02	grabrail,Fastback,stainless	EA
515-03	backrest,10",Tri.swingarm	EA
515-03/A	backrest,14",Tri.swingarm	EA
515-031	pad for515-03,10"backrest	EA
515-031/A	pad for515-031/A backrest	EA
515-04	backrest,10",Commando	EA
515-11	sissybar,low,flt.fend,sq.	EA
515-11/A	sissybar,low,fl.fend,rnd.	EA
515-12	sissybar,low,fatbob,sq.	EA
515-12/A	sissybar,low,fatbob,round	EA

515-13	sissybar,pointed,round	EA
515-24	backrest,univ.swingarm,18"	EA
521-	HANDLEBARS,CUSTOM & UNIV.	*
521-	-----	--
521-1	bars,2 inch rise*	EA
521-177	bars,T,8" rise*	EA
521-30	bars,Ace,narrow,4"drop	EA
521-316	bars,HD pullbacks,6" rise	EA
521-317	bars,HD pullback,8" rise	EA
521-400/33	clipons,33mm,pre71 Triumph style	PR
521-400/34	clipons,34mm,pre71 BSA	PR
521-400/35	clipons,35mm,Nor&l.TriBSA	PR
521-43	bars,Ace,narrow,3in.drop	EA
521-5	bars,3inch rise	EA
521-8	bars,flat type	EA
521-M	bars,Norman Hyde"M" type	EA
521-M/ER	bars,"M" type,econo.repl.	EA
521-W10	bars,western,10 inch rise	EA
521-W12	bars,western,12 inch rise	EA
521-W18	bars,western,18 inch rise	EA
521-W6	bars,western,6inch rise	EA
521-W8	bars,western,8 inch rise	EA
521-Z6	bars,Z,6 inch rise	EA
522-	HANDLEBAR GRIPS	*
522-	-----	--
522-01	grips,h.bar,Granturismo	PR
522-01/ER	grips,h.bar,economy repl.*	PR
522-02	grips,handlebar,Doherty	PR
522-03	grips,h.bar,foam,GrabOn	PR
522-366011/012	grips,Genuine AMAL	PR
523-	HAND CONTROLS& COMPONENTS	*
523-	-----	--
523-01	cl.lever assy,alloy universal	EA
523-02	brake lever assy,alloy universal	EA
523-100/LH	magneto lever,LH,Doherty	EA
523-100/LH/ER	magneto lever,LH,econo*	EA
523-100/RH	choke lever,RH,early,DOHERTY	EA
523-100/RH/ER	choke lever,RH,early,econo*	EA
523-104/5	adj&nut,threadedlevers,22TPI*	ST
523-105	compr.rel.lever,Doherty,plain*	EA
523-107/LH	clutch lever,plain,w/adj.	EA
523-107/RH	brake lever,plain,w/adj.	EA
523-107P/LH	clutch lever,Doherty,plain	EA
523-107P/LH/ER	clutch lever,plain,econo	EA
523-107P/RH	brake lever,Doherty,plain	EA
523-107P/RH/ER	brake lever,plain,econo	EA
523-11013	screw,controls,long,1BA	EA
523-11013/A	screw,controls,long,10-32	EA
523-11014	screw,1BA,controls,short	EA
523-11014/A	screw,controls,short,10-32	EA
523-12040	USE 523-12595	ea
523-12556	arm,choke lever,RH	EA
523-12595	clamp,control lever	EA
523-12607	screw,choke lever centre	EA
523-12608	choke lever,RH,Amal,late	EA
523-12608/ER	choke lever,RH,late,econo	EA
523-12609	USE 523-100/LH	ea
523-12609/ER	choke lever,LH,late,econo	EA
523-12613	magneto lever assy,LH,1"DOHERTY	EA
523-12613/ER	magneto lever assy,LH,1" econo	EA
523-12614	choke lever assy,RH,1"DOHERTY	EA
523-12614/ER	choke lever assy,RH,1" econo	EA
523-16008	spring,friction,thr.contr	EA
523-16009	screw,friction adj,thr.	EA
523-16010	nut	EA
523-16011	stop,thr.cable,slotted,lg	EA
523-16329	throttle control bot.half	EA
523-18053	nut,1/4CEI,lock	EA
523-18084	screw,1/4BSF	EA
523-18087	screw,pivot,control lever,CEI *	EA
523-181005	adjuster,threadedlevers,22TPI*	EA

523-181005/1006	USE 523-104/5	ea
523-181006	nut,cable adj,threadedlevers,22TPI*	EA
523-181708	USE 523-18838/839 (assy)	ea
523-181709	USE 523-18838/839 (assy)	ea
523-18752	arm,clutchlever,ballend,7/8"centres*	EA
523-18752/A	arm,cl.lever,lg.ballend,7/8"centres*	EA
523-18753	arm,clutchlever,ballend,1-1/16"centres*	EA
523-18754	arm,brake lever,ballend,7/8"centres*	EA
523-18754/A	arm,br.lever,lg.ballend,7/8"centres*	EA
523-18755	arm,brakelever,ballend,1-1/16"centres*	EA
523-18770	USE 523-105	ea
523-18771	USE 523-105 *	ea
523-18823	arm,cl.lever,ballend,7/8"centres,BSA*	EA
523-18824	arm,br.lever,ballend,7/8"centres,BSA*	EA
523-18838/839	adjuster&nut,contr.levers*	ST
523-18864	USE 523-105 *	ea
523-18886	USE 523-219/RH/B *	ea
523-18894	USE 523-219/LH/B *	ea
523-18908	USE 523-18908/909 (pair)	ea
523-18908/909	levers,br&cl,lg.ballend,cam adj,1"	PR
523-18909	USE 523-18908/909 (pair)	ea
523-18951	brake lever assy.	EA
523-18952	cl.lever assy.	EA
523-18978	brake/choke lever assy.	EA
523-19909	USE 523-219/LH/B	ea
523-19951	brake lever,w/mirror hole	EA
523-19951/ER	brake lever w/mirror hole,econo	EA
523-19952	clutch lever,w/mirrorHole	EA
523-19952/ER	clutch lever,w/mirrorhole,econo	EA
523-19978	brake/choke lever,w/hole	EA
523-19978/ER	brake/choke lever,w/hole,econo	EA
523-205	compr.rel.lever,Doherty,ballend*	EA
523-207/LH	clutch lever,Doherty	EA
523-207/LH/A	clutch lever,1",Doherty	EA
523-207/LH/ER	clutch lever,economy repl	EA
523-207/RH	brake lever,Doherty	EA
523-207/RH/A	brake lever,1",Doherty	EA
523-207/RH/ER	brake lever,economy repl.	EA
523-207P/LH	clutch lever,no adj,ballend	EA
523-207P/RH	brake lever,no adj,ballend	EA
523-208/LH/A	USE 523-207/LH/A	ea
523-208/RH/A	USE 523-207/RH/A	ea
523-210007	screw,friction,thr.contr	EA
523-210008	screw,rotor stop,throttle	EA
523-210009	USE 691-5077	ea
523-219/LH/A	clutch lever,Barnett	EA
523-219/LH/B	clutch lever,Barnett,1"	EA
523-219/LH/ER	USE 523-207/LH/ER	ea
523-219/RH/A	brake lever,Barnett	EA
523-219/RH/B	brake lever,Barnett,1"	EA
523-219/RH/ER	USE 523-207/RH/ER	ea
523-31313	throttle control,dualAmal *	EA
523-31313/ER	throttle control,dual,econo	EA
523-31315	USE 523-31313	ea
523-364011	USE 523-364018	ea
523-364016	USE 523-364018	ea
523-364017	USE 523-364018	ea
523-364018	throttle control,Amal type*	EA
523-364018/A	throttle control,1/4 turn,AMAL*	EA
523-366006	stop,thr.cable,slotted,sm	EA
523-61	throttle control,1"	EA
523-71	throttle control,Doherty*	EA
523-71/ER	throttle control,economy	EA
523-711	thrott.contr,dual,universal	EA
523-713	thrott.contr,dual,univ,1"	EA
524-	CONTROL CABLE COMPONENTS	*
524-----	-----	--
524-01	nipple assortment kit	ST
524-17	nipple,3/8"bar,solderless	EA
524-18	nipple,1/4"bar,solderless	EA
524-18872	USE 524-CX69	ea

524-18880	USE 524-CX69	ea
524-19	nipple,pear,solderless	EA
524-244104	junction box,twin cable	EA
524-2442080	junction box,triple cable	EA
524-372	clevisend,brake,universal	EA
524-600638	clevis,brk.cable,SolderOn	EA
524-6132	ferrule,tophat,thr.&choke	EA
524-CX11	ferrule,thrott&chokeCable	EA
524-CX13	ferrule,clutch&brakecable	EA
524-CX16	ferrule,nylon thr&choke cable	EA
524-CX17	ferrule,nylon cl&brk.cable	EA
524-CX32	nipple,.22x.135,thr&choke	EA
524-CX40	nipple,.22x.2",dual throt	EA
524-CX43	nipple,pear,cl.&brk,cable	EA
524-CX53	nipple,thr.cable,carb end	EA
524-CX69	nipple,slotted,clutch&brk	EA
524-CX70	nipple,3/8x5/8,clutch&brk	EA
525-	UNIVERSAL CONTROL CABLES	*
525-----	-----	---
525-01	cable,thr&choke,univ.2into1 assy.*	EA
525-05	cable,thr,mikuni,42"	EA
525-05/A	cable,thr,mikuni,50"	EA
525-41	cable,thrott&choke,universal,41"	EA
525-41/20	cable,throt&choke,univer,62"	EA
525-41/20/A	cable,nylon lined,univer,62"	EA
525-74	cable,clutch&brake,universal,short	EA
525-74/20	cable,cl.&brake,universal,74"	EA
525-74/20/A	cable,nylon lined,univer,74"	EA
525-CP/1/50	outer,thr&ChokeCable,50ft	EA
525-HS/3/50	outer,cl.&brakeCable,50ft*	EA
525-ML1C	outer,nylon thr&choke cable,50ft.	EA
525-ML1L	liner,nylon thr&choke cable,50ft.	EA
525-ML3C	outer,nylon cl&brk.cable,50ft.	EA
525-ML3L	liner,nylon cl&brk.cable,50ft.	EA
525-W1/19/50	inner,thr&chokeCable,50ft	EA
525-W3/19/50	inner,cl&brake cable,50ft	EA
526-	CONTROL CABLES,STD&CUSTOM	*
526-----	-----	---
526-061450	cable,throttle,top,17"	EA
526-066345	cable,thr,top,Mk3 Hi,30"	EA
526-066714	cable,thr,top,850Mk3,22"	EA
526-114	cable,compr.release,35"	EA
526-116	cable,compr.release,B50	EA
526-187	cable,advance,42"	EA
526-2/525	cable,front brake,31"	EA
526-2/525/10	cable,front brake+10	EA
526-2/525/6	cable,front brake+6	EA
526-2/534	cable,front brake,33"	EA
526-2/534/6	cable,front brake,+6"	EA
526-2/535	cable,front brake,33"	EA
526-2/535/8	cable,front brake+8"	EA
526-2/538/5	cable,front brake,43"	EA
526-2/538/8	cable,front brake,+8"	EA
526-2/616	cable,front brake,36"	EA
526-2/616/10	cable,front brake,+10"	EA
526-2/616/6	cable,front brake,+6"	EA
526-2/618	cable,front brake,34"	EA
526-2/618/11	cable,front brake+11"	EA
526-2/618/5	USE 526-619	ea
526-2/618/8	cable,front brake+8"	EA
526-2/620	cable,front brake,DLS,43"	EA
526-2/620/11	cable,front brake+11	EA
526-2/620/5	cable,front brake+5	EA
526-2/663	cable,front brake,40"	EA
526-2/663/4	cable,front brake+4	EA
526-2/663/8	cable,front brake+8"	EA
526-2/729	cable,cl,pre70 A50/65,55"*	EA
526-2/729/10	cable,clutch+10*	EA
526-2/729/10/A	cable,clutch+10,nylonlined	EA
526-2/729/6	cable,clutch+6*	EA
526-2/729/6/A	cable,clutch+6,nylon lined	EA

526-2/729/8/A	cable,clutch+8,nylonlined	EA
526-2/729/A	cable,clutch,nylon lined*	EA
526-2/733	cable,clutch,44"	EA
526-2/739	cable,cl,70onA50/65,47" *	EA
526-2/739/10	cable,clutch+10	EA
526-2/739/6	cable,clutch+6*	EA
526-2/739/8	cable,clutch+8	EA
526-2/739/A	cable,clutch,nylon lined*	EA
526-2/769	USE 526-769/5	ea
526-2/791	USE 526-2/792 *	ea
526-2/792	cable,clutch,47"	EA
526-2/795	cable,clutch,42"	EA
526-2/795/10	USE 526-2/796/6*	ea
526-2/795/2/A	cable,clutch+2"nylonlined	EA
526-2/795/6	USE 526-2/796 *	ea
526-2/796	cable,clutch,47"*	EA
526-2/796/10	cable,clutch+10*	EA
526-2/796/10/A	cable,clutch+10nylonlined	EA
526-2/796/6	cable,clutch+6 *	EA
526-2/796/6/A	cable,clutch,nylon lined	EA
526-2/796/A	cable,clutch,47",nylon lined*	EA
526-2/796/B	cable,clutch,47",nylon lined,large OD*	EA
526-2/797	cable,cl,68onTri.650,47"	EA
526-2/797/10	cable,clutch+10	EA
526-2/797/10/A	cable,clutch+10nylonlined	EA
526-2/797/6	cable,clutch+6	EA
526-2/797/6/A	cable,clutch+6,nylonlined	EA
526-2/797/A	cable,clutch,nylon lined	EA
526-2/798	cable,clutch,Tri750twinUK,45"	EA
526-2/798/10	cable,clutch+10	EA
526-2/798/14/A	cable,clutch+14nylonlined	EA
526-2/798/5	cable,clutch+5(US bars)	EA
526-2/798/5/A	clutch cable+5,nylonlined	EA
526-2/798/A	cable,clutch,nylon lined	EA
526-21/36	cable,choke,16"	EA
526-252	cable,rear brake,Commando	EA
526-252/A	cable,rear brake,Commando,BARNETT	EA
526-29/8	cable,throttle,Mono,+8	EA
526-306	cable,throttle,dualGP,36"	EA
526-315	cable,thr.&choke,top,29"	EA
526-315/5	USE 526-454	ea
526-318	USE 526-M44/35	EA
526-319	cable,choke,bot,w/adj,11"	EA
526-325	cable,thr,top,Bings,23"	EA
526-326	cable,thr&choke,bot,Bings,13"	EA
526-327	cable,thr,top,Bing,20",UK	EA
526-328	cable,choke,upper,Bings	EA
526-331	cable,throttle,upper,26" *	EA
526-331/10	cable,throttle+10 *	EA
526-331/10/A	cable,throt+10,nylonlined *	EA
526-331/6	cable,throttle+6 *	EA
526-331/A	cable,throttle,nylonlined *	EA
526-36/38	USE 526-44/38 *	ea
526-37/36	USE 526-40/36 *	ea
526-38/24D	cable,thr,dual Mono,35"	EA
526-38/24D/6	cable,throttle,dual+6	EA
526-38/27X	cable,throttle,Mono,35"	EA
526-38/29/10	cable,throttle,Mono+6"	EA
526-38/29/6	cable,throttle,Mono	EA
526-38/30D	USE 526-40/30D *	ea
526-40/30D	cable,throt,dual carb,36"	EA
526-40/30D/10	cable,throttle,+10	EA
526-40/30D/6	cable,throttle,+6	EA
526-40/34	USE 526-44/34 *	ea
526-40/36	cable,choke,35"	EA
526-418548	cable,compr.release,30"	EA
526-42/24D	USE 526-38/24D/6 *	EA
526-42/30D	USE 526-40/30D *	ea
526-42/38	USE 526-44/38 *	ea
526-427030	cable,rear brake,Ariel type hub	EA
526-427034	USE 526-427042	ea

526-427042	cable, rear brake, 58on preunit	EA
526-44/30D	USE 526-40/30D/6 *	ea
526-44/34	cable,choke, 40"	EA
526-44/38	cable,choke, 39"	EA
526-44/38/6	cable,choke +6"	EA
526-446	cable,throttle,upper, 21"	EA
526-446/4	cable,throttle upper +4"	EA
526-447	cable,throttle,lower, 11"	EA
526-449	cable,throttle,bottom, 13"	EA
526-45/38	USE 526-44/38 *	ea
526-450	cable,throttle,lower, 18"	EA
526-450/A	cable,thr,bot,nylonlined	EA
526-451	cable,choke,lower, 8"	EA
526-452	cable,choke,lower, 18"	EA
526-452/6	cable,choke +6"	EA
526-453	cable,throttle,upper, 27"	EA
526-454	cable,thr.&choke,top, 34"*	EA
526-454/6	cable,choke +6	EA
526-455	cable,thr,T150&A75 US, 43"*	EA
526-455/6	cable,throttle,A75/T150+6	EA
526-456	cable,choke,top, 60"*	EA
526-456/6	cable,choke,top,+6"	EA
526-457	cable,choke,RH, 3cyl, 12"	EA
526-458	cable,choke,lower, 10"	EA
526-459	cable,choke,left hand, 9"	EA
526-460	cable,thr,A75/T150 UK, 39"*	EA
526-460/6	USE 526-455 *	EA
526-468	cable,choke,to lever, 12"	EA
526-469	cable,choke,TR7RV, 11"	EA
526-470	cable,choke,to lever, 10"	EA
526-477	cable,thr&choke,bot,AmalMk2, 15"	EA
526-477/A	cable,throttle,nylonlined	EA
526-478	cable,throttle, 40"	EA
526-478/3	cable,throttle, 43"	EA
526-479	cable,thr,79-83TR7 UK, 40"	EA
526-480	cable,thr,79-83TR7 US, 43"	EA
526-490	cable,thr,top,AmalMk2, 23"	EA
526-494	cable,thr,top,AmalMk2, 26"	EA
526-494/A	cable,throttle,nylonlined	EA
526-495	cable,choke,lower, 6"	EA
526-496	cable,throttle,upper, 25" *	EA
526-496/8	cable,throttle+8 *	EA
526-496/A	cable,throttle,nylonlined *	EA
526-497	cable,throttle,T160UK, 37"	EA
526-497/5	cable,throttle,T160US, 42"	EA
526-499	cable,throttle,top,UK, 22"	EA
526-525	cable,front brake, 34"	EA
526-525/13	cable,fr.brake, 47"	EA
526-527	cable,front brake, 36"	EA
526-534	cable,front brake, 33"	EA
526-538	cable,front brake, 38"	EA
526-539	cable,front brake, 33"	EA
526-539/3	cable,front brake, 36"	EA
526-579	cable,front brake, 35"	EA
526-579/4	cable,front brake+4"	EA
526-579/6	cable,front brake,+6	EA
526-600247	USE 526-617	ea
526-600248	cable,throttle,SV500	EA
526-600252	cable,compr.rel,TRW 500	EA
526-600269	cable,throttle,6Tw/SUcarb	EA
526-600307	USE 526-794	ea
526-601	cable,front brake, 32"*	EA
526-601/10	cable,front brake,+10	EA
526-601/6	cable,front brake+6*	EA
526-601/8	cable,front brake,+8"	EA
526-602	USE 526-601/6 *	ea
526-602/10	cable,front brake, 47"	EA
526-602119	cable,fr.brk,70B44VS, 36", w/sw.	EA
526-603	cable,fr.brk,w/switch, 37" *	EA
526-603/10	cable,front brake+10,w/sw.	EA
526-603/6	cable,front brake+6,w/sw.	EA

526-603752	USE 526-116	ea
526-616	cable,front brake,37"*	EA
526-616/10	cable,front brake,+10"	EA
526-617	cable,front brake,w/tube,35"	EA
526-617/5	cable,front brake,w/tube	EA
526-619	cable,front brake,39"*	EA
526-619/6	cable,front brake,+6"*	EA
526-620011	cable,clutch,T140 Harris USA	EA
526-620067	cable,choke,top,Harris Bonnie	EA
526-620071	cable,thr,top,85onBon,37"	EA
526-625	cable,fr.brk,36"	EA
526-625/6	cable,fr.brk,+6"	EA
526-630	cable,front brake,36"	EA
526-630/8	cable,front brake,+8"	EA
526-661	cable,fr.brk,68 B44SS,43"	EA
526-661/6	cable,fr.brk,68 B44SS,+6"	EA
526-662	cable,front brake,40"*	EA
526-662/4	cable,front brake+4*	EA
526-663/10	cable,front brake,41"	EA
526-663/5	cable,front brake,36"	EA
526-665	cable,front brake,36"	EA
526-665/10	cable,front brake +10"	EA
526-665/6	cable,front brake +6"	EA
526-666	cable,front brake,31",w/sw.	EA
526-666/10	cable,fr.brake+10,w/sw.	EA
526-666/14	cable,fr.brake+14,w/sw.	EA
526-666/5	cable,front brake,36",w/sw.	EA
526-666/5/ER	cable,fr.brake,36",w/sw,econo.repl.	EA
526-667	cable,front brake,31",w/switch	EA
526-667/10	cable,front brake+10,w/switch	EA
526-667/6	cable,front brake +6"	EA
526-668	cable,front brake,35",w/switch	EA
526-668/10	cable,front brake+10,w/switch	EA
526-669	cable,front brake,41",w/sw.	EA
526-669/10	cable,front brake+10,w/sw.	EA
526-669/14	cable,front brake,no sw.	EA
526-669/6	cable,front brake+6,w/switch	EA
526-669/6/A	cable,front brake+6,no/switch	EA
526-669/A	cable,front brake,41",no sw.	EA
526-670	cable,front brake,41"	EA
526-671	cable,fr.brk,B50T &MX,43"	EA
526-672	cable,front brake,35"	EA
526-672/10	cable,front brake+10	EA
526-672/14	cable,front brake+14	EA
526-672/6	cable,front brake,+6"	EA
526-673	cable,front brake,40",w/sw	EA
526-673/14	cable,front brake,+14"*	EA
526-674	USE 526-669/6	ea
526-687025	cable,rear brake*	EA
526-723	cable,clutch,preunit BSA,48"*	EA
526-723/13	cable,cl,preunit BSA,61"	EA
526-723/8	cable,clutch,preunit BSA,56"	EA
526-730	cable,cl,for alloy levers	EA
526-733	cable,clutch,48"	EA
526-733/10	cable,clutch+10	EA
526-733/6	cable,clutch+6	EA
526-734	USE 526-733	ea
526-738	cable,clutch,56"	EA
526-739	USE 526-2/729	ea
526-740	USE 526-800 *	ea
526-740/6	USE 526-800/5 *	ea
526-764	USE 526-769 *	ea
526-769	cable,clutch,56",Atlas UK*	EA
526-769/11	cable,clutch+11	EA
526-769/11/A	cable,clutch+11nylonlined	EA
526-769/5	cable,clutch+5,US bars	EA
526-792/4	cable,clutch,58"	EA
526-792/8/A	cable,cl,nylon lined,62"	EA
526-794	cable,clutch,Tri.Twin,55-57,51"	EA
526-794/6	cable,clutch,Tri.Twin,55-57,57"	EA
526-796	USE 526-2/796 *	ea

526-797	cable,cl,58/59Tri5/650,49"	EA
526-797/13	cable,clutch+13"	EA
526-797/8	cable,cl,preunit Tri,58"	EA
526-799	cable,clutch,preunit,61"	EA
526-799/8	cable,clutch+8"	EA
526-800	cable,clutch,3 cyl,52"	EA
526-800/10	cable,clutch+10"	EA
526-800/5	cable,clutch+5	EA
526-800/5/A	cable,clutch,BARNETT	EA
526-800/5/B	cable,clutch,VENHILL	EA
526-800/A	cable,clutch,BARNETT,heavy duty	EA
526-811	cable,clutch,45" *	EA
526-811/A	cable,clutch,nylon lined,50"*	EA
526-812	cable,clutch,52"*	EA
526-812/10	cable,clutch+10	EA
526-812/10/A	cable,clutch+10nylonlined	EA
526-812/6	cable,clutch+6	EA
526-812/6/A	cable,clutch+6,nylon lined	EA
526-812/A	cable,clutch,nylon lined	EA
526-812/B	cable,cl,gen.Nort#062813	EA
526-91	cable,thr.&choke,top,19"	EA
526-91/6	USE 526-96 *	ea
526-92	cable,choke,lower,11"	EA
526-96	cable,throt&choke,top,23" *	EA
526-96/6	cable,thr,29",Hirider,std	EA
526-96/A	cable,throttle,nylonlined	EA
526-97	cable,thr.lower,mono,11"	EA
526-99	cable,throttle,lower,11"	EA
526-AM39/24	cable,thr,w/sleeve,34"	EA
526-AM40/21	cable,thr,34"	EA
526-AM40/21/6	cable,thr,+6"	EA
526-AM42/21	USE 526-AM40/21/6 *	ea
526-AM44/24	USE 526-AM40/21/6 *	ea
526-M36/38	USE 526-M38/38 *	ea
526-M37/27/6	USE 526-M43/27	ea
526-M38/29	cable,throttle,34"	EA
526-M38/31	USE 526-M42/31 *	ea
526-M38/35	cable,throttle,34"	EA
526-M38/35/6	USE 526-M44/35	EA
526-M38/38	cable,choke,33"	EA
526-M40/27	cable,thr,37"	EA
526-M40/27X	cable,thr,40"	EA
526-M40/29	USE 526-M43/29 *	ea
526-M42/27	USE 526-M43/27 *	ea
526-M42/29	USE 526-M43/29 *	ea
526-M42/31	cable,throttle,38"	EA
526-M42/31/6	cable,throttle,+6	EA
526-M42/34	cable,choke,38"	EA
526-M42/35	USE 526-M44/35 *	EA
526-M42/35/10	USE 526-M47/35/6 *	EA
526-M42/35/6	USE 526-M44/35/6 *	EA
526-M42/38	cable,choke,37"	EA
526-M43/27	cable,throttle,Mono,40"	EA
526-M43/29	cable,throttle,Mono,39"	EA
526-M44/24D	cable,throttle,dual,41"	EA
526-M44/24D/10	cable,throttle+10	EA
526-M44/24D/5	cable,throttle +5"	EA
526-M44/26D	cable,throttle,dual,41"	EA
526-M44/26D/10	cable,throttle+10	EA
526-M44/29	USE 526-M43/29 *	ea
526-M44/29X	cable,throttle,Mono,40"	EA
526-M44/30D	cable,throttle,dual,40"	EA
526-M44/30D/10	cable,throttle+10	EA
526-M44/30D/6	USE 526-M47/30D/6 *	EA
526-M44/31	cable,throttle,40"	EA
526-M44/31/10	cable,throttle+10	EA
526-M44/31/6	cable,throttle	EA
526-M44/35	cable,throttle,40"	EA
526-M44/35/10	USE 526-M47/35/6 *	ea
526-M44/35/6	cable,throttle+6	EA
526-M44/38	cable,choke,39"*	EA

526-M44/38/6	cable,choke +6'	EA
526-M45/27	USE 526-M43/27 *	ea
526-M46/26D	cable,throttle,dual,43" *	EA
526-M46/26D/10	USE 526-M44/26D/10	ea
526-M46/26D/6	cable,throttle+6	EA
526-M47/30D	cable,throttle,dual,43"	EA
526-M47/30D/10	cable,throttle+10	EA
526-M47/30D/10/A	cable,throt,nylonlined+10	EA
526-M47/30D/6	cable,throttle+6	EA
526-M47/30D/A	cable,throttle,nylonlined	EA
526-M47/30D/ER	cable,throttle,dual43",econo repl.	EA
526-M47/31	USE 526-M44/31/6 *	EA
526-M47/31/6	USE 526-M44/31/10 *	ea
526-M47/35	cable,throttle,43"	EA
526-M47/35/10	cable,throttle+10	EA
526-M47/35/6	cable,throttle+6	EA
526-M47/38	cable,choke,42"*	EA
531-	FORK GAITERS,BELLOWS TYPE	*
531-----	-----	---
531-15	gaiters,pre70Norton	PR
531-20	gaiters,Bantam	PR
531-23	gaiters,preunit Triumph,vinyl	PR
531-24	gaiters,pre 1968 BSA*	PR
531-25	gaiters,1964-68 Triumph	PR
531-27	gaiters,68-70TRIBSAsingle&68 A50/65	PR
531-27/A	USE 531-27	ea
531-27/ER	gaiters,68-70TRIBSAsingle&68 A50/65,econ	PR
531-28	gaiters,69/70TRI style*	PR
531-28/A	USE 531-28	ea
531-28/ER	gaiters,69/70Tri.style,econo	PR
531-35	gaiters,70onCommando UK	PR
531-35/ER	gaiters,70onCommando UK,econo	PR
531-37	gaiters,71 on Triumph UK	PR
531-37/ER	gaiters,71 on Triumph UK,econo repl.	PR
532-	PEG,STAND,& SHIFT RUBBERS	*
532-----	-----	---
532-04	rubber,rider,BSA oval	EA
532-05	rubber,kick,BSA,closedEnd	EA
532-06	rubber,kick,Burman gearbx	EA
532-10	rubber,shift,Burman gbx.	EA
532-11	rubber,shift,preunit BSA	EA
532-1107	rubber,rider,HYDE rearsets	EA
532-1201	rubber,DUNSTALL rearsets	EA
532-15	rubber,shift&stand,TriBSA	EA
532-18	rubber,kick,Norton type*	EA
532-18/ER	rubber,kick,1962on Norton,econo	EA
532-19	rubber,kick,Bantam*	EA
532-21	USE 532-21/A	ea
532-21/A	rubber,rider,BSA logo	EA
532-21/ER	rubber,rider,BSA logo,econo.repl.	EA
532-23	USE 532-23/A OR 532-23/B	ea
532-23/A	rubber,rider,TRIUMPH name	EA
532-23/B	rubber,rider,TRIUMPH logo,early	EA
532-23/C	rubber,rider,TRIUMPH name,cutaway	EA
532-23/ER	rubbers,TRIUMPH name,econo repl.	EA
532-38	rubber,pass,BSA &late Tri,Ariel	EA
532-38/A	rubber,passenger,BSA logo	EA
532-38/ER	rubbers,pass,BSA &late Tri,Ariel,econo	PR
532-44	rubbers,pass,Tri flat type,econo.repl.	PR
532-44/A	rubber,pass,TRIUMPH logo	EA
532-44/A/ER	rubbers,pass,TRIUMPH logo,econo.repl.	PR
532-47	rub,kick,AMCgbx,closedEnd	EA
532-49	rub,shift&stand,Tri.early	EA
532-49/A	rub,stand&shiftTriOpenEnd	EA
532-49/B	rub,shift&stand,TRI logo	EA
532-51	rubber,kick,Tri,closedEnd	EA
532-51/A	rubber,kick,TRIUMPH logo	EA
532-54	rubber,shift,Norton	EA
532-54/ER	rubber,shift,Norton,econo	EA
532-58	rubber,passenger,Norton	EA
532-58/ER	rubbers,passenger,Norton,econo repl.	PR

532-74	rubber,kick,BSA open end,short	EA
532-74/A	rubber,kick,BSA logo,short	EA
532-74/ER	rubber,kick,BSA logo,econo,long	EA
532-75	rubber,rider,fr.folding	EA
532-75/A	rubber,rider,BSA logo	EA
532-80	rubber,kick,Triumph,71onA65,open*	EA
532-80/A	rubber,kick,Triumph open,w/name*	EA
532-81	rubber,fr&early rear,Nort	EA
532-81/ER	rubbers,fr&early rear,Nort,econo	PR
532-825022	rubber,rider,Cub folding,w/logo	EA
532-825022/ER	rubber,rider,Cub folding,blank	EA
532-832651	rubber,rider,oilframe BSA	EA
532-832651/ER	rubbers,rider,oilframe BSA,econo repl*	PR
532-837256	rubber,rider,LH,79on Tri.	EA
532-837256/59/ER	rubbers,rider,79onTR7/140,econo	PR
532-837259	rubber,rider,RH,79on Tri.	EA
532-904805	rubber,footrest,Bantam,early	EA
532-A2/507	rubber,fr,NORTON early,D shape	EA
541-	PEGS,FOOTCONTROLS&MTR.MTS	*
541-----	-----	---
541-01	pegs,folding,TRI logo	PR
541-02	pegs,folding,NOR logo	PR
541-03	pegs,folding,BSA logo	PR
541-07	pegs,folding,oring,universal	PR
541-108	rearsets,Commando,RH shift	EA
541-108/A	rearsets,Commando,RH,Hyde*	ST
541-118	rearsets,pre71Tri650	EA
541-118/A	rearsets,pre71Tri650,Hyde	ST
541-145	rearsets,OilFr.TriRHshift	ST
541-148	rearsets,NortonFeatherbed	ST
541-153	rearsets,Nor.850 Mk3	EA
541-153/A	rearsets,Nort.850Mk3,Hyde*	ST
541-154	rearsets,T140LHshift	ST
541-154/A	rearsets,T140LHshift,Hyde	ST
541-157/A	rearsets,T150,Hyde,rbr.mt	ST
541-162	rearsets,T160	EA
541-162/A	rearsets,T160,Hyde,rbr.mt	ST
541-199	rearsets,adjustable,univ.kit*	ST
541-201	isolastic convKit,Mk3type*	ST
541-202	eng.mt.plts,aly,63-70T120	ST
541-203	mtr.mts,finned T120 rear	PR
541-204	eng.mt.plts,aly,featherbed Nor	ST
541-21	hiway pegs,1pc,universal	EA
541-41	frwrđ.controls,Tri.1pc,stainless	ST
541-41/A	frwrđ.controls,Tri2pc.CCI	ST
541-411	cap,pedal,forward control	EA
541-412	cap,footpeg,forward control	EA
541-413	clevis,forward control,lg.	EA
541-414	clevis,forward control,sm.	EA
541-42	frwrđ.controls,BSA,1pcIEI	ST
542-	CHAINGUARDS,CUSTOM & UNIV	*
542-----	-----	---
542-01	chainguard,custom univ,chr.22"	EA
542-02	chainguard,extended,stainless	EA
542-03	chainguard,custom univ,chr,extended,28"	EA
542-3501	chainguard,BSAhd1	EA
542-3504	chaingrđ,TriHd1+6	EA
542-3506	chaingrđ,Trihd1+4	EA
543-	SHOCK ABSORBERS & PARTS	*
543-----	-----	---
543-01	shocks,Hagon,custom,short,10.9"	PR
543-02	shocks,12.8,EMGO economy repl.	PR
543-03	shocks,13.2,EMGO economy repl.	PR
543-04	shocks,12.9",w/shrouds,replacement	PR
543-05	shocks,12.9",replacement	PR
543-1282	shocks,Koni7610replica,12.9",std.spring*	PR
543-1282/A	shocks,Koni 7610,12.9",HDspring	PR
543-1283	shocks,Koni 7610,13.4",std.spring	PR
543-1373	shocks,Koni 76,12.9",1121b.	PR
543-209/18	springs,chrome,18kg/cmX209mm,HAGON	PR
543-209/20	springs,chrome,20kg/cmX209mm,HAGON	PR

543-209/23	springs,chrome,23kg/cmX209mm,HAGON	PR
543-209/26	springs,chrome,26kg/cmX209mm,HAGON	PR
543-2105	USE 543-6214	ea
543-2107	USE 543-6218	ea
543-2108	USE 543-6213	ea
543-229/18	springs,chrome,18kg/cmX229mm,HAGON	PR
543-229/20	springs,chrome,20kg/cmX229mm,HAGON	PR
543-229/23	springs,chrome,23kg/cmX229mm,HAGON	PR
543-2341	USE 543-6007	ea
543-2564	USE 543-6007	ea
543-29003	shocks,Hagon	PR
543-30003	shocks,Hagon	PR
543-30005	shocks,Hagon	PR
543-32004	shocks,Hagon	PR
543-33001	shocks,Hagon	PR
543-33002	shocks,Hagon	PR
543-33003	shocks,hagon	PR
543-33004	shocks,Hagon	PR
543-33006	shocks,Hagon	PR
543-33007	shocks,Hagon	PR
543-33008	shocks,Hagon	PR
543-33401	shocks,Hagon,VELO	PR
543-34003	shocks,Hagon	PR
543-4423	USE 543-6237	ea
543-4475	USE 543-6213 *	ea
543-4927	USE 543-6210	ea
543-6007	USE 543-32004	ea
543-6135	USE 543-33002	ea
543-6208	USE 543-6213	ea
543-6210	USE 543-33008	ea
543-6213	USE 543-34003	ea
543-6214	USE 543-34003	ea
543-6217	USE 543-6218	ea
543-6218	USE 543-33006	ea
543-6219	USE 543-6218 *	ea
543-6237	USE 543-30003	ea
543-6239	USE 543-6135 *	ea
543-6240	USE 543-33004	ea
543-6250	USE 543-33007	ea
543-6329	USE 543-6007	ea
543-64532778	cover,inner,Girling,chrome	EA
543-64532778/A	cover,inner,Hagon,chrome*	EA
543-64533025	cover,outer,Girling,black	EA
543-64533025/A	cover,outer,Hagon,black*	EA
543-64533645	bushing,shock,.942x.375	EA
543-64533651	bushing,shock,.755x.313	EA
543-64533654	bushing,shock,.942x.500	EA
543-64533656	bushing,shock,1.13x.375	EA
543-64533658	bushing,shock,.755x375	EA
543-64541660	sleeve,shock bush.938x375	EA
543-64541661	USE 543-64533654	EA
543-64543708	spring,chrome,8.4,100 lb.	PR
543-64543735	spring,chrome,9.4,90 lb.	PR
543-64544234	USE 543-209/26	ea
543-64544235	spring,chrome,9.4,110lb.	PR
543-64544621	USE 543-229/23	ea
543-64544754	USE 543-229/20	ea
543-64546048	retainer,sprng,split type	EA
543-64546048/A	retainer,sprng,alloy,Hagon	EA
543-70520135	retainer,spring,1 pc. type	EA
543-81	rebuild kit,koni shocks	ST
543-82	shocks,Koni,12.9,bare	PR
543-83	sleeve,shock bush,8x19mm,Koni style	EA
543-84	sleeve,shock bush,10x19mm,Koni style	EA
543-85	sleeve,shock bush,10x24mm,Koni style	EA
543-9046471	USE 543-64533645	ea
543-9046862	USE 543-64533645	ea
543-9054171	USE 543-64546048	ea
543-9054280	USE 543-64543708 *	ea
543-9054316	USE 543-64533645	ea
543-905494	USE 543-64543735 *	ea

543-COVER	cover set,Girling shocks,blk/chr.	ST
543-COVER/A	cover set,Hagon shocks,blk/chr.	ST
543-COVER/B	cover set,Hagon shocks,all chr.	ST
544-	CUSTOM FRAMES, TAILS&PARTS	*
544-----	-----	---
544-01	lowering kit,TriPreOilFr.	EA
544-11	hardtail,bolton,63-70T120,&T150	EA
544-12	hardtail,bolton,63-70T120,&T150,long	EA
544-13	hardtail,weld on,oilframe,drum*	EA
544-13/A	hardtail,weld on,oilframe,disc	EA
544-14	hardtail,bolton,59-Tri500	EA
544-15	hardtail,weldon,pre71 A65 *	EA
544-200	frame,Featherbed	EA
544-3001	brakerod,extended stainless*	EA
544-3002	brakerod,chr.ex.CustomBSA	EA
544-3005	USE 544-3001	ea
544-5501	plunger arm assy,D5 type	EA
544-5502	spring,plunger,D5 type	EA
544-5517	plunger tail,bolton,63-70 T120,&T150	EA
544-5519	plunger tail,bolton,unitTri500	EA
544-5522	plunger conversion,univ.	EA
544-600	rigid frame,Commando	EA
544-700	rigid frame,Tri.unit6/750,8% rake*	EA
544-700/A	rigid frame,Tri.unit6/750,std rake	EA
544-701	frame,plunger,Tri.650/750,8%rake	EA
544-701/A	frame,plunger,Tri.650/750,std.rake	EA
544-71R	rigid frame kit,unit6/750,71on	EA
544-720	rigid frame,Tri.T150	EA
544-800	rigid frame,BSAunit	EA
544-810	rigid frame,BSApreunit	EA
544-820	rigid frame,TRIPreunit	EA
544-900	rigid frame,univeral	EA
545-	SIDESTANDS,CUSTOM & UNIV.	*
545-----	-----	---
545-01	sidestand,univ.bolton,std	EA
545-02	sidestand,univ.bolton,ext	EA
545-22	sidestand,chr.extPre68Tri	EA
545-23	sidestnd,chr.extBSA<Tri*	EA
545-24	sidestnd,short BSA<Tri,stainless	EA
546-	FORKS&PARTS,CUSTOM& PERF.	*
546-----	-----	---
546-01	collars,external springs,chrome	PR
546-03	tweekbar,69onTri.ext.spr.	EA
546-04	tweekbar,OIF TriBSAw/drums	EA
546-101	forkbrace,Tri.w/disc,CC	EA
546-101/A	forkbrace,Tri,alloy,Hyde*	EA
546-102	forkbrace,Norton disc,CC	EA
546-102/A	forkbrace,Nort,alloy,Hyde	EA
546-103	forkbrace,Norton drum,CC	EA
546-17	tweekbar,Nort,disc & drum	EA
546-18	tweekbar,pre71 BSA Twin	EA
546-201	USE 558-01	ea
546-31	tweekbar,pre`69 Triumph	EA
546-61	tweekbar,Tri.w/disc brake	EA
546-71	forkcrowns,custom,Tri,wide,ext.spring	ST
546-72	forkcrowns,custom,Tri,narrow,ext.spring	ST
546-81	steering damper,univ.hydraulic	EA
546-90	insidespring fork conv.kt	ST
546-95	damper improvment kit,Nor	ST
546-96	springer forks,custom,round stock*	EA
547-	HANDLEBAR RISERS,CUSTOM	*
547-----	-----	---
547-01	risers,Tri.type,custom *	PR
547-011	ext.kit for 547-01 risers	ST
547-02	risers,dogbone type,w/bar	ST
547-03	risers,straight,alloy,6"*	PR
548-	OIL&GAS TANKS, &BAT.BOXES	*
548-----	-----	---
548-01	tank,gas,2imp.gal.peanut	EA
548-11	gastank,Gold Star,repl.	EA
548-12	gastank,A7/10,repl.	EA

548-21	tank,mustang deep tunnel	EA
548-22	tank,MustangDual,shallow	EA
548-23	tank,King Sportster	EA
548-23/ER	tank,Sprtstr,shallow,Econ*	EA
548-24	tank,coffin	EA
548-4102	bat.cov,louvered,oil tank	EA
548-4503	elect.box,custom,stainless	EA
548-4504	USE 548-4803	ea
548-4510	electbox,wrapround	EA
548-8004	oiltank,hex tab mt,chrome	EA
548-8004/A	oiltank,hex,alloy,top mt.	EA
548-8006	oiltnk,hx,tbmt,forBat	EA
548-8008	oiltnk,wrprnd,tbmt	EA
548-8010	oiltank,octagon,postmt,stainless*	EA
548-8028	oiltnk,wrprnd,pstmt,stainless*	EA
548-9000	oiltank,round alloy	EA
549-	FENDERS&BRACKT,UNIV&CUST.	*
549-----	-----	--
549-01	bracket set,fr.fenders,chrome	ST
549-251	mudguard,fatbob deep	EA
549-251/A	mudguard,"flatbob"shallow	EA
549-251/A/C	mudguard,"flatbob"chromed	EA
549-252/5	mudguard,flat 5 inch rear	EA
549-252/5/CHR	mudguard,fl.5"rear chrome	EA
549-252/6	mudguard,flat 6" rear	EA
549-252/6/CHR	mudguard,fl.6"rear chrome	EA
549-2F	mudguard,front,4",bare,C section	EA
549-2FA	mudguard,front,4",alloy,C section	EA
549-2FA/21	mudguard,fr,4"alloy,21"rim,C section	EA
549-2FC	mudguard,front,4"chr,long,"C"section	EA
549-2FC/A	mudguard,fr,4"chr,short,C section	EA
549-2FSS	mudguard,fr,4"Stainless,C section	EA
549-2RC	mudguard,rear,4",chr,C section	EA
549-5007	clip,rear fender,univ,chr	PR
549-5201	brace,flat fender,chr.	EA
549-5202	USE 549-5201	ea
549-5203	brace,fatbob fender,chr.	EA
549-5F	mudguard,fr,5"unpainted,C section	EA
549-5FA	mudguard,fr,5"alloy,Csection	EA
549-5FC	mudguard,front,5"chr,C section	EA
549-5R	mudguard,rear,5",raw,"C"section	EA
549-5RA	mudguard,rear,5",alloy,"C"section	EA
549-5RC	mudguard,rear,5",chr,C section	EA
549-5RSS	mudguard,rear,5",stainless,C section	EA
549-6R	mudguard,rear,6",raw,"C"section	EA
549-6RA	mudguard,rear,6",alloy,"C"section	EA
549-7RB	mudguard,rear rib,6"unpainted,D section	EA
549-8R	mudguard,rear,6" unpainted,D section	EA
549-8RC	mudguard,rear,6" chrome,D section	EA
549-8RSS	mudguard,rear,6" stainless,D section	EA
549-9FB	mudguard,fr,ribbed 5",unpainted	EA
549-9FC	mudguard,fr.ribbed,5"chr.	EA
549-9RB	mudguard,rear rib,5"unpainted	EA
549-9RC	mudguard,rear rib,5" chr.	EA
551-	BRAKE LININGS	*
551-----	-----	--
551-1008	brklining,56&57 BSA F & R	ST
551-1027	brakelining,BSA 190mm Fr.	ST
551-10511	brklining,TriBSA 6"dr,F&R	ST
551-1058	USE 551-10581	ea
551-10581	brklining,TriBSA floating	ST
551-10681	USE 551-2031	ea
551-10682	brklining,TriBSA 7" drum	ST
551-1094	USE 551-2009	ea
551-1095	brklining,66-68 Tri.front	ST
551-2009	brk.lining,TriBSA 8"front	ST
551-2030	brklining,71/72TriBSA DLS	ST
551-2031	brklining,TriBSA floating	ST
551-908	brakelining,7"Nor.F&R,1932-52	EA
551-946	brk.lining,BSA QDrear,etc	ST
551-951	brk.lining,TriBSA 8"front	ST

551-983	brklining,BSA 8"Fr.1/2Hub *	ST
551-996	brakelining,Norton rear	ST
551-997	brk.lining,F&R Bantam&Cub	ST
551-999	brakelining,Norton front	ST
552-	DRIVE CHAINS AND LINKS	*
552-----	-----	--
552-110037/42	chain,Norton ignition	EA
552-110037/44	chain,mag,Matchless G80	EA
552-110037/48	chain,Norton magdyno	EA
552-110037107	conlink,chain,rivet type	EA
552-11003726	conlink,magneto chain	EA
552-110038	chain,single,3/8x.225",per link	EA
552-110038/38	chain,Norton camshaft	EA
552-110038/50	chain,Bantam primary	EA
552-110038/62	chain,T15/20 primary	EA
552-110038107	conlink,camchain,rivet type	EA
552-11003826	conlink,Norton camchain	EA
552-110044	chain,single,1/2x3/16",per link	EA
552-110044/117	USE 552-110044/124	ea
552-110044/124	chain,rear,1/2x3/16	EA
552-11004426	conlink,1/2x3/16 chain	EA
552-110046/121	chain,rear 1/2x5/16	EA
552-110046/80	chain,1/2x5/16,primary*	EA
552-110046/83	chain,1/2x5/16,primary	EA
552-110046107	conlink,1/2x5/16 chain,rivet type	EA
552-11004626	conlink,1/2x5/16 chain	EA
552-11004630	offset link,1/2x5/16chain	EA
552-110054/110	chain,rear,5/8x1/4*	EA
552-110054107	conlink,5/8x1/4,rivet	EA
552-11005426	conlink,5/8x1/4 chain	EA
552-11005430	offset link,5/8x1/4 chain	EA
552-110056	chain,rear,5/8x3/8,per link	EA
552-110056/107	chain,rear,5/8x3/8	EA
552-110056/110	chain,rear,5/8x3/8*	EA
552-110056/128	chain,rear,5/8x3/8*	EA
552-110056107	conlink,5/8x3/8,rivet	EA
552-11005626	conlink,5/8x3/8 chain	EA
552-11005630	offset link,5/8x3/8 chain	EA
552-110500/52	chain,BSA A7/A10 dynamo	EA
552-11050026	masterlink,dynamo chain	EA
552-114038/62	chain,duplex,Triumph Cub	EA
552-114038/70	chain,duplex,250TriBSA1cy	EA
552-114038/70/ER	chain,duplex,econo repl.	EA
552-114038/72	chain,duplex,BSA B44&B50	EA
552-114038/72/ER	chain,duplex,econo repl.	EA
552-114038/78	chain,duplex,Tri.350/500	EA
552-114038/78/ER	chain,duplex,econo repl.	EA
552-114038/80	chain,duplex,A10 plunger pri.	EA
552-114038/84	chain,duplex,Tri.Unit 650	EA
552-114038/84/ER	chain,duplex,econo repl.	EA
552-114038/88	chain,duplex,primary	EA
552-114038/94	chain,duplex,primary	EA
552-11403826	con.link,duplex chain	EA
552-114513/70	chain,duplex,T160 primary*	EA
552-116038/80	chain,triplex,BSA A50&A65	EA
552-116038/80/ER	chain,triplex,econo repl.	EA
552-116038/82	chain,triplex,TriBSA 3cyl	EA
552-116038/82/ER	chain,triplex,econo repl.	EA
552-116038/84	chain,triplex,Tri.750twin	EA
552-116038/84/ER	chain,triplex,econo repl.	EA
552-116038/92	chain,triplex,NorCommando	EA
552-116038/92/ER	chain,triplex,econo.repl.	EA
552-11603826	conlink,triplex chain	EA
552-119058/110	chain,rear,5/8x1/4 GP	EA
552-11905826	conlink,5/8x1/4 GP chain	EA
552-11905830	offset link,5/8x1/4 GP	EA
552-119059/107	USE 552-119059/110	ea
552-119059/110	chain,rear,5/8x3/8 GP	EA
552-119059/111	chain,rear,5/8x3/8 GP	EA
552-119059/120	USE 552-119059/129	ea
552-119059/128	chain,rear,,5/8x3/8 GP	EA

552-119059/129	USE 552-119059/128	ea
552-11905926	conlink,5/8x3/8 GP chain	EA
552-11905930	offset link,5/8x3/8 GP	EA
552-122050/106	chain,5/8x3/8 O ring	EA
552-428/CL	conlink,Diamond 428 chain	EA
552-520/PK	partskit,Diamond520 chain	EA
552-520/RL	rivetlink,Diamond520chain	EA
552-530/110/ER	chain,rear,5/8x3/8,econo	EA
552-530/CL	conlink,Diamond 530 chain	EA
552-530/OL	offsetlink,Diamond 530	EA
552-530XDL/CL	conlink,Diamond XDL chain	EA
552-690006	chain parts kit,Renolds 110056	EA
553-	SPOKE SETS,CUSTOM & PERF.	*
553-----	-----	--
553-01/CHR	spokekit,16",early Tri.	ST
553-01/SS	spokekit,16"early Tri,SS/SS	ST
553-02/CHR	spokekit,16"TriBSAconical*	ST
553-02/SS	spokekit,16"TriBSAconical,SS/SS*	ST
553-03/CHR	spokekit,16"BSA QD hub	ST
553-03/SS	spokeset,16"BSA QD,SS/SS	ST
553-04/CHR	spokekit,16" Norton drum	ST
553-04/SS	spokekit,16"Nort drum,SS/SS	ST
553-05/SS	spokekit,16" Tri disc,ss*	ST
553-06/SS	spokekit,16"Nor850Mk3Disc	ST
553-07/SS	spokekit,16"BSA fullwidth rear,SS/SS	ST
553-08/SS	spokekit,16" Triumph sprunghub	ST
553-10/SS	spokeset,20",Vincent Fr,SS/SS	EA
553-21/SS	spokekit,21"Tri.frontDisc,SS/SS	ST
553-22/SS	spokekit,21",conic.6"F.dr,SS/SS*	ST
553-23/SS	spokekit,21"conic.8"F.dr,SS/SS	ST
553-24/SS	spokekit,21"TriBSA DLS 8",67on,SS/SS	ST
553-25/SS	spokekit,21"TriBSAfullwidth8",pre67	ST
553-26/SS	spokeset,21",NORdisc,SS/SS	ST
553-27/SS	spokekit,21"TriBSAfullwidth7"pre67,SS/SS	ST
553-31/SS	spokekit,18"stk.earlyTri,R,SS/SS*	ST
553-31/SS/A	spokekit,18",Tri,R,SS/SS,swaged*	ST
553-32/SS	spokekit,18"stk.conicalR,SS/SS	ST
553-33/SS	spokekit,18"stk.BSA QD R,SS/SS	ST
553-34/SS	spokekit,18"Tri.discR,lg.dia,SS/SS*	ST
553-38/SS	spokekit,18"stk,AtlasRear,SS/SS*	ST
553-39/SS	spokekit,18" Nor.ReardiscConv.	ST
553-40/SS	spokekit,18"BSA 1/2W.7"F.drums	ST
553-41/SS	spokekit,18" Nor.F.disc conv.	ST
553-42/SS	spokekit,18" Ariel Sq4 R.	ST
553-43/SS	spokekit,18"fullwidth8"dr,late,SS/SS	ST
553-44/SS	spokekit,18"rear,T20M Cub	ST
553-45/SS	spokekit,18"stk.conicF conv,SS/SS	ST
553-46/SS	spokeset,18"fullwidth8"drums,early	ST
553-47/SS	spokekit,18"Tri.FR.discConv,SS/SS	ST
553-51/SS	spokekit,19"stk.conical F,SS/SS	ST
553-52/SS	spokekit,19"stk.con.3cylR,SS/SS	ST
553-53/CHR	spokekit,as 53/SS,chromed	ST
553-53/SS	spokekit,19"stk.Tri.discF,SS/SS	ST
553-54/SS	spokekit,19"stk.TriT160 R,SS/SS	ST
553-55	spokekit,19"stkNorDrumF&R,galv.	ST
553-55/SS	spokekit,19"stkNorDrumF&R,SS/SS	ST
553-56/SS	spokekit,19"stk.Nor.discF,SS/SS	ST
553-57/SS	spokekit,19"stk.BSA1/2W.F,8"drum,SS/SS	ST
553-58/SS	spokekit19"TriBSAearly,8"FW dr,SS/SS*	ST
553-59/SS	spokekit,19"TriBSA 8"F,66onFW,SS/SS*	ST
553-60/SS	spokekit,19"TRIBSAfullwd/7"dr,SS/SS	ST
553-61/SS	spokekit,19" stk.BSA QD R,SS/SS	ST
553-62/SS	spokekit,19"stk.Nor.DiscR,SS/SS	ST
553-63/SS	spokekit,19"stk.earlyTriR,SS/SS	EA
553-64/SS	spokekit,19"stk.sprunghub,SS/SS	EA
553-65/SS	spokekit,19",BSA/ArielHub,SS/SS	ST
553-66/SS	spokekit,19",190mmBSA fr,SS/SS	ST
553-67/SS	spokekit,19"p.unitTri7"F.drums,SS/SS	ST
553-68/SS	spokekit,19"BSAhalfwidth7"F.drums,SS/SS	ST
553-69/SS	spokekit,19"preunit Tri.8"F drums	ST
553-70/SS	spokekit,19"DLS TriBSA,7"dr,SS/SS	ST

553-71/SS	spokekit,19"fr,T20M Cub	ST
553-72/SS	spokeset,19",Vincent R,SS/SS	ST
553-80/SS	spokekit,17"fr,3TA,SS/SS	ST
553-91	nipple,spoke,stainless 8Gx.281"	EA
553-92	nipple,spoke,stainless 9Gx.250"	EA
553-93	nipple,spoke,stainless 10Gx.300"	EA
553-94	nipple,spoke,stainless,10Gx.250"	EA
553-95	nipple,spoke,stainless,10Gx.281"	EA
553-96	nipple,spoke,stainless,8Gx.300"	EA
553-97	nipple,spoke,stainless,9Gx.281"	EA
553-98	nipple,spoke,stainless,9Gx.300"	EA
553-N10257	nipple,spoke,10Gx.250"	EA
553-N10289	nipple,spoke,10Gx.281"	EA
553-N10307	nipple,spoke,10Gx.300"	EA
553-N8289	nipple,spoke,8Gx.281"	EA
553-N8307	nipple,spoke,8Gx.300"	EA
553-N9257	nipple,spoke,9Gx.250"	EA
553-N9289	nipple,spoke,9Gx.281"	EA
553-N9307	nipple,spoke,9Gx.300"	EA
554-	WHEELS AND RIMS,CUSTOM	*
554-----	-----	--
554-01	rim,WM2x21,universal fr. *	EA
554-02	rim,3.5x16"Harley" type	EA
554-02/A	rim,3.5x16"Akront alloy,nonvalanced	EA
554-02/B	rim,3.5x16"Harley"type,alloy,valanced	EA
554-03	rim,WM2x18,universal	EA
554-03/SS	rim,WM2x18,universal,stainless	EA
554-04	rim,WM2x19,universal	EA
554-04/SS	rim,WM2x19,universal,stainless	EA
554-05	rim,WM3x18,universal	EA
554-05/SS	rim,WM3x18,universal,stainless	EA
554-06	rim,WM3x19,universal	EA
554-06/SS	rim,WM3x19,universal,stainless	EA
554-11	wheel assy,21"minibrake	EA
554-WM1X21	rim,WM1x21"alloy w/shoulder,undrilled	EA
554-WM2X18	rim,WM2x18"alloy w/shoulder,undrilled	EA
554-WM2X19	rim,WM2x19"alloy w/shoulder,undrilled	EA
554-WM3X18	rim,WM3x18"Akront alloy,undrilled	EA
554-WM3X19	rim,WM3x19"Akront alloy,undrilled	EA
555-	TYRES	*
555-----	-----	--
555-300X18/K70	3.00x18 Dunlop K70 tyre	EA
555-300X19/MAXI	3.00x19"DunlopMaxiRib	EA
555-300X19/SPEED	3.00x19"Avon Speedmaster	EA
555-300X20/SPEED	3.00x20"Avon Speedmaster	EA
555-300X21/SPEED	3.00x21"Avon Speedmaster	EA
555-325X17/SM	3.25x17 Avon SafetyMileage	EA
555-325X17/SPEED	3.25x17 Avon Speedmaster	EA
555-325X18/K70	3.25x18 Dunlop K70 tyre	EA
555-325X18/SPEED	3.25x18 Avon Speedmaster	EA
555-325X19/K70	3.25x19 Dunlop K70 tyre	EA
555-325X19/MAXI	3.25x19"DunlopMaxiRib	EA
555-325X19/SM	3.25x19 Avon SafetyMileage	EA
555-325X19/SPEED	3.25x19"Avon Speedmaster	EA
555-325X19/UG	3.25x19"Dunlop Uni-Grip tyre	EA
555-350X18/K70	3.50x18 Dunlop K70 tyre*	EA
555-350X18/SM	3.50x18Avon SafetyMileage	EA
555-350X19/K70	3.50x19"Dunlop K70 tyre	EA
555-350X19/SM	3.50x19"AvonSafetyMileage	EA
555-350X19/SPEED	3.50x19"Avon Speedmaster	EA
555-350X19/UG	3.50x19"Dunlop Uni-Grip tyre	EA
555-360X18/K81	3.60x18"Dunlop K81/TT100	EA
555-360X18/RR	90/90H18 Avon Roadrunner	EA
555-360X19/K81	3.60x19" Dunlop K81/TT100	EA
555-360X19/RR	90/90H19 Avon Roadrunner	EA
555-400X18/K70	400x18 Dunlop K70 tyre	EA
555-400X18/SM	4.00x18 AvonSafetyMileage	EA
555-400X19/SM	4.00x19 AvonSafetyMileage	EA
555-410X18/K81	4.10x18 Dunlop K81/TT100	EA
555-410X18/RR	100/90H18 Avon Roadrunner	EA
555-410X19/K81	4.10x19" Dunlop K81/TT100	EA

555-410X19/RR	100/90H19 Avon Roadrunner	EA
555-425X18/K81	4.25x18"Dunlop K81/TT100	EA
555-425X18/RR	110/90H18 Avon Roadrunner	EA
555-470X18/RR	120/90H18 Avon Roadrunner*	EA
555-500X16/SM	500x16Avon Safety Mileage	EA
555-510X16/RR	130/90H(MT90) Avon Roadrunner	EA
556-	INNER TUBES	*
556-----	-----	---
556-250/275X19	tube,2.50/2.75x19 inch	EA
556-275/300X19	tube,2.75/3.00x19 inch	EA
556-275/300X21	tube,2.75/3.00x21 inch	EA
556-275/300X21/A	tube,2.75/3.00x21 inch,DUNLOP	EA
556-300/350X19	tube,3.00/3.25/3.50x19"DUNLOP	EA
556-300X18	tube,3.00x18"DUNLOP	EA
556-325/350X18	tube,3.25/3.50x18 inch	EA
556-325/350X19	tube,3.25/3.50x19 inch	EA
556-325/410X18	tube,3.25/4.10x18"DUNLOP/MICHELIN	EA
556-325/410X19	tube,3.25/4.10x19"DUNLOP/MICHELIN	EA
556-350/400X19	tube,3.50/400x19 inch	EA
556-400/425X18	tube,4.00/4.25x18 inch*	EA
556-400/510X18	tube,4.00/5.10x18"Dunlop/MICHELIN	EA
556-450/475X18	tube,4.50/4.75x18 inches	EA
556-500/510X16	tube,500/510x16",HD type	EA
557-	RIM BANDS AND RIM LOCKS	*
557-----	-----	---
557-16	rimband,16"HD type	EA
557-2	rimband,WM2	EA
557-21	rimtape,21 inch	EA
557-3	rimband,WM3	EA
557-WM1	rimlock,WM1 security bolt,Dunlop	EA
557-WM2	rimlock,WM2 security bolt,rep.	EA
557-WM3	rimlock,WM3 security bolt,Dunlop	EA
557-WM3/ER	rimlock,WM3 security bolt,repl.	EA
558-	BRAKE PARTS & HIPERF.KITS	*
558-----	-----	---
558-01	dual disc.conver,Tri,HYDE	EA
558-02	brakekit,Nort,HYDE,HiPerf	EA
558-03	disc,12"Nort,HYDE*	EA
558-033	disc,12"Tri,incl.mt,HYDE	ST
558-04	brakehosekit,SS,T140D/Etype *	EA
558-05	brakehosekit,SS,T140/160V *	EA
558-08	brakehose kit,SS,Nort.Mk3 *	ST
558-09	hose kit,hydraulic,braided steel,univ.	ST
558-11	bracket,Lockheed caliper-Norton	EA
558-12	brakehosekit,SS,dual disc*	EA
558-13	conversion,mastercyl,13mm,Nort.	EA
558-20	clutch release,hydraulic,Tri6/750	ST
558-3261542	USE 99-2759	ea
558-3261553	USE 99-2759	ea
558-3528441	pin,spiral,m.cyl.plunger	EA
558-3761270	plunger,actuating,F.m.cyl	EA
558-4116153	pushrod,mastercyl,rear	EA
558-51	olive,braided hose	EA
558-52	banjo bolt,3/8x24UNF,stainless	EA
558-52/A	banjo bolt,3/8x24UNF,w/bleed nipple,SS	EA
558-52/B	banjo bolt,3/8x24UNF,w/brakeswitch,SS	EA
558-53	banjo bolt,M10X1,stainless	EA
558-53/A	banjo bolt,M10X1,w/bleed nipple,stainles	EA
558-53/B	banjo bolt,M10X1,w/brakeswitch,stainless	EA
558-54	washer,copper,banjo	EA
558-55	T fitting,3/8x24UNF,chrome w/bracket	EA
558-57	fitting,brakehose,male,M10x1,stainless	EA
558-58	fitting,brakehose,male,3/8X24,stainless	EA
558-59	banjo,brakehose,stainless	EA
558-61	brakehose,braided stainless,teflon lined	FT
558-CP2696	caliper,alloy,1-5/8"	EA
558-CP31254	mastercyl,adj,RH	EA
558-CP31254RK	sealkit,mastercyl	EA
558-CP31255	mastercyl,adj,LH	EA
558-CP3342RK	sealkit,m.cyl,fr&rear,stock Tri.	EA
558-CP4518K	rebuild kit,caliper,alloy 1-5/8"	EA

558-K19866TP	cotter pin,disc pad	EA
558-SSB1250	sealkit,2disc m.cyl.*	EA
558-SSB2618	caliper rebuild kit,2disc,36mm	EA
561-	HANDLE BAR MIRRORS	*
561-----	-----	---
561-01	mirror,5/16",rect,short	EA
561-02	mirror,clampon,rec,short	EA
561-03	mirror,clampon rnd,short	EA
561-04	mirror,8mm,round,short st*	EA
561-05	mirror,bar end,rect.head,econo	EA
561-05/A	mirror,barend,rect,Stadium	EA
561-06	mirror,barend,round,Stadium	EA
561-07	mirror,Maltese cross,5/16"	EA
561-08	mirror,Maltese cross,clampon	EA
561-607249	mirror,10mm round Triumph,blk	EA
561-620060	mirror,8mm,round,Triumph	EA
561-HBM28	mirror,clampon,rect,long	EA
561-HBM28516	mirror,5/16"rect,short st	EA
561-HBM288MM	mirror,8mm rectangular hd	EA
561-HBM28M	mirror,5/16"rect,long stm	EA
561-HBM28NOR	mirror,3/8",rect,short st	EA
561-HBM29	mirror,clampon,round,long	EA
561-HBM29M	mirror,5/16"round,long st	EA
561-HBM29NOR	mirror,3/8",round,short	EA
561-HBM30	mirror,clampon,rnd,econo*	EA
561-RH28	mirror head,rectangular	EA
561-RH29	mirror head,round	EA
562-	CRASH BARS	*
562-----	-----	---
562-01	crash bar,universal*	EA
563-	SADDLEBAGS & TANKBAGS	*
563-----	-----	---
563-01	saddlebags,nylon throOver	EA
563-11	tankbag,TRIUMPH,magnetic	EA
563-11/A	tankbag,TRIUMPH,for parcel grid	EA
563-12	tankbag,MATCHLESS,magnetic	EA
563-13	tankbag,ROYAL ENFIELD,magnetic	EA
563-14	tankbag,VELOCETTE,magnetic	EA
563-15	tankbag,AJS,magnetic	EA
563-16	tankbag,BSA,magnetic	EA
563-17	tankbag,NORTON,magnetic	EA
564-	LUGGAGE RACKS	*
564-----	-----	---
564-115	luggagerack,pre80 TriTwin	EA
564-121	luggagerack,Nor.Commando	EA
564-123	luggagerack,1980onTriumph	EA
565-	WINDSHIELDS	*
565-----	-----	---
565-01	windshield,univers,no brks.	EA
566-	TOURING FAIRINGS	*
566-----	-----	---
566-01	fairing,handlebar mt.	EA
567-	CAFERACER BODY COMPONENTS	*
567-----	-----	---
567-01	fairing,JPN Comm,TwinHdlt	EA
567-01/A	fairing,JPNCom,singleHdlt	EA
567-02	decal kit,JPN fairing	ST
567-03	mirror,John Player Comm.	EA
567-04	tankcover,JohnPlayerNort.	EA
567-05	mudguard,fr.JPN,fiberglas	EA
567-06	seat,dual,JohnPlayerNort.	EA
567-06/A	seat,single,JohnPlayerNor	EA
567-07	decal kit,JPN seat	ST
567-09	windscreen,JPN fairing	EA
567-11	fairing,Norvil Prod.Racer	EA
567-12	seat,Norvil Product.Racer	EA
567-13	tank,petrol,Norvil alloy	EA
567-13/A	tank,fiberglas,std Norvil	EA
567-13/B	tank,fiberglas,lg.Norvil	EA
567-18	windscreen,spare,Norvil	EA
567-19	cover,hdlt,NORVIL fairing,spare	EA

567-21	tank,gas,Slimline,fibergl	EA
567-21/A	tank,gas,alloy,Slimline Nort	EA
567-22	tank,oil,Slimline,fibergl	EA
567-22/A	tank,oil,Slimline,alloy	EA
567-23	batterybox,slimline Nort.	EA
567-24	seat,Manx type,slimline	EA
567-31	tank,gas,alloy,Thruxton T120	EA
567-32	sidepanel set,classic,oilframe twins	PR
567-43	toggle,tankstrap,Featherbed,chrome*	EA
571-	TACH & SPEEDO CABLES	*
571-----	-----	---
571-25/A	cable,2'1"magnetic,square	EA
571-25/C	cable,2'1"magneticW/spade	EA
571-28/A	cable,2'4"magnetic,square*	EA
571-28/C	cable,2'4"magneticW/spade*	EA
571-28/D	cable,2'4" chrono,w/spade	EA
571-30/C	cable,2'6"magneticW/spade*	EA
571-30/E	cable,2'6"w/spade,mod.for minitach	EA
571-31/A	cable,2'7"magnetic,square	EA
571-32/C	cable,2'8"magneticW/spade*	EA
571-32/D	cable,2'8",chrono W/spade	EA
571-32/F	cable,2'8"magnetic,sq,flanged type*	EA
571-33/A	cable,2'9"magnetic,square	EA
571-33/E	cable,2'9"magnetic,mod.for minitach	EA
571-34.5/A	cable,2"10-1/2"magnetic,square	EA
571-34/B	cable,2'10" chrono,square	EA
571-35/C	cable,2'11"magneticWspade	EA
571-38/D	cable,3'2",chrono W/spade	EA
571-40/A	cable,3'4"magnetic,square	EA
571-41/B	cable,3'5" chrono,square	EA
571-42/A	cable,3'6"magnetic,square	EA
571-44/A	cable,3'8"magnetic,square	EA
571-44/B	cable,3'8",chrono,square	EA
571-46.75/B	cable,3'10-3/4",chrono,square	EA
571-49/B	cable,4'1",chrono,square	EA
571-54/B	cable,4'6" chrono,square	EA
571-56/A	cable,4'8"magneticSquare	EA
571-56/B	cable,4'8"chrono,square	EA
571-56/E	cable,4'8"magneticSq,mod.for minispeedo	EA
571-58/A	cable,4'10"magneticSquare	EA
571-59/B	cable,4'11" chrono,square	EA
571-603998	cable,2'1-1/2",TR5T tach.	EA
571-63/A	cable,5'3"magnetic,square	EA
571-63/E	cable,6'3"mod.for minispeedo	EA
571-65/A	cable,5'5",magnetic,square	EA
571-65/B	cable,5'5" chrono,square	EA
571-67.5/B	cable,5'7-1/2",chrono,sq.	EA
571-67/A	cable,5'7"magnetic,square	EA
571-67/E	cable,5'7"mod.for minispeedo	EA
571-69/A	cable,5'9"magnetic,square	EA
571-69/E	cable,5'9"mod.for minispeedo	EA
571-71/A	cable,5'11"magneticSquare	EA
571-71/E	cable,5'11"mod.for minispeedo	EA
571-77/A	cable,6'5"magnetic square	EA
571-77/E	cable,6'5"mod.for minispeedo	EA
572-	TACHS, SPEEDOS, DRIVES, & PTS	*
572-----	-----	---
572-01	spade & clip,tach cable	ST
572-02	bezel&glass,speedo/tach,magnetic,80mm	ST
572-03	knob,trip control,short,SSM	EA
572-03/A	knob,trip control,medium,SSM	EA
572-03/B	trip control knob,chrono	EA
572-04	knob,trip control,long,SSM	EA
572-04/A	trip control w/knob,long,chrono	EA
572-05	bulbholder assy,Chrono	EA
572-06	bezel,speedo/tach,chrono,3"	EA
572-07	bezel,speedo,TRIUMPH nacelle Chron.	EA
572-07/A	bezel,speedo,dash mt.Chron.	EA
572-08	rubber grommet,SSM/RSM speedo case	EA
572-09	rubber ring,SSM/RSMglass	EA
572-10	bulbholder assy,repl.instr*	EA

572-11	tach,4-1,8000 rpm, repl, no studs*	EA
572-11/A	tach,4-1,8000 rpm, repl, w/studs*	EA
572-12	tach,4-1,Veglia,NVT	EA
572-13	tach,4-1,Veglia,MERIDEN,exch.	EA
572-21	speedo,600/240 kph, repl, no studs*	EA
572-21/A	speedo,600/240 kph, repl, w/studs*	EA
572-22	speedo,1000/150mph, Veglia, MERIDEN, exch.	EA
572-23	speedo,1000/150mph, repl, no studs*	EA
572-23/A	speedo,1000/150mph, repl, w/studs*	EA
572-24	speedo,1000-1Veglia,NVT	EA
572-243800	speedo,1-1CustomW/bracket, no adaptor	EA
572-243830	speedo,1.6-1customW/brack	EA
572-243900	tach,2-1, custom, w/bracket	EA
572-243910	tach,4-1, custom, w/bracket	EA
572-243951	adaptor, cable, customInstr	EA
572-3027603711	USE 21-0778	ea
572-3028201411	USE 60-2391	ea
572-3131513501	cap,SSM/RSM cable entry	EA
572-3152301	USE 60-0494	ea
572-31523106	USE 60-0494	ea
572-4111812647	USE 572-04	ea
572-4111812654	USE 572-04	ea
572-51	tachdrive kit, compl, unit single	ST
572-607091	speedodrive, Veglia type, 79onTri	EA
572-61	screw, SSM/RSM speedo case bottom	EA
572-BG150804	tachdrive,1-1,GS&A10SR	EA
572-BG150805	tachdrive,1-1,preCommando	EA
572-BG150806	tachdrive,2-1,early Comm.	EA
572-BG5330104	speedodrive,2.1-1	EA
572-BG5330164	speedodrive,1.25-1	EA
572-BG5330164/ER	speedodrive,1.25-1,econo repl*	EA
572-BG5330168	speedodrive,1.25-1	EA
572-BG5330171	speedodrive,1.25-1	EA
572-BG5330257	speedodrive,2-1*	EA
572-BG5330287	speedodrive,2-1*	EA
572-BG533031/ER	speedodrive,2-1,econo repl*	EA
572-BG5333164	speedodrive, Triumph T160V	EA
572-BG5333171	speedodrive, Norton850 Mk3	EA
572-CORE	core chg, Smiths RSM & SSM	EA
572-CORE/CHRONO	core charge, Smiths chronometric	EA
572-RC83	tach,8000RPM,CW, Chrono, exch.	EA
572-RSM200102	tach,4-1,12,000 RPM, small, exch.	EA
572-RSM300100	tach,2-1, ccw, greyface, exch.	EA
572-RSM300102	tach,2-1, ccw, exch.	EA
572-RSM300300	tach,2-1,8000rpm, exch.	EA
572-RSM300301	tach,4-1,10,000 rpm, exch.	EA
572-RSM300302	tach,3-1,8000 rpm, exch.	EA
572-RSM300303	tach,4-1,8,000 rpm, exch.	EA
572-RSM300306	tach,3-1,10,000 rpm, exch.	EA
572-RSM300312	tach,4-1,9000rpm, Norton, exch.	EA
572-RSM300313	tach,4-1,10,000 rpm, lg.#s, exch.	EA
572-RSM300314	tach,3-1,10,000 rpm, lg.#s, exch.	EA
572-RSM300315	tach,4-1,9000rpm, Norton, exch.	EA
572-RSM300319	tach,4-1,10,000 rpm, exch.	EA
572-RSM300321	tach,4-1,10,000rpm, NVT, exch.	EA
572-RSM300323	tach,4-1,10,000, exch.	EA
572-RSM300402	tach,4-1,8000RPM, CCW, for nacelle, exch.	EA
572-RSM300600	tach,4-1,10,000 rpm, NVT, exch.	EA
572-S411	speedo,1600/55MPH, Chrono Dshape, exch.	EA
572-S4331L	speedo, Chronometric, exch.	EA
572-S433M	speedo, Chronometric, exch.	EA
572-S46791L	speedo, Chronometric, exch.	EA
572-S4803L	speedo, Chronometric, exch.	EA
572-S5463L	speedo, Chronometric, exch.	EA
572-S60811	speedo,1450/120MPH chrono, exch.	EA
572-S662N	speedo,1550/90MPH, Chrono Dshape, exch.	EA
572-SC110106	USE 572-S662N	ea
572-SC110214	speedo,1550/100MPH, Chrono Dshape, exch.	EA
572-SC330301	speedo,1500/120MPH chrono, exch.	EA
572-SC330419	speedo,1476/120MPH chrono, exch.	EA
572-SC520106	USE 572-S5463L	ea

572-SC530122	speedo,1440/140mphCCW,chr,exch.	EA
572-SC530134	speedo,1620/120MPH,Chrono,exch.	EA
572-SSM200107	speedo,1600/120 mph,small,exch.	EA
572-SSM300100	speedo,1600/120 mph,exch.	EA
572-SSM300102	speedo,1000/150mph,Norton,exch.	EA
572-SSM300105	speedo,1000/150mph,no trip,exch.	EA
572-SSM300109	speedo,150/1000,Norton,exch.	EA
572-SSM300200	speedo,1600/120mph,no trip,exch.	EA
572-SSM400100	speedo,1600/120 mph,exch.	EA
572-SSM400300	speedo,1000/150 mph,NVT,exch.	EA
572-SSM400302	speedo,1000/150 mph,exch.	EA
572-SSM400303	speedo,600/240KPH,exch.	EA
572-SSM400400	speedo,1000/150mph,NVT,exch.	EA
572-SSM500100	speedo,1600/120 mph,exch.	EA
572-SSM500101	speedo,1000/190 KPH,exch.	EA
572-SSM500103	speedo,1600/120 mph,exch.	EA
572-SSM500105	speedo,1000/150 mph,exch.	EA
572-SSM500106	speedo,1000/150 mph,exch.	EA
572-SSM500200	speedo,1600/120mph,64on6T,etc,exch.	EA
572-SSM500700	speedo,1000/150mph,large#,exch.	EA
572-SSM500701	speedo,600/250 KPH,large#,exch.	EA
572-SSM500702	speedo,1600/120MPH,large#,exch.	EA
572-SSM500703	speedo,1000/190KPH,large#,exch.	EA
621-	FUEL PETCOCKS	*
621-----	-----	--
621-01	tap,3/8"HDtype,dual lever	EA
621-02	tap,off/main/res,1/4"BSP,LH,Paoli	EA
621-03	tap,off/main/res,1/4"BSP,RH,Paoli	EA
621-115	tap,1/4"lever type,brass,noTube	EA
621-121	tap,3/8x3/16,pushpull *	EA
621-121/ER	tap,3/8x3/16",pushpull,econo	EA
621-128	tap,1/4"lever type,noTube,econo	EA
621-129	USE 621-132	ea
621-131	tap,1/4"lever type,noTube	EA
621-131/ER	tap,1/4"lever type,no tube,econo	EA
621-132	tap,1/4"lever type,w/tube	EA
621-132/ER	tap,1/4"lever type,w/tube,econo	EA
621-134	tap,1/4"pushpull,no tube,econo	EA
621-134/A	tap,1/4" pushpull,w/tube	EA
621-136	tap,1/4"lever w/tag,no tube	EA
621-136/ER	tap,1/4"lever w/tag,no tube,econo	EA
621-137	tap,1/4"lever w/tag &tube	EA
621-137/ER	tap,1/4"lever w/tag &tube,econo	EA
621-428075	tap,3/8",banjo type	EA
621-54	tap,1/4,dual plunger*	EA
621-607266	tap,1/4"main,late Triumph,PAOLI	EA
621-607266/ER	tap,1/4"main,late Triumph,repl.	EA
621-607267	tap,1/4"reserve,late Tri,PAOLI	EA
621-607267/ER	tap,1/4"reserve,late Tri,repl.	EA
621-607508	tap,LH,w/female inl.nut,lateTri*	EA
621-607509	tap,RH,w/female inl.nut,lateTri*	EA
621-678057	tap,1/8",banjo type	EA
621-71	USE 621-115	EA
622-	FUEL AND OIL TANK CAPS	*
622-----	-----	--
622-01	cap,gas,HD style,vented	EA
622-03	USE 622-04/B	ea
622-04	cap,gas,2.5"pre 1982 Tri,etc,flat	EA
622-04/A	cap,gas,2.5"pre 1982 Tri,etc,domed	EA
622-04/B	cap,oil,2.5"nonvented,flat	EA
622-05	cap,gas,locking pre82 Tri	EA
622-06	cap,2"oil tank,no dipstick,chrome*	EA
622-07	cap,oiltank,pushin chrome	EA
622-07/A	cap,oiltank,tempguage	EA
622-08	cap,gas,MONZAtype,alloy,2.5"	EA
622-08/A	collar,alloy,Monza 2.5" cap	EA
622-08/B	gasket,rubber,Monza cap,2-1/2"	EA
622-09	cap,gas,MONZAtype,alloy,2"	EA
622-09/B	gasket,rubber,Monza cap,2"	EA
622-607503	cap,gas,82 on flipUp type	EA
622-607552	cap,gas,82-flipUp locking	EA

622-607657	cap,gas,82- round locking	EA
623-	FUEL & OIL LINE FITTINGS	*
623-----	-----	---
623-01	adaptor,3/8X1/4BSP,BSAtank/TriTap	EA
623-02	washer,fibre,1/4" tap	EA
623-02/A	washer,copper/rubber,tap	EA
623-10	ferrule,fuel&oiline,large	EA
623-102	plunger&cork,pushpull tap*	EA
623-103	cork,pushpull tap plunger	EA
623-104	cork,blade pushpull taps	EA
623-105	screw,plunger,pushpullTap	EA
623-11	ferrule,fuel&oiline,small	EA
623-12	ferrule,fuel&oiline,med*	EA
623-13	spigot,fueline,large	EA
623-14	spigot,fueline,small	EA
623-15	nut,fueline,large	EA
623-16	nut,fueline,small	EA
623-24	fitting,T junction,1/4"	EA
623-25	fitting,Tjunct.w/nut,1/4"	EA
623-26	fitting,elbow w/lg.nut,fuel	EA
623-27	fitting,elbow w/sm.nut,fuel	EA
624-	FUEL AND OIL LINE	*
624-----	-----	---
624-01	hose,1/4"braided clear*	FT
624-01/A	hose,1/4"braided clear,25ft.	EA
624-02	hose,5/16"braided clear	FT
624-02/A	hose,5/16"braided clear,25ft.	EA
624-04	hose,3/16"braided clear	FT
624-04/A	hose,3/16",braided clear,25ft.	EA
624-07	hose,3/8"steelbraided,6Ft.	EA
624-08	hose,1/4"steelBraided,3Ft	EA
624-09	hose,5/16steelbraided,6 ft.	EA
624-11	clamp,1/4&5/16steelbr.hose,chr	EA
624-12	clamp,3/8steelbrHose,chr	EA
624-21	oiline set,Trident/R3,stock	ST
624-31	hose,3/16"herringbone"braided rubber *	FT
624-32	hose,1/4"herringbone"braided rubber *	FT
624-33	hose,9/32"herringbone"braided rubber*	FT
624-34	hose,5/16"herringbone"braided rubber*	FT
624-35	hose,3/8"herringbone"braided rubber*	FT
624-36	hose,7/16"herringbone"braided rubber *	FT
624-37	hose,7/32"herringbone"braided rubber *	FT
624-38	hose,1/2"herringbone"braided rubber *	FT
624-41	hose,3/16"clear	FT
624-42	hose,1/4" clear*	FT
624-44	hose,5/16" clear	FT
624-51	hose,3/16"black rubber,fuel/oil	FT
624-52	hose,1/4"black rubber,fuel/oil	FT
624-53	hose,5/16"black rubber,fuel/oil	FT
624-54	hose,3/8"black rubber,oil	FT
624-63	hose,5/16 thinwall,breather*	FT
624-64	hose,5/16 thickwall,breather*	FT
624-71	hose,breather,D section,greay	FT
624-72	hose,3/4"breather,greay	FT
624-81	hose,3/16"blk.neoprene,BSA fueline	FT
631-	OIL FILTERS	*
631-----	-----	---
631-01	oilfilter,full flow *	EA
631-01/CHR	oilfilter,as631-01,chrome*	EA
631-02	oilfilter,tube type	EA
632-	FUEL FILTERS	*
632-----	-----	---
632-01	fuelfilter,Viewall type	EA
633-	AIR FILTERS	*
633-----	-----	---
633-01	a/c element,round,std.paper	EA
633-01/A	a/c elem,rnd.K&N washable	EA
633-01/B	a/c element,round,std.gauze	EA
633-01/ER	a/c element,round,paper,econo repl.	EA
633-02	adaptor,airfilter,900 Amal*	EA
633-03	adaptor,airfilter,389 Amal	EA

633-04	adaptor,airfilter,376&600Amal	EA
633-05	adaptor,airfilter,289&375Amal	EA
633-11	plate,airfilter rear,raised	EA
633-389	USE 633-900	ea
633-389/A	filter,central,Amal 389	EA
633-600	filter,offset,Amal376&600*	EA
633-600/A	filter,centralAmal376&600 *	EA
633-600/A/ER	filter,centralAmal376&600,econo*	EA
633-600/ER	filter,offset,Amal376&600,compl,econo	EA
633-621220	K&N T160 cr.case breather	EA
633-621340	K&N74onTriTwinPriBreather	EA
633-621360	K&N 70-73 Tri priBreather	EA
633-900	filter,offset,Amal 389&900*	EA
633-900/A	filter,central,Amal 900	EA
633-900/ER	filter,offset,Amal 900,compl,econo.	EA
633-RC109	K&N tapered a/c,Amal 900	EA
633-RC125	K&Ntapered a/c,Mk2&Mikuni*	EA
633-RC16	K&N filters,Triumph T160V	EA
633-RC17	K&Nfilter,Amal 376 & 600	EA
633-RC1950	K&N offset a/c,Mk2&Mikuni,30-34mm,thick*	EA
633-RC1950/A	K&N offset a/c,MK2&Mikuni,30-34mm,thin	EA
633-RC2362	K&N,dual Mk2,assy.	EA
633-RC2870	airfilter,K&N,Mikuni 26&28mm	EA
633-RC33	K&Noffset filter,Amal 900	EA
633-RC850	K&N filter assy,Mikuni 36/38mm	EA
633-U801	Unifilter,foam,Amal 900	EA
633-U802	Unifilter,foam,Mk2&Mikuni	EA
634-	VELOCITY STACKS	*
634-----	-----	--
634-275	velocity stack,275/276,screened,350"long	EA
634-375	velocity stack,Amal375	EA
634-376	USE 634-600	ea
634-389	velocity stack,Amal389&689,screened,2.45	EA
634-389/A	velocity stack,389&689,1.375",screened	EA
634-600	velocity stack,Amal376&600	EA
634-900	velocity stack,Amal900&1900,screened	EA
634-900/A	velocity stack,Amal900&1900,short*	EA
641-	OIL COOLERS & SUMP VALVES	*
641-----	-----	--
641-01	oilcooler,mini	EA
641-03	oilcoolerkit,HYDE Nort.	EA
641-04	oilcooler kit,HYDE Triumph	EA
641-09	thermostat,oil,3 cyl.	EA
641-10	thermostat,oil,twins	EA
641-11	USE 641-10	ea
641-21	valve,antidrain,inline,universal	EA
645-	CHAINOILERS	*
645-----	-----	--
645-01	chainoiler kit,Scottoil	EA
646-	OIL PRESS AND TEMP GUAGES	*
646-----	-----	--
646-01	oilpressure gauge	EA
646-10	adaptor,pressure gauge,Norton	EA
651-	CARB MANIFOLD ADAPT. KITS	*
651-----	-----	--
651-01	man,1Mk2/Mikuni36-38,Comm	EA
651-02	man,1Mk2/Mikuni30-34,Comm	EA
651-03	man,1concentric,pre Comm.	EA
651-04	man,1 Conc.or Mono ,Comm.	EA
651-05	man,1Mikuni,pre Comm,30-34mm*	EA
651-09	man,1 Mk2/mikuni,TR6orTR7*	EA
651-10	man.rubber,flanged30-34mm	EA
651-11	man.rubber,flanged36-38mm	EA
651-12	man.rubber,flanged26-28mm	EA
651-13	man,pre69 Bonn,Mk2/Mikuni,20TPI*	PR
651-14	man,69-71 T120,Mk2/Mikuni,16TPI*	PR
651-25	man,bolton,Mikuni/AmalMk2	EA
651-26	manifolds,commando,dualMK2	PR
651-26/A	man,Commando,dual,Mikuni	PR
691-	AMAL CARBS & PARTS	*
691-----	-----	--

691-1034060/2.5	slide,throttle,#2-1/2	EA
691-1034060/3	slide,throttle,#3	EA
691-1034060/3.5	slide,throttle,#3-1/2	EA
691-1034060/4	slide,throttle,#4	EA
691-1034070	USE 691-1034084	ea
691-1034084	velocity stack,1000 series	EA
691-116162	washer,fibre,mono	EA
691-124026	jet,SPECIFY SIZE	ea
691-124026/15	jet,#15	EA
691-124026/20	jet,#20	EA
691-124026/25	jet,#25	EA
691-124026/30	jet,#30	EA
691-124026/35	jet,#35	EA
691-124026/40	jet,#40	EA
691-124026/45	jet,#45	EA
691-124026/50	jet,#50	EA
691-13163	washer,fibre,banjo bolt	EA
691-14032	spring,tickler	EA
691-14175	washer,fibre,mono	EA
691-23110	USE 00-0203	EA
691-2441048	oring,mono,376/389/689	EA
691-2442283	rod,throttle,T160	EA
691-244765	oring,mono,375	EA
691-2622065	plug,drain,float bowl,MK2	EA
691-2622066	washer,sealing,drainplug	EA
691-2622067	clip,jet needle	EA
691-2622069	spindle,float	EA
691-2622070	gasket,float bowl	EA
691-2622073	screws,intake adaptor	EA
691-2622075	lever&bracket assy,choke,w/handle	EA
691-2622079	plunger,choke,lever oper.	EA
691-2622084	spring,choke plunger,cable operated	EA
691-2622086	screw,float bowl,Mk2 carb	EA
691-2622087	spring,click,choke	EA
691-2622091	adaptor,threaded,choke,cable oper.	EA
691-2622092	cap,plunger,cable operated	EA
691-2622094	plunger,choke,cable oper.	EA
691-2622124	needle,jet,"2A1"ident.	EA
691-2622128	USE 691-622076	ea
691-2622129	USE 691-622077	ea
691-2622130	seat,float needle,Mk2	EA
691-2622134	clip,air vent tube	EA
691-2622139	float bowl	EA
691-2622142	plug,blanking,jet	EA
691-2622144	gasket&oring kit,Mk2 Amal	EA
691-2622145	tube,vent	EA
691-2622149	choke plunger assy,cable operated	EA
691-2622169	lever&bracket assy,choke,RH T140E	EA
691-276AE/1BE	carb,1"clip mt,Norton 16H	EA
691-276AU/1BE	carb,1-1/16"clip mt,Norton ES2	EA
691-276BR/1B	carb,1-1/16"flange mt,BSA M21	EA
691-276C/1B	carb,1",flange mt,BSA M20	EA
691-276CH/2DS	carb,1-1/16"clip mt,Vin.Rapide,Rear	EA
691-276DK/1AT	carb,15/16",flange mt,Tri.5T	EA
691-276DQ/1DV	carb,1-1/16"clip mt,Vin.Rapide Front	EA
691-276EU/1DB	carb,15/16",flange mt,BSA A7	EA
691-276FH/1AT	carb,1",flange mt,T100	EA
691-276GG/1DB	carb,1-1/16"flange mt,BSA A10	EA
691-29057	guide,choke,mono	EA
691-29201	clip,top ring,mono	EA
691-29276	gasket set,pre-monobloc carb *	EA
691-2928030	needle,jet,"2C3" ident.	EA
691-2928031/105	jet,needle,#105	EA
691-2928060	slide,SPECIFY SIZE	ea
691-2928060/2	slide,throttle,#2	EA
691-2928060/2.5	slide,throttle,#2-1/2	EA
691-2928060/3	slide,throttle,#3	EA
691-2928060/3.5	slide,throttle,#3-1/2	EA
691-2928060/4	slide,throttle,#4	EA
691-2928061	spring,throttle slide	EA
691-2928062	adaptor,intake	EA

691-2928064	cap,mix. chamber,for adj.	EA
691-2928071	disc,needle retaining	EA
691-2928079	jet,needle,SPECIFY SIZE	ea
691-2928079/106	jet,needle,106	EA
691-2928079/107	jet,needle,107	EA
691-2928079/108	jet,needle,108	EA
691-2928079/109	jet,needle,109	EA
691-2928100/120	jet,needle,alcohol,120	EA
691-2928100/125	jet,needle,alcohol,125	EA
691-2928119	adaptor,rubber,28-34mm,alcohol	EA
691-2928122	jet,needle,SPECIFY SIZE	ea
691-2928122/105	jet,needle,#105	EA
691-2928122/106	jet,needle,#106	EA
691-2928122/107	jet,needle,#107	EA
691-2928122/108	jet,needle,#108	EA
691-2928122/109	jet,needle,#109	EA
691-2928123	adaptor,rubber,28-34mm MK2	EA
691-2928124	needle,jet,"2D2"ident.	EA
691-2928126	velocity stack,Mk2	EA
691-2928146	clamp,intake adaptor hose	EA
691-2928170	slide,SPECIFY SIZE	ea
691-2928170/2.5	slide,throttle,chrome#2.5	EA
691-2928170/3	slide,throttle,chrome #3	EA
691-2928170/3.5	slide,throttle,chrome#3.5	EA
691-2928170/4	slide,throttle,chrome #4	EA
691-2928178	repair kit,Mk2	EA
691-332017	screw,air,mono	EA
691-343011	body,tickler,mono	EA
691-375057	jet block,25/32" bore	EA
691-375060/3	slide,#3,mono	EA
691-375060/3.5	slide,#3-1/2,mono	EA
691-375060/4	slide,#4,mono	EA
691-375061	spring,throt.return,mono	EA
691-375062	slide,choke,mono	EA
691-375063	needle,jet,mono,"B",w/clip	EA
691-375067	gasket,jetblock,mono	EA
691-376/15	carb,15/16" monobloc	EA
691-376/16	carb,1" monobloc	EA
691-376/17	carb,1-1/16" monobloc	EA
691-376/27	carb,1-1/16" monobloc,chopped	EA
691-376/75	carb,15/16" monobloc,chopped	EA
691-376057	jet block,1-1/16 *	EA
691-376060/3	slide,#3,mono	EA
691-376060/3.5	slide,#3.5,mono	EA
691-376060/4	slide,#4,mono	EA
691-376060/5	slide,#3,mono	EA
691-376061	spring,thr.return,mono	EA
691-376062	slide,choke,mono	EA
691-376063	needle,jet,"C",mono,w/clip	EA
691-376065	ring,cap,mono	EA
691-376066	tube,air intake	EA
691-376067	washer,fibre,mono	EA
691-376068	screw,thr.stop,mono	EA
691-376069	spring,thr.stop screw,mon	EA
691-376070	screw,peg,mono	EA
691-376072	jet,needle,SPECIFY SIZE	ea
691-376072/105	jet,needle,#105,mono	EA
691-376072/106	jet,needle,#106,mono	EA
691-376072/107	jet,needle,#107,mono	EA
691-376072/109	jet,needle,#109,mono	EA
691-376073	jetholder,short,mono	EA
691-376074	USE 82-9204	ea
691-376075	nut,mainjet cover,mono	EA
691-376076	jet,pilot,SPECIFY SIZE	ea
691-376076/15	jet,pilot,#15,mono	EA
691-376076/20	jet,pilot,#20,mono	EA
691-376076/25	jet,pilot,#25,mono	EA
691-376076/30	jet,pilot,#30,mono	EA
691-376076/35	jet,pilot,#35,mono	EA
691-376076/40	jet,pilot,#40,mono	EA
691-376077	cover,floatchamber,Mono	EA

691-376077/A	cover,extended,Mono float *	EA
691-376078	gasket,float chamber,mono	EA
691-376079	screw,float chamber,mono	EA
691-376083	float,mono *	EA
691-376085	spindle,float,mono	EA
691-376086	plunger,tickler,mono	EA
691-376087	spring,tickler,mono	EA
691-376088	seat,float,mono,w/needle	EA
691-376089	USE 691-622197	ea
691-376090	banjo,single,threaded	EA
691-376091	bolt,banjo,mono	EA
691-376092	washer,fibre*	EA
691-376093	filter,banjo	EA
691-376094	spacer,float spindle,mono	EA
691-376095	nut,pilotjet cover,mono	EA
691-376097	banjo,single,metal	EA
691-376097/ER	banjo,single,plastic	EA
691-376100	jet,main,SPECIFY SIZE	EA
691-376100/100	jet,main,#100	EA
691-376100/110	jet,main,#110	EA
691-376100/120	jet,main,#120	EA
691-376100/130	jet,main,#130	EA
691-376100/140	jet,main,#140	EA
691-376100/150	jet,main,#150	EA
691-376100/160	jet,main,#160	EA
691-376100/170	jet,main,#170	EA
691-376100/180	jet,main,#180	EA
691-376100/190	jet,main,#190	EA
691-376100/200	jet,main,#200	EA
691-376100/210	jet,main,#210	EA
691-376100/220	jet,main,#220	EA
691-376100/230	jet,main,#230	EA
691-376100/240	jet,main,#240	EA
691-376100/250	jet,main,#250	EA
691-376100/260	jet,main,#260	EA
691-376100/270	jet,main,#270	EA
691-376100/280	jet,main,#280	EA
691-376100/290	jet,main,#290	EA
691-376100/300	jet,main,#300	EA
691-376100/310	jet,main,#310	EA
691-376100/320	jet,main,#320	EA
691-376100/330	jet,main,#330	EA
691-376100/340	jet,main,#340	EA
691-376100/350	jet,main,#350	EA
691-376100/360	jet,main,#360	EA
691-376100/370	jet,main,#370	EA
691-376100/380	jet,main,#380	EA
691-376100/390	jet,main,#390	EA
691-376100/400	jet,main,#400	EA
691-376100/410	jet,main,#410	EA
691-376100/420	jet,main,#420	EA
691-376100/430	jet,main,#430	EA
691-376100/440	jet,main,#440	EA
691-376100/450	jet,main,#450	EA
691-376100/460	jet,main,#460	EA
691-376100/470	jet,main,#470	EA
691-376100/480	jet,main,#480	EA
691-376100/490	jet,main,#490	EA
691-376100/500	jet,main,#500	EA
691-376100/510	jet,main,#510	EA
691-376100/520	jet,main,#520	EA
691-376100/530	jet,main,#530	EA
691-376100/540	jet,main,#540	EA
691-376100/550	jet,main,#550	EA
691-376100/90	jet,main,#90	EA
691-376108	banjo,90deg.dual,threaded	EA
691-376110	USE 70-4576	ea
691-376132	USE 691-376061	ea
691-376133	USE 691-376075	ea
691-376135	banjo,90 degree dual	EA
691-376139	banjo,150 degree dual	EA

691-376140	jetholder, long, mono	EA
691-376141	banjo, remote bowl type	EA
691-376188	banjo, 45degree upswept	EA
691-376410	banjo, 55 degree dual	EA
691-376419	banjo, 180 degree dual	EA
691-376421	USE 691-389121	EA
691-389/18	carb, 1-1/8" monobloc	EA
691-389/18.5	carb, 1-5/32" monobloc	EA
691-389/19	carb, 1-3/16" monobloc	EA
691-389056	jet block, 1-1/8, mono	EA
691-389057	jet block, 1-5/32, mono	EA
691-389058	jet block, 1-3/16, mono	EA
691-389060/2	slide, #2, mono	EA
691-389060/2.5	slide, #2-1/2, mono	EA
691-389060/3	slide, #3, mono	EA
691-389060/3.5	slide, #3-1/2, mono	EA
691-389060/4	slide, #4, mono	EA
691-389060/4.5	slide, #4-1/2, mono	EA
691-389061	USE 691-389092	ea
691-389062	slide, choke, mono	EA
691-389063	needle, jet, "D", mono, w/clip	EA
691-389064	cap, mixing chamber, mono	EA
691-389065	ring, mix chamber cap, mono	EA
691-389068/A	clip, cap ring, mono, w/screw	EA
691-389092	spring, throt. slide, mono*	EA
691-389121	gasket set, monobloc carb *	EA
691-4035	adjuster, cable*	EA
691-4042	jet, main, SPECIFY SIZE	EA
691-4042/140	jet, main, #140	EA
691-4042/150	jet, main, #150	EA
691-4042/160	jet, main, #160	EA
691-4042/170	jet, main, #170	EA
691-4042/180	jet, main, #180	EA
691-4042/190	jet, main, #190	EA
691-4042/195	jet, main, #195	EA
691-4042/200	jet, main, #200	EA
691-4042/220	jet, main, #220	EA
691-4042/230	jet, main, #230	EA
691-4042/240	jet, main, #240	EA
691-4042/250	jet, main, #250	EA
691-4042/260	jet, main, #260	EA
691-4042/270	jet, main, #270	EA
691-4042/280	jet, main, #280	EA
691-4042/290	jet, main, #290	EA
691-4042/300	jet, main, #300	EA
691-4046	spring, choke, Mono	EA
691-4053	washer, fibre	EA
691-4137	plug, choke blanking*	EA
691-4148	spring, adj. screw, mono	EA
691-4230	clip, jet needle, mono	EA
691-4235	clip, cap ring retaining	EA
691-4241	screw, mono	EA
691-4276	USE 691-4235	ea
691-5047	guide, choke, 375	EA
691-5077	nut, adj	EA
691-510001	floatchamber assy, Matchbox type*	EA
691-510009	float, "matchbox", type	EA
691-6047	guide, choke, 276, 376	EA
691-622050	float bowl, no drain hole	EA
691-622055	floatbowl w/drain, .10seat	EA
691-622060/2.5	slide, throttle, #2-1/2	EA
691-622060/2.5/C	slide, throttle, #2-1/2, chromed	EA
691-622060/3	slide, throttle, #3	EA
691-622060/3.5	slide, throttle, #3-1/2	EA
691-622060/3.5/C	slide, throttle, #3-1/2, chromed	EA
691-622060/3/C	slide, throttle, #3, chromed	EA
691-622060/4	slide, throttle, #4	EA
691-622060/4/C	slide, throttle, #4, chromed	EA
691-622061	USE 691-622131	ea
691-622062	slide, choke	EA
691-622063	needle, jet, 1 ident. groove *	EA

691-622064	top,mix chamber,for 2 adj	EA
691-622065	USE 691-622129	ea
691-622067	clip,jet needle	EA
691-622068	needle,inlet,nylon*	EA
691-622069	float	EA
691-622071	spindle,float	EA
691-622073	gasket,float bowl	EA
691-622075	tube,spray,all exc.850 Nort*	EA
691-622076	screw,pilot air adjusting	EA
691-622077	screw,throttle stop	EA
691-622078	bolt,banjo	EA
691-622079	jet,needle,SPECIFY SIZE *	ea
691-622079/105	jet,needle,#105 *	EA
691-622079/106	jet,needle,#106 *	EA
691-622079/107	jet,needle,#107 *	EA
691-622079/108	jet,needle,#108 *	EA
691-622079/109	jet,needle,#109 *	EA
691-622080	USE 691-622235 (set)	ea
691-622082	oring	EA
691-622085	welch plug,carb body	EA
691-622086	screw,float bowl&carb top*	EA
691-622089	pin,tickler	EA
691-622097	top,mix chamber,for 1 adj	EA
691-622098	top,mix chamber,2ferrule	EA
691-622101	oring	EA
691-622102	boot,rubber dustcover	EA
691-622113	spring,throttle rod,triples	EA
691-622115	abutment,spring,top,triples	EA
691-622116	abutment,spring,bottom,triples	EA
691-622119	rod,throttle,triples,pre75	EA
691-622121	seat,float needle,concentric	EA
691-622122	jet,needle,SPECIFY SIZE	ea
691-622122/105	jet,needle,#105	EA
691-622122/106	jet,needle,#106	EA
691-622122/107	jet,needle,#107	EA
691-622124	needle,jet,2 ident.groove	EA
691-622125	clip,carb top,triples	EA
691-622126	washer,sealing,triples	EA
691-622128	jet holder	EA
691-622129	spring,choke	EA
691-622131	spring,throttle slide	EA
691-622132	screw,extended,floatbowl	EA
691-622134	guide,choke slide	EA
691-622147	plug,bowldrain,plastic *	EA
691-622149	needle,inlet,viton tipped	EA
691-622151	washer,sealing,drainplug,fibre*	EA
691-622151/A	washer,sealing,drainplug,nylon	EA
691-622155	plug,bowl drain,brass*	EA
691-622155/A	plug,bowl drain,alloy hex*	EA
691-622168	screw,pilot air,extended	EA
691-622169	screw,throt.stop,extended	EA
691-622171	screw kit,hex head,Amal	ST
691-622172	tickler,shielded type,kit	EA
691-622186	spring,choke	EA
691-622195	screw,velocity stack securing	EA
691-622197	needle,inlet,viton tipped	EA
691-622197/ER	needle,inlet,viton tipped,repl.	EA
691-622208	gasket&oring kit,std.conc	EA
691-622208/A	gasket kit,w/thick oring	EA
691-622235	kit,update,early concent.	EA
691-622238	repair kit,concentrics *	EA
691-622277	spring,throttle slide,T160	EA
691-622278	needle,jet,5 ident.groove	EA
691-622295	gasket&oring kit,Mk1-1/2 concentric	EA
691-689060/3	slide,throttle,#3,mono	EA
691-689060/3.5	slide,throttle,#3-1/2mono	EA
691-689060/4	slide,throttle,#4,mono	EA
691-928060	slide,SPECIFY SIZE	ea
691-928060/2	slide,throttle,#2	EA
691-928060/2.5	slide,throttle,#2-1/2	EA
691-928060/2.5/C	slide,throttle,#2-1/2,chromed	EA

691-928060/2/C	slide,throttle,#2,chromed	EA
691-928060/3	slide,throttle,#3	EA
691-928060/3.5	slide,throttle,#3-1/2	EA
691-928060/3.5/C	slide,throttle,#3-1/2,chromed	EA
691-928060/3/C	slide,throttle,#3,chromed	EA
691-928060/4	slide,throttle,#4	EA
691-928060/4/C	slide,throttle,#4,chromed	EA
691-928062	slide,choke	EA
691-928063	needle,jet,3 ident.groove *	EA
691-928064	top,mix chamber,for 2 adj	EA
691-928066	tube,air intake	EA
691-928069	velocity stack,Amal900,open	EA
691-928076	velocity stack,900 series,tuned	EA
691-928097	top,mix chamber,for 1 adj	EA
691-928097/A	top,carb,racing	EA
691-928098	top,mix chamber,2 ferrule	EA
691-928102	boot,rubber dustcover	EA
691-928103	guide,choke slide	EA
691-928104	needle,jet,4 ident.groove	EA
691-928107	tube,spray,850 Norton	EA
691-928112	USE 691-928076 *	ea
691-L2928	carb body,LH 28mm,MK2	EA
691-L2930	carb body,LH 30mm,MK2	EA
691-L2930/301	carb,30mm Mk2,L,universal	EA
691-L2932	carb body,LH 32mm,Mk2	EA
691-L2932/301	carb,32mm Mk2,L,universal	EA
691-L2934	carb body,LH 34mm,Mk2	EA
691-L2934/301	carb,34mm Mk2,L,universal	EA
691-L624/301	carb,24mm,LH,universal	EA
691-L626	carb body,LH,26mm	EA
691-L626/301	carb,26mm,LH,universal	EA
691-L626/67	carb,27mm,Triples,LH	EA
691-L626/9	carb,26mm,Tri.500 twin,LH	EA
691-L627	carb body,LH 27mm	EA
691-L928	carb body,LH 28mm	EA
691-L930	carb body,LH 30mm	EA
691-L930/301	carb,30mm,LH,universal	EA
691-L930/69	carb,30mm,Nor 750,LH	EA
691-L930/93	carb,30mm,Tri T120/T140,LH	EA
691-L932	carb body,LH 32mm	EA
691-L932/20	carb,32mm,Nor750 Combat,L	EA
691-L932/30	carb,32mm,Nor 850,LH	EA
691-L932/301	carb,32mm,LH,universal	EA
691-R1034/300	carb,34mm1000,R,universal	EA
691-R1036/300	carb,36mm1000,R,universal	EA
691-R2036/300	carb,36mm Mk2,R,universal	EA
691-R2038/300	carb,38mm Mk2,R,universal	EA
691-R2928	carb body,RH 28mm,Mk2	EA
691-R2930	carb body,RH 30mm,Mk2	EA
691-R2930/300	carb,30mm Mk2,R,universal	EA
691-R2932	carb body,RH 32mm,Mk2	EA
691-R2932/300	carb,32mm Mk2,R,universal	EA
691-R2934	carb body,RH 34mm,Mk2	EA
691-R2934/300	carb,34mm Mk2,R,universal	EA
691-R622/10	carb,22mm,TigerCub	EA
691-R622/300	carb,22mm,RH,universal	EA
691-R624/300	carb,24mm,RH,universal	EA
691-R626	carb body,RH 26mm	EA
691-R626/10	carb,26mm,Tri.500 twin,RH	EA
691-R626/300	carb,26mm,RH,universal	EA
691-R626/52	carb,26mm,Tri500sing.carb	EA
691-R626/66	carb,27mm,Triples,R.H.	EA
691-R626/68	carb,27mm,Triples,center	EA
691-R627	carb body,RH 27mm	EA
691-R928	carb body,RH 28mm	EA
691-R928/17	carb,28mm,A65 single carb	EA
691-R928/300	carb,28mm,RH,universal	EA
691-R930	carb body,RH 30mm	EA
691-R930/23	carb,30mm,Tri650sing.carb	EA
691-R930/300	carb,30mm,RH,universal	EA
691-R930/68	carb,30mm,Nor 750,RH	EA

691-R930/89	carb,30mm,Tri750sing.carb	EA
691-R930/92	carb,30mm,Tri T120/140,RH	EA
691-R932	carb body,RH 32mm	EA
691-R932/19	carb,32mm,Nor750 Combat,R	EA
691-R932/29	carb,32mm,Norton 850,RH	EA
691-R932/300	carb,32mm,RH,universal	EA
691-RK3GP/1	gask.kit,GP3 carb	EA
691-RKGP/2	needle & seat,remote floatbowl#510	ST
691-RKGP/3	tickler repair kit,remote floatbowl#510	ST
691-RKGP/4	gasket set,remote floatbowl#510	ST
691-T10GP2	carb,1-5/32",GP	EA
691-T3GP2	carb,1-1/2",GP*	EA
691-T5GP2	carb,1-3/8",GP 3	EA
692-	MIKUNI CARBS & PARTS	*
692-----	-----	---
692-001250	carb conv,Com,32mmMIKUNI,dual	ST
692-001251	carb conv,Com,34mmMIKUNI,dual	ST
692-001252	carb conv,Com34mm,1MIKUNI	ST
692-001253	carb conv,Com36mm,1MIKUNI	ST
692-001254	carb conv,Com38mm,1MIKUNI	ST
692-001275	carb conv,T120,30mmMIKUNI,UNF	ST
692-001276	carb conv,T120,32mmMIKUNI,UNF	ST
692-001277	carb conv,T120,34mmMIKUNI,UNF	ST
692-001278	carb conv,T120,30mmMIKUNI,CEI	ST
692-001279	carb conv,T120,32mmMIKUNI,CEI	ST
692-001280	carb conv,T120,34mmMIKUNI,CEI	ST
692-001290	carb conv,T120/140,30mmMIKUNI	ST
692-001291	carb conv,T120/140,32mmMIKUNI	ST
692-001292	carb conv,T120/140,34mmMIKUNI	ST
692-001293	carb conv,TR6/7,30mmMIKUNI	ST
692-001294	carb conv,TR6/7,32mmMIKUNI	ST
692-001295	carb conv,TR6/7,34mmMIKUNI	ST
692-01/30	carb set,Mikuni30mm,Bonnie,etc.	PR
692-01/32	carb set,Mikuni32mm,Bonnie,etc.	PR
692-01/34	carb set,Mikuni34mm,Bonnie,etc.	PR
692-02/30	carb,Mikuni30mm,TR6,etc.	EA
692-02/32	carb,Mikuni32mm,TR6,etc.	EA
692-02/34	carb,Mikuni34mm,TR6,etc.	EA
692-03/34	carb,Mikuni34mm,Nor.single carb	EA
692-03/36	carb,Mikuni36mm,Nor.single carb	EA
692-03/38	carb,Mikuni38mm,Nor.single carb	EA
692-04/26	carb set,Mikuni26mm,Trident	ST
692-04/28	carb set,Mikuni28mm,Trident	ST
692-05/32	carb set,Mikuni32mm Commando,etc.	PR
692-05/34	carb set,Mikuni34mm Commando,etc.	PR
692-159P-2	jet,needle,Mikuni	EA
692-159P-4	jet,needle,Mikuni	EA
692-159P-6	jet,needle,Mikuni	EA
692-4/042	USE 691-4042	ea
692-4/053	USE 691-4053	ea
692-6DH3	needle,jet,Mikuni	EA
692-6DP17	needle,jet,Mikuni	EA
692-6FJ6	needle,jet,Mikuni	EA
692-B30/247	nut,cable adj.	EA
692-B34/52-0.5	washer,needlevalve,Mikuni	EA
692-BS3097/2.0	jet,air,#2	EA
692-M12F/46A	spring,air adj.screw,Mikuni	EA
692-M21/14	adjuster,cable	EA
692-VM20/214	screw,air adj,Mikuni	EA
692-VM20/369	clip,jet needle	EA
692-VM22210/25	jet,pilot,#25	EA
692-VM22210/35	jet,pilot,#35	EA
692-VM22210/40	jet,pilot,#40	EA
692-VM22210/45	jet,pilot,#45	EA
692-VM22210/50	jet,pilot,#50	EA
692-VM26/26	needle&seat,Mikuni,26-28mm	EA
692-VM26/46	cap,thr.cable	EA
692-VM32/65	slide,2.5,Mikuni	EA
692-VM34/110	slide,2.5,Mikuni	EA
692-VM34/114	baffle plate,Mikuni	EA
692-VM34/27	top cap,carb,30-34mm Mikuni	EA

692-VM34/30	gask,floatbowl,30-34mmMikuni	EA
692-VM34/36	float,plastic,Mikuni	EA
692-VM34/39	needle&seat,Mikuni,30-38mm	EA
692-VM34/68	floatbowl,VM34	EA
692-VM36/07	floatbowl,VM36	EA
692-VM36/17	ring,mainjet,Mikuni	EA
692-VM36/20	gask,floatbowl,36-38mmMikuni	EA
693-	BING CARB PARTS	*
693-----	-----	---
693-01	carb gasket set,2 Bings	ST
693-02	carb update set,2 Bings	ST
693-06	carb repair set,2 Bings	ST
694-	SOLEX CARB PARTS	*
694-----	-----	---
694-01	rebuild kit,SOLEX 26WH-2	ST
694-10002	gasket,fixing,throttle chamber,ARIEL4G	EA
694-10173	screw,fixing,throttle chamber,ARIEL4G	EA
694-2261	washer,fibre,needle&seat,ARIEL4G	EA
694-26WH2	carb,SOLEX 26WH-2	EA
694-3430	washer,starterjet,ARIEL4G	EA
694-3947	screw,throttle butterfly,ARIEL4G	EA
694-3950	nut,throttle stop,ARIEL4G	EA
694-4019	abutmentplate,throttle,ARIEL4G	EA
694-4023	screw,throttle stop,ARIEL4G	EA
694-4024	nut,starterspindle,ARIEL4G	EA
694-4124	washer,large,banjo union,ARIEL4G	EA
694-4124/1	washer,small,banjo union,ARIEL4G	EA
694-4263/9	throttle lever,ARIEL4G	EA
694-4384	spring,screw,throttle stop,ARIEL4G	EA
694-50235/1/23	choke tube,ARIEL4G	EA
694-50239	screw,short,floatcover,ARIEL4G	EA
694-50363	throttle spindle,ARIEL4G	EA
694-50506/3	jet,air,bistarter,ARIEL4G	EA
694-50537	screw,throttle stop,ARIEL4G	EA
694-50552/6/120	jet,main,no.120,ARIEL4G	EA
694-50552/70	jet,auxiliary/idle,ARIEL4G	EA
694-50676/2/100	jet,fuel,starter,ARIEL4G	EA
694-50772	float,ARIEL4G	EA
694-50815	washer,fibre,carrierbolt,mainjet,ARIEL4G	EA
694-50820/L1	bolt,carrier,mainjet,ARIEL4G	EA
694-50893	screw,6mm,air bell,ARIEL4G	EA
694-50894	spacer,air bell,ARIEL4G	EA
694-50906/3.#3	jet,air,bistarter,ARIEL4G	EA
694-51015	screw,long,floatcover,ARIEL4G	EA
694-51274/150	jet,idle air bleed,ARIEL4G	EA
694-51305/7	float needle&seat,ARIEL4G	EA
694-51612/150	jet,correction,ARIEL4G	EA
694-51757/L1	starter valve ass.,ARIEL4G	EA
694-51760	screw,cable fixing,ARIEL4G	EA
694-9583	emulsion tube & carrier,ARIEL4G	EA
694-9585	throttle chamber,ARIEL4G	EA
694-9587	air bell,ARIEL4G	EA
694-9589	floatchamber,ARIEL4G	EA
694-9698	screw,fixing,cable support,ARIEL4G	EA
695-	SU CARB PARTS	*
695-----	-----	---
695-112/4931	screw jet & head assembly,SUcarb	EA
695-1158	spring,gland,SUcarb	EA
695-1167	spring,piston,suction chamber,SUcarb	EA
695-117	sealing ring,alum.,SUcarb	EA
695-118	sealing ring,cork,SUcarb	EA
695-119/1	washer,gland,brass,SUcarb	EA
695-120	washer,gland,cork,SUcarb	EA
695-1216	float chamber,SUcarb	EA
695-122	washer,copper,f.tophalf,SUcarb	EA
695-1223	float,SUcarb	EA
695-1251	pin,hinged lever,float,SUcarb	EA
695-130	washer,15/32x7/8x1/32",fibre,SUcarb	EA
695-1358	screw,throttledisc,SUcarb	EA
695-149	screw,jetneedle,SUcarb	EA
695-1606	cap,floatcover,SUcarb	EA

695-169	throttle disc,SUcarb	EA
695-1859-1121	needle & seat ass.,float,SUcarb	EA
695-1981	hinged lever,float,SUcarb	EA
695-3071	washer,1/2x7/8x1/32",thrust,pistonspring	EA
695-3230	bearing,jet,top,SUcarb	EA
695-3231	bearing,jet,bottom,SUcarb	EA
695-3233	washer,copper,f.bottom half,SUcarb	EA
695-4517	lid,floatchamber,SUcarb	EA
695-4642/1	washer,19/32x23/32x3/32",copper,SUcarb	EA
695-4804	adaptorjoint,throttlebarrel,SUcarb	EA
695-4805	screw,adapter,throttlebarrel,SUcarb	EA
695-4885	washer,fibre,bolt,jet lever,SUcarb	EA
695-4900	washer,11/16x7/8x1/16",fibre,SUcarb	EA
695-4901	spindle,throttle,SUcarb	EA
695-4920	oil cap,octagonal,SUcarb	EA
695-AUC-4924	adaptor,throttlebarrel,SUcarb	EA
695-AUC-8006	suctionchamber ass.,SUcarb	EA
695-DN-114	spring,adj.nut,SUcarb	EA
695-DN-1163	nut,floatlid,SUcarb	EA
695-DN-121	nut,adj.,SUcarb	EA
695-DN-1500/6	throttlelever ass.,SUcarb	EA
695-DN-1541/3	bolt,holding,SUcarb	EA
695-DN-156	nut,2BA,SUcarb	EA
695-DN-3232	screw,jet,SUcarb	EA
695-DN-3464	screw,3.5mm,adj.,throttlestop,SUcarb	EA
695-DN-3465	spring,screw,adj.,throttlestop,SUcarb	EA
695-DN-4857	screw,securing,SUcarb	EA
695-DN-4872/1	spring,return,SUcarb	EA
695-DN-4875/2	washer,1/4",spring,double coil,SUcarb	EA
695-DN-4884/1	bolt,jet lever,SUcarb	EA
695-DN-5070	spring,return,throttle lever,SUcarb	EA
695-GN	jet needle,SUcarb	EA
695-MC2/605	carb ass.,MARKIII,4G	EA
711-	STOCK MUFFLERS	*
711-----	-----	--
711-01	mufflers,Interceptor Mk2	PR
711-02	mufflers,peardrop,Nort1953-56	PR
711-061312	muffler,Commando"S"&SSmodel	EA
711-412725	muffler,BSA 441 Victor,pre69	EA
711-422774/2775	muffler set,A10,54-58,Toga	PR
711-422774/2775/A	muffler set,A10,54-58	PR
711-652754	muffler,BSA B31rigid	EA
711-672700/2701	muffler set,A7/10 rigid,TOGA	PR
711-703261	muffler,Tiger Cub,plunger	EA
711-703450	muffler,TRW 500	EA
711-704132	muffler,TR6 siamese hipipe,LH	EA
711-704132/4176	mufflers,T120C hi,1 ea.side*	ST
711-706974/6975	mufflers,TR6C &T100C,67/68	PR
711-709206	mufflers,Firebird,pre1971 LH hi	PR
711-709669/9670	mufflers,TR6C &T100C,69on	PR
711-712400	muffler,7lon Tri/BSA 1cyl*	EA
711-712654	muffler,A65Firebird,1971	PR
711-712956/7/8	muffler set,Hurricane	ST
711-713793	muffler,TR5T,74 style	EA
711-828857	muffler,pre69 650Firebird	PR
711-VEL/01	muffler assy,VeloFishtail	EA
711-Z601	muffler,70-74 Roadster	EA
711-Z601/A	muffler,gen.Norton#061978	EA
711-Z601/B	muffler,Commando1-1/2"	EA
711-Z601/C	muffler,Roadster,smooth	EA
711-Z601/D	muffler,Commando1-1/2",T140mounts*	EA
711-Z601/E	muffler,Commando1-3/8",T140mounts	EA
711-Z601/E/ER	muffler,Commando1-3/8",T140mounts,econo	EA
711-Z601/ER	muffler,70-74 Rdstr,econo	EA
711-Z601/SS	muffler,Commando,stainless	EA
711-Z602	muffler,blackcap,850Mk2A&3,T160	EA
711-Z602/A	muffler,850Mk2A&3,T160,TOGA	EA
711-Z602/B	muffler,JPN,black finish,TOGA	EA
711-Z602/C	muffler,850Mk2A&3,T160,perform.	EA
711-Z603	USE 711-Z602	EA
711-Z603/A	USE 711-Z602/A	EA

711-Z604	muffler,71/72 TriBSA 2&3	EA
711-Z604/A	muffler,71/72 TriBSA 2&3,TOGA	EA
711-Z605	muffler set,Tri.unit 500	ST
711-Z605/A	muffler set,Tri unit 500,TOGA	PR
711-Z610	muffler,74onTriumph,1-3/8 *	EA
711-Z610/A	muffler,74onTriumph,1-3/8,TOGA *	EA
711-Z610/ER	muffler,74on T140,1-3/8",econo *	EA
711-Z611	muffler set,Norton Atlas	ST
711-Z623	muffler,pre71 Triumph 650,1-1/2"*	EA
711-Z623/A	muffler,preunitTri,1-3/4"*	EA
711-Z623/B	muffler,63-70 Tri.650,TOGA	EA
711-Z623/C	muffler set,1960-62 Tri.650,TOGA	PR
711-Z623/C/A	muffler set,1960-62 Tri.650	PR
711-Z623/D	muffler set,54-59p-unitTri*	PR
711-Z623/E	muffler,ext.early Tri,1-1/2"	EA
711-Z623/E/138	muffler,ext.early Tri,1-3/8"	EA
711-Z623/ER	muffler,pre71Tri650,econo*	EA
711-Z623/F	mufflers,BloorBonneville	PR
711-Z623/SS	muffler,pre71 Tri650,1-1/2",stainless*	EA
711-Z624	muffler,Goldstar"Twitter"	EA
711-Z624/A	muffler,Goldstar"Twitter",TOGA	EA
711-Z624/A/1.5	muffler,Twitter,1.5"	EA
711-Z624/B	muffler set,Twitter,1-1/2",TOGA *	PR
711-Z624/B/A	muffler set,Twitter,1-1/2"	PR
711-Z624/C	muffler set,Twitter,1-3/4"	PR
711-Z624/D	muffler,Bullet"Twitter"	EA
711-Z625	mufflers,ARIEL SQ.4	PR
711-Z628	muffler,Norton early twin	EA
711-Z629	mufflerset,T150/A75raygun	ST
711-Z629/A	mufflerset,T150/A75raygun,TOGA	ST
711-Z629/B	mufflerset,T160raygun	ST
711-Z633	muffler,BSA B31/B33 lt.swingarm*	EA
711-Z634	muffler,BSA M20/21plunger	EA
711-Z634/A	muffler,BSA M20/21plunger,TOGA	EA
711-Z635	muffler,BSA M20/21rigid	EA
711-Z635/A	muffler,M20/21rigid,TOGA	EA
711-Z636	muffler,A7/10 plunger	EA
711-Z636/A	muffler,A7/10 plunger,TOGA*	EA
711-Z637	muffler,BSA B31 plunger	EA
711-Z637/A	muffler,BSA B31 plunger,TOGA	EA
711-Z638	muffler,BSA C11,1946-55*	EA
711-Z638/A	muffler,BSA C11,1946-55,TOGA	EA
711-Z646	muffler,Norton Interstate	EA
711-Z662	mufflers,A7/A10,58on*	PR
711-Z662/A	mufflers,A7/10,58on,TOGA-*	PR
711-Z663	muffler,pre71 BSA A50&A65	EA
711-Z663/A	muffler,pre71 BSA A50/65,TOGA	EA
711-Z664	muffler,early unit 650 Tri,long	EA
711-Z664/A	muffler,early unit,long,Toga	EA
711-Z664/ER	muffler,asZ623,long,econo	EA
711-Z677	muffler,Tiger Cub,low	EA
711-Z677/A	muffler,Tiger Cub,low,TOGA*	EA
711-Z683	muffler,B25/B44 low level,1-3/8" *	EA
711-Z683/A	muffler,B25/B44 low,TOGA 1-3/8"	EA
711-Z683/B	muffler,B25/B44 low,1-1/2" ID	EA
711-Z690	muffler,BSA 441 Victor,69/70 *	EA
711-Z691	muffler,Tiger Cub,hi pipe	EA
711-Z691/A	muffler,Tiger Cub,hi,Toga	EA
711-Z695	mufflerset,1938-54Tri.rigid	ST
711-Z695/A	mufflerset,1938-54Tri,TOGA	PR
711-Z810	mufflers,P11,shorty	PR
711-Z811	muffler,P11A	PR
711-Z844	muffler,ARIEL 650	PR
712-	CUSTOM MUFFLERS	*
712-----	-----	---
712-01	turnout shorty muffler	EA
712-02	slash cut shorty muffler	EA
712-03	shorty muffler*	EA
712-04	tapered custom muffler	EA
712-05	muffler,megaphone,short	EA
712-06	mufflers,upswept megaphone,univ.	PR

712-07	muffler,tapered custom fishtail	EA
712-102	muffler,Dunstall Decibel,econo repl.	EA
712-102/A	muff,Decibel,1-3/8&1-1/2",England.*	EA
712-102/B	muff,Decibel,1-5/8&1-3/4",England	EA
712-114	muffler,Megaton type megaphone,econo	EA
712-Z600/112	muffler,long mega,univ.1-1/2"	EA
712-Z600/138	muffler,long mega,univ.1-3/8"	EA
712-Z631	muffler,barrel,univ.1-3/4"	EA
712-Z639	muff.st,upswept meg,1-3/4*	ST
712-Z639/1.5	muff.st,upswept meg,1-1/2*	ST
712-Z639A	muffler,custom megaphone,1-3/4"	EA
712-Z639A/1.5	muffler,custom meg,1-1/2"	EA
712-Z639A/158	muffler,custom meg,1-5/8"	EA
721-	STOCK EXHAUST PIPES	*
721-----	-----	---
721-01	xpipe set,T140D,no collector	ST
721-412722	xpipe,B44E &VS,66/67	EA
721-682796/2797	xpipes,67 BSA Wasp/Hornet	ST
721-702947/2949	x pipes,Triumph TRWamy,siamese	ST
721-707597	x manifold,Triumph T150	EA
721-709198/9200	xpipes,69/70 BSA A65F	ST
721-709412	xpipe,pre71 B25,high	EA
721-709514	xpipe,Tri.250,high,1968	EA
721-709659	xpipe,Tri.250,high,1969	EA
721-709677	xpipe,BSA 441VS,69/70	EA
721-711157	x manifold,BSA Rocket 3	EA
721-711408	xpipe,B44 Shooting Star,1-1/2"	EA
721-717671/7672	xpipes,Tri.TSS 8vlv,w/bal	ST
721-828418/8420	xpipes,68 BSA Firebird*	ST
721-828449	xpipe,B44VS,1968 only	EA
721-A52	xpipes,Ariel 650	PR
721-B14	xpipes,D14/4,B175,1968on,low	EA
721-B250	xpipe,oilframe250,high	EA
721-B26	xpipe,M20/21 rigid	EA
721-B27	xpipes,BSA A7 plunger&rigid	ST
721-B31	xpipe,B31/33,rigid & plunger	EA
721-B34	xpipe,Goldstar DBD34	EA
721-B42	xpipe,M20/21 plunger	EA
721-B44	xpipe,B44 Shooting Star,1-3/8OD	EA
721-B45	xpipe,B31/33,1953-57	EA
721-B46	xpipes,BSA early swingarm A7 *	ST
721-B47	xpipes,BSA A10 swingarm,pre58	ST
721-B500	xpipe,B50,high	EA
721-B500/A	xpipe,B50,low	EA
721-B54	xpipe,C11,C12*	EA
721-B55	xpipes,BSA A10 swingarm,1958on	ST
721-B56	xpipes,D7,1959on,low	EA
721-B57	xpipe,B31/33,1958on	EA
721-B58	xpipes,BSA A7 swingarm,58on*	ST
721-B64	xpipes,69/70 BSA A65w/bal	ST
721-B65	xpipes,71on BSA A65,w/bal	ST
721-B66	xpipes,BSA A75,w/manifold,1-1/2"	ST
721-B66/A	xpipes,A75,w/manifold,1-1/4"	ST
721-B68	xpipe,low,C15	EA
721-B72	USE 721-682796/2797	ea
721-B77	xpipes,A10 Spitfire	PR
721-B78	xpipes,C15T,C15S,1959on,high	EA
721-B80	xpipes,D7,high	EA
721-B87	xpipes,BSA A50/65,no bal.	ST
721-B87/A	xpipes,BUB,as B87,no tabs	EA
721-B87/B	xpipes,BSA A50/65,no bal,TJW	PR
721-B88	USE 721-B68	ea
721-B89	xpipe,low,67-70 BSA 250	EA
721-B89/A	xpipe,low,70 BSA 250,1-1/2"OD	EA
721-B91	xpipes,BSA rigid A10	ST
721-B92	xpipes,BSA plunger A10	ST
721-M26	xpipes,G15CS&Mk2	PR
721-M27	xpipes,G15CSR,sweptback	PR
721-N1	xpipes,Norton 99,1957-59	PR
721-N48	xpipes,ES2,1954-56	EA
721-N49	xpipes,Norton 88	PR

721-N52	xpipes,ES2,1957-59	EA
721-N56	xpipes,ES2,1960on	EA
721-N60	xpipes,Norton Atlas,lg.bore*	ST
721-N61	xpipes,Norton Atlas,sm.bore*	ST
721-N62	xpipes,pre70 Commando,low	ST
721-N63	xpipes,Roadster,no bal.	ST
721-N63/A	xpipe,BUB,N63w/conicalInl	ST
721-N63/A/BLK	xpipe,BUB,as N63/A,&black	ST
721-N63/B	xpipes,Roadster,no bal,TJW	PR
721-N63/C	xpipes,Roadster,no bal,1-1/2"outlet	PR
721-N63/ER	xpipe,Roadster,no bal,econo*	PR
721-N63/SS	xpipes,Roadster,stainless	PR
721-N64	xpipes,850Nort,w/bal.*	ST
721-N65	xpipes,850Mk3 type,w.bal.*	ST
721-N65/A	xpipes,850Mk3 type,w.bal,blk*	ST
721-N66	xpipes,Commando S,lh high	ST
721-N67	xpipes,Interstate,w/bal.	ST
721-N68	xpipes,Commando SS,hi,1 ea side	ST
721-N69	xpipes,P11A	ST
721-N69/A	xpipes,P11,high	ST
721-N70	xpipes,Interstate,no bal.	ST
721-T100	x,siamese hi,58onTR5	ST
721-T25	xpipes,rigid 5T/6Tw/gen.*	PR
721-T25/A	xpipes,rigid 5T/6Tw/alt.	PR
721-T39	xpipe,Cub,low,pre63	EA
721-T41	xpipes,1955onTri.5&6Tw/alt.	PR
721-T41/D	xpipes,1955-59 Tri.5&6Tw/dynamo	PR
721-T43	xpipes,1957-59 T110& T120*	PR
721-T43/A	xpipes,alloy T100*	PR
721-T47	xpipes,59-67Tri500,no bal	PR
721-T48	xpipes,60-62 T110/120*	ST
721-T63	xpipes,Tri.650unit,1963/4	ST
721-T64	xpipe,Cub,low,63on	EA
721-T65	xpipe,Cub,high,63on	EA
721-T66	xpipe,Cub,high,pre63**	EA
721-T68	xpipes,Tri.650unit,no bal	ST
721-T68/A	xpipes,USmade BUB,as T68	ST
721-T68/B	xpipes,1-3/4"od,custom *	ST
721-T68/C	xpipes,Tri.650,"factory"	PR
721-T68/ER	xpipes,Tri.650unit,no bal,econo repl	PR
721-T68/SS	xpipes,Tri.650unit,no bal,stainless	PR
721-T70	xpipes,64-66 T90 style,no bal	ST
721-T72	xpipes,68Tri500,no bal.	ST
721-T72/A	xpipes,USmade BUB,as T72	ST
721-T73	xpipes,67&68 T100C,highLH	ST
721-T73X	xpipes,69on T100C,high,LH	PR
721-T74	xpipes,67&68 TR6C,high,LH *	PR
721-T74X	xpipes,69&70 TR6C,high,LH	PR
721-T77	xpipes,clamponT120 w/bal,69/70	ST
721-T77/A	xpipes,clamponT120w/bal,69/70,TJW	ST
721-T78	xpipes,clamponT100R w/bal,early*	ST
721-T79	xpipes,clamponT120 w/bal,oilframe*	ST
721-T80	xpipes,clampon T100,w/bal,1971	ST
721-T81	xpipes,pushinT100,longWbal,1-1/2"	ST
721-T81/A	xpipes,pushinT100short w/bal,1-1/2"	PR
721-T84	xpipes,pushinTri650 w/bal*	ST
721-T85	xpipes,Tri.750 Twin,w/bal *	ST
721-T85/A	xpipeUSmadeBUBast85,w/bal	ST
721-T85/B	xpipes,Tri.750 Twin,no balance	ST
721-T85/C	xpipes,TR7/140,w/bal,TJW	ST
721-T86	xpipes w/manifold,T150,1-3/8"*	ST
721-T86/A	xpipes w/manifold,T150,1-1/4"	ST
721-T86/B	xpipes w/manifold,T150,1-1/2"	ST
721-T86/C	xpipes w/man,T150,1-3/8",factory*	ST
721-T87	xpipe set,T160 Trident	ST
721-T88	xpipe,pushinT100shortWbal,1-3/8"	ST
721-T89	xpipes,TR5T	ST
721-T90	xpipes,clampon T140 w/bal	ST
721-T92	xpipes,X75 Hurricane	ST
721-T93	xpipes,Tri.TSS 8vlv,not bal	ST
721-T95	xpipes,high,T120C,1 ea.side*	ST

721-T97	xpipes,T140 clampon,no balance	PR
721-T99	x,siamese hi,TR6C,pre60	ST
721-T99A	x,siamese hi,60onTR6C	ST
724-	TT PIPE SETS	*
724-----	-----	---
724-01	TT pipes,clampon Tri.500	ST
724-02	TTpipes,Tri650 clampon,custom *	ST
724-02/A	TT Xsystem w/mufflers,BUB	ST
724-02/A/BLK	TT Xsyst.as724-02/A,Black	ST
724-02/B	TTpipes,Tri650 clampon,factory	ST
724-03	TTpipes,BSAtwin	ST
724-04	TT pipes,Atlas/650	PR
726-	CROSSOVER DRAG PIPE SETS	*
726-----	-----	---
726-01	dragpipes,RHexit,Tri.650/750 twin *	ST
726-02	dragpipes,RHexit,Tri500,slashcut	ST
726-03	dragpipes,RH exit,BSA A65	ST
726-04	xpipes,rh exit commando	ST
727-	SWEPTBACK EXH.PIPE SETS	*
727-----	-----	---
727-01	xpipes,sweptback,BSA A65	ST
727-02	xpipes,sweptback,A7/10BSA	ST
727-03	xpipes,sweptback,Atlas	ST
727-04	xpipes,sweptback,Commando*	ST
727-05	xpipes,sweptback,T100R	ST
727-06	xpipes,sweptback,T120unit type	ST
727-07	xpipes,sweptback,500/650PreunitTri	ST
727-08	xpipes,sweptback,Bullet 500	EA
731-	2 INTO 1 EXHAUST SYSTEMS	*
731-----	-----	---
731-01	2intol,6/750 pushin,BUB	EA
731-01/BLK	2intol,6/750 pushin,BUB,blk.	EA
731-02	2intol,clampon T120,BUB	EA
731-02/BLK	2intol,clampon T120,BUB,blk.	EA
731-02/C	2intol,clampon T120,no muffler	EA
731-03	2intol,Commando,BUB *	EA
731-03/BLK	2intol,Commando,BUB,blk.*	EA
731-03/C	2intol exh,Commando,no muffler	ST
731-04	siamese xpipe only,Tri500unit	EA
731-05	siamese xpipeOnly,A50/65	EA
731-06	siamese xpipe only,Tri650 unit	EA
731-07	2intol,clampon T100,no muffler	EA
731-08	siamese xpipeOnly,A7/10 only*	EA
731-09	2intol exh,A50/65,no muffler	ST
731-10	2intol exh,Atlas/650,no muffler	EA
732-	3 INTO 1 EXHAUST SYSTEMS	*
732-----	-----	---
732-01	3intolsystem,Tri.T150,BUB	EA
732-01/A	3intolsystem,Tri.T150,HYDE	EA
732-01/BLK	3intolsystem,T150,black *	EA
732-02	3intol system,T160,BUB	EA
732-02/A	3intol system,T160,HYDE	EA
732-02/BLK	3intol system,T160,black	EA
732-03	3intol system,A75R,BUB	EA
732-03/BLK	3intol system,A75R,black	EA
735-	EXHAUST EXTENSIONS	*
735-----	-----	---
735-01	extension,fishtail,1-3/4"ID,29"long*	EA
741-	FINNED EXH.CLAMPS,CUSTOM	*
741-----	-----	---
741-112	finned clip,alloy,1-1/2",large	EA
741-134	finned clip,alloy 1-3/4",large	EA
741-138	finned clip,alloy,1-3/8"	EA
741-158	finned clip,alloy,1-5/8",large	EA
742-	MUFFLER CLAMPS,UNIVERSAL	*
742-----	-----	---
742-1	clamp,frame,1"	EA
742-112	muffler clamp,1-1/2"	EA
742-112/A	muff.clamp,heavyduty1-1/2	EA
742-112/ER	muffler clamp,1-1/2"econo	EA
742-114	clamp,frame,1-1/4"	EA

742-118	clamp, frame, 1-1/8"	EA
742-134	muffler clamp, 1-3/4"	EA
742-134/A	muff. clamp, heavyduty 1-3/4	EA
742-134/ER	muffler clamp, 1-3/4", econo	EA
742-138	muffler clamp, 1-3/8"	EA
742-138/A	muff. clamp, heavyduty 1-3/8	EA
742-138/ER	muffler clamp, 1-3/8", econo	EA
742-158	muffler clamp, 1-5/8"	EA
742-158/A	muff. clamp, heavyduty 1-5/8	EA
742-158/ER	muffler clamp, 1-5/8", econo	EA
742-178	muffler clamp, 1-7/8"	EA
742-178/A	muff. clamp, heavyduty 1-7/8	EA
742-178/ER	muffler clamp, 1-7/8", econo	EA
742-218/A	muff. clamp, heavyduty 2-1/8	EA
742-78	clamp, frame, 7/8"	EA
743-	EXHAUST PIPE BRACKETS	*
743-	-----	---
743-112	P clamp, 1-1/2inch ex.pipe	EA
743-1134	P clamp, 1-3/4inch ex.pipe	EA
743-1134/A	clamp, 1-3/4" dual ex.pipe *	EA
743-212	P clamp, 2-1/2inch muffler	EA
743-95001	brackets, muff, Bloor Thunderbird	PR
743-95002	brackets, muff, oilframe to Z623/E	PR
744-	EXHAUST PIPE BAFFLES	*
744-	-----	---
744-112	baffle, 1-1/2 inch	EA
744-134	baffle, 1-3/4 inch	EA
744-2	baffle, 2"inch	EA
745-	EXHAUST ADAPTORS	*
745-	-----	---
745-01	conversion, clampon X, T140 type	PR
745-01/A	conversion, clampon X, T140, alloy	PR
745-01/B	conversion, clampon X, T140 oversize	PR
745-02	conv, BSA 1-1/2toTri. 1-3/4"	PR
745-03	conv, clampon ex, late T100	PR
745-112/134	adaptor, 1-1/2to1-3/4muff.	EA
745-112/158	adaptor, 1-1/2to1-5/8muff.	EA
745-114/138	adaptor, 1-1/4to1-3/8muff.	EA
745-138/112	adaptor, 1-3/8to1-1/2muff.	EA
745-138/134	adaptor, 1-3/8to1-3/4muff.	EA
745-158/134	adaptor, 1-5/8to1-3/4muff.	EA
900-	MOTORCYCLES	*
900-	-----	---
900-101	minibike, BSA, 50cc, 10" wheels	EA
901-	ROTAX PARTS	*
901-	-----	---
901-256180	oilfilter element	EA
901-292742	gasket set, Rotax 500, 1cyl	EA
903-	SIDECARS	*
903-	-----	---
903-01	sidecar, Watsonian G.P.	EA
903-02	sidecar, Watsonian Monza	EA
903-101	sidecar, COZY, black*	EA

□